

## **CASIO VX-4 8K to 32K Internal SRAM upgrade**

Images from: <a href="https://icelord.net/wordpress/archives/17133">https://icelord.net/wordpress/archives/17133</a>

## **Original 8K:**



## 32K upgrade:



After swap: Install batteries, press reset button (through hole) on back, press 'All Reset' (through hole) on keyboard. Type in: SYSTEM\* then hit EXE. Run RAM tests 4, 5, 6. If no errors returned your upgrade is OK.