CRiS Management Module
Interactive Map Help Page

The is the mapping interface used for all modules in the Curb Ramp Inventory System.

The city boundary is drawn with a blue line. Everything outside of the city limits is masked in yellow. The intersections are drawn with red circles. The areas near public facilities are shaded in orange.

A progress label appears in the upper left with up to date statistics. This label is draggable so you can move it out of the way if necessary.

This map supports zooming (two-finger pinch gesture) and panning (one-finger drag gesture). The map will always keep a ‘North up’ orientation.

The button on the bottom right is a ‘zoom to extent’ button and will bring the map back to its original position and zoom level.

You can use the vertical segmented control on the bottom left to switch the map between standard and hybrid modes. The default mode is standard.

The ‘Add To List’ button only appears when adding a new city to the active cities list. Simply tap on this button if city presented is the one you intended to add.