
Ergodonk L	H Restrictions	Pinout	Pinout	Pinout	Restricti	Ergodonk LH
Row 0		B12		5V		
Row 1		B13		GND		TRRS, SPLIT_H
Row 2		B14		3V		TRRS (5v?)
Row 3		B15		B10		TRRS (SCL2)
Row 4		A8		B2	is used l	
	Avoid, usable with pullup (USB	A9		B1		solenoid
	Avoid, usable with pullup (USB	A10		B0		SPLIT_HAND_P
	are not useable because they'r	A11		A7	are used	by the SOI8 foo
	are not useable because they'r	A12		A6	are used	by the SOI8 foot
Row 5		A15		A5	are used by the SOI8 foot	
Row 6		B3		A4	are used	by the SOI8 foot
Col 4		B4		A3		
Col 5	Pins A0 and B5 are not 5V tole	B5		A2		
Col 6		B6		A1		
Col 7		B7		A0	is share	Col 3
Col 8		B8		R	is not a	
Col 9 (RH Only)		B9		C15	have lin	Col 2
Solenoid		5V		C14	have lin	Col 1
Solenoid		GND		C13	have lii	Col 0
SPLIT_HAND_PIN high = left, low = right		3V		VB	is not a	
			3V A13 A14 GND			
			Rot Rot Rot			



Updated: 2020-03-16 Richard Balint