# CENG 3420 Computer Organization & Design

## Lecture 04: Control Instruction

Bei Yu CSE Department, CUHK byu@cse.cuhk.edu.hk

(Textbook: Chapters 2.8 – 2.11)

2024 Spring

#### Overview



- 1 Introduction
- 2 Control Instructions
- **3** Accessing Procedures
- 4 Summary



Introduction

#### **RISC-V Instruction Fields**



#### RISC-V fields are given names to make them easier to refer to

31 30 25	24 21	20 19	15 14 12	2 11 8 7	6 0	
funct7	rs2	rs1	funct3	rd	opcode	R-type
imm[1]	1:0]	rs1	funct3	rd	opcode	I-type
imm[11:5]	rs2	rs1	funct3	imm[4:0]	opcode	S-type
						_
$[imm[12] \mid imm[10:5]$	rs2	rs1	funct3	imm[4:1]   imm[11]	opcode	B-type
	imm[31:12]					
			rd	opcode	U-type	
[imm[20]] $imm[10]$	0:1] imr	n[11] im	m[19:12]	rd	opcode	J-type

opcode 7-bits, opcode that specifies the operation
rs1 5-bits, register file address of the first source operand
rs2 5-bits, register file address of the second source operand
rd 5-bits, register file address of the result's destination
imm 12-bits / 20-bits, immediate number field
funct 3-bits / 10-bits, function code augmenting the opcode

#### The RISC-V ISA



#### **Instruction Categories**

- Load and Store instructions
- Bitwise instructions
- Arithmetic instructions
- Control transfer instructions
- Pseudo instructions

# Aside: RISC-V Register Convention




Table: Register names and descriptions

Register Names	ABI Names	Description
x0	zero	Hard-wired zero
x1	ra	Return address
x2	sp	Stack pointer
x3	gp	Global pointer
x4	tp	Thread pointer
<b>x</b> 5	t0	Temporary / Alternate link register
x6-7	t1 - t2	Temporary register
x8	s0 / fp	Saved register / Frame pointer
x9	s1	Saved register
x10-11	a0-a1	Function argument / Return value registers
x12-17	a2-a7	Function argument registers
x18-27	s2-s11	Saved registers
x28-31	t3-t6	Temporary registers

#### History of RISC-V





# **Control Instructions**

#### RISC-V Control Flow Instructions



#### RISC-V conditional branch instructions:

```
bne s0, s1, Lb1 # go to Lb1 if s0 != s1 
beq s0, s1, Lb1 # go to Lb1 if s0 = s1
```

#### Example

```
if (i==j) h = i + j;
bne s0, s1, Lbl1
add s3, s0, s1
Lbl1: ...
```

- Instruction Format (B format)
- How is the branch destination address specified?

#### RISC-V Control Flow Instructions



```
.globl _start
    .text
   _start:
5
6
7
            li a0, 1
            li a1, 1
            li t0, 20
8
            li t1, 23
            bne t0, t1, inst1
10
            addi a0, a0, 1
11
            beq t0, t1, inst2
12
   inst1: addi a0, a0, 2
13
            bne t0, zero, end
14 inst2: addi a0, a0, 3
15
    end:
            sub a0, a0, a1
```

RARS example: beq

• What is the final value of a0?

#### RISC-V Control Flow Instructions



```
.globl _start
 1
2
3
    .text
    _start:
 5
6
7
             li a0, 1
             li a1, 1
             li t0, 20
 8
9
             li t1, 23
             bne t0, t1, inst1
10
             addi a0, a0, 1
11
             beq t0, t1, inst2
12
   instl:
            addi a0, a0, 2
13
             bne t0, zero, end
   inst2: addi a0, a0, 3
15
    end:
            sub a0, a0, a1
```

RARS example: beq

• What is the final value of a0?

• a0 = 0x2



- We have beg, bne, but what about other kinds of branches (e.g., branch-if-less-than)?
- For this, we need yet another instruction, slt

#### Set on less than instruction:

```
slt t0, s0, s1  # if s0 < s1 then  # t0 = 1 else  # t0 = 0
```

• Instruction format (R format or I format)

#### Alternate versions of slt.

```
slti t0, s0, 25 # if s0 < 25 then t0 = 1 ... sltu t0, s0, s1 # if s0 < s1 then t0 = 1 ... sltiu t0, s0, 25 # if s0 < 25 then t0 = 1 ...
```



```
.globl _start
    .text
   start:
            li a0, 1
            li t0, 20
            li t1, 23
            slt a1, t0, t1
            beq a0, a1, inst1
            addi a0, a0, 2
10
   inst1: addi a0, a0, 3
11
```

RARS example: slt

• What is the final value of a0?



```
.globl _start
    .text
    start:
            li a0, 1
            li t0, 20
 6
            li t1, 23
            slt a1, t0, t1
 9
            beq a0, a1, inst1
            addi a0, a0, 2
10
    inst1: addi a0, a0, 3
11
```

RARS example: slt

What is the final value of a0?

• a0 = 0x4

#### Aside: More Branch Instructions



Can use slt, beq, bne, and the fixed value of 0 in register zero to create other conditions

• less than: blt s1, s2, Label

```
slt t0, s1, s2  # t0 set to 1 if
bne t0, zero, Label  # s1 < s2</pre>
```

- less than or equal to: ble s1, s2, Label
- greater than: bgt s1, s2, Label
- great than or equal to: bge s1, s2, Label
- Such branches are included in the instruction set as pseudo instructions recognized (and expanded) by the assembler



#### Which instruction is equivalent to the following program?

```
slt t0, s1, s2
beq t0, zero, Label
```

- A: blt s1, s2, Label
- B: ble s1, s2, Label
- C: bgt s1, s2, Label
- D: **bge** s1, s2, Label



#### Which instruction is equivalent to the following program?

```
slt t0, s1, s2
beq t0, zero, Label
```

- A: blt s1, s2, Label
- B: ble s1, s2, Label
- C: bgt s1, s2, Label
- D: **bge** s1, s2, Label

Ans: D

#### **Bounds Check Shortcut**



• Treating signed numbers as if they were unsigned gives a low cost way of checking if  $0 \le x < y$  (index out of bounds for arrays)

- The key is that negative integers in two's complement look like large numbers in unsigned notation.
- Thus, an unsigned comparison of x < y also checks if x is negative as well as if x is less than y.

#### Other Control Flow Instructions



• RISC-V also has an unconditional branch instruction or jump instruction:

```
jal zero, label # go to label, label can be an
  immediate value
```

- Instruction Format (J Format)
- J is a pseudo instruction of unconditional jal and it will discard the return address (e.g., j label)



pc := pc + sign extended(imm20 << 1)



```
.globl _start
    .text
    start:
5
            li a0, 1
6
            li t0, 20
            jal ra, loop
8
    loop:
            addi a0, a0, 1
            beg a0, t0, end
10
            j loop # j is a pseudo instruction for jal
11
12
    end:
            addi a0, a0, 1
```

RARS example: jal

• What is the final value of a0?



```
.globl _start
    .text
    start:
5
            li a0, 1
6
            li t0, 20
            jal ra, loop
8
    loop:
            addi a0, a0, 1
            beg a0, t0, end
10
            j loop # j is a pseudo instruction for jal
11
12
    end:
            addi a0, a0, 1
```

RARS example: jal

• What is the final value of a0?

```
• a0 = 0x15
```



#### EX-2: Branching Far Away

What if the branch destination is further away than can be captured in 12 bits? Re-write the following codes.

**beq** s0, s1, L1

#### Solution:



#### EX-2: Branching Far Away

What if the branch destination is further away than can be captured in 12 bits? Re-write the following codes.

```
beq s0, s1, L1
```

#### Solution:

```
bne s0, s1, L2
j L1
L2: ...
```

j is a pseudo instruction for jal (i.e., jal zero, label)



#### EX: Compiling a while Loop in C

Assume that i and k correspond to registers s3 and s5 and the base of the array save is in s6.



#### EX: Compiling a while Loop in C

```
while (save[i] == k) i += 1;
```

Assume that i and k correspond to registers s3 and s5 and the base of the array save is in s6.

```
Loop: slli t1, s3, 2  # Temp reg t1 = s3 * 4
    add t1, t1, s6  # t1 = address of save[i]
    lw t0, 0(t1)  # Temp reg t0 = save[i]
    bne t0, s5, Exit # go to Exit if save[i] != k
    addi s3, s3,1  # i = i + 1
    j Loop  # j is a pseudo instruction for jal
    # go to Loop
Exit:
```

Note: left shift s3 to align word address, and later address is increased by 1

#### Six Steps in Execution of a Procedure



- Main routine (caller) places parameters in a place where the procedure (callee) can access them
  - a0 a7: for argument registers
- 2 Caller transfers control to the callee
- Callee acquires the storage resources needed
- 4 Callee performs the desired task
- 6 Callee places the result value in a place where the caller can access it
  - s0-s11: 12 value registers for result values
- 6 Callee returns control to the caller
  - ra: one return address register to return to the point of origin

#### 0.060

**Accessing Procedures** 

#### Instructions for Accessing Procedures



#### We have learnt jal, now let's continue

• RISC-V procedure call instruction:

- Saves PC + 4 in register ra to have a link to the next instruction for the procedure return
- Machine format (J format):
- Then can do procedure return with a

```
jalr x0, 0(ra) # return
```

• Instruction format (I format)



#### Which instruction is incorrect? Why?

- A: jal x1, label
- B: jalr x2, 0(ra)
- C: jal x3, 0x8008
- D: jalr x0, label



#### Which instruction is incorrect? Why?

- A: jal x1, label
- B: jalr x2, 0(ra)
- C: jal x3, 0x8008
- D: jalr x0, label

Ans: D

## Example of Accessing Procedures



```
.globl start
    .text
    _start:
            li a0, 20
            li a1, 23
            # we call a function: add two numbers,
 8
            # and put the result in t1
            ial ra, add two numbers
            addi t1, a2, 0 # a2 = add_two_numbers(a0, a1)
10
11
            i end
12
13
    add_two_numbers:
14
            mv a3, a0 # mv is a pseudo instruction for addi
15
            mv a4, a1 # equal to "addi a4, a1, 0"
16
            add a2, a3, a4
17
            jalr zero, 0(ra)
18
19
    end:
20
            # we add t1 again
21
            addi t1, t1, 1
```

RARS example: accessing a procedure with jal & jalr

• What is the final value of t1?

#### Example of Accessing Procedures



```
.globl start
    .text
    _start:
            li a0, 20
            li a1, 23
            # we call a function: add two numbers,
 8
            # and put the result in t1
            ial ra, add two numbers
            addi t1, a2, 0 # a2 = add_two_numbers(a0, a1)
10
11
            i end
12
13
    add_two_numbers:
14
            mv a3, a0 # mv is a pseudo instruction for addi
15
            mv a4, a1 # equal to "addi a4, a1, 0"
16
            add a2, a3, a4
17
            jalr zero, 0(ra)
18
19
    end:
20
            # we add t1 again
21
            addi t1, t1, 1
```

RARS example: accessing a procedure with jal & jalr

• What is the final value of t1?

• t1 = 0x2c

## **Example of Accessing Procedures**



- For a procedure that computes the GCD of two values i (in t0) and j (in t1): gcd(i,j);
- The caller puts the i and j (the parameters values) in a0 and a1 and issues a

```
jal ra, gcd # jump to routine gcd
```

• The callee computes the GCD, puts the result in s0, and returns control to the caller using

```
gcd: . . . # code to compute gcd
jalr x0, 0(ra) # return
```




# What if the callee needs to use more registers than allocated to argument and return values?

- Use a stack: a last-in-first-out queue
- One of the general registers, sp, is used to address the stack
- "grows" from high address to low address
- push: add data onto the stack, data on stack at new sp

$$sp = sp - 4$$

pop: remove data from the stack, data from stack at sp


$$sp = sp + 4$$



#### Allocating Space on the **Stack**



- The segment of the stack containing a procedure's saved registers and local variables is its procedure frame (aka activation record)
- The frame pointer (fp) points to the first word of the frame of a procedure – providing a stable "base" register for the procedure
- fp is initialized using sp on a call and sp is restored using fp on a return



#### Allocating Space on the **Stack**



```
.globl start
    .text
    _start:
            li a0, 20
 6
            li a1, 23
            # we call a function: add_two_numbers,
            # and put the result in t\overline{1}
            jal ra, add two numbers
            addi t1, a2, 0 # a2 = add_two_numbers(a0, a1)
11
            i end
12
13
    add two numbers:
14
            addi sp. sp -8 # we assign 8x4 bytes in the stack
15
                           # stack: top (high address) -> bottom (low address)
16
                           # we save arguments in the stack
            sw a0, 4(sp)
17
            sw a1, 0(sp)
18
            add a2, a0, a1 # the a0 and a1 can be used directly since the
19
                            # original values of a0 and a1 are saved in the stack
20
                           # we restore arguments
             lw a0, 4(sp)
21
            lw a1, 0(sp)
22
            addi sp. sp. 8 # NOTICE: we need to free the stack we have allocated!
23
            jalr zero, 0(ra)
24
25
   end:
26
            # we add t1 again
27
            addi t1. t1. 1
```

RARS example: allocating space on the stack

• What is the final value of t1?

#### Allocating Space on the Stack



```
.globl start
    .text
    _start:
            li a0, 20
 6
            li a1, 23
            # we call a function: add_two_numbers,
            # and put the result in t\overline{1}
            jal ra, add two numbers
            addi t1, a2, 0 # a2 = add_two_numbers(a0, a1)
11
            i end
12
13
    add two numbers:
14
            addi sp. sp -8 # we assign 8x4 bytes in the stack
15
                            # stack: top (high address) -> bottom (low address)
16
            sw a0, 4(sp) # we save arguments in the stack
17
            sw a1, 0(sp)
18
            add a2, a0, a1 # the a0 and a1 can be used directly since the
19
                            # original values of a0 and a1 are saved in the stack
20
                           # we restore arguments
             lw a0, 4(sp)
21
            lw a1, 0(sp)
22
            addi sp. sp. 8 # NOTICE: we need to free the stack we have allocated!
23
            jalr zero, 0(ra)
24
25
   end:
26
            # we add t1 again
27
            addi t1, t1, 1
```


RARS example: allocating space on the stack

- What is the final value of t1?
- t1 = 0x2c

## Allocating Space on the Heap



- Static data segment for constants and other static variables (e.g., arrays)
- Dynamic data segment (aka heap) for structures that grow and shrink (e.g., linked lists)
- Allocate space on the heap with malloc() and free it with free() in C



#### EX-3: Compiling a C Leaf Procedure



Leaf procedures are ones that do not call other procedures. Give the RISC-V assembler code for the follows.

```
int leaf_ex (int g, int h, int i, int j)
{
    int f;
    f = (g+h) - (i+j);
    return f;
}
```

#### Solution:

#### EX-3: Compiling a C Leaf Procedure



Leaf procedures are ones that do not call other procedures. Give the RISC-V assembler code for the follows.

```
int leaf_ex (int g, int h, int i, int j)
{
    int f;
    f = (g+h) - (i+j);
    return f;
}
```

#### Solution:

#### Suppose g, h, i, and j are in a0, a1, a2, a3

#### **Nested Procedures**



- Nested Procedure: call other procedures
- What happens to return addresses with nested procedures?

```
int rt_1 (int i)
{
    if (i == 0) return 0;
    else return rt_2(i-1);
}
```

#### Nested procedures (cont.)



```
caller: jal rt_1
next: . . .
rt_1: bne a0, zero, to_2
       add s0, zero, zero
      jalr zero, 0(ra)
to_2: addi a0, a0, -1
       jal ra, rt_2
       jalr zero, 0(ra)
rt_2: . . .
```

• On the call to rt\_1, the return address (next in the caller routine) gets stored in ra.

#### Question:

What happens to the value in ra (when a0 != 0) when to\_2 makes a call to rt\_2?

## Compiling a Recursive Procedure



#### A procedure for calculating factorial

```
int fact (int n)
{
    if (n < 1) return 1;
    else return (n * fact (n-1));
}</pre>
```

• A recursive procedure (one that calls itself!)

```
fact (0) = 1

fact (1) = 1 * 1 = 1

fact (2) = 2 * 1 * 1 = 2

fact (3) = 3 * 2 * 1 * 1 = 6

fact (4) = 4 * 3 * 2 * 1 * 1 = 24
```

• Assume n is passed in a0; result returned in s0

## Compiling a Recursive Procedure (cont.)



```
fact: addi sp, sp, -8 # adjust stack pointer
     sw ra, 4(sp) # save return address
          a0, 0(sp) # save argument n
     sw
     slti t0, a0, 1 # test for n < 1
     beq t0, zero, L1 # if n \ge 1, go to L1
     addi s0, zero, 1 # else return 1 in s0
     addi sp, sp, 8  # adjust stack pointer
     jalr zero, 0(ra) # return to caller
     addi a0, a0, -1 # n \ge 1, so decrement n
L1:
     ial ra, fact # call fact with (n-1)
                       # this is where fact returns
bk_f: lw a0, 0(sp) # restore argument n
     lw ra, 4(sp) # restore return address
     addi sp, sp, 8 # adjust stack pointer
     mul s0, a0, s0 # s0 = n * fact(n-1)
     jalr zero, 0(ra) # return to caller
```

Note: bk\_f is carried out when fact is returned.

## Compiling a Recursive Procedure (cont.)



```
1 .globl _start
 2 .text
    _start: li a0, 20
            li a1, 23
            ial ra. func # we call a function: func
                         # func implements (a0 \times 2 + a1)
                         # and put the result in t1
            addi t1, a2, 0 # a2 = func(a0, a1)
            i end
    func:
            addi sp, sp -12
11
            sw ra, 8(sp)
12
            sw a0, 4(sp)
13
            sw a1. 0(sp)
14
            slli a0, a0, 1
15
            jal ra, add_two_numbers # add_two_numbers implements (a0 + a1)
            lw ra. 8(sp)
17
            lw a0, 4(sp)
18
            lw a1, 0(sp)
19
            addi sp, sp, 12
            ialr zero. 0(ra)
    add_two_numbers: addi sp, sp -8 # we assign 8x4 bytes in the stack
22
                                    # stack: top (high address) -> bottom (low address)
23
            sw a0, 4(sp) # we save arguments in the stack
24
            sw a1. 0(sp)
            add a2. a0, a1 # the a0 and a1 can be used directly since the
26
                           # original values of a0 and a1 are saved in the stack
27
            lw a0, 4(sp) # we restore arguments
28
            lw a1. 0(sp)
29
            addi sp. sp. 8 # NOTICE: we need to free the stack we have allocated!
30
            jalr zero, 0(ra)
31 end:
32
            # we add t1 again
33
            addi t1, t1, 1
```

RARS example: compiling a recursive procedure

• What is the final value of t1?

## Compiling a Recursive Procedure (cont.)



```
1 .globl _start
 2 .text
    _start: li a0, 20
            li a1, 23
            ial ra. func # we call a function: func
                         # func implements (a0 \times 2 + a1)
                         # and put the result in t1
            addi t1, a2, 0 # a2 = func(a0, a1)
            i end
    func:
            addi sp, sp -12
11
            sw ra, 8(sp)
12
            sw a0, 4(sp)
13
            sw a1. 0(sp)
14
            slli a0, a0, 1
15
            jal ra, add_two_numbers # add_two_numbers implements (a0 + a1)
            lw ra. 8(sp)
17
            lw a0, 4(sp)
18
            lw a1, 0(sp)
19
            addi sp, sp, 12
            jalr zero, 0(ra)
    add two numbers: addi sp. sp -8 # we assign 8x4 bytes in the stack
22
                                    # stack: top (high address) -> bottom (low address)
23
            sw a0, 4(sp) # we save arguments in the stack
24
            sw a1. 0(sp)
            add a2. a0, a1 # the a0 and a1 can be used directly since the
26
                           # original values of a0 and a1 are saved in the stack
27
            lw a0, 4(sp) # we restore arguments
28
            lw a1. 0(sp)
29
            addi sp. sp. 8 # NOTICE: we need to free the stack we have allocated!
30
            jalr zero, 0(ra)
31 end:
32
            # we add t1 again
33
            addi t1, t1, 1
```

RARS example: compiling a recursive procedure

What is the final value of t1?


• t1 = 0x40



# **Summary**

# The C Code Translation Hierarchy





## Compiler Benefits



- Comparing performance for bubble (exchange) sort
- To sort 100,000 words with the array initialized to random values on a Pentium 4 with a 3.06 clock rate, a 533 MHz system bus, with 2 GB of DDR SDRAM, using Linux version 2.4.20

The un-optimized code has the best CPI<sup>1</sup>, the O1 version has the lowest instruction count, but the O3 version is the fastest.

gcc opt	Relative performance	Clock cycles (M)	Instr count (M)	СРІ
None	1.00	158,615	114,938	1.38
O1 (medium)	2.37	66,990	37,470	1.79
O2 (full)	2.38	66,521	39,993	1.66
O3 (proc mig)	2.41	65,747	44,993	1.46

<sup>&</sup>lt;sup>1</sup>CPI: clock cycles per instruction

## Addressing Modes Illustrated



