I/O Worksheet

Item Nintendo 3DS

Input	Ouput	Features
● D-Pad (Arrow Keys)	Moves the selecting box In the direction you input	Changes shapes and colors depending on where you are
	 Lets you know where you are pointing at on the screen 	 Sometimes makes different sound effects
	Makes it easy to select an option	

Item DVD Player

Ouput	Features
Turns on or off the power	Turns on indication lights
 Opens the CD tray 	Displays words on LCD scre
Fastforward/Rewind	
	Turns on or off the powerOpens the CD tray

Item IPod

Input	Ouput	Features
Swipe Screen	Unlocks phone	Makes locking sounds
Push Buttons	Powers on/off	Lights up screen
	Opens recent open apps	Allows the selection of apps