

### A. BRAKE TEST ON LOW SPEED MOTOR

- Make the connections as shown in figure.
- Keep belt on brake drum in loose position (motor on no load)
- Switch on the 3 phase supply while the motor is on no load.
- By tightening the brake drum, increase the load on the motor upto rated value. Note down the speed, spring balance readings, and voltmeter, ammeter and wattmeter readings.
- Now decrease the load in steps upto no load and note down the readings each time.
- If any of the wattmeter readings shows negative on *no load* or light loads, switch of the supply & interchange the terminals of pressure coils/current coils (not both) of that wattmeter.
- Now, again starting the motor (follow above procedure for starting), take readings. Switch off the supply. Measure the radius of the brake drum.

[illegible]