

目 录

前言.....	ii
1 使用 MIB 查询工具查询产品 MIB 信息.....	1
2 MIB 简介.....	2
2.1 网络管理概述.....	2
2.2 基于 SNMP 的网络管理.....	2
2.3 SNMP 介绍.....	3
2.3.1 SNMP 版本.....	3
2.3.2 SNMP 协议数据单元.....	4
2.3.3 SNMP 报文处理过程.....	4
2.4 MIB 介绍.....	5
2.4.1 MIB 树结构.....	5
2.4.2 MIB 分类.....	6
2.4.3 MIB 的几个概念.....	7
3 MIB 典型使用实例.....	9
3.1 配置网管工具与交换机连接.....	9
3.2 MIB 文件下载.....	13
3.3 MIB 加载.....	13
3.4 常用 MIB 节点.....	20
3.5 通过 MIB 管理配置文件.....	23
3.6 通过 MIB 保存配置文件.....	27
3.7 通过 MIB 升级设备.....	32
3.8 MIB 典型查询和配置案例.....	38
3.8.1 设备物理信息查询和配置.....	38
3.8.1.1 查询 CPU 使用率.....	38
3.8.1.2 查询内存大小.....	39
3.8.1.3 查询内存使用率.....	41
3.8.1.4 查询温度.....	42
3.8.1.5 查询设备功耗信息.....	43
3.8.1.6 查询序列号.....	43
3.8.1.7 查询光模块信息.....	44
3.8.1.8 查询电子标签信息.....	46
3.8.1.9 查询风扇状态.....	47

3.8.1.10 查询系统 MAC 地址.....	48
3.8.1.11 配置系统节能模式.....	48
3.8.1.12 配置功耗数据统计周期.....	49
3.8.1.13 查询主备倒换的配置信息.....	50
3.8.2 堆叠信息查询.....	51
3.8.2.1 查询堆叠是否使能.....	51
3.8.2.2 查询堆叠成员设备的基本属性信息.....	52
3.8.2.3 查询堆叠端口信息.....	53
3.8.2.4 查询堆叠 CPU 和内存使用率.....	53
3.8.3 接口信息查询.....	54
3.8.3.1 查询接口 Up/Down 信息.....	56
3.8.3.2 查询接口报文统计信息.....	57
3.8.3.3 查询接口的 MAC 地址.....	58
3.8.3.4 查询接口的速率信息.....	59
3.8.3.5 查询 Trunk 接口的最小 Up 接口数.....	61
3.8.4 MAC 地址表查询.....	62
3.8.4.1 查询 MAC 地址和接口的对应关系.....	62
3.8.4.2 根据指定条件查询动态 MAC.....	66
3.8.5 VLAN 信息查询.....	76
3.8.5.1 查询已经创建的 VLAN 信息.....	76
3.8.5.2 查询 VLAN 与加入该 VLAN 的接口信息.....	77
3.8.6 STP 查询.....	79
3.8.6.1 查询 STP 使能情况.....	79
3.8.6.2 查询 STP 的类型.....	81
3.8.6.3 查询当前接口的转发状态.....	81
3.8.7 IP 地址信息查询.....	82
3.8.7.1 查询所有接口的 IP 地址.....	83
3.8.7.2 查询某个接口的 IP 地址.....	83
3.8.8 路由总数查询案例.....	83
3.8.8.1 查询各种路由协议的 IP 路由总数.....	84
3.8.9 BFD 信息查询.....	85
3.8.9.1 查询 BFD 状态（UP/DOWN）信息.....	85
3.8.10 VRRP 信息查询.....	87
3.8.10.1 查询 VRRP 备份组的状态信息.....	87
3.8.10.2 查询 VRRP 备份组的虚拟 MAC 地址信息.....	88
3.8.11 QoS 查询.....	89
3.8.11.1 查询接口队列统计信息.....	89
3.8.11.2 查询流分类.....	91
3.8.11.3 查询流量监管配置信息.....	92
3.8.12 LLDP 信息查询.....	93
3.8.12.1 LLDP 基本信息查询.....	93
3.8.12.1.1 查询 LLDP 配置信息.....	94

3.8.12.1.2 查询 LLDP 远端设备信息.....	96
3.8.12.1.3 查询 LLDP 本地设备数据.....	96
3.8.12.1.4 查询 LLDP 远端设备数据.....	97
3.8.12.2 LLDP 扩展信息查询.....	98
3.8.12.2.1 查询 LLDP-EXT-DOT1-MIB 信息.....	99
3.8.12.2.2 查询 LLDP-EXT-DOT3-MIB 信息.....	100
3.8.12.3 LLDP 华为 MIB 信息查询.....	101
3.8.12.3.1 查询 HUAWEI-LLDP-MIB 信息.....	101
3.8.13 NQA 信息查询.....	102
3.8.13.1 查看 NQA 测试例的运行结果.....	103
3.8.14 RMON 信息查询.....	104
3.8.14.1 查询 RMON 以太网统计表信息.....	104
3.8.14.2 查询 RMON 历史控制表信息.....	104
3.8.14.3 查询 RMON 以太网历史表信息.....	105
3.8.14.4 查询 RMON 告警表信息.....	105
3.8.14.5 查询 RMON 事件表信息.....	106
3.8.14.6 查询 RMON 日志表信息.....	106
4 BGP4-MIB.....	108
4.1 功能简介.....	108
4.2 表间关系.....	109
4.3 单节点详细描述.....	109
4.3.1 bgpVersion 详细描述.....	109
4.3.2 bgpLocalAs 详细描述.....	109
4.3.3 bgpIdentifier 详细描述.....	110
4.4 MIB Table 详细描述.....	110
4.4.1 bgpPeerTable 详细描述.....	110
4.4.2 bgp4PathAttrTable 详细描述.....	116
4.5 告警节点详细描述.....	120
4.5.1 bgpEstablished 详细描述.....	121
4.5.2 bgpBackwardTransition 详细描述.....	121
5 BRIDGE-MIB.....	122
5.1 功能简介.....	122
5.2 表间关系.....	122
5.3 单节点详细描述.....	123
5.3.1 dot1dBaseBridgeAddress 详细描述.....	123
5.3.2 dot1dBaseNumPorts 详细描述.....	123
5.3.3 dot1dBaseType 详细描述.....	123
5.3.4 dot1dStpPriority 详细描述.....	124
5.3.5 dot1dStpTimeSinceTopologyChange 详细描述.....	124
5.3.6 dot1dStpDesignatedRoot 详细描述.....	124
5.3.7 dot1dStpRootCost 详细描述.....	124
5.3.8 dot1dStpRootPort 详细描述.....	125

5.3.9 dot1dStpMaxAge 详细描述.....	125
5.3.10 dot1dStpHelloTime 详细描述.....	125
5.3.11 dot1dStpHoldTime 详细描述.....	125
5.3.12 dot1dStpForwardDelay 详细描述.....	126
5.3.13 dot1dStpBridgeMaxAge 详细描述.....	126
5.3.14 dot1dStpBridgeHelloTime 详细描述.....	126
5.3.15 dot1dStpBridgeForwardDelay 详细描述.....	126
5.3.16 dot1dTpLearnedEntryDiscards 详细描述.....	127
5.3.17 dot1dTpAgingTime 详细描述.....	127
5.4 MIB Table 详细描述.....	127
5.4.1 dot1dBasePortTable 详细描述.....	127
5.4.2 dot1dStpPortTable 详细描述.....	128
5.4.3 dot1dTpPortTable 详细描述.....	131
5.4.4 dot1dTpFdbTable 详细描述.....	131
5.5 告警节点详细描述.....	132
5.5.1 newRoot 详细描述.....	133
5.5.2 topologyChange 详细描述.....	133
6 DISMAN-PING-MIB.....	134
6.1 功能简介.....	134
6.2 表间关系.....	135
6.3 单节点详细描述.....	135
6.3.1 pingMaxConcurrentRequests 详细描述.....	136
6.4 MIB Table 详细描述.....	136
6.4.1 pingCtlTable 详细描述.....	137
6.4.2 pingResultsTable 详细描述.....	153
6.4.3 pingProbeHistoryTable 详细描述.....	156
6.5 告警节点详细描述.....	158
6.5.1 pingProbeFailed 详细描述.....	159
6.5.2 pingTestFailed 详细描述.....	160
6.5.3 pingTestCompleted 详细描述.....	161
7 DISMAN-TRACEROUTE-MIB.....	162
7.1 功能简介.....	162
7.2 表间关系.....	163
7.3 单节点详细描述.....	163
7.3.1 traceRouteMaxConcurrentRequests 详细描述.....	164
7.4 MIB Table 详细描述.....	164
7.4.1 traceRouteCtlTable 详细描述.....	164
7.4.2 traceRouteResultsTable 详细描述.....	176
7.4.3 traceRouteProbeHistoryTable 详细描述.....	178
7.4.4 traceRouteHopsTable 详细描述.....	181
7.5 告警节点详细描述.....	184
7.5.1 traceRoutePathChange 详细描述.....	184

7.5.2 traceRouteTestFailed 详细描述.....	185
7.5.3 traceRouteTestCompleted 详细描述.....	185
8 ENTITY-MIB.....	186
8.1 功能简介.....	186
8.2 表间关系.....	186
8.3 单节点详细描述.....	188
8.3.1 entLastChangeTime 详细描述.....	188
8.4 MIB Table 详细描述.....	189
8.4.1 entPhysicalTable 详细描述.....	189
8.4.2 entLogicalTable 详细描述.....	191
8.4.3 entLPMappingTable 详细描述.....	193
8.4.4 entAliasMappingTable 详细描述.....	193
8.4.5 entPhysicalContainsTable 详细描述.....	194
8.5 告警节点详细描述.....	194
8.5.1 entConfigChange 详细描述.....	195
8.6 不支持节点.....	195
9 EtherLike-MIB.....	196
9.1 功能简介.....	196
9.2 表间关系.....	196
9.3 单节点详细描述.....	196
9.4 MIB Table 详细描述.....	196
9.4.1 dot3StatsTable 详细描述.....	196
9.4.2 dot3CollTable 详细描述.....	199
9.4.3 dot3ControlTable 详细描述.....	200
9.4.4 dot3PauseTable 详细描述.....	201
9.4.5 dot3HCStatsTable 详细描述.....	203
9.5 告警节点详细描述.....	204
10 HUAWEI-AAA-MIB.....	205
10.1 功能简介.....	205
10.2 表间关系.....	205
10.3 单节点详细描述.....	205
10.4 MIB Table 详细描述.....	205
10.4.1 hwAuthenSchemeTable 详细描述.....	206
10.4.2 hwAcctSchemeTable 详细描述.....	222
10.4.3 hwAcctSchemeExtTable 详细描述.....	223
10.4.4 hwAAAOOfflineRecordTable 详细描述.....	224
10.4.5 hwAAASetting 详细描述.....	227
10.4.6 hwAAASState 详细描述.....	233
10.4.7 hwDomainTable 详细描述.....	234
10.4.8 hwDomainExtTable 详细描述.....	238
10.4.9 hwAuthorSchemeTable 详细描述.....	239

10.4.10 hwLocalUserTable 详细描述.....	252
10.4.11 hwLocalUserExtTable 详细描述.....	255
10.4.12 hwRecordSchemeTable 详细描述.....	256
10.4.13 hwServiceSchemeTable 详细描述.....	257
10.4.14 hwUserGroupTable 详细描述.....	260
10.4.15 hwAccessTable 详细描述.....	263
10.4.16 hwAccessExtTable 详细描述.....	269
10.4.17 hwCutAccessUserTable 详细描述.....	275
10.4.18 hwAuthEventCfgTable 详细描述.....	277
10.4.19 hwAuthorCmdTable 详细描述.....	279
10.4.20 hwOfflineReasonStatTable 详细描述.....	280
10.4.21 hwLocalUserPwPolicyAdmin 详细描述.....	280
10.4.22 hwLocalUserPwPolicyAcc 详细描述.....	281
10.4.23 userAuthenProfileTable 详细描述.....	282
10.4.24 userAuthenticationFreeRuleTable 详细描述.....	288
10.4.25 hwDot1xAccessProfileTable 详细描述.....	289
10.4.26 hwMACAuthenAccessProfileTable 详细描述.....	292
10.4.27 hwPortalAccessProfileTable 详细描述.....	295
10.4.28 userAuthenticationFreeRuleExtTable 详细描述.....	298
10.4.29 hwReAuthenUserTable 详细描述.....	300
10.4.30 hwAccessUserNumberTable 详细描述.....	301
10.4.31 hwWlanVlanPoolTable 详细描述.....	301
10.5 告警节点详细描述.....	303
10.5.1 hwMacMovedQuietMaxUserAlarm 详细描述.....	303
10.5.2 hwMacMovedQuietUserClearAlarm 详细描述.....	303
10.5.3 hwNacUserClearAlarm 详细描述.....	304
10.5.4 hwNacMaxUserAlarm 详细描述.....	304
10.5.5 hwChangePasswordAlarm 详细描述.....	304
10.5.6 hwPPPMAXUserAlarm 详细描述.....	305
10.5.7 hwPPPMAXUserClearAlarm 详细描述.....	305
10.5.8 hwMacQuietMaxUserAlarm 详细描述.....	305
10.5.9 hwMacQuietUserClearAlarm 详细描述.....	306
10.5.10 hwQuietUserClearAlarm 详细描述.....	306
10.5.11 hwQuietUserMaxAlarm 详细描述.....	307
10.5.12 hwQuietPortClearAlarm 详细描述.....	307
10.5.13 hwQuietPortMaxAlarm 详细描述.....	308
10.5.14 hwMaxUclGroupIpNumAlarm 详细描述.....	308
10.5.15 hwMaxUclGroupIpNumClearAlarm 详细描述.....	309
10.5.16 hwIPGroupChannelUp 详细描述.....	309
10.5.17 hwIPGroupChannelDown 详细描述.....	309
10.5.18 hwHacaChannelUp 详细描述.....	310
10.5.19 hwHacaChannelDown 详细描述.....	310

10.5.20 hwAuthorDynAclRuleExceed 详细描述.....	310
10.5.21 hwAuthorAclRuleExceed 详细描述.....	311
10.5.22 hwDymicUclGroupIpNumAlarm 详细描述.....	311
10.5.23 hwDymicUclGroupIpNumResume 详细描述.....	311
10.6 不支持节点.....	312
11 HUAWEI-ACL-MIB.....	328
11.1 功能简介.....	328
11.2 表间关系.....	329
11.3 单节点详细描述.....	330
11.4 MIB Table 详细描述.....	330
11.4.1 hwAclNumGroupTable 详细描述.....	330
11.4.2 hwAclBasicRuleTable 详细描述.....	333
11.4.3 hwAclAdvancedRuleTable 详细描述.....	337
11.4.4 hwAclEthernetFrameRuleTable 详细描述.....	342
11.4.5 hwAclUserRuleTable 详细描述.....	346
11.4.6 hwAclIpv6BasicRuleTable 详细描述.....	353
11.4.7 hwAclIpv6AdvancedRuleTable 详细描述.....	356
11.4.8 hwAclIpv6NumGroupTable 详细描述.....	361
11.4.9 hwAclResourceTrapsTable 详细描述.....	362
11.4.10 hwCounterResourceTrapsTable 详细描述.....	363
11.4.11 hwMeterResourceTrapsTable 详细描述.....	364
11.5 告警节点详细描述.....	365
11.5.1 hwAclResThresholdExceedClearTrap 详细描述.....	365
11.5.2 hwAclResThresholdExceedTrap 详细描述.....	366
11.5.3 hwAclResTotalCountExceedClearTrap 详细描述.....	366
11.5.4 hwAclResTotalCountExceedTrap 详细描述.....	366
11.5.5 hwCounterResThresholdExceedClear 详细描述.....	366
11.5.6 hwCounterResThresholdExceed 详细描述.....	367
11.5.7 hwCounterResTotalCountExceedClear 详细描述.....	367
11.5.8 hwCounterResTotalCountExceed 详细描述.....	367
11.5.9 hwMeterResThresholdExceedClear 详细描述.....	368
11.5.10 hwMeterResThresholdExceed 详细描述.....	368
11.5.11 hwMeterResTotalCountExceedClear 详细描述.....	368
11.5.12 hwMeterResTotalCountExceed 详细描述.....	368
11.6 不支持节点.....	369
12 HUAWEI-ALARM-MIB.....	371
12.1 功能简介.....	371
12.2 表间关系.....	371
12.3 单节点详细描述.....	371
12.3.1 hwMinAlarmSyncIndex 详细描述.....	372
12.3.2 hwMaxAlarmSyncIndex 详细描述.....	372
12.3.3 hwMinEventSyncIndex 详细描述.....	372

12.3.4 hwMaxEventSyncIndex 详细描述.....	372
12.3.5 hwAlarmDateAndTime 详细描述.....	372
12.3.6 hwAlarmOrEventFlag 详细描述.....	373
12.3.7 hwAlarmReasonInfo 详细描述.....	373
12.3.8 hwAlarmSeverity 详细描述.....	374
12.4 MIB Table 详细描述.....	374
12.4.1 hwAlarmSyncTable 详细描述.....	374
12.4.2 hwEventSyncTable 详细描述.....	375
12.4.3 hwAlarmActiveTable 详细描述.....	376
12.4.4 hwEventTable 详细描述.....	377
12.4.5 hwSnmpTargetAddrExtTable 详细描述.....	379
12.4.6 hwSnmpTargetSyncIndexTable 详细描述.....	379
12.4.7 hwAlarmAttrTable 详细描述.....	381
12.4.8 hwEventAttrTable 详细描述.....	382
12.5 告警节点详细描述.....	383
12.5.1 hwAlarmTargetHostDel 详细描述.....	383
12.5.2 hwAlarmStorm 详细描述.....	383
13 HUAWEI-ALARM-RELIABILITY-MIB.....	384
13.1 功能简介.....	384
13.2 表间关系.....	384
13.3 单节点详细描述.....	384
13.3.1 hwARInformPendings 详细描述.....	385
13.3.2 hwARRetryCount 详细描述.....	385
13.3.3 hwARTimeout 详细描述.....	386
13.4 MIB Table 详细描述.....	386
13.5 告警节点详细描述.....	386
14 HUAWEI-AUTODIAGNOSE-MIB.....	387
14.1 功能简介.....	387
14.2 表间关系.....	387
14.3 单节点详细描述.....	388
14.4 MIB Table 详细描述.....	388
14.4.1 hwAutoDiagnoseTable 详细描述.....	388
14.4.2 hwAutoDiagnoseIssueResultTable 详细描述.....	390
14.4.3 hwAutoDiagnoseSubIssueResultTable 详细描述.....	391
14.4.4 hwAutoDiagnoseSubIssueDetailResultTable 详细描述.....	392
14.5 告警节点详细描述.....	393
14.6 不支持节点.....	394
15 HUAWEI-BASE-TRAP-MIB.....	395
15.1 功能简介.....	395
15.2 表间关系.....	395
15.3 单节点详细描述.....	395

15.3.1 hwBaseTrapSeverity 详细描述.....	396
15.3.2 hwBaseTrapProbableCause 详细描述.....	396
15.3.3 hwBaseTrapEventType 详细描述.....	396
15.3.4 hwBaseTrapRelativeResource 详细描述.....	397
15.3.5 hwBaseTrapReasonDescr 详细描述.....	397
15.3.6 hwFIBOverloadModule 详细描述.....	397
15.3.7 hwBaseTrapCurPortType 详细描述.....	397
15.3.8 hwBaseTrapLastPortType 详细描述.....	398
15.4 MIB Table 详细描述.....	398
15.4.1 hwBaseThresholdTable 详细描述.....	398
15.4.2 hwBaseUsageTable 详细描述.....	400
15.5 告警节点详细描述.....	401
15.5.1 hwFIBOverloadSuspend 详细描述.....	402
15.5.2 hwFIBOverloadSusResume 详细描述.....	402
15.5.3 hwFIBOverloadForward 详细描述.....	403
15.5.4 hwFIBOverloadFwResume 详细描述.....	403
15.5.5 hwEntityInvalid 详细描述.....	403
15.5.6 hwEntityResume 详细描述.....	404
15.5.7 hwEntityOffline 详细描述.....	405
15.5.8 hwEntityOnline 详细描述.....	406
15.5.9 hwProcessExitTrap 详细描述.....	407
15.5.10 hwTempRisingAlarm 详细描述.....	407
15.5.11 hwTempRisingResume 详细描述.....	408
15.5.12 hwTempFallingAlarm 详细描述.....	409
15.5.13 hwTempFallingResume 详细描述.....	410
15.5.14 hwCPUUtilizationRisingAlarm 详细描述.....	412
15.5.15 hwCPUUtilizationResume 详细描述.....	413
15.5.16 hwPortPhysicalEthHalfDuplexAlarm 详细描述.....	413
15.5.17 hwPortPhysicalEthFullDuplexClear 详细描述.....	414
15.5.18 hwPortPhysicalPortTypeChange 详细描述.....	415
15.5.19 hwEntityDyingGasp 详细描述.....	416
15.5.20 hwOpticalPowerAbnormal 详细描述.....	417
15.5.21 hwOpticalPowerResume 详细描述.....	417
15.6 不支持节点.....	418
16 HUAWEI-BFD-MIB.....	422
16.1 功能简介.....	422
16.2 表间关系.....	422
16.3 单节点详细描述.....	423
16.3.1 hwBfdVersionNumber 详细描述.....	423
16.3.2 hwBfdAdminStatus 详细描述.....	423
16.3.3 hwBfdSessLimitNumber 详细描述.....	424
16.3.4 hwBfdSessInterfaceLimitNumber 详细描述.....	424

16.3.5 hwBfdSessStaticNumber 详细描述.....	424
16.3.6 hwBfdSessDynamicNumber 详细描述.....	425
16.3.7 hwBfdSessGlobalDefaultIpAddr 详细描述.....	425
16.3.8 hwBfdTrapSendInterval 详细描述.....	425
16.4 MIB Table 详细描述.....	426
16.4.1 hwBfdIfConfTable 详细描述.....	426
16.4.2 hwBfdSessionConfTable 详细描述.....	427
16.4.3 hwBfdSessionTable 详细描述.....	441
16.4.4 hwBfdSessionPerTable 详细描述.....	454
16.5 告警节点详细描述.....	456
16.5.1 hwBfdSessDown 详细描述.....	457
16.5.2 hwBfdSessUp 详细描述.....	458
16.5.3 hwBfdSessReachLimit 详细描述.....	458
16.5.4 hwBfdSessReachLimitBindIf 详细描述.....	459
16.6 不支持节点.....	459
17 HUAWEI-BFD-CONFIG-TRAP-MIB.....	460
17.1 功能简介.....	460
17.2 表间关系.....	460
17.3 单节点详细描述.....	460
17.3.1 hwBfdConfigLocalDis 详细描述.....	461
17.4 告警节点详细描述.....	461
17.4.1 hwBfdConfigIntervalShort 详细描述.....	461
18 HUAWEI-BGP-VPN-MIB.....	462
18.1 功能简介.....	462
18.2 表间关系.....	462
18.3 单节点详细描述.....	463
18.3.1 hwBgpPeerSessionNum 详细描述.....	463
18.3.2 hwIBgpPeerSessionNum 详细描述.....	463
18.3.3 hwEBgpPeerSessionNum 详细描述.....	463
18.3.4 hwBgpPeerSessionMaxNum 详细描述.....	463
18.3.5 hwBgpDynamicPeerSessionNum 详细描述.....	464
18.3.6 hwBgpDynamicPeerSessionMaxNum 详细描述.....	464
18.4 MIB Table 详细描述.....	464
18.4.1 hwBgpPeerAddrFamilyTable 详细描述.....	464
18.4.2 hwBgpPeerTable 详细描述.....	466
18.4.3 hwBgpPeerRouteTable 详细描述.....	469
18.4.4 hwBgpPeerMessageTable 详细描述.....	470
18.4.5 hwBgpPeerConfigTable 详细描述.....	473
18.4.6 hwBgpVpnTunnelTable 详细描述.....	474
18.4.7 hwBgpVpnServiceIdTable 详细描述.....	477
18.4.8 hwTn2VpnTrapTable 详细描述.....	478
18.4.9 hwBgpVpnScalars 详细描述.....	479

18.4.10 hwBgpRouteLimitTable 详细描述.....	480
18.5 告警节点详细描述.....	482
18.5.1 hwBgpPeerRouteNumThresholdExceed 详细描述.....	482
18.5.2 hwBgpPeerRouteNumThresholdClear 详细描述.....	482
18.5.3 hwBgpPeerGRStatusChange 详细描述.....	483
18.5.4 hwBgpPeerEstablished 详细描述.....	483
18.5.5 hwBgpPeerBackwardTransition 详细描述.....	483
18.5.6 hwBgpRouteThresholdExceed 详细描述.....	484
18.5.7 hwBgpRouteThresholdClear 详细描述.....	484
18.5.8 hwBgpRouteMaxExceed 详细描述.....	484
18.5.9 hwBgpRouteMaxClear 详细描述.....	485
18.5.10 hwTnl2VpnTrapEvent 详细描述.....	485
18.5.11 hwBgpDynamicPeerSessionExceed 详细描述.....	485
18.5.12 hwBgpDynamicPeerSessionExceedClear 详细描述.....	486
19 HUAWEI-BRAS-RADIUS-MIB.....	487
19.1 功能简介.....	487
19.2 表间关系.....	487
19.3 单节点详细描述.....	488
19.4 MIB Table 详细描述.....	488
19.4.1 hwRadiusAuthorServerTable 详细描述.....	488
19.4.2 hwRadiusGroupTable 详细描述.....	490
19.4.3 hwRadiusServerTable 详细描述.....	498
19.4.4 hwRadiusAttrCheckTable 详细描述.....	501
19.4.5 hwRadiusAttrDisableTable 详细描述.....	502
19.4.6 hwRadiusAttrTranslateTable 详细描述.....	503
19.4.7 hwRadiusAttrSetTable 详细描述.....	507
19.4.8 hwRadiusAccountTest 详细描述.....	508
19.5 告警节点详细描述.....	509
19.5.1 hwRadiusAuthServerUp 详细描述.....	510
19.5.2 hwRadiusAuthServerDown 详细描述.....	510
19.5.3 hwRadiusAcctServerUp 详细描述.....	510
19.5.4 hwRadiusAcctServerDown 详细描述.....	510
19.5.5 hwRadiusAuthServerForceUp 详细描述.....	511
19.5.6 hwRadiusAcctServerForceUp 详细描述.....	511
19.6 不支持节点.....	511
20 HUAWEI-BRAS-SRVCFG-EAP-MIB.....	513
20.1 功能简介.....	513
20.2 表间关系.....	513
20.3 单节点详细描述.....	513
20.3.1 hwDot1xGlobal 详细描述.....	513
20.3.2 hwDot1xAuthenMethod 详细描述.....	514
20.3.3 hwDot1xDhcpTrigger 详细描述.....	514

20.3.4 hwDot1xQuietPeriod 详细描述.....	515
20.3.5 hwDot1xRetry 详细描述.....	515
20.3.6 hwDot1xTimerQuietPeriod 详细描述.....	516
20.3.7 hwDot1xTimerClientTimeout 详细描述.....	516
20.3.8 hwDot1xTimerTxPeriod 详细描述.....	517
20.3.9 hwDot1xReauthenPeriod 详细描述.....	517
20.3.10 hwDot1xQuietFailTimes 详细描述.....	517
20.4 MIB Table 详细描述.....	518
20.4.1 hwDot1xPortConfigTable 详细描述.....	518
20.5 告警节点详细描述.....	522
20.5.1 hwSrvcfgEapMaxUserAlarm 详细描述.....	522
20.6 不支持节点.....	523
21 HUAWEI-BRAS-SRVCFG-STATICUSER-MIB.....	524
21.1 功能简介.....	524
21.2 表间关系.....	524
21.3 单节点详细描述.....	524
21.3.1 hwStaticUserPassword 详细描述.....	524
21.3.2 hwStaticUserNameFormatInclud 详细描述.....	525
21.4 MIB Table 详细描述.....	525
21.4.1 hwStaticUserTable 详细描述.....	525
21.5 告警节点详细描述.....	527
21.6 不支持节点.....	527
22 HUAWEI-CBQOS-MIB.....	528
22.1 功能简介.....	528
22.2 表间关系.....	528
22.3 单节点详细描述.....	531
22.3.1 hwCBQoSClassifierIndexNext 详细描述.....	531
22.3.2 hwCBQoSBehaviorIndexNext 详细描述.....	531
22.3.3 hwCBQoSPolicyIndexNext 详细描述.....	532
22.4 MIB Table 详细描述.....	532
22.4.1 hwCBQoSClassifierCfgInfoTable 详细描述.....	532
22.4.2 hwCBQoSMatchRuleCfgInfoTable 详细描述.....	533
22.4.3 hwCBQoSBehaviorCfgInfoTable 详细描述.....	539
22.4.4 hwCBQoSCarCfgInfoTable 详细描述.....	540
22.4.5 hwCBQoSRemarkCfgInfoTable 详细描述.....	546
22.4.6 hwCBQoSFirewallCfgInfoTable 详细描述.....	550
22.4.7 hwCBQoSMirrorCfgInfoTable 详细描述.....	551
22.4.8 hwCBQoSCountCfgInfoTable 详细描述.....	552
22.4.9 hwCBQoSPolicyCfgInfoTable 详细描述.....	553
22.4.10 hwCBQoSPolicyClassCfgInfoTable 详细描述.....	554
22.4.11 hwCBQoSIfApplyPolicyTable 详细描述.....	555
22.4.12 hwCBQoSvlanApplyPolicyTable 详细描述.....	557

22.4.13 hwCBQoSPolicyStatisticsTable 详细描述.....	558
22.4.14 hwCBQoSPolicyStatisticsClassifierTable 详细描述.....	560
22.5 告警节点详细描述.....	561
22.6 不支持节点.....	561
23 HUAWEI-CCC-MIB.....	565
23.1 功能简介.....	565
23.2 表间关系.....	565
23.3 单节点详细描述.....	565
23.3.1 hwCCCVcStateChangeReason 详细描述.....	566
23.4 MIB Table 详细描述.....	566
23.4.1 hwCCCVcTable 详细描述.....	566
23.5 告警节点详细描述.....	569
23.5.1 hwCCCVcDown 详细描述.....	570
23.5.2 hwCCCVcUp 详细描述.....	570
23.6 附录.....	570
23.6.1 hwCCCVcStateChangeReason.....	570
23.6.2 hwCCCVcEncapType.....	572
24 HUAWEI-CDP-COMPLIANCE-MIB.....	573
24.1 功能简介.....	573
24.2 表间关系.....	573
24.3 单节点详细描述.....	573
24.3.1 hwCdpComplianceEnable 详细描述.....	574
24.3.2 hwCdpComplianceStatsRemTablesLastChangeTime 详细描述.....	574
24.3.3 hwCdpComplianceStatsRemTablesAgeouts 详细描述.....	574
24.4 MIB Table 详细描述.....	574
24.4.1 hwCdpCompliancePortConfigTable 详细描述.....	575
24.4.2 hwCdpComplianceStatsRxPortTable 详细描述.....	577
24.4.3 hwCdpComplianceRemoteTable 详细描述.....	577
24.5 不支持节点.....	578
25 HUAWEI-CONFIG-MAN-MIB.....	580
25.1 功能简介.....	580
25.2 表间关系.....	581
25.3 单节点详细描述.....	583
25.3.1 hwCfgRunModifiedLast 详细描述.....	583
25.3.2 hwCfgRunSavedLast 详细描述.....	583
25.3.3 hwCfgStartModifiedLast 详细描述.....	584
25.3.4 hwCfgLogLimitedEntries 详细描述.....	584
25.3.5 hwCfgLogDeletedEntries 详细描述.....	584
25.3.6 hwCfgLogWantBackup 详细描述.....	585
25.3.7 hwCfgOperateGlobalEntryLimit 详细描述.....	585
25.3.8 hwCfgOperateEntryAgeOutTime 详细描述.....	585

25.3.9 hwCfgOperateResultGlobalEntryLimit 详细描述.....	586
25.3.10 hwCfgOperateCompareConfig 详细描述.....	586
25.3.11 hwCfgRestoreErrCode 详细描述.....	587
25.3.12 hwCfgOperateLockConfigDataStore 详细描述.....	588
25.3.13 hwCfgSaveAutoInterval 详细描述.....	589
25.3.14 hwCfgSaveAutoTime 详细描述.....	589
25.3.15 hwCfgSaveAutoCpuLimit 详细描述.....	590
25.3.16 hwCfgSaveAutoDelay 详细描述.....	590
25.3.17 hwCfgSaveManualTime 详细描述.....	590
25.4 MIB Table 详细描述.....	590
25.4.1 hwCfgLogTable 详细描述.....	590
25.4.2 hwCfgOperateTable 详细描述.....	596
25.4.3 hwCfgOperateResultTable 详细描述.....	600
25.4.4 hwCfgBackup2ServerTable 详细描述.....	604
25.4.5 hwCfgOperateLevelUsersTable 详细描述.....	607
25.5 告警节点详细描述.....	608
25.5.1 hwCfgManEventlog 详细描述.....	609
25.5.2 hwCfgB2STransferFail 详细描述.....	609
25.5.3 hwCfgB2SOperate 详细描述.....	610
25.5.4 hwCfgOperateCompletion 详细描述.....	610
25.5.5 hwCfgRestoreFail 详细描述.....	610
26 HUAWEI-CLOCK-MIB.....	611
26.1 功能简介.....	611
26.2 表间关系.....	611
26.3 单节点详细描述.....	611
26.3.1 hwClockAlarmThresholdFrequencyOffset 详细描述.....	612
26.3.2 hwClockSourceEthClkEnable 详细描述.....	612
26.3.3 hwClockSourceSsmUnknown 详细描述.....	612
26.3.4 hwClockSourceSsmControl 详细描述.....	613
26.3.5 hwClockSourceHoldMode 详细描述.....	613
26.3.6 hwClockSourceFreqCheckEnable 详细描述.....	613
26.3.7 hwClockSourceRetrieveMode 详细描述.....	613
26.4 MIB Table 详细描述.....	614
26.4.1 hwClockAttributeTable 详细描述.....	614
26.4.2 hwClockSrcCfgTable 详细描述.....	617
26.4.3 hwClockSrcSelTable 详细描述.....	619
26.5 告警节点详细描述.....	620
26.5.1 hwClockSourceFailed 详细描述.....	621
26.5.2 hwClockSourceValid 详细描述.....	621
26.5.3 hwClockSourceFreqCheckResume 详细描述.....	621
26.5.4 hwClockSourceOutputBelowThresholdResume 详细描述.....	622
26.5.5 hwClockSourceSwitch 详细描述.....	622

26.5.6 hwClockSourceInputBelowThreshold 详细描述.....	622
26.5.7 hwClockSourceInputBelowThresholdResume 详细描述.....	623
26.5.8 hwClockSourceSysClkLockModeChange 详细描述.....	623
26.5.9 hwClockSourceStateChange 详细描述.....	623
26.5.10 hwClockSourceFreqCheck 详细描述.....	624
26.5.11 hwClockSourceOutputBelowThreshold 详细描述.....	624
26.5.12 hwClockNotInLockedMode 详细描述.....	624
26.5.13 hwClockInLockedMode 详细描述.....	625
26.5.14 hwClockSsmPktLos 详细描述.....	625
26.5.15 hwClockSsmPktLosResume 详细描述.....	625
27 HUAWEI-CPU-MIB.....	626
27.1 功能简介.....	626
27.2 表间关系.....	626
27.3 单节点详细描述.....	626
27.4 MIB Table 详细描述.....	627
27.4.1 hwCpuDevTable 详细描述.....	627
27.5 告警节点详细描述.....	628
28 HUAWEI-DAD-MIB.....	629
28.1 功能简介.....	629
28.2 表间关系.....	629
28.3 单节点详细描述.....	629
28.4 MIB Table 详细描述.....	629
28.5 告警节点详细描述.....	629
28.5.1 hwMadConflictDetect 详细描述.....	630
28.5.2 hwMadConflictResume 详细描述.....	630
29 HUAWEI-DC-TRAP-MIB.....	631
29.1 功能简介.....	631
29.2 表间关系.....	631
29.3 单节点详细描述.....	631
29.4 MIB Table 详细描述.....	631
29.5 告警节点详细描述.....	631
29.5.1 hwSuperChangeSuccessful 详细描述.....	632
29.5.2 hwSuperChangeFailure 详细描述.....	632
29.6 不支持节点.....	632
30 HUAWEI-DATASYNC-MIB.....	638
30.1 功能简介.....	638
30.2 表间关系.....	638
30.3 单节点详细描述.....	638
30.3.1 hwCurrentCfgChgSeqID 详细描述.....	639
30.3.2 hwCfgChgSeqIDReveralCount 详细描述.....	639
30.3.3 hwCfgChgTableMaxItem 详细描述.....	639

30.4 MIB Table 详细描述.....	639
30.4.1 hwCfgChgTable 详细描述.....	639
30.4.2 hwCollectTable 详细描述.....	642
30.5 告警节点详细描述.....	644
30.5.1 hwCfgChgNotify 详细描述.....	644
31 HUAWEI-DEVICE-MIB.....	645
31.1 功能简介.....	645
31.2 表间关系.....	645
31.3 单节点详细描述.....	645
31.4 MIB Table 详细描述.....	645
31.4.1 hwFrameTable 详细描述.....	645
31.4.2 hwSlotTable 详细描述.....	646
31.4.3 hwDevCompatibleTable 详细描述.....	647
31.5 告警节点详细描述.....	647
32 HUAWEI-DHCPR-MIB.....	648
32.1 功能简介.....	648
32.2 表间关系.....	648
32.3 单节点详细描述.....	648
32.3.1 hwDHCPRelayCycleStatus 详细描述.....	648
32.3.2 hwDHCPRRxBadPktNum 详细描述.....	649
32.3.3 hwDHCPRRxServerPktNum 详细描述.....	649
32.3.4 hwDHCPRTxServerPktNum 详细描述.....	649
32.3.5 hwDHCPRRxClientPktNum 详细描述.....	649
32.3.6 hwDHCPRTxClientPktNum 详细描述.....	650
32.3.7 hwDHCPRTxClientUniPktNum 详细描述.....	650
32.3.8 hwDHCPRTxClientBroPktNum 详细描述.....	650
32.3.9 hwDHCPRelayDiscoverPktNum 详细描述.....	650
32.3.10 hwDHCPRelayRequestPktNum 详细描述.....	651
32.3.11 hwDHCPRelayDeclinePktNum 详细描述.....	651
32.3.12 hwDHCPRelayReleasePktNum 详细描述.....	651
32.3.13 hwDHCPRelayInformPktNum 详细描述.....	651
32.3.14 hwDHCPRelayOfferPktNum 详细描述.....	652
32.3.15 hwDHCPRelayAckPktNum 详细描述.....	652
32.3.16 hwDHCPRelayNakPktNum 详细描述.....	652
32.3.17 hwDHCPRelayStatisticsReset 详细描述.....	652
32.4 MIB Table 详细描述.....	653
32.4.1 hwDHCPRIPTable 详细描述.....	653
32.4.2 hwDHCPRSeletAllocateModeTable 详细描述.....	654
32.5 告警节点详细描述.....	655
32.5.1 hwpDRouteExceed 详细描述.....	655
32.5.2 hwpDRouteExceedResume 详细描述.....	655

33 HUAWEI-DHCPS-MIB.....	656
33.1 功能简介.....	656
33.2 表间关系.....	656
33.3 单节点详细描述.....	659
33.3.1 hwDHCPSServiceStatus 详细描述.....	659
33.3.2 hwDHCPSDetectingServerStatus 详细描述.....	660
33.3.3 hwDHCPSPingNum 详细描述.....	660
33.3.4 hwDHCPSPingTimeout 详细描述.....	660
33.3.5 hwDHCPSWriteDataStatus 详细描述.....	660
33.3.6 hwDHCPSWriteDataDirection 详细描述.....	661
33.3.7 hwDHCPSWriteDataDelay 详细描述.....	661
33.3.8 hwDHCPSWriteDataRecover 详细描述.....	661
33.3.9 hwDHCPSIPInUseResetIP 详细描述.....	662
33.3.10 hwDHCPSConflictIPResetIP 详细描述.....	662
33.3.11 hwDHCPSIPResetFlag 详细描述.....	662
33.3.12 hwDHCPSGlobalPoolNumber 详细描述.....	663
33.3.13 hwDHCPSGlobalPoolAutoBindingNum 详细描述.....	663
33.3.14 hwDHCPSGlobalPoolManualBindingNum 详细描述.....	663
33.3.15 hwDHCPSGlobalPoolExpiredBindingNum 详细描述.....	664
33.3.16 hwDHCPSInterfacePoolNumber 详细描述.....	664
33.3.17 hwDHCPSInterfacePoolAutoBindingNum 详细描述.....	664
33.3.18 hwDHCPSInterfacePoolManualBindingNum 详细描述.....	665
33.3.19 hwDHCPSInterfacePoolExpiredBindingNum 详细描述.....	665
33.3.20 hwDHCPSBadPktNum 详细描述.....	665
33.3.21 hwDHCPSBootRequestPktNum 详细描述.....	666
33.3.22 hwDHCPSDiscoverPktNum 详细描述.....	666
33.3.23 hwDHCPSRequestPktNum 详细描述.....	666
33.3.24 hwDHCPSDeclinePktNum 详细描述.....	667
33.3.25 hwDHCPSReleasePktNum 详细描述.....	667
33.3.26 hwDHCPSInformPktNum 详细描述.....	667
33.3.27 hwDHCPSBootReplyPktNum 详细描述.....	668
33.3.28 hwDHCPSOfferPktNum 详细描述.....	668
33.3.29 hwDHCPSAckPktNum 详细描述.....	668
33.3.30 hwDHCPSNakPktNum 详细描述.....	669
33.3.31 hwDHCPSStatisticsReset 详细描述.....	669
33.4 MIB Table 详细描述.....	669
33.4.1 hwDHCPSGlobalPoolTable 详细描述.....	669
33.4.2 hwDHCPSGlobalPoolConfigTable 详细描述.....	670
33.4.3 hwDHCPSGlobalPoolParaTable 详细描述.....	673
33.4.4 hwDHCPSGlobalPoolOptionTable 详细描述.....	677
33.4.5 hwDHCPSInterfacePoolParaTable 详细描述.....	679
33.4.6 hwDHCPSInterfacePoolOptionTable 详细描述.....	683

33.4.7 hwDHCPsInterfacePoolStaticBindTable 详细描述.....	685
33.4.8 hwDHCPsIPInUseTable 详细描述.....	686
33.4.9 hwDHCPsIPPOOLForbiddenIPTable 详细描述.....	687
33.4.10 hwDHCPsIPPOOLConflictIPTable 详细描述.....	688
33.5 告警节点详细描述.....	689
33.6 不支持节点.....	690
34 HUAWEI-DHCP-SNOOPING-MIB.....	691
34.1 功能简介.....	691
34.2 表间关系.....	691
34.3 单节点详细描述.....	693
34.3.1 hwDhcpSnpGlobal 详细描述.....	693
34.3.2 hwDhcpPktRateCheck 详细描述.....	693
34.3.3 hwDhcpPktRate 详细描述.....	694
34.3.4 hwDhcpPktRateAlarmThreshold 详细描述.....	694
34.3.5 hwDhcpPktRateAlarmEnable 详细描述.....	694
34.3.6 hwDhcpSnpBindTblNomatchedArpGlobalAction 详细描述.....	695
34.3.7 hwDhcpSnpBindTblNomatchedIpGlobalAction 详细描述.....	695
34.3.8 hwDhcpSnpBindTblAutosaveFilename 详细描述.....	695
34.3.9 hwDhcpSnpBindTblAutosave 详细描述.....	695
34.3.10 hwDhcpSnpGlobalThreshold 详细描述.....	696
34.3.11 hwDhcpPktRateDiscardNum 详细描述.....	696
34.4 MIB Table 详细描述.....	696
34.4.1 hwDhcpSnpCfgTable 详细描述.....	696
34.4.2 hwDhcpSnpBindTable 详细描述.....	701
34.4.3 hwDhcpSnpFalsePktStatisticTable 详细描述.....	703
34.4.4 hwDhcpSnpGlobalOption82PktFormatTable 详细描述.....	705
34.5 告警节点详细描述.....	706
34.5.1 hwDhcpSnpChaddrAlarm 详细描述.....	706
34.5.2 hwUntrustedReplyPktAlarm 详细描述.....	706
34.5.3 hwNomatchSnpBindTblDhcpPktAlarm 详细描述.....	707
34.5.4 hwDhcpPktRateAlarm 详细描述.....	707
34.5.5 hwSnpUserNumberAlarmIf 详细描述.....	707
34.5.6 hwSnpUserNumberAlarmIfResume 详细描述.....	707
34.5.7 hwSnpUserNumberAlarmVlan 详细描述.....	708
34.5.8 hwSnpUserNumberAlarmVlanResume 详细描述.....	708
34.5.9 hwSnpUserNumberAlarmGlobal 详细描述.....	708
34.5.10 hwSnpUserNumberAlarmGlobalResume 详细描述.....	709
34.5.11 hwNdSnpUserNumberAlarmIf 详细描述.....	709
34.5.12 hwNdSnpUserNumberAlarmIfResume 详细描述.....	709
34.5.13 hwNdSnpUserNumberAlarmGlobal 详细描述.....	710
34.5.14 hwNdSnpUserNumberAlarmGlobalResume 详细描述.....	710
34.5.15 hwNomatchSnpBindTblDhcpv6PktAlarm 详细描述.....	710

34.5.16 hwNomatchSnPBindTbINDPktAlarm 详细描述.....	711
34.5.17 hwSnPRemoteBackupAlarm 详细描述.....	711
34.5.18 hwSnPRemoteBackupAlarmResume 详细描述.....	711
34.5.19 hwRequestNoTrustPktAlarm 详细描述.....	712
34.5.20 hwNomatchSnPBindTbINDPktAlarmBd 详细描述.....	712
34.5.21 hwDhcpSnPChaddrAlarmBd 详细信息.....	712
34.5.22 hwNomatchSnPBindTbIDhcpPktAlarmBd 详细信息.....	713
34.5.23 hwUntrustedReplyPktAlarmBd 详细信息.....	713
34.5.24 hwDHCPv6SnPDetectAlarm 详细信息.....	713
34.5.25 hwRequestNoTrustPktAlarmBd 详细信息.....	714
34.6 不支持节点.....	714
35 HUAWEI-DIE-MIB.....	716
35.1 功能简介.....	716
35.2 表间关系.....	716
35.3 单节点详细描述.....	716
35.3.1 hwDeviceSensorDhcpOption 详细描述.....	716
35.3.2 hwDeviceSensorLLDPTlv 详细描述.....	717
35.4 MIB Table 详细描述.....	717
35.4.1 hwDIETable 详细描述.....	717
35.4.2 hwDIERuleTable 详细描述.....	719
35.5 告警节点详细描述.....	722
36 HUAWEI-DNS-MIB.....	723
36.1 功能简介.....	723
36.2 表间关系.....	723
36.3 单节点详细描述.....	723
36.4 MIB Table 详细描述.....	723
36.4.1 hwDnsHostsDynamicTable 详细描述.....	723
36.4.2 hwDns6HostsDynamicTable 详细描述.....	725
37 HUAWEI-DLDP-MIB.....	727
37.1 功能简介.....	727
37.2 表间关系.....	727
37.3 单节点详细描述.....	727
37.3.1 hwDldpEnable 详细描述.....	727
37.3.2 hwDldpUnidirectionalShutdown 详细描述.....	728
37.3.3 hwDldpWorkMode 详细描述.....	728
37.3.4 hwDldpAdvertInterval 详细描述.....	729
37.3.5 hwDelayDownTimer 详细描述.....	729
37.3.6 hwDldpAuthenMode 详细描述.....	729
37.3.7 hwDldpMd5Password 详细描述.....	730
37.3.8 hwDldpSimplePassword 详细描述.....	731
37.3.9 hwDldpShaPassword 详细描述.....	732

37.4 MIB Table 详细描述.....	732
37.4.1 hwDldpPortTable 详细描述.....	732
37.4.2 hwDldpNeighbourTable 详细描述.....	734
37.4.3 hwDldpIfTable 详细描述.....	735
37.4.4 hwDldpIfNeighbourTable 详细描述.....	737
37.4.5 hwDldpPortStatisticsTable 详细描述.....	738
37.4.6 hwDldpIfStatisticsTable 详细描述.....	740
37.5 告警节点详细描述.....	741
37.5.1 hwDldpUnidirectionalLink 详细描述.....	741
37.5.2 hwDldpLinkResume 详细描述.....	741
37.5.3 hwDldpLoopDetect 详细描述.....	742
37.5.4 hwDldpLoopResume 详细描述.....	742
37.5.5 hwDldpNeighborNum 详细描述.....	742
37.5.6 hwDldpNeighborNumResume 详细描述.....	743
38 HUAWEI-ERPS-MIB.....	744
38.1 功能简介.....	744
38.2 表间关系.....	745
38.3 单节点详细描述.....	747
38.3.1 hwErpsGlobalResetRapsPktCnt 详细描述.....	747
38.4 MIB Table 详细描述.....	747
38.4.1 hwErpsRingConfigTable 详细描述.....	747
38.4.2 hwErpsRingStatusTable 详细描述.....	750
38.4.3 hwErpsPortConfigTable 详细描述.....	752
38.4.4 hwErpsPortStatusTable 详细描述.....	754
38.4.5 hwErpsPortStatisticsTable 详细描述.....	755
38.4.6 hwErpsPortTrackTable 详细描述.....	756
38.5 告警节点详细描述.....	758
38.5.1 hwErpsFwStateForwarding 详细描述.....	758
38.5.2 hwErpsFwStateDiscarding 详细描述.....	759
39 HUAWEI-ERRORDOWN-MIB.....	760
39.1 功能简介.....	760
39.2 表间关系.....	760
39.3 单节点详细描述.....	760
39.3.1 hwErrordownCause 详细描述.....	761
39.3.2 hwErrordownRecoverType 详细描述.....	761
39.4 告警节点详细描述.....	761
39.4.1 hwErrordown 详细描述.....	761
39.4.2 hwErrordownRecovery 详细描述.....	762
40 HUAWEI-ENERGYMNGT-MIB.....	763
40.1 功能简介.....	763
40.2 表间关系.....	763

40.3 单节点详细描述.....	763
40.3.1 hwPowerConsumption 详细描述.....	764
40.3.2 hwPowerStatPeriod 详细描述.....	764
40.3.3 hwAveragePower 详细描述.....	764
40.3.4 hwRatedPower 详细描述.....	765
40.3.5 hwThresholdOfPower 详细描述.....	765
40.3.6 hwCurrentPower 详细描述.....	765
40.3.7 hwTypicalPower 详细描述.....	765
40.3.8 hwInboundPower 详细描述.....	766
40.3.9 hwEnergySavingMode 详细描述.....	766
40.4 MIB Table 详细描述.....	766
40.4.1 hwBoardPowerMngtTable 详细描述.....	766
40.4.2 hwEnergySavingParameterTable 详细描述.....	767
40.4.3 hwEnergySavingCapabilityMngtTable 详细描述.....	768
40.5 告警节点详细描述.....	769
40.5.1 hwEnergyDevChangeToSleep 详细描述.....	769
40.6 不支持节点.....	769
41 HUAWEI-EASY-OPERATION-MIB.....	771
41.1 功能简介.....	771
41.2 表间关系.....	771
41.3 单节点详细描述.....	772
41.3.1 hwEasyOperationCommanderEnable 详细描述.....	772
41.3.2 hwEasyOperationCommanderIpAddress 详细描述.....	772
41.3.3 hwEasyOperationCommanderIpAddressType 详细描述.....	772
41.3.4 hwEasyOperationCommanderUdpPort 详细描述.....	773
41.3.5 hwEasyOperationServerType 详细描述.....	773
41.3.6 hwEasyOperationServerIpAddress 详细描述.....	773
41.3.7 hwEasyOperationServerIpAddressType 详细描述.....	774
41.3.8 hwEasyOperationServerPort 详细描述.....	774
41.3.9 hwEasyOperationAutoClearEnable 详细描述.....	774
41.3.10 hwEasyOperationActivateMode 详细描述.....	774
41.3.11 hwEasyOperationActivateDelayTime 详细描述.....	775
41.3.12 hwEasyOperationActivateInTime 详细描述.....	775
41.3.13 hwEasyOperationBackupConfigMode 详细描述.....	775
41.3.14 hwEasyOperationBackupConfigInterval 详细描述.....	776
41.3.15 hwEasyOperationDefaultSysSoftware 详细描述.....	776
41.3.16 hwEasyOperationDefaultSysSoftwareVer 详细描述.....	776
41.3.17 hwEasyOperationDefaultConfig 详细描述.....	777
41.3.18 hwEasyOperationDefaultPatch 详细描述.....	777
41.3.19 hwEasyOperationDefaultWebfile 详细描述.....	777
41.3.20 hwEasyOperationDefaultLicense 详细描述.....	777
41.3.21 hwEasyOperationDefaultCustomfile1 详细描述.....	778

41.3.22 hwEasyOperationDefaultCustomfile2 详细描述.....	778
41.3.23 hwEasyOperationDefaultCustomfile3 详细描述.....	778
41.3.24 hwEasyOperationClientAutoJoinEnable 详细描述.....	779
41.3.25 hwEasyOperationTotalGroupNumber 详细描述.....	779
41.3.26 hwEasyOperationBuildInGroupNumber 详细描述.....	779
41.3.27 hwEasyOperationCustomGroupNumber 详细描述.....	779
41.3.28 hwEasyOperationClientNumber 详细描述.....	780
41.3.29 hwEasyOperationTopologyEnable 详细描述.....	780
41.3.30 hwEasyOperationClientAgingTime 详细描述.....	780
41.3.31 hwEasyOperationDtIsEnable 详细描述.....	781
41.4 MIB Table 详细描述.....	781
41.4.1 hwEasyOperationGroupTable 详细描述.....	781
41.4.2 hwEasyOperationGroupMatchTable 详细描述.....	783
41.4.3 hwEasyOperationClientInfoTable 详细描述.....	785
41.4.4 hwEasyOperationClientReplaceTable 详细描述.....	790
41.4.5 hwEasyOperationDevicePowerInfoTable 详细描述.....	792
41.4.6 hwEasyOperationPortPowerInfoTable 详细描述.....	793
41.4.7 hwEasyOperationNetPowerHistoryInfoTable 详细描述.....	795
41.4.8 hwEasyOperationTopologyTable 详细描述.....	795
41.4.9 hwEasyOperationSavedTopologyTable 详细描述.....	797
41.5 告警节点详细描述.....	798
41.5.1 hwEasyOperationClientAdded 详细描述.....	798
41.5.2 hwEasyOperationClientLost 详细描述.....	799
41.5.3 hwEasyOperationClientJoinNotPermit 详细描述.....	800
41.5.4 hwEasyOperationClientProcessFailed 详细描述.....	800
42 HUAWEI-ENTITY-EXTENT-MIB.....	802
42.1 功能简介.....	802
42.2 表间关系.....	802
42.3 单节点详细描述.....	804
42.3.1 hwAlarmResendInterval 详细描述.....	805
42.3.2 hwEntitySystemNetID 详细描述.....	805
42.3.3 hwEntitySystemModel 详细描述.....	805
42.3.4 hwEntityHeartbeatOnOff 详细描述.....	805
42.3.5 hwEntityHeartbeatPeriod 详细描述.....	806
42.3.6 hwEntityExtTrapBoardDropRuntPktStatistics 详细描述.....	806
42.3.7 hwEntityExtTrapBoardDropRuntPktTimeInterval 详细描述.....	806
42.4 MIB Table 详细描述.....	807
42.4.1 hwEntityStateTable 详细描述.....	807
42.4.2 hwRUModuleInfoTable 详细描述.....	811
42.4.3 hwOpticalModuleInfoTable 详细描述.....	814
42.4.4 hwFanStatusTable 详细描述.....	819
42.4.5 hwVirtualCableTestTable 详细描述.....	821

42.4.6 hwSystemPowerTable 详细描述.....	832
42.4.7 hwPwrStatusTable 详细描述.....	833
42.4.8 hwPnpOperateTable 详细描述.....	835
42.4.9 hwBoardDcOutputStateTable 详细描述.....	839
42.4.10 hwBoardDcOutputInfoTable 详细描述.....	840
42.4.11 hwBoardAcOutputStateTable 详细描述.....	841
42.4.12 hwIntegratedPowerSystemTable 详细描述.....	842
42.4.13 hwIntegratedPowerTable 详细描述.....	842
42.4.14 hwLithiumBatteryGroupTable 详细描述.....	845
42.4.15 hwLithiumBatteryTable 详细描述.....	846
42.5 告警节点详细描述.....	848
42.5.1 hwEntityExtMonitorBoardAbnormalNotification 详细描述.....	848
42.5.2 hwEntityExtMonitorBoardNormalNotification 详细描述.....	848
42.5.3 hwEntityExtMonitorPortAbnormalNotification 详细描述.....	849
42.5.4 hwEntityExtMonitorPortNormalNotification 详细描述.....	849
42.5.5 hwEntityHeartbeatTrap 详细描述.....	849
42.5.6 hwEntityHigErrorPacketThresholdAlarm 详细描述.....	850
42.5.7 hwEntityHigDiscardPacketNotify 详细描述.....	850
42.5.8 hwEntityHigStateChangeNotify 详细描述.....	851
42.5.9 hwEntityHigStateDownNotify 详细描述.....	852
42.5.10 hwEntityInputRateThresholdAlarm 详细描述.....	853
42.5.11 hwEntityInputRateThresholdAlarmResume 详细描述.....	854
42.5.12 hwEntityOutputRateThresholdAlarm 详细描述.....	854
42.5.13 hwEntityOutputRateThresholdAlarmResume 详细描述.....	855
42.5.14 hwBoardDropRuntPacketNotify 详细描述.....	855
42.6 不支持节点.....	855
43 HUAWEI-ENTITY-TRAP-MIB.....	859
43.1 功能简介.....	859
43.2 表间关系.....	859
43.3 单节点详细描述.....	859
43.3.1 hwEntityPhysicalIndex 详细描述.....	860
43.3.2 hwEntityTrapEntType 详细描述.....	860
43.3.3 hwEntityTrapFaultID 详细描述.....	861
43.3.4 hwEntityCommunicateType 详细描述.....	876
43.3.5 hwUserDefAlarmName 详细描述.....	877
43.3.6 hwUserDefChannel 详细描述.....	877
43.3.7 hwEntityTrapReasonDescr 详细描述.....	877
43.4 MIB Table 详细描述.....	877
43.4.1 hwEntityThresholdTable 详细描述.....	878
43.5 告警节点详细描述.....	879
43.5.1 hwBoardRemove 详细描述.....	879
43.5.2 hwBoardInsert 详细描述.....	879

43.5.3 hwBoardFail 详细描述.....	880
43.5.4 hwBoardFailResume 详细描述.....	880
43.5.5 hwBoardInvalid 详细描述.....	880
43.5.6 hwBoardInvalidResume 详细描述.....	881
43.5.7 hwBoardUpCoverAlarm 详细描述.....	881
43.5.8 hwBoardUpCoverResume 详细描述.....	881
43.5.9 hwBrdTempAlarm 详细描述.....	882
43.5.10 hwBrdTempResume 详细描述.....	882
43.5.11 hwCardInsert 详细描述.....	882
43.5.12 hwCardRemove 详细描述.....	883
43.5.13 hwCardFail 详细描述.....	883
43.5.14 hwCardInvalidResume 详细描述.....	884
43.5.15 hwCardInvalid 详细描述.....	884
43.5.16 hwCardFailResume 详细描述.....	884
43.5.17 hwCardPortInvalid 详细描述.....	885
43.5.18 hwCommunicateError 详细描述.....	885
43.5.19 hwCPUUtilizationRising 详细描述.....	886
43.5.20 hwCPUUtilizationResume 详细描述.....	886
43.5.21 hwMemUtilizationRising 详细描述.....	887
43.5.22 hwMemUtilizationResume 详细描述.....	887
43.5.23 hwFanInsert 详细描述.....	888
43.5.24 hwFanInvalid 详细描述.....	888
43.5.25 hwFanInvalidResume 详细描述.....	888
43.5.26 hwFanRemove 详细描述.....	889
43.5.27 hwIntegratedPowerFault 详细描述.....	889
43.5.28 hwIntegratedPowerFaultResume 详细描述.....	889
43.5.29 hwOpticalBiasCurrentAlarm 详细描述.....	890
43.5.30 hwOpticalBiasCurrentAlarmResume 详细描述.....	890
43.5.31 hwOpticalInvalid 详细描述.....	891
43.5.32 hwOpticalInvalidResume 详细描述.....	891
43.5.33 hwOpticalFail 详细描述.....	891
43.5.34 hwOpticalFailResume 详细描述.....	892
43.5.35 hwPortNoSupportOETrap 详细描述.....	892
43.5.36 hwPowerInsert 详细描述.....	892
43.5.37 hwPowerInvalid 详细描述.....	893
43.5.38 hwPowerInvalidResume 详细描述.....	893
43.5.39 hwPowerRemove 详细描述.....	893
43.5.40 hwRpsPowerRemove 详细描述.....	894
43.5.41 hwRpsPowerInsert 详细描述.....	894
43.5.42 hwRpsPowerOn 详细描述.....	894
43.5.43 hwRpsPowerOff 详细描述.....	895
43.5.44 hwBatteryFull 详细描述.....	895

43.5.45 hwBatteryGroupFault 详细描述.....	895
43.5.46 hwBatteryGroupFaultResume 详细描述.....	896
43.5.47 hwBatteryFault 详细描述.....	896
43.5.48 hwBatteryFaultResume 详细描述.....	897
43.5.49 hwBatteryMinorFault 详细描述.....	897
43.5.50 hwBatteryMinorFaultResume 详细描述.....	898
43.5.51 hwOpticalTunableNotMatch 详细描述.....	898
43.5.52 hwOpticalUnauthorized 详细描述.....	898
43.5.53 hwPatchDelNeedReStartTrap 详细描述.....	899
43.5.54 hwBoardPortsConflict 详细描述.....	899
43.5.55 hwVirtualLicenseNearDeadline 详细描述.....	899
43.5.56 hwVirtualLicenseNearDeadlineResume 详细描述.....	900
43.5.57 hwVirtualLicenseExpire 详细描述.....	900
43.5.58 hwVirtualLicenseExpResume 详细描述.....	900
43.5.59 hwNetconfDatabaseAbnormal 详细描述.....	900
43.5.60 hwNetconfDatabaseRestore 详细描述.....	901
43.5.61 hwEntityFileSystemAbnormal 详细描述.....	901
43.5.62 hwPeerDevPnPTTrunkAggregationFailure 详细描述.....	901
43.5.63 hwCommunicateConnect 详细描述.....	901
43.5.64 hwCommunicateDisconnect 详细描述.....	902
43.6 不支持节点.....	902
44 HUAWEI-ESAP-HOT-STANDBY-MIB.....	906
44.1 功能简介.....	906
44.2 表间关系.....	906
44.3 单节点详细描述.....	906
44.3.1 hwEsapHsbMIBNotifications 详细描述.....	907
44.4 MIB Table 详细描述.....	907
44.4.1 hwHsbServiceTable 详细描述.....	907
44.4.2 hwHsbGroupTable 详细描述.....	909
44.4.3 hwHsbIfMapTable 详细描述.....	911
44.5 告警节点详细描述.....	912
44.5.1 hwEsapHsbStatusNotification 详细描述.....	912
44.6 不支持节点.....	912
45 HUAWEI-ESAP-MDNS-GATEWAY-MIB.....	913
45.1 功能简介.....	913
45.2 表间关系.....	913
45.3 单节点详细描述.....	913
45.4 MIB Table 详细描述.....	914
45.4.1 hwEsapMdnsGatewayGlobalTable 详细描述.....	914
45.4.2 hwEsapMdnsGatewayServiceProbeTable 详细描述.....	915
45.4.3 hwEsapMdnsGatewayServiceTable 详细描述.....	916
45.4.4 hwEsapMdnsGatewayGroupTable 详细描述.....	920

45.5 告警节点详细描述.....	922
46 HUAWEI-ETHARP-MIB.....	923
46.1 功能简介.....	923
46.2 表间关系.....	924
46.3 单节点详细描述.....	924
46.3.1 hwEthernetARPAntiAttackLog 详细描述.....	924
46.3.2 hwEthernetARPLearningStrict 详细描述.....	924
46.3.3 hwEthernetARPSpeedLimitIfIndex 详细描述.....	924
46.3.4 hwEthernetARPSpeedLimitConfigured 详细描述.....	925
46.3.5 hwEthernetARPSpeedLimitCurrent 详细描述.....	925
46.3.6 hwEthernetARPSpeedLimitType 详细描述.....	925
46.3.7 hwEthernetARPSpeedLimitSrcIPAddr 详细描述.....	925
46.3.8 hwEthernetARPSpeedLimitDstIPAddr 详细描述.....	926
46.3.9 hwEthernetARPSpeedLimitVPNInstance 详细描述.....	926
46.3.10 hwEthernetARPThresholdValue 详细描述.....	926
46.3.11 hwEthernetARPThresholdDynamicNumber 详细描述.....	926
46.3.12 hwEthernetARPThresholdStaticNumber 详细描述.....	927
46.3.13 hwEthernetARPConflictDetect 详细描述.....	927
46.3.14 hwEthernetARPEntrySpecValue 详细描述.....	927
46.3.15 hwEthernetARPEntrySpecDynamicNumber 详细描述.....	928
46.4 MIB Table 详细描述.....	928
46.4.1 hwEthernetARPSpeedLimitTable 详细描述.....	928
46.4.2 hwEthernetARPStaticsTable 详细描述.....	929
46.4.3 hwEthARPLimitTable 详细描述.....	931
46.4.4 hwEthernetARPLearningStrictInterfaceTable 详细描述.....	932
46.4.5 hwArpEntryExpireControlTable 详细描述.....	933
46.4.6 hwArpDynTable 详细描述.....	934
46.4.7 hwArpCfgTable 详细描述.....	938
46.4.8 hwArpSecValidateTable 详细描述.....	940
46.5 告警节点详细描述.....	941
46.5.1 hwEthernetARPSpeedLimitAlarm 详细描述.....	942
46.5.2 hwEthernetARPThresholdExceedAlarm 详细描述.....	942
46.5.3 hwEthernetARPThresholdResumeAlarm 详细描述.....	943
46.5.4 hwEthernetARPIPConflictEvent 详细描述.....	943
46.5.5 hwEthernetARPDynEntryExceedAlarm 详细描述.....	944
46.5.6 hwEthernetARPDynEntryResumeAlarm 详细描述.....	944
46.6 不支持节点.....	944
47 HUAWEI-ETHOAM-MIB.....	945
47.1 功能简介.....	945
47.2 表间关系.....	945
47.3 单节点详细描述.....	945
47.3.1 hwDot1agCfmGmacTraceEnabled 详细描述.....	946

47.3.2 hwDot3ahEfmEnabled 详细描述.....	946
47.3.3 hwY1731AisMaxPktNum 详细描述.....	946
47.4 MIB Table 详细描述.....	947
47.4.1 hwDot1agCfmGmacTraceTable 详细描述.....	947
47.4.2 hwDot1agCfmGmacTraceReplyTable 详细描述.....	950
47.4.3 hwDot3ahEfmTable 详细描述.....	952
47.4.4 hwDot3ahEfmEventConfigTable 详细描述.....	953
47.4.5 hwDot1agCfmQueryMdIndexTable 详细描述.....	956
47.4.6 hwDot1agCfmQueryMaIndexTable 详细描述.....	957
47.4.7 hwCfmVlanOneDelayTrapLogTable 详细描述.....	958
47.4.8 hwCfmVlanOneDelayRcoverTrapLogTable 详细描述.....	958
47.4.9 hwCfmVlanTwoDelayTrapLogTable 详细描述.....	959
47.4.10 hwCfmVlanTwoDelayRcoverTrapLogTable 详细描述.....	960
47.4.11 hwY1731BaseConfigTable 详细描述.....	961
47.4.12 hwY1731ConfigTable 详细描述.....	963
47.4.13 hwY1731AisTable 详细描述.....	971
47.4.14 hwY1731AisLinkStatusTable 详细描述.....	972
47.4.15 hwY1731AisVlanConfigTable 详细描述.....	973
47.4.16 hwY1731ResetStatisticTable 详细描述.....	977
47.4.17 hwY1731StatisticTable 详细描述.....	980
47.4.18 hwY1731TestIdTable 详细描述.....	984
47.4.19 hwY1731TestIdSingleEndedLMSendTable 详细描述.....	986
47.4.20 hwY1731TestIdSingleEndedLMReceiveTable 详细描述.....	987
47.4.21 hwY1731TestIdTwoWayDMSendTable 详细描述.....	988
47.4.22 hwY1731TestIdTwoWayDMReceiveTable 详细描述.....	990
47.4.23 hwY1731TestIdSingleLossStatTable 详细描述.....	991
47.4.24 hwY1731TestIdTwoDelayStatTable 详细描述.....	993
47.4.25 hwY1731TestIdStatisticResetTable 详细描述.....	994
47.4.26 hwY1731TestIdSingleSynEndedLMSendTable 详细描述.....	996
47.4.27 hwY1731TestIdSingleSynEndedLMReceiveTable 详细描述.....	998
47.4.28 hwY1731TestIdSingleSynLossStatTable 详细描述.....	998
47.4.29 hwY1731TestIdStatTrapLogTable 详细描述.....	1000
47.5 告警节点详细描述.....	1002
47.5.1 hwDot3ahEfmThresholdEvent 详细描述.....	1003
47.5.2 hwDot3ahEfmNonthresholdEvent 详细描述.....	1003
47.5.3 hwDot3ahEfmNonThresholdRecovery 详细描述.....	1004
47.5.4 hwDot3ahEfmLoopbackFailed 详细描述.....	1004
47.5.5 hwDot3ahEfmRemoteDyingGaspEvent 详细描述.....	1004
47.5.6 hwCfmVlanOnewayDelay 详细描述.....	1005
47.5.7 hwCfmVlanOnewayDelayRecovery 详细描述.....	1005
47.5.8 hwCfmVlanTwowayDelay 详细描述.....	1006
47.5.9 hwCfmVlanTwowayDelayRecovery 详细描述.....	1006

47.5.10 hwY1731AisDefectAlarm 详细描述.....	1007
47.5.11 hwY1731AisDefectAlarmRecovery 详细描述.....	1007
47.5.12 hwY1731AisExceedMaxPktNum 详细描述.....	1007
47.5.13 hwY1731AisExceedMaxPktNumCleared 详细描述.....	1008
47.5.14 hwY1731TestIdStatistic 详细描述.....	1008
47.5.15 hwY1731TestIdStatisticClear 详细描述.....	1008
47.5.16 hwDot1agCfmMismerge 详细描述.....	1009
47.5.17 hwDot1agCfmMismergeCleared 详细描述.....	1009
47.5.18 hwDot1agCfmUnexpectedMEP 详细描述.....	1010
47.5.19 hwDot1agCfmUnexpectedMEPCleared 详细描述.....	1010
47.5.20 hwDot1agCfmUnexpectedPeriod 详细描述.....	1011
47.5.21 hwDot1agCfmUnexpectedPeriodCleared 详细描述.....	1012
47.5.22 hwDot1agCfmUnexpectedMAC 详细描述.....	1013
47.5.23 hwDot1agCfmUnexpectedMACCleared 详细描述.....	1014
47.5.24 hwDot1agCfmLOC 详细描述.....	1015
47.5.25 hwDot1agCfmLOCcleared 详细描述.....	1015
47.5.26 hwDot1agCfmRDI 详细描述.....	1015
47.5.27 hwDot1agCfmRDICleared 详细描述.....	1016
47.6 不支持节点.....	1016
48 HUAWEI-E-TRUNK-MIB.....	1017
48.1 功能简介.....	1017
48.2 表间关系.....	1018
48.3 单节点详细描述.....	1018
48.4 MIB Table 详细描述.....	1018
48.4.1 hwETrunkTable 详细描述.....	1018
48.4.2 hwETrunkMemberTable 详细描述.....	1022
48.5 告警节点详细描述.....	1026
48.5.1 hwETrunkStatusChange 详细描述.....	1026
48.5.2 hwETrunkMemberStatusChange 详细描述.....	1026
49 HUAWEI-FLASH-MAN-MIB.....	1027
49.1 功能简介.....	1027
49.2 表间关系.....	1027
49.3 单节点详细描述.....	1027
49.3.1 hwFlhSupportNum 详细描述.....	1028
49.4 MIB Table 详细描述.....	1028
49.4.1 hwFlashTable 详细描述.....	1028
49.4.2 hwFlhChipTable 详细描述.....	1032
49.4.3 hwFlhPartitionTable 详细描述.....	1033
49.4.4 huaweiFlhFileTable 详细描述.....	1036
49.4.5 hwStorageTable 详细描述.....	1037
49.4.6 huaweiFlhOpTable 详细描述.....	1039
49.4.7 hwFlhSyncTable 详细描述.....	1046

49.5 告警节点详细描述.....	1047
49.5.1 hwFlhOperNotification 详细描述.....	1047
49.5.2 hwFlhStorageFullTrap 详细描述.....	1048
49.5.3 hwFlhSyncSuccessNotification 详细描述.....	1048
49.5.4 hwFlhSyncFailNotification 详细描述.....	1048
50 HUAWEI-FWD-RES-TRAP-MIB.....	1049
50.1 功能简介.....	1049
50.2 表间关系.....	1049
50.3 单节点详细描述.....	1049
50.3.1 hwEntPhysicalindex 详细描述.....	1050
50.3.2 hwFwdResLackSlotStr 详细描述.....	1050
50.3.3 hwFwdResLackReasonId 详细描述.....	1050
50.3.4 hwFwdResThreshold 详细描述.....	1050
50.3.5 hwL3FailedService 详细描述.....	1051
50.3.6 hwNoSuppVxlanFragVni 详细描述.....	1051
50.3.7 hwNoSuppVxlanFragSourceIp 详细描述.....	1051
50.3.8 hwNoSuppVxlanFragPeerIp 详细描述.....	1051
50.3.9 hwL2mcGrpAddress 详细描述.....	1052
50.3.10 hwL2mcVlanIdx 详细描述.....	1052
50.4 MIB Table 详细描述.....	1052
50.5 告警节点详细描述.....	1052
50.5.1 hwWholeFwdResLack 详细描述.....	1052
50.5.2 hwWholeFwdResLackResume 详细描述.....	1053
50.5.3 hwBoardFwdResLack 详细描述.....	1053
50.5.4 hwBoardFwdResLackResume 详细描述.....	1053
50.5.5 hwBoardL3FwdResLack 详细描述.....	1054
50.5.6 hwBoardL3FwdResLackResume 详细描述.....	1054
50.5.7 hwBoardL3ACLResLack 详细描述.....	1054
50.5.8 hwBoardL2mcResLack 详细描述.....	1055
50.5.9 hwBoardL2mcResLackResume 详细描述.....	1055
50.5.10 hwBoardIpmcResLack 详细描述.....	1055
50.5.11 hwBoardIpmcResLackResume 详细描述.....	1055
50.5.12 hwBoardIPv6ACLResLack 详细描述.....	1056
50.5.13 hwBoardMplsPhpResLack 详细描述.....	1056
50.5.14 hwBoardMplsFwdResLack 详细描述.....	1057
50.5.15 hwBoardMplsFwdResLackResume 详细描述.....	1057
50.5.16 hwNotSuppDecapVxlanFragPackets 详细描述.....	1057
50.5.17 hwVxlanTnlCfgFailed 详细描述.....	1058
50.5.18 hwNotSuppDecapVxlanPackets 详细描述.....	1058
50.5.19 hwBoardL3NDResLack 详细描述.....	1058
50.5.20 hwBoardL3FIBResLack 详细描述.....	1058
50.5.21 hwFwdEntryConflict 详细描述.....	1059

50.5.22 hwFwdEntryConflictResume 详细描述.....	1059
50.5.23 hwBoardMcResFull 详细描述.....	1059
50.5.24 hwBoardMplsFwdResFull 详细描述.....	1060
50.5.25 hwBoardL3ResFull 详细描述.....	1060
50.5.26 hwEMDIIndicatorOverThreshold 详细描述.....	1061
50.5.27 hwEMDIIndicatorOverThresholdResume 详细描述.....	1061
50.5.28 hwEMDIReceiveDuplicatePackets 详细描述.....	1061
50.5.29 hwEMDIReceiveDuplicatePacketsResume 详细描述.....	1062
50.5.30 hwEMDIResLack 详细描述.....	1062
50.5.31 hwEMDIResLackResume 详细描述.....	1062
50.5.32 hwVlanSrcExeedAlarm 详细描述.....	1063
50.5.33 hwVlanSrcExeedResume 详细描述.....	1063
50.5.34 hwSaidPingPktModifiedAlarm 详细描述.....	1063
50.5.35 hwNsOrigFlexFlowExceedAlarm 详细描述.....	1063
50.5.36 hwNsOrigFlexFlowExceedResume 详细描述.....	1064
50.5.37 hwNsAggFlowExceedAlarm 详细描述.....	1064
50.5.38 hwNsAggFlowExceedResume 详细描述.....	1064
50.5.39 hwCapwapNoFragmentAlarm 详细描述.....	1064
50.5.40 hwCapwapDiscardBroadcastAlarm 详细描述.....	1065
50.6 不支持节点.....	1065
51 HUAWEI-GARP-APP-MIB.....	1066
51.1 功能简介.....	1066
51.2 表间关系.....	1066
51.3 单节点详细描述.....	1067
51.3.1 hwGarpAppLeaveAllTime 详细描述.....	1067
51.4 MIB Table 详细描述.....	1068
51.4.1 hwGarpAppSwitchCountTable 详细描述.....	1068
51.4.2 hwGarpAppHoldTimeTable 详细描述.....	1069
51.4.3 hwGarpAppTrunkStatusTable 详细描述.....	1070
51.5 告警节点详细描述.....	1071
52 HUAWEI-GTL-MIB.....	1072
52.1 功能简介.....	1072
52.2 表间关系.....	1072
52.3 单节点详细描述.....	1072
52.3.1 hwGtlDefaultValueReason 详细描述.....	1072
52.3.2 hwGtlResourceItem 详细描述.....	1073
52.3.3 hwGtlFeatureName 详细描述.....	1073
52.3.4 hwGtlRemainTime 详细描述.....	1073
52.3.5 hwGtlActive 详细描述	1073
52.3.6 hwGtlShowActLCSName 详细描述	1074
52.4 MIB Table 详细描述.....	1074
52.4.1 hwGtlItemTable 详细描述.....	1074

52.5 告警节点详细描述.....	1075
52.5.1 hwGtlDefaultValue 详细描述.....	1075
52.5.2 hwGtlDefaultValueCleared 详细描述.....	1075
52.5.3 hwGtlResourceUsedUp 详细描述.....	1076
52.5.4 hwGtlResourceUsedUpCleared 详细描述.....	1076
52.5.5 hwGtlNearDeadline 详细描述.....	1076
52.5.6 hwGtlNearDeadlineCleared 详细描述.....	1077
52.5.7 hwGtlEsnMismatch 详细描述.....	1077
52.5.8 hwGtlEsnMismatchCleared 详细描述.....	1077
53 HUAWEI-GTSM-MIB.....	1078
53.1 功能简介.....	1078
53.2 表间关系.....	1078
53.3 单节点详细描述.....	1079
53.3.1 hwGTSMDefaultAction 详细描述.....	1079
53.4 MIB Table 详细描述.....	1079
53.4.1 hwGTSMPolicyTable 详细描述.....	1079
53.4.2 hwGTSMBgpPeergroupTable 详细描述.....	1082
53.4.3 hwGTSMStatisticsInfoTable 详细描述.....	1084
53.4.4 hwGTSMGlobalConfigInfoTable 详细描述.....	1085
53.5 告警节点详细描述.....	1086
54 HUAWEI-HGMP-MIB.....	1087
54.1 功能简介.....	1087
54.2 表间关系.....	1087
54.3 单节点详细描述.....	1087
54.3.1 hgmpNTDPCollectTopTime 详细描述.....	1088
54.3.2 hgmpNTDPHopRange 详细描述.....	1088
54.3.3 hgmpNTDPRun 详细描述.....	1088
54.3.4 hgmpNTDPPortDelay 详细描述.....	1089
54.3.5 hgmpNTDPHopDelay 详细描述.....	1089
54.3.6 hgmpNTDPExplore 详细描述.....	1089
54.3.7 hwNDPStatus 详细描述.....	1090
54.3.8 hwNDPHelloTimer 详细描述.....	1090
54.3.9 hwNDPAgingTime 详细描述.....	1090
54.3.10 hwNDPTrunkMemberEnable 详细描述.....	1091
54.4 MIB Table 详细描述.....	1091
54.4.1 hgmpNTDPInterfaceTable 详细描述.....	1091
54.4.2 hgmpNTDPTopoLinkTable 详细描述.....	1092
54.4.3 hwNDPPortTable 详细描述.....	1093
54.5 告警节点详细描述.....	1094
54.5.1 hgmpNTDPTopoChange 详细描述.....	1094
55 HUAWEI-HTTP-MIB.....	1095

55.1 功能简介.....	1095
55.2 表间关系.....	1095
55.3 单节点详细描述.....	1095
55.4 MIB Table 详细描述.....	1095
55.4.1 hwHttpUserInfoTable 详细描述.....	1095
55.5 告警节点详细描述.....	1096
55.5.1 hwHttpUserLogin 详细描述.....	1097
55.5.2 hwHttpUserLoginFail 详细描述.....	1097
55.5.3 hwHttpUserLogout 详细描述.....	1097
56 HUAWEI-HQOS-MIB.....	1098
56.1 功能简介.....	1098
56.2 表间关系.....	1098
56.3 单节点详细描述.....	1099
56.4 MIB Table 详细描述.....	1099
56.4.1 hwhqosFlowMappingTable 详细描述.....	1099
56.4.2 hwhqosFlowMappingCfgTable 详细描述.....	1100
56.4.3 hwhqosFlowQueueTable 详细描述.....	1102
56.4.4 hwhqosFlowQueueCfgTable 详细描述.....	1103
56.4.5 hwhqosFlowWredTable 详细描述.....	1105
56.4.6 hwhqosFlowWredColorTable 详细描述.....	1106
56.4.7 hwhqosIfUserQueueTable 详细描述.....	1108
56.4.8 hwhqosIfUserQueueStatisticsTable 详细描述.....	1109
56.5 告警节点详细描述.....	1112
57 HUAWEI-HWTACACS-MIB.....	1113
57.1 功能简介.....	1113
57.2 表间关系.....	1113
57.3 单节点详细描述.....	1113
57.4 MIB Table 详细描述.....	1113
57.4.1 hwTACACSServerGroupTable 详细描述.....	1114
57.4.2 hwTacacsSetting 详细描述.....	1118
57.5 告警节点详细描述.....	1120
57.6 不支持节点.....	1120
58 HUAWEI-IF-EXT-MIB.....	1127
58.1 功能简介.....	1127
58.2 表间关系.....	1128
58.3 单节点详细描述.....	1128
58.3.1 hwIFExtPhyStatus 详细描述.....	1129
58.3.2 hwIFExtMemberOf 详细描述.....	1129
58.3.3 hwIFExtPhyNumber 详细描述.....	1129
58.3.4 hwTrunkIfMax 详细描述.....	1130
58.3.5 hwTrunkNextIndex 详细描述.....	1130

58.3.6 hwTrunkSystemPriority 详细描述.....	1131
58.3.7 hwTrunkETrunkSystemPriority 详细描述.....	1131
58.3.8 hwTrunkETrunkSystemID 详细描述.....	1131
58.3.9 hwIFFlowStatGlobalInterval 详细描述.....	1132
58.3.10 hwLinkDownReason 详细描述.....	1133
58.3.11 hwMainIfName 详细描述.....	1134
58.3.12 hwCfmOverPhysicalName 详细描述.....	1134
58.4 MIB Table 详细描述.....	1134
58.4.1 hwIFExtTable 详细描述.....	1134
58.4.2 hwIfIpTable 详细描述.....	1140
58.4.3 hwIfIpAddrTable 详细描述.....	1142
58.4.4 hwIfQueryTable 详细描述.....	1145
58.4.5 hwLogicIfTable 详细描述.....	1146
58.4.6 hwTrunkIfTable 详细描述.....	1147
58.4.7 hwTrunkMapTable 详细描述.....	1157
58.4.8 hwTrunkMemTable 详细描述.....	1157
58.4.9 hwIfMonitorThresholdTable 详细描述.....	1160
58.4.10 hwIfEtherStatTable 详细描述.....	1161
58.5 告警节点详细描述.....	1167
58.5.1 hwIfFlowDown 详细描述.....	1167
58.5.2 hwIfFlowUp 详细描述.....	1167
58.5.3 hwLacpTotalLinkLoss 详细描述.....	1167
58.5.4 hwLacpTotalLinkLossResume 详细描述.....	1168
58.5.5 hwLacpPartialLinkLoss 详细描述.....	1168
58.5.6 hwLacpPartialLinkLossResume 详细描述.....	1168
58.5.7 hwLacpPartnerExpiredLoss 详细描述.....	1168
58.5.8 hwExtLinkDown 详细描述.....	1169
58.5.9 hwExtLinkUp 详细描述.....	1169
58.5.10 hwLacpNegotiateFailed 详细描述.....	1170
58.5.11 hwLacpNegotiateResume 详细描述.....	1170
58.5.12 hwLacpPDUChange 详细描述.....	1170
58.5.13 hwLacpPDUChangeResume 详细描述.....	1171
58.5.14 hwExtAllMemberDownNotify 详细描述.....	1171
58.5.15 hwExtAllMemberDownResume 详细描述.....	1171
58.5.16 hwExtInterfaceDelete 详细描述.....	1172
58.5.17 hwExtTrunkMemberCountExceedThreshold 详细描述.....	1172
58.5.18 hwExtTrunkMemberCountExceedThresholdResume 详细描述.....	1172
58.5.19 hwIfIpAddressChange 详细描述.....	1173
58.5.20 hwIfMonitorCrcErrorRising 详细描述.....	1173
58.5.21 hwIfMonitorCrcErrorResume 详细描述.....	1173
58.5.22 hwIfMonitorInputRateRising 详细描述.....	1174
58.5.23 hwIfMonitorInputRateResume 详细描述.....	1174

58.5.24 hwIfMonitorOutputRateRising 详细描述.....	1174
58.5.25 hwIfMonitorOutputRateResume 详细描述.....	1175
58.6 不支持节点.....	1175
59 HUAWEI-INFOCENTER-MIB.....	1177
59.1 功能简介.....	1177
59.2 表间关系.....	1177
59.3 单节点详细描述.....	1178
59.3.1 hwICEnable 详细描述.....	1178
59.3.2 hwICLogFileName 详细描述.....	1178
59.3.3 hwICLoghostSourceInterface 详细描述.....	1178
59.4 MIB Table 详细描述.....	1178
59.4.1 hwICLoghostTable 详细描述.....	1178
59.4.2 hwICChannelTable 详细描述.....	1181
59.4.3 hwICModuleTable 详细描述.....	1182
59.4.4 hwICLogFilterTable 详细描述.....	1183
59.5 告警节点详细描述.....	1185
59.5.1 hwICLogFileAging 详细描述.....	1185
59.5.2 hwICLogBufferLose 详细描述.....	1185
60 HUAWEI-IPFPM-MIB.....	1186
60.1 功能简介.....	1186
60.2 表间关系.....	1187
60.3 单节点详细描述.....	1187
60.3.1 hwIpfpmMcpEnable 详细描述.....	1187
60.3.2 hwIpfpmMcpld 详细描述.....	1187
60.3.3 hwIpfpmMcpUdpPort 详细描述.....	1188
60.3.4 hwIpfpmMcplnInstSpec 详细描述.....	1188
60.3.5 hwIpfpmMcplnInstCurNum 详细描述.....	1188
60.3.6 hwIpfpmDcpEnable 详细描述.....	1188
60.3.7 hwIpfpmDcpId 详细描述.....	1189
60.3.8 hwIpfpmDcpMeasureColorFlag 详细描述.....	1189
60.3.9 hwIpfpmDcpMcpld 详细描述.....	1190
60.3.10 hwIpfpmDcpMcpPort 详细描述.....	1190
60.3.11 hwIpfpmDcpMcpVpnName 详细描述.....	1190
60.3.12 hwIpfpmDcpMcpVpnType 详细描述.....	1190
60.3.13 hwIpfpmTlpExceedBoardId 详细描述.....	1191
60.3.14 hwIpfpmTlpNumber 详细描述.....	1191
60.3.15 hwIpfpmTlpThreshold 详细描述.....	1191
60.4 MIB Table 详细描述.....	1191
60.4.1 hwIpfpmMcpAuthTable 详细描述.....	1191
60.4.2 hwIpfpmMcplnInstTable 详细描述.....	1192
60.4.3 hwIpfpmMcpDcpTable 详细描述.....	1194
60.4.4 hwIpfpmMcpAchTable 详细描述.....	1195

60.4.5 hwlpfpmMcpTlpTable 详细描述.....	1196
60.4.6 hwlpfpmMcpInstAchIndexTable 详细描述.....	1197
60.4.7 hwlpfpmMcpLossStatsTable 详细描述.....	1197
60.4.8 hwlpfpmDcpAuthTable 详细描述.....	1203
60.4.9 hwlpfpmDcpInstTable 详细描述.....	1204
60.4.10 hwlpfpmDcpInstAuthTable 详细描述.....	1206
60.4.11 hwlpfpmDcpFlowTable 详细描述.....	1207
60.4.12 hwlpfpmDcpInstTlpTable 详细描述.....	1210
60.4.13 hwlpfpmDcpLossMeasTable 详细描述.....	1211
60.4.14 hwlpfpmDcpTlpTable 详细描述.....	1212
60.4.15 hwlpfpmDcpTlpQueryTable 详细描述.....	1213
60.5 告警节点详细描述.....	1214
60.5.1 hwlpfpmLossRatioExceed 详细描述.....	1215
60.5.2 hwlpfpmLossRatioRecovery 详细描述.....	1215
60.5.3 hwlpfpmTlpExceed 详细描述.....	1215
60.5.4 hwlpfpmTlpRecovery 详细描述.....	1216
60.5.5 hwlpfpmStreamResourceExceed 详细描述.....	1216
60.5.6 hwlpfpmStreamResourceRecovery 详细描述.....	1216
60.5.7 hwlpfpmBoardStreamResourceExceed 详细描述.....	1217
60.5.8 hwlpfpmBoardStreamResourceRecovery 详细描述.....	1217
60.5.9 hwlpfpmBoardPktDscpConflict 详细描述.....	1218
60.5.10 hwlpfpmBoardStreamCreateFail 详细描述.....	1219
60.5.11 hwlpfpmBoardAclResourceExceed 详细描述.....	1219
61 HUAWEI-IPLPM-MIB.....	1220
61.1 功能简介.....	1220
61.2 表间关系.....	1220
61.3 单节点详细描述.....	1220
61.3.1 hwlplpmLossMeasureEnable 详细描述.....	1221
61.3.2 hwlplpmLossMeasureColorFlag 详细描述.....	1221
61.3.3 hwlplpmLossMeasureInterval 详细描述.....	1222
61.3.4 hwlplpmLossMeasureAlarmEnable 详细描述.....	1222
61.3.5 hwlplpmGlobalLatestPeriodNo 详细描述.....	1222
61.3.6 hwlplpmGlobalLatestHisRecordNo 详细描述.....	1223
61.4 MIB Table 详细描述.....	1223
61.4.1 hwlplpmIntfConfigTable 详细描述.....	1223
61.4.2 hwlplpmBoardEntityTable 详细描述.....	1225
61.4.3 hwlplpmGlobalStatsTable 详细描述.....	1225
61.4.4 hwlplpmLinkPeriodNoTable 详细描述.....	1227
61.4.5 hwlplpmLinkLossStatsTable 详细描述.....	1227
61.4.6 hwlplpmPortQosQueStatsTable 详细描述.....	1229
61.4.7 hwlplpmPortFlowStatsTable 详细描述.....	1231
61.4.8 hwlplpmGlobalHisRecordTable 详细描述.....	1231

61.4.9 hwIplpmLinkHisRecordEntryTable 详细描述.....	1233
61.4.10 hwIplpmGateWaySearchTable 详细描述.....	1234
61.4.11 hwIplpmHostInfoSearchTable 详细描述.....	1237
61.4.12 hwIplpmLocalIpSearchTable 详细描述.....	1238
61.4.13 hwIplpmIpRouteSearchTable 详细描述.....	1239
61.5 告警节点详细描述.....	1240
61.5.1 hwIplpmGlobalLossRatioExceed 详细描述.....	1240
61.5.2 hwIplpmGlobalLossRatioRecovery 详细描述.....	1240
61.5.3 hwIplpmLinkForwardLossRatioExceed 详细描述.....	1241
61.5.4 hwIplpmLinkForwardLossRatioRecovery 详细描述.....	1241
61.5.5 hwIplpmGlobalLossRatioExceed 详细描述.....	1242
61.5.6 hwIplpmGlobalLossRatioRecovery 详细描述.....	1242
61.6 不支持节点.....	1242
62 HUAWEI-IPMCAST-MIB.....	1244
62.1 功能简介.....	1244
62.2 表间关系.....	1245
62.3 单节点详细描述.....	1245
62.3.1 hwIpMcastEnable 详细描述.....	1245
62.3.2 hwIpMcastRouteEntryCount 详细描述.....	1246
62.3.3 hwIpMcastSGCurrentCount 详细描述.....	1246
62.3.4 hwIpMcastSGThreshold 详细描述.....	1246
62.3.5 hwIpMcastSGTotalCount 详细描述.....	1246
62.4 MIB Table 详细描述.....	1247
62.4.1 hwIpMcastRouteTable 详细描述.....	1247
62.4.2 hwIpMcastRouteNextHopTable 详细描述.....	1251
62.4.3 hwIpMcastBoundaryTable 详细描述.....	1254
62.5 告警节点详细描述.....	1256
62.5.1 hwIpMcastSGThresholdExceed 详细描述.....	1256
62.5.2 hwIpMcastSGThresholdExceedClear 详细描述.....	1256
62.5.3 hwIpMcastSGExceed 详细描述.....	1257
62.5.4 hwIpMcastSGExceedClear 详细描述.....	1257
63 HUAWEI-IPPOOL-MIB.....	1258
63.1 功能简介.....	1258
63.2 表间关系.....	1258
63.3 单节点详细描述.....	1258
63.3.1 hwIPPoolNum 详细描述.....	1259
63.3.2 hwIPIdleTotalNum 详细描述.....	1259
63.3.3 hwIPUsedTotalNum 详细描述.....	1259
63.3.4 hwIPConflictTotalNum 详细描述.....	1259
63.3.5 hwIPExcludeTotalNum 详细描述.....	1260
63.4 MIB Table 详细描述.....	1260
63.4.1 hwIPPoolTable 详细描述.....	1260

63.4.2 hwIPPoolExtTable 详细描述.....	1264
63.4.3 hwDhcpSvrGroupTable 详细描述.....	1267
63.5 告警节点详细描述.....	1269
63.5.1 hwUsedIPReachThreshold 详细描述.....	1269
63.5.2 hwUsedIPReachThresholdResume 详细描述.....	1269
63.6 不支持节点.....	1270
64 HUAWEI-IPV6-MIB.....	1274
64.1 功能简介.....	1274
64.2 表间关系.....	1275
64.3 MIB Table 详细描述.....	1275
64.3.1 hwIpv6IfTable 详细描述.....	1275
64.3.2 hwIpv6LinklocalCfgTable 详细描述.....	1276
64.3.3 hwIpv6GlobalCfgTable 详细描述.....	1277
64.4 告警节点详细描述.....	1279
65 HUAWEI-ISOLATE-MIB.....	1280
65.1 功能简介.....	1280
65.2 表间关系.....	1280
65.3 单节点详细描述.....	1280
65.3.1 hwPortIsolateMode 详细描述.....	1280
65.4 MIB Table 详细描述.....	1281
65.4.1 hwPortIsolateTable 详细描述.....	1281
65.4.2 hwAmlIsolateTable 详细描述.....	1282
65.5 告警节点详细描述.....	1283
66 HUAWEI-KOMPELLA-MIB.....	1284
66.1 功能简介.....	1284
66.2 表间关系.....	1285
66.3 单节点详细描述.....	1285
66.3.1 hwKompellaVcStateChangeReason 详细描述.....	1286
66.3.2 hwKompellaSwitchRmtCEID 详细描述.....	1291
66.4 MIB Table 详细描述.....	1291
66.4.1 hwKompellaVpnTable 详细描述.....	1291
66.4.2 hwKompellaVpnTargetTable 详细描述.....	1295
66.4.3 hwKompellaCeTable 详细描述.....	1296
66.4.4 hwKompellaVcTable 详细描述.....	1298
66.4.5 hwKompellaVcTnlTable 详细描述.....	1307
66.5 告警节点详细描述.....	1308
66.5.1 hwKompellaVcDown 详细描述.....	1309
66.5.2 hwKompellaVcUp 详细描述.....	1309
66.5.3 hwKompellaSwitchWtoP 详细描述.....	1309
66.5.4 hwKompellaSwitchPtoW 详细描述.....	1310
66.6 附录.....	1310

66.6.1 hwKompellaVcStateChangeReason.....	1310
66.6.2 KompellaVpnVcType.....	1311
67 HUAWEI-L2IF-MIB.....	1313
67.1 功能简介.....	1313
67.2 表间关系.....	1314
67.3 单节点详细描述.....	1314
67.3.1 hwL2IfPortMax 详细描述.....	1315
67.3.2 hwL2TopologyDetect 详细描述.....	1315
67.4 MIB Table 详细描述.....	1315
67.4.1 hwL2IfTable 详细描述.....	1315
67.4.2 hwL2IfHybridPortTable 详细描述.....	1319
67.4.3 hwL2IfTrunkPortTable 详细描述.....	1321
67.4.4 hwL2IfDynPortVlanTable 详细描述.....	1322
67.5 告警节点详细描述.....	1324
67.6 不支持节点.....	1324
68 HUAWEI-L2MAM-MIB.....	1325
68.1 功能简介.....	1325
68.2 表间关系.....	1326
68.3 单节点详细描述.....	1326
68.3.1 hwL2MaxMacLimit 详细描述.....	1327
68.3.2 hwMacAgingTime 详细描述.....	1327
68.3.3 hwMacGlobalStatistics 详细描述.....	1327
68.3.4 hwDiscardIllegalMacEnable 详细描述.....	1327
68.3.5 hwDiscardIllegalMacAlarm 详细描述.....	1328
68.3.6 hwMacSpoofingDefend 详细描述.....	1328
68.4 MIB Table 详细描述.....	1328
68.4.1 hwdbCfgFdbTable 详细描述.....	1328
68.4.2 hwdbDynFdbTable 详细描述.....	1331
68.4.3 hwDynMacAddrQueryTable 详细描述.....	1333
68.4.4 hwL2ProtclTnlStdTable 详细描述.....	1338
68.4.5 hwL2ProtclTnlCusTable 详细描述.....	1340
68.4.6 hwL2ProtclTnlEnableTable 详细描述.....	1343
68.4.7 hwL2ProtclTnlStatisticsTable 详细描述.....	1344
68.4.8 hwMacInfoQueryTable 详细描述.....	1346
68.4.9 hwCfgMacAddrQueryTable 详细描述.....	1351
68.4.10 hwMacLimitTable 详细描述.....	1354
68.4.11 hwMacIfStatisticsTable 详细描述.....	1356
68.4.12 hwMacSlotStatisticsTable 详细描述.....	1356
68.4.13 hwMacSpoofingDefendTable 详细描述.....	1357
68.4.14 hwMacVlanStatisticsTable 详细描述.....	1358
68.4.15 hwPortSecurityTable 详细描述.....	1359
68.5 告警节点详细描述.....	1360

68.5.1 hwSlotMacLimitNumRaisingThreshold 详细描述.....	1361
68.5.2 hwSlotMacLimitNumFallingThreshold 详细描述.....	1361
68.5.3 hwL2ProtocolTunnelDropThresholdRaising 详细描述.....	1361
68.5.4 hwL2ProtocolTunnelDropThresholdFalling 详细描述.....	1362
68.5.5 hwPortSecRcvInsecurePktAlarm 详细描述.....	1362
68.5.6 hwRecIllegalMacPktAlarm 详细描述.....	1362
68.5.7 hwMacLimitOverThresholdAlarm 详细描述.....	1363
68.5.8 hwMacLimitOverThresholdAlarmResume 详细描述.....	1364
68.5.9 hwPortStickyReachMaxAlarm 详细描述.....	1364
68.6 不支持节点.....	1364
69 HUAWEI-L2VC-STATISTIC-MIB.....	1366
69.1 功能简介.....	1366
69.2 表间关系.....	1366
69.3 单节点详细描述.....	1366
69.3.1 hwL2vcStatisticEnable 详细描述.....	1367
69.4 MIB Table 详细描述.....	1367
69.4.1 hwL2vcStatisticsTable 详细描述.....	1367
70 HUAWEI-L2VLAN-MIB.....	1369
70.1 功能简介.....	1369
70.2 表间关系.....	1370
70.3 单节点详细描述.....	1370
70.3.1 hwVcmpDeviceMac 详细描述.....	1370
70.3.2 hwL2VlanPrecedence 详细描述.....	1371
70.3.3 hwL2VlanVoiceVlan8021p 详细描述.....	1371
70.3.4 hwL2VlanVoiceVlanDscp 详细描述.....	1371
70.4 MIB Table 详细描述.....	1371
70.4.1 hwL2VlanMIBTable 详细描述.....	1372
70.4.2 hwSuperVlanTable 详细描述.....	1376
70.4.3 hwL2UntagAddDTagTable 详细描述.....	1377
70.4.4 hwL2VlanIpSubnetVlanTable 详细描述.....	1379
70.4.5 hwL2VlanMacVlanNewTable 详细描述.....	1380
70.4.6 hwL2VlanProtocolVlanNewTable 详细描述.....	1381
70.4.7 hwL2VlanProtocolVlanPortNewTable 详细描述.....	1386
70.4.8 hwL2VlanVoiceVlanPortTable 详细描述.....	1387
70.4.9 hwL2VlanVoiceVlanOuiTable 详细描述.....	1389
70.4.10 hwL2VlanPolicyVlanNewTable 详细描述.....	1390
70.4.11 hwL2QinQVlanTable 详细描述.....	1392
70.4.12 hwL2VlanQinqVlanTransEnaTable 详细描述.....	1397
70.4.13 hwL2VlanQinqVlanTransMissDropTable 详细描述.....	1398
70.4.14 hwL2VlanStackingMaskTable 详细描述.....	1399
70.4.15 hwL2VlanMappingMultiTable.....	1401
70.4.16 hwL2VlanMultiVoiceVlanPortTable 详细描述.....	1403

70.5 告警节点详细描述.....	1405
70.5.1 hwVcmpServerMacConflict 详细描述.....	1405
70.5.2 hwVcmpRevisionConflict 详细描述.....	1406
70.5.3 hwMuxVlanGroupCountExceedThreshold 详细描述.....	1406
70.5.4 hwMuxVlanGroupCountExceedThresholdResume 详细描述.....	1407
70.5.5 hwVlantransCountExceedThreshold 详细描述.....	1407
70.5.6 hwVlantransCountExceedThresholdResume 详细描述.....	1408
70.6 不支持节点.....	1408
71 HUAWEI-L2VPN-MIB.....	1415
71.1 功能简介.....	1415
71.2 表间关系.....	1415
71.3 单节点详细描述.....	1415
71.3.1 hwL2VpnEnable 详细描述.....	1416
71.3.2 hwL2VpnWorkingMode 详细描述.....	1416
71.3.3 hwL2VpnLocalCCCNumer 详细描述.....	1416
71.3.4 hwL2VpnRemoteCCCNumer 详细描述.....	1417
71.3.5 hwL2VpnSvcNumber 详细描述.....	1417
71.3.6 hwL2VpnLdpVcNumber 详细描述.....	1417
71.3.7 hwL2VpnBgpVcNumber 详细描述.....	1417
71.3.8 hwL2VpnVsiNumber 详细描述.....	1418
71.3.9 hwL2VpnBgpVsiNumber 详细描述.....	1418
71.3.10 hwL2VpnVsiVcNumber 详细描述.....	1418
71.3.11 hwVplsVcNumberMaxNum 详细描述.....	1418
71.3.12 hwVplsVcNumberUpperThreshold 详细描述.....	1419
71.3.13 hwL2VpnVcLimitClass 详细描述.....	1419
71.3.14 hwL2VpnSwitchVcNumber 详细描述.....	1419
72 HUAWEI-LDT-MIB.....	1420
72.1 功能简介.....	1420
72.2 表间关系.....	1420
72.3 单节点详细描述.....	1420
72.3.1 hwLdtPortLoopAutoTrapVlanList 详细描述.....	1421
72.3.2 hwPortLoopDetectL2vpnPeVlanList 详细描述.....	1421
72.3.3 hwPortLoopDetectL2vpnCeVlanList 详细描述.....	1421
72.3.4 hwLoopDetectSendingPacketInterval 详细描述.....	1422
72.4 MIB Table 详细描述.....	1422
72.4.1 hwPortLoopDetectTable 详细描述.....	1422
72.5 告警节点详细描述.....	1425
72.5.1 hwLdtPortLoopDetect 详细描述.....	1425
72.5.2 hwLdtPortLoopDetectRecovery 详细描述.....	1425
72.5.3 hwPortL2vpnLoopDetect 详细描述.....	1426
72.5.4 hwPortL2vpnLoopDetectRecovery 详细描述.....	1426
72.6 不支持节点.....	1426

73 HUAWEI-LSP-PING-TRACE-TRAP-MIB.....	1428
73.1 功能简介.....	1428
73.2 表间关系.....	1428
73.3 单节点详细描述.....	1428
73.3.1 hwLspTunnelID 详细描述.....	1429
73.3.2 hwLspSenderAddress 详细描述.....	1429
73.3.3 hwLspEndPointAddress 详细描述.....	1429
73.3.4 hwLspTTL 详细描述.....	1429
73.3.5 hwLspHandle 详细描述.....	1430
73.4 告警节点详细描述.....	1430
73.4.1 hwLspPingProbe 详细描述.....	1430
73.4.2 hwLspTraceProbe 详细描述.....	1430
74 HUAWEI-LLDP-MIB.....	1431
74.1 功能简介.....	1431
74.2 表间关系.....	1431
74.3 单节点详细描述.....	1431
74.3.1 hwLldpEnable 详细描述.....	1431
74.3.2 hwLldpLocManIPAddr 详细描述.....	1432
74.3.3 hwLldpCounterReset 详细描述.....	1432
74.3.4 hwLldpNotificationEnable 详细描述.....	1433
74.3.5 hwLldpTrapIfName 详细描述.....	1433
74.4 MIB Table 详细描述.....	1433
74.4.1 hwLldpPortConfigTable 详细描述.....	1434
74.4.2 hwLldpRemProtoTypeTable 详细描述.....	1434
74.5 告警节点详细描述.....	1435
74.5.1 hwLldpEnabled 详细描述.....	1435
74.5.2 hwLldpDisabled 详细描述.....	1435
74.5.3 hwLldpLocSysCapSupportedChange 详细描述.....	1436
74.5.4 hwLldpLocSysCapEnabledChange 详细描述.....	1436
74.5.5 hwLldpLocManIPAddrChange 详细描述.....	1436
74.5.6 hwLldpMdnRemTablesChange 详细描述.....	1436
74.5.7 hwLldpRateExcessive 详细描述.....	1437
75 HUAWEI-MAC-AUTHEN-MIB.....	1438
75.1 功能简介.....	1438
75.2 表间关系.....	1438
75.3 单节点详细描述.....	1438
75.3.1 hwMacAuthenGlobalEnable 详细描述.....	1438
75.3.2 hwMacAuthenModeUsername 详细描述.....	1440
75.3.3 hwMacAuthenPassword 详细描述.....	1441
75.3.4 hwMacAuthenUsername 详细描述.....	1442
75.3.5 hwMacAuthenDomain 详细描述.....	1442
75.3.6 hwMacAuthenTimerOfflineDetect 详细描述.....	1442

75.3.7 hwMacAuthenTimerQuiet 详细描述.....	1443
75.3.8 hwMacAuthenReauthInterval 详细描述.....	1443
75.3.9 hwMacAuthenPwdType 详细描述.....	1443
75.4 MIB Table 详细描述.....	1444
75.4.1 hwMacAuthenCfgTable 详细描述.....	1444
75.5 告警节点详细描述.....	1445
75.5.1 hwMacAuthenMaxUserAlarm 详细描述.....	1445
75.6 不支持节点.....	1446
76 HUAWEI-MDNS-RELAY-MIB.....	1447
76.1 功能简介.....	1447
76.2 表间关系.....	1447
76.3 单节点详细描述.....	1447
76.3.1 hwMdnsRelayGatewayIPGlobal 详细描述.....	1447
76.3.2 hwMdnsRelaySourceIPGlobal 详细描述.....	1448
76.4 MIB Table 详细描述.....	1448
76.4.1 hwMdnsRelayCfgTable 详细描述.....	1448
76.5 告警节点详细描述.....	1450
77 HUAWEI-MEMORY-MIB.....	1451
77.1 功能简介.....	1451
77.2 表间关系.....	1451
77.3 单节点详细描述.....	1451
77.4 MIB Table 详细描述.....	1451
77.4.1 hwMemoryDevTable 详细描述.....	1451
77.4.2 hwBufferTable 详细描述.....	1453
77.5 告警节点详细描述.....	1454
78 HUAWEI-MFF-MIB.....	1455
78.1 功能简介.....	1455
78.2 表间关系.....	1455
78.3 单节点详细描述.....	1455
78.3.1 hwMffGlobal 详细描述.....	1456
78.4 MIB Table 详细描述.....	1456
78.4.1 hwMffVlanCfgTable 详细描述.....	1456
78.4.2 hwMffNetworkPortTable 详细描述.....	1458
78.4.3 hwMffServerCfgTable 详细描述.....	1459
78.4.4 hwMffUserGatewayTable 详细描述.....	1460
78.4.5 hwMffModUserTable 详细描述.....	1461
78.5 告警节点详细描述.....	1463
79 HUAWEI-MFLP-MIB.....	1464
79.1 功能简介.....	1464
79.2 表间关系.....	1464
79.3 单节点详细描述.....	1464

79.3.1 hwMflpBdId 详细描述.....	1464
79.3.2 hwMflpIfName 详细描述.....	1465
79.3.3 hwMflpAlarmReason 详细描述.....	1465
79.4 MIB Table 详细描述.....	1465
79.4.1 hwMflpVlanCfgTable 详细描述.....	1465
79.5 告警节点详细描述.....	1468
79.5.1 hwMflpVlanAlarm 详细描述.....	1468
79.5.2 hwMflpVsiAlarm 详细描述.....	1468
79.5.3 hwMflpQuitVlanAlarm 详细描述.....	1468
79.5.4 hwMflpQuitVlanResume 详细描述.....	1469
79.5.5 hwMflpBdAlarm 详细描述.....	1469
79.6 不支持节点.....	1469
80 HUAWEI-MGMD-STD-MIB.....	1471
80.1 功能简介.....	1471
80.2 表间关系.....	1472
80.3 单节点详细描述.....	1472
80.3.1 hwMgmdLimitInterfaceIfIndex 详细描述.....	1472
80.3.2 hwMgmdGlobalEntries 详细描述.....	1472
80.3.3 hwMgmdInterfaceEntries 详细描述.....	1473
80.3.4 hwMgmdTotalEntries 详细描述.....	1473
80.3.5 hwMgmdGmpJoinGrpAddr 详细描述.....	1473
80.3.6 hwMgmdGmpJoinSrcAddr 详细描述.....	1473
80.3.7 hwMgmdGmpJoinSenderId 详细描述.....	1474
80.3.8 hwMgmdGmpJoinVersion 详细描述.....	1474
80.3.9 hwMgmdGmpInterfaceIfIndex 详细描述.....	1474
80.3.10 hwMgmdGmpInterfaceName 详细描述.....	1474
80.3.11 hwMgmdGmpLimitGroupAddressType 详细描述.....	1475
80.3.12 hwMgmdGmpLimitGroup 详细描述.....	1475
80.3.13 hwMgmdGmpLimitSource 详细描述.....	1476
80.3.14 hwMgmdInstanceName 详细描述.....	1476
80.3.15 hwMgmdNotificationAddressType 详细描述.....	1476
80.3.16 hwMgmdTotalLimitCurrentCount 详细描述.....	1477
80.3.17 hwMgmdTotalLimitThreshold 详细描述.....	1477
80.3.18 hwMgmdHostStarGCurrentCount 详细描述.....	1477
80.3.19 hwMgmdHostStarGThreshold 详细描述.....	1477
80.3.20 hwMgmdHostStarGTotalCount 详细描述.....	1478
80.3.21 hwMgmdHostNotificationSrcAddr 详细描述.....	1478
80.3.22 hwMgmdHostNotificationGrpAddr 详细描述.....	1478
80.3.23 hwMgmdHostSGCurrentCount 详细描述.....	1478
80.3.24 hwMgmdHostSGThreshold 详细描述.....	1479
80.3.25 hwMgmdHostSGTotalCount 详细描述.....	1479
80.3.26 hwMgmdHostRerouteDelayPeriod 详细描述.....	1479

80.3.27 hwMgmdHostRerouteImmediate 详细描述.....	1480
80.3.28 hwMgmdTtlCheck 详细描述.....	1480
80.4 MIB Table 详细描述.....	1480
80.4.1 hwMgmdRouterInterfaceTable 详细描述.....	1480
80.4.2 hwMgmdRouterCacheTable 详细描述.....	1486
80.4.3 hwMgmdHostInterfaceTable 详细描述.....	1488
80.4.4 hwMgmdInverseRouterCacheTable 详细描述.....	1491
80.4.5 hwMgmdRouterSrcListTable 详细描述.....	1492
80.4.6 hwMgmdCtlMsgCountTable 详细描述.....	1493
80.5 告警节点详细描述.....	1495
80.5.1 hwMgmdGmpJoin 详细描述.....	1496
80.5.2 hwMgmdGmpLeave 详细描述.....	1496
80.5.3 hwMgmdGMPGlobalLimit 详细描述.....	1497
80.5.4 hwMgmdGMPIInterfaceLimit 详细描述.....	1497
80.5.5 hwMgmdGMPTotalLimit 详细描述.....	1498
80.5.6 hwMgmdGMPIInterfaceLimitClear 详细描述.....	1498
80.5.7 hwMgmdGMPGlobalLimitClear 详细描述.....	1499
80.5.8 hwMgmdGMPTotalLimitClear 详细描述.....	1499
81 HUAWEI-MPLS-EXTEND-MIB.....	1500
81.1 功能简介.....	1500
81.2 表间关系.....	1501
81.3 单节点详细描述.....	1502
81.3.1 hwStaticLspInIfIndex 详细描述.....	1502
81.3.2 hwStaticLspInIfName 详细描述.....	1502
81.3.3 hwMplsTunnelDownIfIpAddrType 详细描述.....	1502
81.3.4 hwStaticLspDownReason 详细描述.....	1503
81.3.5 hwMplsTunnelDownReason 详细描述.....	1504
81.3.6 hwMplsLspProtocol 详细描述.....	1505
81.3.7 hwMplsLspThreshold 详细描述.....	1506
81.3.8 hwMplsLspTotalCount 详细描述.....	1506
81.3.9 hwMplsLspCurrentCount 详细描述.....	1507
81.3.10 hwMplsTunnelDownLSRID 详细描述.....	1507
81.3.11 hwMplsTunnelDownIfIpAddr 详细描述.....	1507
81.3.12 hwMplsGlobalBcModel 详细描述.....	1507
81.3.13 hwMplsDynamicLabelTotalCount 详细描述.....	1508
81.3.14 hwMplsDynamicLabelCurrentCount 详细描述.....	1508
81.3.15 hwMplsDynamicLabelThresholdUpperLimit 详细描述.....	1508
81.3.16 hwMplsDynamicLabelThresholdLowerLimit 详细描述.....	1508
81.3.17 hwMplsResourceType 详细描述.....	1509
81.3.18 hwMplsResourceCurrentCount 详细描述.....	1510
81.3.19 hwMplsResourceThreshold 详细描述.....	1510
81.3.20 hwMplsResourceTotalCount 详细描述.....	1510

81.3.21 hwMplsTunnelIfName 详细描述.....	1510
81.4 MIB Table 详细描述.....	1510
81.4.1 hwMplsTunnelTable 详细描述.....	1511
81.4.2 hwTunnelFrrBypassTable 详细描述.....	1517
81.4.3 hwTunnelFrrARHopTable 详细描述.....	1518
81.4.4 hwTunnelFrrRouteDBTable 详细描述.....	1519
81.4.5 hwStaticLspTable 详细描述.....	1521
81.4.6 hwMplsIfBcTable 详细描述.....	1523
81.4.7 hwStaticLspTnlTable 详细描述.....	1525
81.4.8 hwMplsTeVpnQosTable 详细描述.....	1525
81.4.9 hwMplsLspStatisticsTable 详细描述.....	1526
81.5 告警节点详细描述.....	1528
81.5.1 hwMplsStaticLspUp 详细描述.....	1528
81.5.2 hwMplsStaticLspDown 详细描述.....	1528
81.5.3 hwMplsStaticCRLspUp 详细描述.....	1529
81.5.4 hwMplsStaticCRLspDown 详细描述.....	1529
81.5.5 hwMplsTeFrrProtAval 详细描述.....	1530
81.5.6 hwMplsTeFrrProtNotAval 详细描述.....	1530
81.5.7 hwMplsTeFrrSwitch 详细描述.....	1531
81.5.8 hwMplsTeFrrResume 详细描述.....	1531
81.5.9 hwMplsTunnelHSBSwitch 详细描述.....	1532
81.5.10 hwMplsTunnelHSBResume 详细描述.....	1532
81.5.11 hwMplsTunnelOBSSwitch 详细描述.....	1532
81.5.12 hwMplsTunnelOBResume 详细描述.....	1533
81.5.13 hwMplsTunnelChangeBw 详细描述.....	1533
81.5.14 hwMplsTunnelPrimaryUp 详细描述.....	1533
81.5.15 hwMplsTunnelPrimaryDown 详细描述.....	1534
81.5.16 hwMplsTunnelHotstandbyUp 详细描述.....	1534
81.5.17 hwMplsTunnelHotstandbyDown 详细描述.....	1535
81.5.18 hwMplsTunnelOrdinaryUp 详细描述.....	1535
81.5.19 hwMplsTunnelOrdinaryDown 详细描述.....	1536
81.5.20 hwMplsTunnelBesteffortUp 详细描述.....	1536
81.5.21 hwMplsTunnelBesteffortDown 详细描述.....	1537
81.5.22 hwMplsTeAutoTunnelDownClear 详细描述.....	1537
81.5.23 hwMplsTeAutoTunnelPrimaryDownClear 详细描述.....	1537
81.5.24 hwMplsExtTunnelDown 详细描述.....	1538
81.5.25 hwMplsExtTunnelDownClear 详细描述.....	1539
81.5.26 hwMplsTunnelBBSwitch 详细描述.....	1539
81.5.27 hwMplsTunnelBBResume 详细描述.....	1540
81.5.28 hwMplsLspThresholdExceed 详细描述.....	1540
81.5.29 hwMplsLspThresholdExceedClear 详细描述.....	1540
81.5.30 hwMplsLspTotalCountExceed 详细描述.....	1541

81.5.31 hwMplsLspTotalCountExceedClear 详细描述.....	1541
81.5.32 hwMplsTunnelDelete 详细描述.....	1541
81.5.33 hwMplsOamLocalLock 详细描述.....	1542
81.5.34 hwMplsOamLocalLockRecovery 详细描述.....	1542
81.5.35 hwMplsDynamicLabelThresholdExceed 详细描述.....	1543
81.5.36 hwMplsDynamicLabelThresholdExceedClear 详细描述.....	1544
81.5.37 hwMplsDynamicLabelTotalCountExceed 详细描述.....	1544
81.5.38 hwMplsDynamicLabelTotalCountExceedClear 详细描述.....	1545
81.5.39 hwMplsResourceThresholdExceed 详细描述.....	1545
81.5.40 hwMplsResourceThresholdExceedClear 详细描述.....	1545
81.5.41 hwMplsResourceTotalCountExceed 详细描述.....	1546
81.5.42 hwMplsResourceTotalCountExceedClear 详细描述.....	1546
81.5.43 hwMplsTunnelCommitLost 详细描述.....	1546
81.5.44 hwMplsTunnelCommitLostClear 详细描述.....	1546
81.5.45 hwMplsTunnelHotstandbySwitch 详细描述.....	1547
81.5.46 hwMplsTunnelHotstandbyResume 详细描述.....	1547
81.5.47 hwMplsTeLspBfdDown 详细描述.....	1547
81.5.48 hwMplsTeLspBfdDownClear 详细描述.....	1547
82 HUAWEI-MPLSLDP-MIB.....	1548
82.1 功能简介.....	1548
82.2 表间关系.....	1548
82.3 单节点详细描述.....	1549
82.3.1 hwMplsLdpProcessName 详细描述.....	1549
82.3.2 hwMplsLdpLspFec 详细描述.....	1549
82.3.3 hwMplsLdpLspInLabel 详细描述.....	1549
82.3.4 hwMplsLdpLspOutLabel 详细描述.....	1549
82.3.5 hwMplsLdpLspOutIfIndex 详细描述.....	1550
82.3.6 hwMplsLdpLspDownReason 详细描述.....	1550
82.3.7 hwLdpCapabilityConfig 详细描述.....	1550
82.3.8 hwLdpLsrId 详细描述.....	1551
82.3.9 hwLdpPropagateIpPrefix 详细描述.....	1551
82.3.10 hwLdpGlobalRemotePwe3 详细描述.....	1551
82.3.11 hwLdpMtuSignaling 详细描述.....	1552
82.3.12 hwLdpMtuApplyTlv 详细描述.....	1552
82.3.13 hwLdpGrCapabilityConfig 详细描述.....	1552
82.3.14 hwLdpGrNeighborLivenessTimer 详细描述.....	1553
82.3.15 hwLdpGrReconnectTimer 详细描述.....	1553
82.3.16 hwLdpGrRecoveryTimer 详细描述.....	1553
82.3.17 hwLdpLongestMatch 详细描述.....	1554
82.3.18 hwLdpRemotePeerAutoDodRequest 详细描述.....	1554
82.3.19 hwMplsLspTrigger 详细描述.....	1554
82.3.20 hwMplsLspTriggerIpPrefix 详细描述.....	1554

82.3.21 hwLdpReset 详细描述.....	1555
82.3.22 hwLdpOutBoundSplitHorizonAll 详细描述.....	1555
82.3.23 hwLdpDeleteGtsmAll 详细描述.....	1555
82.3.24 hwMplsFrrLspTrigger 详细描述.....	1556
82.3.25 hwMplsFrrLspTriggerIpPrefix 详细描述.....	1556
82.3.26 hwMplsLspTriggerBgpRoute 详细描述.....	1556
82.3.27 hwMplsLspTriggerBgpRouteIpPrefix 详细描述.....	1556
82.3.28 hwLdpBackOffTimerInit 详细描述.....	1557
82.3.29 hwLdpBackOffTimerMax 详细描述.....	1557
82.3.30 hwLdpInBoundPolicyPeerAllRange 详细描述.....	1557
82.3.31 hwLdpInBoundPolicyPeerAllIpPrefix 详细描述.....	1557
82.3.32 hwLdpLocalOperationalSessionNumber 详细描述.....	1558
82.3.33 hwLdpRemoteOperationalSessionNumber 详细描述.....	1558
82.3.34 hwLdpLocalAndRemoteOperationalSessionNumber 详细描述.....	1558
82.3.35 hwLdpTotalOperationalSessionNumber 详细描述.....	1559
82.4 MIB Table 详细描述.....	1559
82.4.1 hwMplsLdpSessionTable 详细描述.....	1559
82.4.2 hwMplsLdpSessionStateTable 详细描述.....	1562
82.4.3 hwLdpRemoteEntityTable 详细描述.....	1564
82.4.4 hwLdpPeerTable 详细描述.....	1566
82.4.5 hwLdpVpnPeerTable 详细描述.....	1569
82.4.6 hwLdpInterfaceTable 详细描述.....	1571
82.4.7 hwLdpPeerGroupTable 详细描述.....	1573
82.5 告警节点详细描述.....	1574
82.6 不支持节点.....	1574
83 HUAWEI-MPLSLSR-EXT-MIB.....	1575
83.1 功能简介.....	1575
83.2 表间关系.....	1575
83.3 单节点详细描述.....	1575
83.3.1 hwMplsLsrId 详细描述.....	1576
83.3.2 hwMplsCapabilityConfig 详细描述.....	1576
83.3.3 hwMplsLabelAdvertise 详细描述.....	1576
83.3.4 hwMplsBfdCapabilityConfig 详细描述.....	1577
83.3.5 hwMplsBfdMinTx 详细描述.....	1577
83.3.6 hwMplsBfdMinRx 详细描述.....	1577
83.3.7 hwMplsBfdDetectMultiplier 详细描述.....	1577
83.3.8 hwMplsFecListName 详细描述.....	1578
83.3.9 hwMplsBfdTrigger 详细描述.....	1578
83.3.10 hwMplsBfdTriggerNextHop 详细描述.....	1578
83.3.11 hwMplsBfdTriggerInterface 详细描述.....	1579
83.3.12 hwMplsBfdTriggerFecListName 详细描述.....	1579
83.3.13 hwLdpVirtualTunnelFEC 详细描述.....	1579

83.3.14 hwMplsBgpBfdCapabilityConfig 详细描述.....	1580
83.3.15 hwMplsBgpBfdMinTx 详细描述.....	1580
83.3.16 hwMplsBgpBfdMinRx 详细描述.....	1580
83.3.17 hwMplsBgpBfdDetectMultiplier 详细描述.....	1581
83.3.18 hwMplsBgpBfdTriggerTunnel 详细描述.....	1581
83.3.19 hwMplsBgpBfdTriggerTunnelIpprefix 详细描述.....	1581
83.4 MIB Table 详细描述.....	1582
83.4.1 hwMplsFecListTable 详细描述.....	1582
83.4.2 hwMplsInterfaceTable 详细描述.....	1583
83.4.3 hwLdpStaticFrrInterfaceTable 详细描述.....	1584
83.4.4 hwLdpVirtualTunnelTable 详细描述.....	1585
83.4.5 hwMplsStaticLspTable 详细描述.....	1586
83.5 告警节点详细描述.....	1587
83.5.1 hwMplsLdpVirtualTunnelUp 详细描述.....	1588
83.5.2 hwMplsLdpVirtualTunnelDown 详细描述.....	1588
84 HUAWEI-MPLSOAM-MIB.....	1589
84.1 功能简介.....	1589
84.2 表间关系.....	1589
84.3 MIB Table 详细描述.....	1589
84.3.1 hwMplsPsTable 详细描述.....	1589
84.4 告警节点详细描述.....	1596
84.4.1 hwMplsPsSwitchPtoW 详细描述.....	1596
84.4.2 hwMplsPsSwitchWtoP 详细描述.....	1596
84.5 不支持节点.....	1596
85 HUAWEI-MSDP-MIB.....	1598
85.1 功能简介.....	1598
85.2 表间关系.....	1598
85.3 单节点详细描述.....	1598
85.3.1 hwMsdplInstanceId 详细描述.....	1599
85.3.2 hwMsdplInstanceName 详细描述.....	1599
85.3.3 hwMsdplNotificationReason 详细描述.....	1600
85.4 MIB Table 详细描述.....	1600
85.5 告警节点详细描述.....	1601
86 HUAWEI-MSTP-MIB.....	1602
86.1 功能简介.....	1602
86.2 表间关系.....	1603
86.3 单节点详细描述.....	1604
86.3.1 hwMstpStatus 详细描述.....	1604
86.3.2 hwMstpForceVersion 详细描述.....	1604
86.3.3 hwMstpDiameter 详细描述.....	1605
86.3.4 hwMstpBridgeMaxHops 详细描述.....	1605

86.3.5 hwMstpMasterBridgeID 详细描述.....	1606
86.3.6 hwMstpMasterPathCost 详细描述.....	1606
86.3.7 hwMstpBpduGuard 详细描述.....	1607
86.3.8 hwMstpAdminFormatSelector 详细描述.....	1607
86.3.9 hwMstpAdminRegionName 详细描述.....	1608
86.3.10 hwMstpAdminRevisionLevel 详细描述.....	1608
86.3.11 hwMstpOperFormatSelector 详细描述.....	1608
86.3.12 hwMstpOperRegionName 详细描述.....	1609
86.3.13 hwMstpOperRevisionLevel 详细描述.....	1609
86.3.14 hwMstpRegionConfActive 详细描述.....	1610
86.3.15 hwMstpDefaultVlanAllo 详细描述.....	1610
86.3.16 hwMstpDefaultRegionName 详细描述.....	1611
86.3.17 hwMstpPathCostStandard 详细描述.....	1611
86.3.18 hwMstpTcGuard 详细描述.....	1612
86.3.19 hwMstpTcGuardThreshold 详细描述.....	1612
86.3.20 hwMstpEdgedPortDefault 详细描述.....	1613
86.3.21 hwMstpBpduFilterPortDefault 详细描述.....	1613
86.3.22 hwMstpTransmitLimitDefault 详细描述.....	1614
86.4 MIB Table 详细描述.....	1614
86.4.1 hwMstpVIDAllocationTable 详细描述.....	1614
86.4.2 hwMstpInstanceTable 详细描述.....	1615
86.4.3 hwMstpPortTable 详细描述.....	1619
86.4.4 hwMstpProTable 详细描述.....	1631
86.4.5 hwMstpPortBindTable 详细描述.....	1639
86.4.6 hwMstpProInstanceTable 详细描述.....	1642
86.4.7 hwMstpProNewPortTable 详细描述.....	1645
86.5 告警节点详细描述.....	1656
86.5.1 hwMstpiPortStateForwarding 详细描述.....	1657
86.5.2 hwMstpiPortStateDiscarding 详细描述.....	1657
86.5.3 hwMstpiBridgeLostRootPrimary 详细描述.....	1658
86.5.4 hwMstpiPortRootGuarded 详细描述.....	1658
86.5.5 hwMstpiPortBpduGuarded 详细描述.....	1659
86.5.6 hwMstpiPortLoopGuarded 详细描述.....	1659
86.5.7 hwMstpiEdgePortChanged 详细描述.....	1659
86.5.8 hwMstpiTcGuarded 详细描述.....	1660
86.5.9 hwMstpProTcGuarded 详细描述.....	1660
86.5.10 hwMstpProRootChanged 详细描述.....	1660
86.5.11 hwMstpProNewPortStateForwarding 详细描述.....	1661
86.5.12 hwMstpProNewPortStateDiscarding 详细描述.....	1661
86.5.13 hwMstpProNewBridgeLostRootPrimary 详细描述.....	1662
86.5.14 hwMstpProNewPortRootGuarded 详细描述.....	1662
86.5.15 hwMstpProNewPortBpduGuarded 详细描述.....	1663

86.5.16 hwmstpProNewPortLoopGuarded 详细描述.....	1663
86.5.17 hwmstpProNewEdgePortChanged 详细描述.....	1663
86.5.18 hwmstpProLoopbackDetected 详细描述.....	1664
86.5.19 hwmstpProRootLost 详细描述.....	1664
86.5.20 hwmstpProRootResume 详细描述.....	1664
87 HUAWEI-MULTICAST-MIB.....	1665
87.1 功能简介.....	1665
87.2 表间关系.....	1665
87.3 单节点详细描述.....	1667
87.3.1 hwlGmpSnoopingEnabled 详细描述.....	1667
87.3.2 hwSendQueryEnabled 详细描述.....	1667
87.3.3 hwSendQuerySourceIpAddr 详细描述.....	1668
87.3.4 hwSystemRecvVlanUpEventTimes 详细描述.....	1668
87.3.5 hwSystemRecvVlanDownEventTimes 详细描述.....	1668
87.3.6 hwSystemRecvVlanDelEventTimes 详细描述.....	1669
87.3.7 hwSystemRecvPortUpEventTimes 详细描述.....	1669
87.3.8 hwSystemRecvPortDownEventTimes 详细描述.....	1669
87.3.9 hwSystemRecvPortDelEventTimes 详细描述.....	1669
87.3.10 hwSystemRecvPortIncEventTimes 详细描述.....	1670
87.3.11 hwSystemRecvPortExcEventTimes 详细描述.....	1670
87.3.12 hwSystemRecvMSTPBlockEventTimes 详细描述.....	1670
87.3.13 hwSystemRecvMSTPForwardEventTimes 详细描述.....	1671
87.3.14 hwSystemIGMPSysClearStats 详细描述.....	1671
87.3.15 hwSystemIGMPPacketClearStats 详细描述.....	1671
87.3.16 hwSystemRecvLinkChangeEventTimes 详细描述.....	1671
87.3.17 hwMldSnoopingEnabled 详细描述.....	1672
87.3.18 hwMldSendQueryEnabled 详细描述.....	1672
87.3.19 hwMldSendQuerySourceIpAddr 详细描述.....	1672
87.3.20 hwMldSnoopingSuppressionTime 详细描述.....	1673
87.3.21 hwMldSystemRecvVlanUpEventTimes 详细描述.....	1673
87.3.22 hwMldSystemRecvVlanDownEventTimes 详细描述.....	1673
87.3.23 hwMldSystemRecvVlanDelEventTimes 详细描述.....	1673
87.3.24 hwMldSystemRecvPortUpEventTimes 详细描述.....	1674
87.3.25 hwMldSystemRecvPortDownEventTimes 详细描述.....	1674
87.3.26 hwMldSystemRecvPortDelEventTimes 详细描述.....	1674
87.3.27 hwMldSystemRecvPortIncEventTimes 详细描述.....	1674
87.3.28 hwMldSystemRecvPortExcEventTimes 详细描述.....	1675
87.3.29 hwMldSystemRecvMstpBlockEventTimes 详细描述.....	1675
87.3.30 hwMldSystemRecvMstpForwardEventTimes 详细描述.....	1675
87.3.31 hwMldSystemSysClearStats 详细描述.....	1675
87.3.32 hwMldSystemPacketClearStats 详细描述.....	1676
87.3.33 hwMldSystemRecvLinkChangeEventTimes 详细描述.....	1676

87.3.34 hwBtvEnabled 详细描述.....	1676
87.4 MIB Table 详细描述.....	1676
87.4.1 hwVlanCfgTable 详细描述.....	1676
87.4.2 hwVlanStatisticsTable 详细描述.....	1679
87.4.3 hwIPGrpInfoTable 详细描述.....	1681
87.4.4 hwExternIPGrpInfoTable 详细描述.....	1682
87.4.5 hwPortStaticGrpTable 详细描述.....	1684
87.4.6 hwGrpPolicyCfgTable 详细描述.....	1685
87.4.7 hwRouterPortInfoTable 详细描述.....	1687
87.4.8 hwRouterPortCfgTable 详细描述.....	1688
87.4.9 hwPortGroupPolicyTable 详细描述.....	1689
87.4.10 hwExternPortStaticGrpTable 详细描述.....	1690
87.4.11 hwPortVlanLimitTable 详细描述.....	1691
87.4.12 hwMldVlanCfgTable 详细描述.....	1692
87.4.13 hwMldVlanStatisticsTable 详细描述.....	1695
87.4.14 hwMldIpGrpInfoTable 详细描述.....	1696
87.4.15 hwMldPortStaticGrpTable 详细描述.....	1698
87.4.16 hwMldGrpPolicyCfgTable 详细描述.....	1699
87.4.17 hwMldRouterPortInfoTable 详细描述.....	1701
87.4.18 hwMldRouterPortCfgTable 详细描述.....	1702
87.4.19 hwMldPortLimitTable 详细描述.....	1702
87.4.20 hwMldPortGroupPolicyTable 详细描述.....	1704
87.4.21 hwMVlanEnableTable 详细描述.....	1705
87.4.22 hwMVlanUserVlanTable 详细描述.....	1706
87.4.23 hwUserVlanTable 详细描述.....	1707
87.4.24 hwMcSourceDenyTable 详细描述.....	1707
87.4.25 hwMVlanGrpInfoTable 详细描述.....	1708
87.4.26 hwMVlanStaticFlowTable 详细描述.....	1709
87.4.27 hwMVlanIpv6StaticFlowTable 详细描述.....	1710
87.4.28 hwExternMVlanStaticFlowTable 详细描述.....	1711
87.4.29 hwMcastGroupTable 详细描述.....	1712
87.4.30 hwMcastListTable 详细描述.....	1714
87.4.31 hwMcastProfileTable 详细描述.....	1715
87.4.32 hwMcastProfileCfgTable 详细描述.....	1716
87.4.33 hwMcastListReferTable 详细描述.....	1717
87.4.34 hwMcastProfileReferTable 详细描述.....	1717
87.4.35 hwVlanApplyProfileTable 详细描述.....	1718
87.4.36 hwMcastIpv6GroupTable 详细描述.....	1719
87.4.37 hwExternVlanApplyProfileTable 详细描述.....	1720
87.5 告警节点详细描述.....	1721
87.6 不支持节点.....	1722
88 HUAWEI-NETSTREAM-MIB.....	1726

88.1 功能简介.....	1726
88.2 表间关系.....	1726
88.3 单节点详细描述.....	1726
88.3.1 hwNetStreamlastchangedtime 详细描述.....	1727
88.3.2 hwNetStreamTemplateRefresh 详细描述.....	1727
88.4 MIB Table 详细描述.....	1727
88.4.1 hwNetStreamIfIndexTable 详细描述.....	1727
88.5 告警节点详细描述.....	1728
88.5.1 hwNetStreamIndexUsedUp 详细描述.....	1728
89 HUAWEI-NTPV3-MIB.....	1729
89.1 功能简介.....	1729
89.2 表间关系.....	1729
89.3 单节点详细描述.....	1729
89.3.1 hwNtpV3ServerIPAdd 详细描述.....	1730
89.3.2 hwNtpV3TimeSyncPeriod 详细描述.....	1730
89.3.3 hwNtpV3TimeAfterNTPCal 详细描述.....	1730
89.4 告警节点详细描述.....	1731
90 HUAWEI-NTP-TRAP-MIB.....	1732
90.1 功能简介.....	1732
90.2 表间关系.....	1732
90.3 单节点详细描述.....	1732
90.3.1 hwNtpState 详细描述.....	1732
90.3.2 hwNtpSource 详细描述.....	1733
90.3.3 hwNtpSourceVpnName 详细描述.....	1733
90.4 告警节点详细描述.....	1734
90.4.1 hwNtpStateChangeTrap 详细描述.....	1734
91 HUAWEI-OSPFV2-MIB.....	1735
91.1 功能简介.....	1735
91.2 表间关系.....	1736
91.3 单节点详细描述.....	1736
91.3.1 hwOspfv2MibBinding 详细描述.....	1736
91.3.2 hwOspfv2MIBObjectsChange 详细描述.....	1737
91.3.3 hwOspfv2ProcessChange 详细描述.....	1737
91.3.4 hwOspfv2AreaChange 详细描述.....	1737
91.3.5 hwOspfv2NetworkChange 详细描述.....	1738
91.3.6 hwOspfv2NbrChgReason 详细描述.....	1738
91.3.7 hwOspfv2IfChgReason 详细描述.....	1739
91.3.8 hwOspfv2Areald 详细描述.....	1739
91.3.9 hwOspfv2NewRouterId 详细描述.....	1739
91.3.10 hwOspfv2PeerFlappingSuppressStatus 详细描述.....	1740
91.3.11 hwOspfv2PeerFlappingSuppressReason 详细描述.....	1741

91.4 MIB Table 详细描述.....	1741
91.4.1 hwOspfV2ProcessTable 详细描述.....	1741
91.4.2 hwOspfV2AreaTable 详细描述.....	1753
91.4.3 hwOspfV2NetworkTable 详细描述.....	1765
91.4.4 hwOspfV2NeighborTable 详细描述.....	1766
91.4.5 hwOspfV2InterfaceTable 详细描述.....	1769
91.5 告警节点详细描述.....	1770
91.5.1 hwOspfV2IntraAreaRouterIdConflict 详细描述.....	1770
91.5.2 hwOspfV2IntraAreaDRIPAddressConflict 详细描述.....	1771
91.5.3 hwOspfV2IntraAreaRouterIdConflictRecovered 详细描述.....	1771
91.5.4 hwOspfV2PeerFlappingSuppressStatusChange 详细描述.....	1771
92 HUAWEI-OSPFV3-MIB.....	1772
92.1 功能简介.....	1772
92.2 表间关系.....	1772
92.3 单节点详细描述.....	1772
92.3.1 hwOspfV3RouterId 详细描述.....	1773
92.3.2 hwOspfV3AdminStatus 详细描述.....	1773
92.3.3 hwOspfV3VersionNumber 详细描述.....	1773
92.3.4 hwOspfV3AreaBdrRtrStatus 详细描述.....	1774
92.3.5 hwOspfV3AsBdrRtrStatus 详细描述.....	1774
92.3.6 hwOspfV3AsScopeLsaCount 详细描述.....	1774
92.3.7 hwOspfV3AsScopeLsaCksumSum 详细描述.....	1774
92.3.8 hwOspfV3OriginateNewLsas 详细描述.....	1775
92.3.9 hwOspfV3RxNewLsas 详细描述.....	1775
92.3.10 hwOspfV3ExtLsaCount 详细描述.....	1775
92.3.11 hwOspfV3ExtAreaLsdbLimit 详细描述.....	1776
92.3.12 hwOspfV3RestartSupport 详细描述.....	1776
92.3.13 hwOspfV3RestartInterval 详细描述.....	1777
92.3.14 hwOspfV3RestartStatus 详细描述.....	1777
92.3.15 hwOspfV3RestartAge 详细描述.....	1777
92.3.16 hwOspfV3RestartExitRc 详细描述.....	1778
92.3.17 hwOspfV3NotificationEnable 详细描述.....	1778
92.3.18 hwOspfV3ReferenceBandwidth 详细描述.....	1778
92.3.19 hwOspfV3ConfigErrorType 详细描述.....	1779
92.3.20 hwOspfV3PacketType 详细描述.....	1779
92.3.21 hwOspfV3PacketSrc 详细描述.....	1780
92.3.22 hwOspfV3IfName 详细描述.....	1780
92.3.23 hwOspfV3IfStateChgReason 详细描述.....	1780
92.3.24 hwOspfV3NbrStateChgReason 详细描述.....	1781
92.3.25 hwOspfV3ProcessId 详细描述.....	1782
92.3.26 hwOspfV3AreaIdIndex 详细描述.....	1782
92.3.27 hwOspfV3NewRouterId 详细描述.....	1782

92.3.28 hwOspfV3PeerFlappingSuppressStatus 详细描述.....	1783
92.3.29 hwOspfV3PeerFlappingSuppressReason 详细描述.....	1784
92.4 MIB Table 详细描述.....	1784
92.4.1 hwOspfV3AreaTable 详细描述.....	1784
92.4.2 hwOspfV3AsLsdbTable 详细描述.....	1787
92.4.3 hwOspfV3AreaLsdbTable 详细描述.....	1789
92.4.4 hwOspfV3LinkLsdbTable 详细描述.....	1791
92.4.5 hwOspfV3IfTable 详细描述.....	1793
92.4.6 hwOspfV3VirtIfTable 详细描述.....	1797
92.4.7 hwOspfV3NbrTable 详细描述.....	1799
92.4.8 hwOspfV3CfgNbrTable 详细描述.....	1802
92.4.9 hwOspfV3VirtNbrTable 详细描述.....	1803
92.4.10 hwOspfV3AreaAggregateTable 详细描述.....	1806
92.5 告警节点详细描述.....	1808
92.5.1 hwOspfV3VirtIfStateChange 详细描述.....	1809
92.5.2 hwOspfV3NbrStateChange 详细描述.....	1809
92.5.3 hwOspfV3VirtNbrStateChange 详细描述.....	1809
92.5.4 hwOspfV3IfConfigError 详细描述.....	1810
92.5.5 hwOspfV3VirtIfConfigError 详细描述.....	1810
92.5.6 hwOspfV3IfRxBadPacket 详细描述.....	1811
92.5.7 hwOspfV3VirtIfRxBadPacket 详细描述.....	1811
92.5.8 hwOspfV3IfStateChange 详细描述.....	1811
92.5.9 hwOspfV3RestartStatusChange 详细描述.....	1812
92.5.10 hwOspfV3NbrRestartHelperStatusChange 详细描述.....	1812
92.5.11 hwOspfV3VirtNbrRestartHelperStatusChange 详细描述.....	1813
92.5.12 hwOspfV3NssaTranslatorStatusChange 详细描述.....	1813
92.5.13 hwOspfV3LastAuthKeyExpiry 详细描述.....	1813
92.5.14 hwOspfV3AuthSequenceNumWrap 详细描述.....	1814
92.5.15 hwOspfV3IntraAreaRouterIdConflictRecovered 详细描述.....	1814
92.5.16 hwOspfV3PeerFlappingSuppressStatusChange 详细描述.....	1815
93 HUAWEI-PERFMGMT-MIB.....	1816
93.1 功能简介.....	1816
93.2 表间关系.....	1817
93.3 单节点详细描述.....	1817
93.3.1 hwPMStatisticsEnable 详细描述.....	1818
93.3.2 hwPMStatisticsMaxFilesPerTask 详细描述.....	1818
93.3.3 hwPMStatisticsMaxTasks 详细描述.....	1819
93.3.4 hwPMStatisticsCurrentTasks 详细描述.....	1819
93.3.5 hwPMStatisticsTaskIndicateLowValue 详细描述.....	1819
93.3.6 hwPMStatisticsTaskIndicateHighValue 详细描述.....	1820
93.4 MIB Table 详细描述.....	1820
93.4.1 hwPMStatisticsTaskTable 详细描述.....	1820

93.4.2 hwPMStatisticsTaskInstanceTable 详细描述.....	1824
93.4.3 hwPMStatisticsTaskIndicatorTable 详细描述.....	1825
93.4.4 hwPMStatisticsTaskThresholdRuleTable 详细描述.....	1826
93.4.5 hwPMStatisticsTaskFileTable 详细描述.....	1828
93.4.6 hwPMServerTable 详细描述.....	1829
93.4.7 hwPMFileUploadCfgTable 详细描述.....	1834
93.4.8 hwPMFileUploadMgmtTable 详细描述.....	1835
93.4.9 hwPMHistoryDataTable 详细描述.....	1837
93.4.10 hwPMCurrentDataTable 详细描述.....	1839
93.4.11 hwPMIntervalTypeTable 详细描述.....	1842
93.4.12 hwPMInstanceTypeTable 详细描述.....	1844
93.4.13 hwPMIndicatorTable 详细描述.....	1845
93.5 告警节点详细描述.....	1846
93.5.1 hwPMStatisticsTaskThresholdClearAlarm 详细描述.....	1847
93.5.2 hwPMStatisticsTaskThresholdTriggerAlarm 详细描述.....	1848
93.5.3 hwPMMeasureExceed 详细描述.....	1849
94 HUAWEI-PERFORMANCE-MIB.....	1850
94.1 功能简介.....	1850
94.2 表间关系.....	1850
94.3 单节点详细描述.....	1850
94.4 MIB Table 详细描述.....	1850
94.4.1 prialarmTable 详细描述.....	1850
94.5 告警节点详细描述.....	1855
94.5.1 pririsingAlarm 详细描述.....	1855
94.5.2 prifallingAlarm 详细描述.....	1855
95 HUAWEI-PIM-BSR-MIB.....	1856
95.1 功能简介.....	1856
95.2 表间关系.....	1856
95.3 单节点详细描述.....	1856
95.4 MIB Table 详细描述.....	1856
95.4.1 hwPimBsrElectedBsrRpSetTable 详细描述.....	1857
95.5 告警节点详细描述.....	1858
96 HUAWEI-PIM-STD-MIB.....	1859
96.1 功能简介.....	1859
96.2 表间关系.....	1859
96.3 单节点详细描述.....	1860
96.3.1 hwPimkeepalivePeriod 详细描述.....	1860
96.3.2 hwPimRegisterSuppressionTime 详细描述.....	1860
96.3.3 hwPimStarGEntries 详细描述.....	1861
96.3.4 hwPimStarGIEntries 详细描述.....	1861
96.3.5 hwPimSGEntries 详细描述.....	1861

96.3.6 hwPimSGIEntries 详细描述.....	1861
96.3.7 hwPimSGRptEntries 详细描述.....	1862
96.3.8 hwPimSGRptIEntries 详细描述.....	1862
96.3.9 hwPimOutAsserts 详细描述.....	1862
96.3.10 hwPimInAsserts 详细描述.....	1862
96.3.11 hwPimLastAssertInterface 详细描述.....	1863
96.3.12 hwPimLastAssertGroupAddressType 详细描述.....	1863
96.3.13 hwPimLastAssertGroupAddress 详细描述.....	1863
96.3.14 hwPimLastAssertSourceAddressType 详细描述.....	1864
96.3.15 hwPimLastAssertSourceAddress 详细描述.....	1864
96.3.16 hwPimNeighborLossNotificationPeriod 详细描述.....	1864
96.3.17 hwPimNeighborLossCount 详细描述.....	1865
96.3.18 hwPimInvalidRegisterNotificationPeriod 详细描述.....	1865
96.3.19 hwPimInvalidRegisterMsgsRcvd 详细描述.....	1865
96.3.20 hwPimInvalidRegisterAddressType 详细描述.....	1866
96.3.21 hwPimInvalidRegisterOrigin 详细描述.....	1866
96.3.22 hwPimInvalidRegisterGroup 详细描述.....	1866
96.3.23 hwPimInvalidRegisterRp 详细描述.....	1867
96.3.24 hwPimInvalidJoinPruneNotificationPeriod 详细描述.....	1867
96.3.25 hwPimInvalidJoinPruneMsgsRcvd 详细描述.....	1867
96.3.26 hwPimInvalidJoinPruneAddressType 详细描述.....	1868
96.3.27 hwPimInvalidJoinPruneOrigin 详细描述.....	1868
96.3.28 hwPimInvalidJoinPruneGroup 详细描述.....	1868
96.3.29 hwPimInvalidJoinPruneRp 详细描述.....	1869
96.3.30 hwPimRpMappingNotificationPeriod 详细描述.....	1869
96.3.31 hwPimRpMappingChangeCount 详细描述.....	1869
96.3.32 hwPimInterfaceElectionNotificationPeriod 详细描述.....	1869
96.3.33 hwPimInterfaceElectionWinCount 详细描述.....	1870
96.3.34 hwPimRefreshInterval 详细描述.....	1870
96.3.35 hwPimDeviceConfigStorageType 详细描述.....	1870
96.3.36 hwPimNeighborAddCount 详细描述.....	1871
96.3.37 hwPimNeighborAddNotificationPeriod 详细描述.....	1871
96.3.38 hwPimMrtLimitAddressType 详细描述.....	1871
96.3.39 hwPimMrtLimitSource 详细描述.....	1872
96.3.40 hwPimMrtLimitGroup 详细描述.....	1872
96.3.41 hwPimInstanceId 详细描述.....	1872
96.3.42 hwPimInstanceName 详细描述.....	1872
96.3.43 hwPimNeighborNotificationReason 详细描述.....	1873
96.3.44 hwPimNotificationAddressType 详细描述.....	1874
96.3.45 hwPimStarGCurrentCount 详细描述.....	1874
96.3.46 hwPimStarGTotalCount 详细描述.....	1874
96.3.47 hwPimStarGThreshold 详细描述.....	1874

96.3.48 hwPimSGCurrentCount 详细描述.....	1875
96.3.49 hwPimSGTotalCount 详细描述.....	1875
96.3.50 hwPimSGThreshold 详细描述.....	1875
96.3.51 hwPimNotificationSrcAddr 详细描述.....	1875
96.3.52 hwPimNotificationGrpAddr 详细描述.....	1876
96.4 MIB Table 详细描述.....	1876
96.4.1 hwPimInterfaceTable 详细描述.....	1876
96.4.2 hwPimNeighborTable 详细描述.....	1881
96.4.3 hwPimNbrSecAddressTable 详细描述.....	1884
96.4.4 hwPimStarGTable 详细描述.....	1886
96.4.5 hwPimStarGTable 详细描述.....	1891
96.4.6 hwPimSGTable 详细描述.....	1894
96.4.7 hwPimSGTable 详细描述.....	1900
96.4.8 hwPimSGRptTable 详细描述.....	1903
96.4.9 hwPimSGRptITable 详细描述.....	1904
96.4.10 hwPimGroupMappingTable 详细描述.....	1905
96.4.11 hwPimGlobalCtlMsgCountTable 详细描述.....	1907
96.4.12 hwPimInterfaceCtlMsgCountTable 详细描述.....	1908
96.5 告警节点详细描述.....	1910
96.5.1 hwPimNeighborLoss 详细描述.....	1910
96.5.2 hwPimInvalidRegister 详细描述.....	1911
96.5.3 hwPimInvalidJoinPrune 详细描述.....	1911
96.5.4 hwPimRpMappingChange 详细描述.....	1912
96.5.5 hwPimInterfaceElection 详细描述.....	1912
96.5.6 hwPimNeighborAdd 详细描述.....	1913
96.5.7 hwPimMrtLimit 详细描述.....	1913
96.5.8 hwPimMrtLimitClear 详细描述.....	1913
97 HUAWEI-POE-MIB.....	1914
97.1 功能简介.....	1914
97.2 表间关系.....	1915
97.3 单节点详细描述.....	1915
97.4 MIB Table 详细描述.....	1915
97.4.1 hwPoeSlotTable 详细描述.....	1915
97.4.2 hwPoePortTable 详细描述.....	1917
97.4.3 hwPoePowerInfoTable 详细描述.....	1922
97.4.4 hwPoePortJudgeTable 详细描述.....	1924
97.4.5 hwPoeMultiMcuTable 详细描述.....	1924
97.5 告警节点详细描述.....	1925
97.5.1 hwPoePowerOff 详细描述.....	1926
97.5.2 hwPoePowerOn 详细描述.....	1926
97.5.3 hwPoePdConnected 详细描述.....	1926
97.5.4 hwPoePdDisconnected 详细描述.....	1926

97.5.5 hwPoePdClassInvalid 详细描述.....	1927
97.5.6 hwPoePdClassOvercurrent 详细描述.....	1927
97.5.7 hwPoePdPriorityDifferent 详细描述.....	1927
97.5.8 hwPoePowerOverUtilizationThreshold 详细描述.....	1928
97.5.9 hwPoePowerOverUtilizationThresholdResume 详细描述.....	1928
97.5.10 hwPoePowerAbsent 详细描述.....	1928
97.5.11 hwPoePowerAbsentResume 详细描述.....	1929
97.5.12 hwPoeRpsPowerOutputAlarm 详细描述.....	1929
97.5.13 hwPoeRpsPowerOutputAlarmResume 详细描述.....	1929
97.5.14 hwPoeCardAbsent 详细描述.....	1930
97.5.15 hwPoePortFail 详细描述.....	1930
97.5.16 hwPoePortFailResume 详细描述.....	1931
97.6 不支持节点.....	1931
98 HUAWEI-PORT-MIB.....	1933
98.1 功能简介.....	1933
98.2 表间关系.....	1933
98.3 单节点详细描述.....	1933
98.4 MIB Table 详细描述.....	1933
98.4.1 hwEthernetTable 详细描述.....	1933
98.4.2 hwPhysicalPortTable 详细描述.....	1936
98.4.3 hwPortAlarmThresholdTable 详细描述.....	1939
98.4.4 hwPortProtectGroupCfgTable 详细描述.....	1940
98.4.5 hwPortDescriptionTable 详细描述.....	1941
98.4.6 hwIPIfStatTable 详细描述.....	1942
98.5 告警节点详细描述.....	1944
98.5.1 hwInputDiscardNotice 详细描述.....	1945
98.5.2 hwOutputDiscardNotice 详细描述.....	1945
98.5.3 hwInputRateChangeOverThresholdNotice 详细描述.....	1946
98.5.4 hwOutputRateChangeOverThresholdNotice 详细描述.....	1946
98.5.5 hwNotSameBoardInTrunk 详细描述.....	1947
98.5.6 hwPortLRMStateAbnormal 详细描述.....	1947
98.5.7 hwPortSfpNotSupportSingleFiber 详细描述.....	1947
98.5.8 hwPhysicalPortCrcRatioExceed 详细描述.....	1947
98.5.9 hwPhysicalPortCrcRatioResume 详细描述.....	1948
98.5.10 hwPhysicalPortInBroadcastRapidChange 详细描述.....	1949
98.5.11 hwSubIfNumExceededSpecAlarm 详细描述.....	1949
98.5.12 hwSubIfNumExceededSpecAlarmResume 详细描述.....	1949
98.5.13 hwTunnellIfNumExceededSpecAlarm 详细描述.....	1950
98.5.14 hwCableSnrAbnormal 详细描述.....	1950
98.5.15 hwCableSnrNormal 详细描述.....	1950
98.5.16 hwCableSnrDetectNotSupport 详细描述.....	1951
98.5.17 hwVxlanTrunkHashNotSupport 详细描述.....	1951

98.5.18 hwPortErrPktSpeedDownGrade 详细描述.....	1952
98.5.19 hwPortErrPktSpeedDownGradeResume 详细描述.....	1952
99 HUAWEI-PORTAL-MIB.....	1953
99.1 功能简介.....	1953
99.2 表间关系.....	1953
99.3 单节点详细描述.....	1953
99.3.1 hwWebAuthServerListeningPort 详细描述.....	1954
99.3.2 hwWebAuthServerReplyMessage 详细描述.....	1954
99.3.3 hwWebAuthServerVersione 详细描述.....	1954
99.3.4 hwPortalOfflineDetect 详细描述.....	1954
99.3.5 hwPortalLocalServerIp 详细描述.....	1955
99.3.6 hwPortalLocalServerSSLPolicyName 详细描述.....	1955
99.3.7 hwPortalLocalServerSSLPolicyPortNum 详细描述.....	1955
99.3.8 hwPortalMaxUser 详细描述.....	1955
99.3.9 hwPortalLocalServerAuthMethod 详细描述.....	1956
99.3.10 hwPortalUserAlarmPercentageLower 详细描述.....	1956
99.3.11 hwPortalUserAlarmPercentageUpper 详细描述.....	1956
99.3.12 hwPortalCaptiveBypassEnable 详细描述.....	1956
99.3.13 hwPortalCaptiveAdaptiveEnable 详细描述.....	1957
99.4 MIB Table 详细描述.....	1957
99.4.1 hwPortalConfigPara 详细描述.....	1957
99.4.2 hwPortalFreeRuleTable 详细描述.....	1958
99.4.3 hwWebAuthServerCfgTable 详细描述.....	1961
99.4.4 hwWebAuthServerIpCfgTable 详细描述.....	1969
99.4.5 hwWebAuthenCfgTable 详细描述.....	1970
99.4.6 hwWebAuthenAuthNetWorkCfgTable 详细描述.....	1971
99.4.7 hwWebAuthenLocalServerCfgTable 详细描述.....	1972
99.4.8 hwPortalUrlTemplateCfgTable 详细描述.....	1973
99.4.9 hwUrlTemplateUrlCfgTable 详细描述.....	1976
99.5 告警节点详细描述.....	1977
99.5.1 hwPortalServerUp 详细描述.....	1977
99.5.2 hwPortalServerDown 详细描述.....	1978
99.5.3 hwPortalMaxUserAlarm 详细描述.....	1978
99.5.4 hwPortalUserClearAlarm 详细描述.....	1978
99.5.5 hwPortalPassDNS 详细描述.....	1979
99.6 不支持节点.....	1979
100 HUAWEI-PTP-MIB.....	1981
100.1 功能简介.....	1981
100.2 表间关系.....	1981
100.3 单节点详细描述.....	1981
100.3.1 hwPtpChassisIndex 详细描述.....	1982
100.3.2 hwPtpChassisDeviceType 详细描述.....	1982

100.3.3 hwPtpChassisSlaveOnly 详细描述.....	1983
100.3.4 hwPtpChassisLocalClockId 详细描述.....	1983
100.3.5 hwPtpChassisLocalClockAccuracy 详细描述.....	1984
100.3.6 hwPtpChassisLocalClockClass 详细描述.....	1985
100.3.7 hwPtpChassisLocalClockPriority1 详细描述.....	1985
100.3.8 hwPtpChassisLocalClockPriority2 详细描述.....	1986
100.3.9 hwPtpChassisLocalClockTimeSource 详细描述.....	1986
100.3.10 hwPtpChassisLocalClockLocalPriority 详细描述.....	1987
100.3.11 hwPtpEnable 详细描述.....	1987
100.3.12 hwPtpDomain 详细描述.....	1987
100.3.13 hwPtpDeviceType 详细描述.....	1988
100.3.14 hwPtpSlaveOnly 详细描述.....	1989
100.3.15 hwPtpLocalClockId 详细描述.....	1989
100.3.16 hwPtpLocalClockAccuracy 详细描述.....	1990
100.3.17 hwPtpLocalClockClass 详细描述.....	1991
100.3.18 hwPtpLocalClockPriority1 详细描述.....	1991
100.3.19 hwPtpLocalClockPriority2 详细描述.....	1992
100.3.20 hwPtpLocalClockTimeSource 详细描述.....	1992
100.3.21 hwPtpVersion 详细描述.....	1993
100.3.22 hwPtpProfile 详细描述.....	1993
100.4 MIB Table 详细描述.....	1993
100.4.1 hwPtpPortTable 详细描述.....	1993
100.4.2 hwPtpPortStatisticTable 详细描述.....	2002
100.5 告警节点详细描述.....	2005
100.5.1 hwPTPRingFiberLengthChange 详细描述.....	2005
100.5.2 hwPTPRingFiberLengthChangeResume 详细描述.....	2005
100.5.3 hwPtpTimeLockFail 详细描述.....	2005
100.5.4 hwPtpTimeLockFailResume 详细描述.....	2006
100.5.5 hwPtpFrequencyLockFail 详细描述.....	2006
100.5.6 hwPtpFrequencyLockResume 详细描述.....	2006
100.5.7 hwPtpPortStateChange 详细描述.....	2007
100.5.8 hwPtpPassiveFiberLengthChange 详细描述.....	2007
100.5.9 hwPtpClockSourceChange 详细描述.....	2007
100.5.10 hwPtpPortBmcInfoChange 详细描述.....	2008
100.5.11 hwPtpTimeSourceClockClassDecline 详细描述.....	2008
100.5.12 hwPtpTimeSourceClockClassDeclineResume 详细描述.....	2008
100.5.13 hwPtpPktLos 详细描述.....	2008
100.5.14 hwPtpPktLosResume 详细描述.....	2009
100.5.15 hwPtpTimeOffsetSumOver 详细描述.....	2009
100.5.16 hwPtpTimeOffsetSumOverResume 详细描述.....	2009
100.5.17 hwPtpTimeSyncFaulty 详细描述.....	2009
100.5.18 hwPtpTimeSyncResume 详细描述.....	2010

101 HUAWEI-PWE3-MIB.....	2011
101.1 功能简介.....	2011
101.2 表间关系.....	2012
101.3 单节点详细描述.....	2013
101.3.1 hwPWVcStateChangeReason 详细描述.....	2014
101.3.2 hwSvcStateChangeReason 详细描述.....	2020
101.4 MIB Table 详细描述.....	2025
101.4.1 hwPWVcTable 详细描述.....	2025
101.4.2 hwPWVcTnlTable 详细描述.....	2043
101.4.3 hwPWRemoteVcTable 详细描述.....	2043
101.4.4 hwSvcTable 详细描述.....	2047
101.4.5 hwSvcTnlTable 详细描述.....	2054
101.4.6 hwSvcExtTable 详细描述.....	2055
101.4.7 hwPWTemplateTable 详细描述.....	2061
101.5 告警节点详细描述.....	2065
101.5.1 hwPwVcSwitchWtoP 详细描述.....	2065
101.5.2 hwPwVcSwitchPtoW 详细描述.....	2065
101.5.3 hwPWVcDeleted 详细描述.....	2066
101.5.4 hwPwVcDown 详细描述.....	2067
101.5.5 hwPwVcUp 详细描述.....	2068
101.5.6 hwPWVcBackup 详细描述.....	2069
101.5.7 hwSvcDeleted 详细描述.....	2069
101.5.8 hwSvcDown 详细描述.....	2070
101.5.9 hwSvcUp 详细描述.....	2071
101.5.10 hwSvcSwitchWtoP 详细描述.....	2071
101.5.11 hwSvcSwitchPtoW 详细描述.....	2072
101.5.12 hwPWVcStatusChange 详细描述.....	2072
101.5.13 hwVpwsPwRedundancyDegraded 详细描述.....	2072
101.5.14 hwVpwsPwRedundancyDegradedClear 详细描述.....	2072
101.6 附录.....	2073
101.6.1 hwPwStateChangeReason.....	2073
101.6.2 hwPwVcType.....	2074
102 HUAWEI-PWE3-TNL-MIB.....	2076
102.1 功能简介.....	2076
102.2 表间关系.....	2076
102.3 MIB Table 详细描述.....	2076
102.3.1 hwPwe3TunnelTable 详细描述.....	2076
102.3.2 hwPwe3ExtTunnelTable 详细描述.....	2082
103 HUAWEI-QINQ-MIB.....	2088
103.1 功能简介.....	2088
103.2 表间关系.....	2089
103.3 MIB Table 详细描述.....	2092

103.3.1 hwQinQBpduTunnelTable 详细描述.....	2092
103.3.2 hwQinQModeCfgTable 详细描述.....	2094
103.3.3 hwQinQSubIfStackingStatTable 详细描述.....	2095
103.3.4 hwQinQSubIfTermTable 详细描述.....	2098
103.3.5 hwQinQSubIfVlanStackingTable 详细描述.....	2100
103.3.6 hwQinQStaticARPCfgTable 详细描述.....	2102
103.3.7 hwQinQStaticMACCfgTable 详细描述.....	2103
103.3.8 hwQinQSubIfDot1qTermTable 详细描述.....	2106
103.3.9 hwQinQStackingVlanCfgTable 详细描述.....	2108
103.3.10 hwQinQSubIfMapTable 详细描述.....	2109
103.4 告警节点详细描述.....	2111
103.5 不支持节点.....	2111
104 HUAWEI-RIPV2-EXT-MIB.....	2112
104.1 功能简介.....	2112
104.2 表间关系.....	2112
104.3 单节点详细描述.....	2112
104.4 MIB Table 详细描述.....	2113
104.4.1 hwRip2ProcInstTable 详细描述.....	2113
104.5 告警节点详细描述.....	2114
104.5.1 hwRip2DBOverFlow 详细描述.....	2114
104.5.2 hwRip2DBOverFlowResume 详细描述.....	2114
105 HUAWEI-RM-EXT-MIB.....	2115
105.1 功能简介.....	2115
105.2 表间关系.....	2115
105.3 单节点详细描述.....	2115
105.3.1 hwCurlpv4PrefixNum 详细描述.....	2115
105.3.2 hwIpv4PrefixLimitValue 详细描述.....	2116
105.3.3 hwCurlpv6PrefixNum 详细描述.....	2116
105.3.4 hwIpv6PrefixLimitValue 详细描述.....	2116
105.3.5 hwIpv6PrefixLimitVpnName 详细描述.....	2116
105.4 MIB Table 详细描述.....	2116
105.4.1 hwRouteStatTable 详细描述.....	2117
105.4.2 hwIpv6RouteStatTable 详细描述.....	2118
105.4.3 hwStaticRouteExtTable 详细描述.....	2119
105.4.4 hwIpv6StaticRouteTable 详细描述.....	2121
105.4.5 hwRmInfo 详细描述.....	2124
105.5 告警节点详细描述.....	2125
105.5.1 hwTunnelGroupUp 详细描述.....	2125
105.5.2 hwTunnelGroupDown 详细描述.....	2126
105.5.3 hwPublicIpv4PrefixExceed 详细描述.....	2126
105.5.4 hwPublicIpv4PrefixExceedClear 详细描述.....	2126
105.5.5 hwPublicIpv4PrefixThresholdExceed 详细描述.....	2126

105.5.6 hwPublicIpv4PrefixThresholdExceedClear 详细描述.....	2127
105.5.7 hwPublicIpv6PrefixExceed 详细描述.....	2127
105.5.8 hwPublicIpv6PrefixExceedClear 详细描述.....	2127
105.5.9 hwPublicIpv6PrefixThresholdExceed 详细描述.....	2127
105.5.10 hwPublicIpv6PrefixThresholdExceedClear 详细描述.....	2128
106 HUAWEI-RRPP-MIB.....	2129
106.1 功能简介.....	2129
106.2 表间关系.....	2130
106.3 单节点详细描述.....	2130
106.3.1 hwRrppEnableStatus 详细描述.....	2130
106.3.2 hwRrppLinkupDelayTime 详细描述.....	2131
106.4 MIB Table 详细描述.....	2131
106.4.1 hwRrppDomainTable 详细描述.....	2131
106.4.2 hwRrppRingTable 详细描述.....	2133
106.4.3 hwRrppPortTable 详细描述.....	2137
106.4.4 hwRrppRingGroupTable 详细描述.....	2141
106.4.5 hwRrppRingGroupMemberTable 详细描述.....	2142
106.4.6 hwRrppSnoopingInterfaceTable 详细描述.....	2143
106.4.7 hwRrppSnoopingVsiTable 详细描述.....	2145
106.5 告警节点详细描述.....	2146
106.5.1 hwRrppRingRecover 详细描述.....	2146
106.5.2 hwRrppRingFail 详细描述.....	2146
106.5.3 hwRrppMultiMaster 详细描述.....	2146
107 HUAWEI-RSVPTE-MIB.....	2147
107.1 功能简介.....	2147
107.2 表间关系.....	2148
107.3 单节点详细描述.....	2151
107.3.1 hwRsvpTeNbr 详细描述.....	2151
107.3.2 hwRsvpTelfNbrCurrentCount 详细描述.....	2151
107.3.3 hwRsvpTelfNbrThreshold 详细描述.....	2151
107.3.4 hwRsvpTelfNbrTotalCount 详细描述.....	2152
107.3.5 hwRsvpTelfName 详细描述.....	2152
107.4 MIB Table 详细描述.....	2152
107.4.1 hwRsvpTeSessionTable 详细描述.....	2152
107.4.2 hwRsvpTeSenderTable 详细描述.....	2155
107.4.3 hwRsvpTeResvTable 详细描述.....	2172
107.4.4 hwRsvpTeResvFwdTable 详细描述.....	2178
107.4.5 hwRsvpTelfTable 详细描述.....	2184
107.4.6 hwRsvpTeNbrTable 详细描述.....	2187
107.4.7 hwRsvpTeMessagIdTable 详细描述.....	2190
107.4.8 hwRsvpTeFilterSpecTable 详细描述.....	2191
107.4.9 hwRsvpTeRroTable 详细描述.....	2192

107.4.10 hwRsvpTeEroTable 详细描述.....	2194
107.5 告警节点详细描述.....	2195
107.5.1 hwRsvpTeHelloLost 详细描述.....	2195
107.5.2 hwRsvpTeHelloLostRecovery 详细描述.....	2195
107.5.3 hwRsvpTeAuthFail 详细描述.....	2195
107.5.4 hwRsvpTeAuthSuccess 详细描述.....	2195
107.5.5 hwRsvpTelfNbrThresholdExceed 详细描述.....	2196
107.5.6 hwRsvpTelfNbrThresholdExceedClear 详细描述.....	2196
107.5.7 hwRsvpTelfNbrTotalCountExceed 详细描述.....	2196
107.5.8 hwRsvpTelfNbrTotalCountExceedClear 详细描述.....	2197
108 HUAWEI-RUMNG-MIB.....	2198
108.1 功能简介.....	2198
108.2 表间关系.....	2198
108.3 单节点详细描述.....	2198
108.4 MIB Table 详细描述.....	2198
108.4.1 hwRuMngDevTable 详细描述.....	2199
108.4.2 hwRuMngPortTable 详细描述.....	2201
108.4.3 hwRuMngSfpTable 详细描述.....	2203
108.5 告警节点详细描述.....	2205
108.5.1 hwRuMngRuLinkAbnormal 详细描述.....	2205
108.5.2 hwRuMngRuLinkNormal 详细描述.....	2205
108.5.3 hwRuMngRuPortLinkDown 详细描述.....	2206
108.5.4 hwRuMngRuPortLinkUp 详细描述.....	2206
108.5.5 hwRuPortInputDiscardNotice 详细描述.....	2206
108.5.6 hwRuPortOutputDiscardNotice 详细描述.....	2207
108.5.7 hwRuPortCrcErrorRising 详细描述.....	2208
108.5.8 hwRuPortCrcErrorResume 详细描述.....	2208
108.5.9 hwRuPortInputRateRising 详细描述.....	2209
108.5.10 hwRuPortInputRateResume 详细描述.....	2209
108.5.11 hwRuPortOutputRateRising 详细描述.....	2209
108.5.12 hwRuPortOutputRateResume 详细描述.....	2210
108.5.13 hwRuPortOpticalPowerAbnormal 详细描述.....	2210
108.5.14 hwRuPortOpticalPowerResume 详细描述.....	2211
108.5.15 hwRuMngDevFull 详细描述.....	2211
108.5.16 hwRuMngFirmwareUpdateFail 详细描述.....	2211
108.5.17 hwRuMngPortRuFull 详细描述.....	2212
108.5.18 hwRuMngOnline 详细描述.....	2212
108.5.19 hwRuMngOffline 详细描述.....	2212
108.5.20 hwRuPseV33Abnormal 详细描述.....	2213
108.5.21 hwRuPseV33Resume 详细描述.....	2213
108.5.22 hwRuPsePowerStatAbnormal 详细描述.....	2213
108.5.23 hwRuPsePowerStatResume 详细描述.....	2213

108.5.24 hwRuTemperatureAbnormal 详细描述.....	2214
108.5.25 hwRuTemperatureResume 详细描述.....	2214
108.5.26 hwRuPhyStatAbnormal 详细描述.....	2214
108.5.27 hwRuPhyStatResume 详细描述.....	2214
108.5.28 hwRuIICFault 详细描述.....	2215
108.5.29 hwRuAuthFail 详细描述.....	2215
108.5.30 hwRuAuthSuccess 详细描述.....	2215
108.5.31 hwRuPortCongestAlarm 详细描述.....	2215
108.5.32 hwRuPortCongestResume 详细描述.....	2216
108.5.33 hwRuUartStatAbnormal 详细描述.....	2216
108.5.34 hwRuUartStatResume 详细描述.....	2216
109 HUAWEI-SECURITY-MIB.....	2217
109.1 功能简介.....	2217
109.2 表间关系.....	2217
109.3 单节点详细描述.....	2217
109.3.1 hwOlcSlotStr 详细描述.....	2218
109.3.2 hwOlcThreshold1 详细描述.....	2218
109.3.3 hwOlcCurrentCpuUsage 详细描述.....	2218
109.3.4 hwOlcCpuSampleCycle 详细描述.....	2218
109.3.5 hwEngineFlowSlot 详细描述.....	2219
109.3.6 hwEngineFlowTotalNum 详细描述.....	2219
109.3.7 hwEngineFlowUsedNum 详细描述.....	2219
109.3.8 hwEngineFlowThreshold 详细描述.....	2220
109.3.9 hwEngineAppFeatureSlot 详细描述.....	2220
109.3.10 hwEngineAppFeatureTotalNum 详细描述.....	2220
109.3.11 hwEngineAppFeatureUsedNum 详细描述.....	2221
109.3.12 hwEngineAppFeatureThreshold 详细描述.....	2221
109.3.13 hwEngineFlowAlarm 详细描述.....	2221
109.3.14 hwEngineFlowAlarmResume 详细描述.....	2222
109.3.15 hwEngineAppFeatureAlarm 详细描述.....	2222
109.3.16 hwEngineAppFeatureAlarmResume 详细描述.....	2222
109.4 MIB Table 详细描述.....	2222
109.4.1 hwTrafficSuppressionTable 详细描述.....	2223
109.5 告警节点详细描述.....	2223
109.5.1 hwStrackUserInfo 详细描述.....	2224
109.5.2 hwStrackIfVlanInfo 详细描述.....	2224
109.5.3 hwStrackDenyPacket 详细描述.....	2225
109.5.4 hwStrackErrorDown 详细描述.....	2225
109.5.5 hwStrackIpInfo 详细描述.....	2225
109.5.6 hwArpsGatewayConflict 详细描述.....	2226
109.5.7 hwArpsEntryCheck 详细描述.....	2226
109.5.8 hwArpsPacketCheck 详细描述.....	2227

109.5.9 hwArpsDaiDropALarm 详细描述.....	2227
109.5.10 hwArpGlobleSpeedLimitALarm 详细描述.....	2227
109.5.11 hwArpIfSpeedLimitALarm 详细描述.....	2227
109.5.12 hwArpVlanSpeedLimitALarm 详细描述.....	2228
109.5.13 hwArpMissGlobleSpeedLimitALarm 详细描述.....	2228
109.5.14 hwArpMissIfSpeedLimitALarm 详细描述.....	2228
109.5.15 hwArpMissVlanSpeedLimitALarm 详细描述.....	2229
109.5.16 hwArpSourceIpSpeedLimitALarm 详细描述.....	2229
109.5.17 hwArpMissSourceIpSpeedLimitALarm 详细描述.....	2229
109.5.18 hwArpIfRateLimitBlockALarm 详细描述.....	2230
109.5.19 hwArpSourceMacSpeedLimitAlarm 详细描述.....	2230
109.5.20 hwArpsDaiBDDropALarm 详细描述.....	2230
109.5.21 hwArpsDaiVlanDropALarm 详细描述.....	2231
109.5.22 hwIPSGDropALarm 详细描述.....	2231
109.5.23 hwIPSGVlanDropALarm 详细描述.....	2231
109.5.24 hwIPSGv4ResourceALarm 详细描述.....	2231
109.5.25 hwIPSGv4ResourceResume 详细描述.....	2232
109.5.26 hwIPSGv6ResourceALarm 详细描述.....	2232
109.5.27 hwIPSGv6ResourceResume 详细描述.....	2232
109.5.28 hwIcmpGlobalDropALarm 详细描述.....	2232
109.5.29 hwIcmpIfDropALarm 详细描述.....	2233
109.5.30 hwCpcarDropPacketAlarm 详细描述.....	2233
109.5.31 hwStrackPortAtk 详细描述.....	2233
109.5.32 hwOlcStartAlarm 详细描述.....	2234
109.5.33 hwOlcStopAlarm 详细描述.....	2234
109.5.34 hwEngineSessThresholdAlarm 详细描述.....	2234
109.5.35 hwEngineSessThresholdResume 详细描述.....	2235
109.5.36 hwWeakEAConfigAlarm 详细描述.....	2235
109.5.37 hwTerminalStatusAbnormal 详细描述.....	2235
109.5.38 hwTerminalStatusResume 详细描述.....	2236
109.5.39 hwTerminalNumAlarm 详细描述.....	2236
109.5.40 hwEngineFlowAlarm 详细描述.....	2236
109.5.41 hwEngineFlowAlarmResume 详细描述.....	2236
109.5.42 hwEngineAppFeatureAlarm 详细描述.....	2237
109.5.43 hwEngineAppFeatureAlarmResume 详细描述.....	2237
109.5.44 hwSSHAttackAlarm 详细描述.....	2237
109.6 不支持节点.....	2238
110 HUAWEI-SECURITY-PKI-MIB.....	2239
110.1 功能简介.....	2239
110.2 表间关系.....	2239
110.3 单节点详细描述.....	2239
110.3.1 hwPKICrlUrl 详细描述.....	2239

110.3.2 hwPKILdapIP 详细描述.....	2240
110.3.3 hwPKILdapPort 详细描述.....	2240
110.3.4 hwPKILdapVersion 详细描述.....	2240
110.3.5 hwPKICrlAttribute 详细描述.....	2240
110.3.6 hwPKICrlDN 详细描述.....	2241
110.3.7 hwPKICertUrl 详细描述.....	2241
110.3.8 hwPKICertSaveName 详细描述.....	2241
110.3.9 hwPKICertAttribute 详细描述.....	2241
110.3.10 hwPKICertDN 详细描述.....	2242
110.3.11 hwCACertStartTime 详细描述.....	2242
110.3.12 hwPKICACertFinishTime 详细描述.....	2242
110.3.13 hwPKICACertIssuer 详细描述.....	2242
110.3.14 hwPKICACertSubject 详细描述.....	2243
110.3.15 hwPKILocalCertStartTime 详细描述.....	2243
110.3.16 hwPKILocalCertFinishTime 详细描述.....	2243
110.3.17 hwPKILocalCertIssuer 详细描述.....	2243
110.3.18 hwPKILocalCertSubject 详细描述.....	2244
110.3.19 hwPKICrlStartTime 详细描述.....	2244
110.3.20 hwPKICrlFinishTime 详细描述.....	2244
110.3.21 hwPKICrlIssuer 详细描述.....	2244
110.3.22 hwPKICMPUrl 详细描述.....	2245
110.3.23 hwPKICASubject 详细描述.....	2245
110.3.24 hwPKICMPSessionName 详细描述.....	2245
110.3.25 hwPKISCEPUrl 详细描述.....	2245
110.3.26 hwPKIRealmName 详细描述.....	2246
110.3.27 hwPKIKeyName 详细描述.....	2246
110.3.28 hwPKIKeyBit 详细描述.....	2246
110.3.29 hwPKICrlFileName 详细描述.....	2246
110.3.30 hwPKICrlFileLength 详细描述.....	2247
110.3.31 hwPKICrlMaxLength 详细描述.....	2247
110.4 MIB Table 表详细描述.....	2247
110.5 告警节点详细描述.....	2247
110.5.1 hwPKIGetCrlSucHttp 详细描述.....	2247
110.5.2 hwPKIGetCrlFailHttp 详细描述.....	2248
110.5.3 hwPKIGetCrlSucLdap 详细描述.....	2248
110.5.4 hwPKIGetCrlFailLdap 详细描述.....	2248
110.5.5 hwPKIGetCertSucHttp 详细描述.....	2249
110.5.6 hwPKIGetCertFailHttp 详细描述.....	2249
110.5.7 hwPKIGetCertSucLdap 详细描述.....	2249
110.5.8 hwPKIGetCertFailLdap 详细描述.....	2250
110.5.9 hwPKICACertInvalid 详细描述.....	2250
110.5.10 hwPKICACertValid 详细描述.....	2251

110.5.11 hwPKICACertNearlyExpired 详细描述.....	2251
110.5.12 hwPKILocalCertInvalid 详细描述.....	2252
110.5.13 hwPKILocalCertValid 详细描述.....	2252
110.5.14 hwPKILocalCertNearlyExpired 详细描述.....	2253
110.5.15 hwPKICrlInvalid 详细描述.....	2253
110.5.16 hwPKICrlValid 详细描述.....	2254
110.5.17 hwPKICrlNearlyExpired 详细描述.....	2254
110.5.18 hwPKIRequestCertSucCmp 详细描述.....	2254
110.5.19 hwPKIRequestCertFailCmp 详细描述.....	2255
110.5.20 hwPKIRequestCertSucScep 详细描述.....	2255
110.5.21 hwPKIRequestCertFailScep 详细描述.....	2255
110.5.22 hwPKIRsaHrpBackFail 详细描述.....	2256
110.5.23 hwPKIUpdateLocalCertSucCmp 详细描述.....	2256
110.5.24 hwPKIUpdateLocalCertFailCmp 详细描述.....	2256
110.5.25 hwPKIUpdateLocalCertSucScep 详细描述.....	2257
110.5.26 hwPKIUpdateLocalCertFailScep 详细描述.....	2257
110.5.27 hwPKIGetCrlSucScep 详细描述.....	2257
110.5.28 hwPKIGetCrlFailScep 详细描述.....	2258
110.5.29 hwPKICrlLengthExceedThreshold 详细描述.....	2258
111 HUAWEI-SECURITY-IPSEC-MIB.....	2259
111.1 功能简介.....	2259
111.2 告警节点详细描述.....	2259
111.2.1 hwIPSecTunnelStart 详细描述.....	2260
111.2.2 hwIPSecTunnelStop 详细描述.....	2262
111.2.3 hwIPSecPolicyAdd 详细描述.....	2265
111.2.4 hwIPSecPolicyDel 详细描述.....	2265
111.2.5 hwIPSecPolicyAttach 详细描述.....	2266
111.2.6 hwIPSecPolicyDetach 详细描述.....	2267
111.2.7 hwIPSecIKEReset 详细描述.....	2267
111.2.8 hwIPSecIPSecReset 详细描述.....	2268
111.2.9 hwIPSecTunnelReachMax 详细描述.....	2268
111.2.10 hwIPSecTunnelReachMaxAtOnce 详细描述.....	2268
111.2.11 hwIKEPeerReachMax 详细描述.....	2268
111.2.12 hwIKEPeerReachMaxAtOnce 详细描述.....	2268
111.2.13 hwIKESaPhase1Establish 详细描述.....	2269
111.2.14 hwIPSecNegoFail 详细描述.....	2270
111.2.15 hwIPSecTunnelHaveReachMax 详细描述.....	2271
111.2.16 hwIPSecWeakEncr 详细描述.....	2271
112 HUAWEI-SEP-MIB.....	2272
112.1 功能简介.....	2272
112.2 表间关系.....	2273
112.3 单节点详细描述.....	2275

112.3.1 hwSepResetPktCnt 详细描述.....	2275
112.4 MIB Table 详细描述.....	2275
112.4.1 hwSepSegmentTable 详细描述.....	2275
112.4.2 hwSepTopologyTable 详细描述.....	2279
112.4.3 hwSepPortTable 详细描述.....	2284
113 HUAWEI-SNMP-EXT-MIB.....	2292
113.1 功能简介.....	2292
113.2 表间关系.....	2292
113.3 单节点详细描述.....	2292
113.3.1 hwSnmpExtErrorCodeEnable 详细描述.....	2293
113.3.2 hwSnmpListenPort 详细描述.....	2293
113.3.3 hwSnmpRemotIpAddressType 详细描述.....	2293
113.3.4 hwSnmpRemotIpAddress 详细描述.....	2294
113.3.5 hwSnmpRaisingThreshold 详细描述.....	2294
113.3.6 hwSnmpFallingThreshold 详细描述.....	2294
113.4 MIB Table 详细描述.....	2294
113.5 告警节点详细描述.....	2295
113.5.1 hwSNMPLockThreshold 详细描述.....	2295
113.5.2 hwSNMPLockThresholdResume 详细描述.....	2295
114 HUAWEI-SSH-MIB.....	2296
114.1 功能简介.....	2296
114.2 表间关系.....	2296
114.3 单节点详细描述.....	2296
114.3.1 hwStelnetServerEnable 详细描述.....	2297
114.3.2 hwSftpServerEnable 详细描述.....	2297
114.3.3 hwSSHServerComp1x 详细描述.....	2297
114.3.4 hwSSHServerTimeOut 详细描述.....	2298
114.3.5 hwSSHServerRetry 详细描述.....	2298
114.3.6 hwSSHServerPort 详细描述.....	2298
114.3.7 hwSSHServerKeyTimeOut 详细描述.....	2298
114.3.8 hwSftpMaxUserNum 详细描述.....	2299
114.3.9 hwSftpOnLineUserNum 详细描述.....	2299
114.3.10 hwSSHIpv4ServerPort 详细描述.....	2299
114.3.11 hwSSHIpv6ServerPort 详细描述.....	2299
114.3.12 hwStelnetIpv4ServerEnable 详细描述.....	2300
114.3.13 hwStelnetIpv6ServerEnable 详细描述.....	2300
114.3.14 hwSftpIpv4ServerEnable 详细描述.....	2300
114.3.15 hwSftpIpv6ServerEnable 详细描述.....	2300
114.3.16 hwSSHFirstTimeAuthEnable 详细描述.....	2301
114.4 MIB Table 详细描述.....	2301
114.4.1 hwSSHUserTable 详细描述.....	2301
114.4.2 hwSSHServerSessionTable 详细描述.....	2306

114.4.3 hwSSHServerInfoTable 详细描述.....	2309
114.5 告警节点详细描述.....	2311
114.5.1 hwSSHsftpUserNumExceedMax 详细描述.....	2311
115 HUAWEI-STACK-MIB.....	2312
115.1 功能简介.....	2312
115.2 表间关系.....	2327
115.3 单节点详细描述.....	2327
115.3.1 hwStackRun 详细描述.....	2327
115.3.2 hwStackTopoType 详细描述.....	2328
115.3.3 hwStackMacAddressSwitchTime 详细描述.....	2328
115.3.4 hwStackSystemMac 详细描述.....	2328
115.3.5 hwStackIsStackDevice 详细描述.....	2328
115.3.6 hwStackReservedVlanId 详细描述.....	2329
115.3.7 hwStackMemberSpec 详细描述.....	2329
115.3.8 hwStackVlanConflictDescription 详细描述.....	2329
115.3.9 hwStackVlanID 详细描述.....	2329
115.4 MIB Table 详细描述.....	2330
115.4.1 hwStackMemberInfoTable 详细描述.....	2330
115.4.2 hwStackPortTable 详细描述.....	2331
115.4.3 hwStackUpgradeTable 详细描述.....	2332
115.4.4 hwStackUpgradeResultTable 详细描述.....	2335
115.4.5 hwStackMemberPortEnableTable 详细描述.....	2337
115.4.6 hwStackPortInfoTable 详细描述.....	2338
115.5 告警节点详细描述.....	2341
115.5.1 hwStackLinkUp 详细描述.....	2341
115.5.2 hwStackLinkDown 详细描述.....	2341
115.5.3 hwStackStandbyChange 详细描述.....	2341
115.5.4 hwStackSwitchOver 详细描述.....	2341
115.5.5 hwStackSystemRestart 详细描述.....	2342
115.5.6 hwStackStackMemberAdd 详细描述.....	2342
115.5.7 hwStackStackMemberLeave 详细描述.....	2342
115.5.8 hwStackStackMacChange 详细描述.....	2342
115.5.9 hwStackLogicStackPortLinkErr 详细描述.....	2343
115.5.10 hwStackPhyStackPortLinkErr 详细描述.....	2343
115.5.11 hwPhyStackPortIsDown 详细描述.....	2343
115.5.12 hwPhyStackPortDownResume 详细描述.....	2344
115.5.13 hwPhyStackPortIsUp 详细描述.....	2344
115.5.14 hwStackPortConfigureFailed 详细描述.....	2344
115.5.15 hwStackMemberExceedSpec 详细描述.....	2345
115.5.16 hwPhyStackPortErrorDown 详细描述.....	2345
115.5.17 hwPhyStackPortErrorDownRecover 详细描述.....	2345
115.5.18 hwPhyStackVlanConflict 详细描述.....	2345

115.5.19 hwStackPortErrorDown 详细描述.....	2346
115.5.20 hwStackPortErrorDownRecovery 详细描述.....	2346
115.5.21 hwStackSetUpFailure 详细描述.....	2346
115.5.22 hwStackAutoConfigFailed 详细描述.....	2347
115.5.23 hwStackPortLinkErr 详细描述.....	2347
115.5.24 hwStackCmngMemberNumExceedAlarm 详细描述.....	2347
115.5.25 hwStackCmngMemberNumExceedResume 详细描述.....	2348
115.6 不支持节点.....	2348
116 HUAWEI-SWITCH-L2MAM-EXT-MIB.....	2349
116.1 功能简介.....	2349
116.2 单节点详细描述.....	2349
116.2.1 hwMacTrapInterval 详细描述.....	2349
116.3 MIB Table 详细描述.....	2350
116.3.1 hwMacTrapPortCfgTable 详细描述.....	2350
116.4 告警节点详细描述.....	2350
116.4.1 hwMacTrapAlarm 详细描述.....	2351
116.4.2 hwPortVlanSecureMacAlarm 详细描述.....	2351
116.4.3 hwSlotMacUsageRaisingThreshold 详细描述.....	2352
116.4.4 hwSlotMacUsageFallingThreshold 详细描述.....	2352
116.4.5 hwMacTrapHashConflictAlarm 详细描述.....	2352
116.4.6 hwTrunkMemSpeedDifferentAlarm 详细描述.....	2353
116.4.7 hwTrunkMemSpeedDifferentResume 详细描述.....	2353
116.4.8 hwPortsecStaticFlpAlarm 详细描述.....	2353
116.4.9 hwSlotMuxMacUsageAlarm 详细描述.....	2354
116.4.10 hwSlotMuxMacUsageResume 详细描述.....	2354
117 HUAWEI-SWITCH-SRV-RES-TRAP-MIB.....	2355
117.1 功能简介.....	2355
117.2 单节点详细描述.....	2355
117.2.1 hwSrvServiceId 详细描述.....	2355
117.2.2 hwSrvServiceDescr 详细描述.....	2356
117.2.3 hwSrvRecommendThreshold 详细描述.....	2356
117.2.4 hwSrvServiceFailDescr 详细描述.....	2356
117.3 MIB Table 详细描述.....	2356
117.4 告警节点详细描述.....	2356
117.4.1 hwSrvServiceExceedThreshold 详细描述.....	2357
117.4.2 hwSrvServiceExceedThresholdResume 详细描述.....	2357
117.4.3 hwSrvServiceConfigFailed 详细描述.....	2357
118 HUAWEI-SYS-CLOCK-MIB.....	2358
118.1 功能简介.....	2358
118.2 表间关系.....	2358
118.3 单节点详细描述.....	2358

118.3.1 hwUTClock 详细描述.....	2358
119 HUAWEI-SYS-MAN-MIB.....	2359
119.1 功能简介.....	2359
119.2 表间关系.....	2359
119.2.1 表间关系.....	2360
119.3 单节点详细描述.....	2360
119.3.1 hwSysLocalClock 详细描述.....	2360
119.3.2 hwSysReloadSchedule 详细描述.....	2361
119.3.3 hwSysReloadAction 详细描述.....	2361
119.3.4 hwSysReboot 详细描述.....	2362
119.3.5 hwSysRebootTimes 详细描述.....	2362
119.3.6 hwSysSlaveSwitchEnable 详细描述.....	2362
119.3.7 hwSysLatestRebootErrorInfo 详细描述.....	2363
119.3.8 hwSysDelayReboot 详细描述.....	2363
119.3.9 hwSysImageNum 详细描述.....	2363
119.3.10 hwSysCFGFileNum 详细描述.....	2363
119.3.11 hwPatchFileNum 详细描述.....	2364
119.3.12 hwPatchRecordReset 详细描述.....	2364
119.3.13 hwPatchErrorTableMax 详细描述.....	2364
119.3.14 hwPatchFailReason 详细描述.....	2365
119.4 MIB Table 详细描述.....	2365
119.4.1 hwSysCurTable 详细描述.....	2365
119.4.2 hwSysReloadScheduleTable 详细描述.....	2366
119.4.3 hwSysCFGFileTable 详细描述.....	2370
119.4.4 hwSysImageTable 详细描述.....	2371
119.4.5 hwSysSlaveSwitchTable 详细描述.....	2372
119.4.6 hwPatchFileTable 详细描述.....	2373
119.4.7 hwLoadPatchTable 详细描述.....	2374
119.4.8 hwPatchTable 详细描述.....	2376
119.4.9 hwPatchStateTable 详细描述.....	2378
119.4.10 hwPatchHistoryTable 详细描述.....	2378
119.4.11 hwPatchErrorTable 详细描述.....	2379
119.4.12 hwBootRomTable 详细描述.....	2393
119.4.13 hwSysSourceIndexTable 详细描述.....	2395
119.4.14 hwSysRebootRecordTable 详细描述.....	2396
119.5 告警节点详细描述.....	2397
119.5.1 hwSysClockChangedNotification 详细描述.....	2397
119.5.2 hwSysReloadNotification 详细描述.....	2397
119.5.3 hwSysMasterHDError 详细描述.....	2398
119.5.4 hwSysSlaveHDError 详细描述.....	2398
119.5.5 hwPatchErrorTrap 详细描述.....	2398
119.5.6 hwPatchActiveOverTimeTrap 详细描述.....	2398

119.5.7 hwPatchMalfunctionComebackTrap 详细描述.....	2399
119.5.8 hwSysSlaveSwitchSuccessNotification 详细描述.....	2399
119.5.9 hwSysSlaveSwitchFailNotification 详细描述.....	2399
119.6 不支持节点.....	2399
120 HUAWEI-SYS-RES-TRAP-MIB.....	2402
120.1 功能简介.....	2402
120.2 表间关系.....	2402
120.3 单节点详细描述.....	2402
120.4 MIB Table 详细描述.....	2402
120.4.1 hwSysResTrapTable 详细描述.....	2402
120.5 告警节点详细描述.....	2403
120.5.1 hwSysResourceExceed 详细描述.....	2404
120.5.2 hwSysResourceExceedResume 详细描述.....	2404
120.5.3 hwSysResourceThresholdExceed 详细描述.....	2404
120.5.4 hwSysResourceThresholdExceedResume 详细描述.....	2405
120.5.5 hwSysSecureRiskWarning 详细描述.....	2405
120.5.6 hwSysSecureRiskWarningClear 详细描述.....	2405
121 HUAWEI-TCP-MIB.....	2406
121.1 功能简介.....	2406
121.2 表间关系.....	2406
121.3 单节点详细描述.....	2406
121.4 MIB Table 详细描述.....	2406
121.5 告警节点详细描述.....	2407
121.5.1 hwTCPMD5AuthenFail 详细描述.....	2407
121.5.2 hwTCPBindPort 详细描述.....	2407
122 HUAWEI-TFTPC-MIB.....	2408
122.1 功能简介.....	2408
122.2 表间关系.....	2408
122.3 单节点详细描述.....	2408
122.3.1 hwTftpClientSourceAddress 详细描述.....	2409
122.3.2 hwTftpClientSourceInterfaceName 详细描述.....	2409
122.4 MIB Table 详细描述.....	2409
122.5 告警节点详细描述.....	2409
123 HUAWEI-TRNG-MIB.....	2410
123.1 功能简介.....	2410
123.2 表间关系.....	2410
123.3 单节点详细描述.....	2411
123.4 MIB Table 详细描述.....	2411
123.4.1 hwTrngCreateTimerangeTable 详细描述.....	2411
123.4.2 hwTrngAbsoluteTable 详细描述.....	2412
123.4.3 hwTrngPeriodicTable 详细描述.....	2414

123.5 告警节点详细描述.....	2416
124 HUAWEI-TUNNEL-TE-MIB.....	2417
124.1 功能简介.....	2417
124.2 表间关系.....	2418
124.3 单节点详细描述.....	2418
124.4 MIB Table 详细描述.....	2418
124.4.1 hwTunnelTeStatisticsTable 详细描述.....	2418
124.5 不支持节点.....	2419
125 HUAWEI-TWAMP-MIB.....	2423
125.1 功能简介.....	2423
125.2 表间关系.....	2423
125.3 单节点详细描述.....	2423
125.3.1 hwTwampResponderEnable 详细描述.....	2424
125.4 MIB Table 详细描述.....	2424
125.4.1 hwTwampResponderTable 详细描述.....	2424
125.5 告警节点详细描述.....	2428
126 HUAWEI-UNIMNG-MIB.....	2429
126.1 功能简介.....	2429
126.2 表间关系.....	2430
126.3 单节点详细描述.....	2431
126.3.1 hwUniMngEnable 详细描述.....	2432
126.3.2 hwAsAutoReplaceEnable 详细描述.....	2432
126.3.3 hwAsAuthMode 详细描述.....	2432
126.3.4 hwTopomngExploreTime 详细描述.....	2432
126.3.5 hwTopomngLastCollectDuration 详细描述.....	2433
126.3.6 hwVermngFileServerType 详细描述.....	2433
126.3.7 hwTplmConfigCommitAll 详细描述.....	2433
126.3.8 hwAsVpnInstance 详细描述.....	2433
126.4 MIB Table 详细描述.....	2434
126.4.1 hwAsTable 详细描述.....	2434
126.4.2 hwAuthenUserTable 详细描述.....	2437
126.4.3 hwAsIfTable 详细描述.....	2438
126.4.4 hwAsifXTable 详细描述.....	2439
126.4.5 hwAsSlotTable 详细描述.....	2441
126.4.6 hwAsMacWhitelistTable 详细描述.....	2442
126.4.7 hwAsMacBlacklistTable 详细描述.....	2443
126.4.8 hwAsEntityPhysicalTable 详细描述.....	2444
126.4.9 hwAsEntityStateTable 详细描述.....	2446
126.4.10 hwAsEntityAliasMappingTable 详细描述.....	2447
126.4.11 hwTopomngTopoTable 详细描述.....	2448
126.4.12 hwMbrMngFabricPortTable 详细描述.....	2450

126.4.13 hwVermngUpgradeInfoTable 详细描述.....	2451
126.4.14 hwVermngAsTypeCfgInfoTable 详细描述.....	2454
126.4.15 hwTplmASGroupTable 详细描述.....	2456
126.4.16 hwTplmASTable 详细描述.....	2456
126.4.17 hwTplmPortGroupTable 详细描述.....	2457
126.4.18 hwTplmPortTable 详细描述.....	2459
126.4.19 hwTplmConfigManagementTable 详细描述.....	2459
126.4.20 hwUnAuthenUserTable 详细描述.....	2460
126.5 告警节点详细描述.....	2461
126.5.1 hwTopomngLinkNormal 详细描述.....	2461
126.5.2 hwTopomngLinkAbnormal 详细描述.....	2462
126.5.3 hwAsFaultNotify 详细描述.....	2462
126.5.4 hwAsNormalNotify 详细描述.....	2463
126.5.5 hwAsAddOffLineNotify 详细描述.....	2463
126.5.6 hwAsDelOffLineNotify 详细描述.....	2464
126.5.7 hwAsPortStateChangeToDownNotify 详细描述.....	2464
126.5.8 hwAsPortStateChangeToUpNotify 详细描述.....	2464
126.5.9 hwAsModelNotMatchNotify 详细描述.....	2465
126.5.10 hwAsVersionNotMatchNotify 详细描述.....	2465
126.5.11 hwAsNameConflictNotify 详细描述.....	2466
126.5.12 hwAsSlotModelNotMatchNotify 详细描述.....	2466
126.5.13 hwAsFullNotify 详细描述.....	2467
126.5.14 hwUnimngModeNotMatchNotify 详细描述.....	2467
126.5.15 hwAsBoardAddNotify 详细描述.....	2467
126.5.16 hwAsBoardDeleteNotify 详细描述.....	2468
126.5.17 hwAsBoardPlugInNotify 详细描述.....	2468
126.5.18 hwAsBoardPlugOutNotify 详细描述.....	2469
126.5.19 hwAsBlacklistNotify 详细描述.....	2469
126.5.20 hwAsUncofirmedNotify 详细描述.....	2469
126.5.21 hwAsComboPortTypeChangeNotify 详细描述.....	2469
126.5.22 hwAsOnlineFailNotify 详细描述.....	2470
126.5.23 hwAsSlotIdInvalidNotify 详细描述.....	2471
126.5.24 hwAsSysmacSwitchCfgErrNotify 详细描述.....	2471
126.5.25 hwAsSlotOnlineFailNotify 详细描述.....	2472
126.5.26 hwUniMbrConnectError 详细描述.....	2472
126.5.27 hwUniMbrAsDiscoverAttack 详细描述.....	2472
126.5.28 hwUniMbrFabricPortMemberDelete 详细描述.....	2473
126.5.29 hwUniMbrIllegalFabricConfig 详细描述.....	2473
126.5.30 hwVermngUpgradeFail 详细描述.....	2473
126.5.31 hwTplmCmdExecuteFailedNotify 详细描述.....	2474
126.5.32 hwTplmCmdExecuteSuccessfulNotify 详细描述.....	2474
126.5.33 hwTplmDirectCmdRecoverFail 详细描述.....	2474

126.5.34 hwASBrdTempAlarm 详细描述.....	2475
126.5.35 hwASBrdTempResume 详细描述.....	2475
126.5.36 hwASBoardFail 详细描述.....	2476
126.5.37 hwASBoardFailResume 详细描述.....	2476
126.5.38 hwASOpticalInvalid 详细描述.....	2477
126.5.39 hwASOpticalInvalidResume 详细描述.....	2477
126.5.40 hwASPowerRemove 详细描述.....	2478
126.5.41 hwASPowerInsert 详细描述.....	2478
126.5.42 hwASPowerInvalid 详细描述.....	2479
126.5.43 hwASPowerInvalidResume 详细描述.....	2479
126.5.44 hwASFanRemove 详细描述.....	2480
126.5.45 hwASFanInsert 详细描述.....	2480
126.5.46 hwASFanInvalid 详细描述.....	2481
126.5.47 hwASFanInvalidResume 详细描述.....	2481
126.5.48 hwASCommunicateError 详细描述.....	2482
126.5.49 hwASCommunicateResume 详细描述.....	2482
126.5.50 hwASCPUtilizationRising 详细描述.....	2483
126.5.51 hwASCPUtilizationResume 详细描述.....	2484
126.5.52 hwASMemUtilizationRising 详细描述.....	2484
126.5.53 hwASMemUtilizationResume 详细描述.....	2485
126.5.54 hwASMadConflictDetect 详细描述.....	2486
126.5.55 hwASMadConflictResume 详细描述.....	2486
127 HUAWEI-USA-MIB.....	2487
127.1 功能简介.....	2487
127.2 表间关系.....	2487
127.3 单节点详细描述.....	2487
127.3.1 hwUserDetectInterval 详细描述.....	2487
127.3.2 hwUserDetectRetry 详细描述.....	2488
127.3.3 hwUserSyncInterval 详细描述.....	2488
127.3.4 hwGlobalLinkDownOffline 详细描述.....	2488
127.3.5 hwGlobalControlDownOffline 详细描述.....	2489
127.3.6 hwAuthenSpeedLimitMaxNum 详细描述.....	2489
127.3.7 hwAuthenSpeedLimitInterval 详细描述.....	2489
127.3.8 hwAuthenAssociateAlarmRestrained 详细描述.....	2489
127.3.9 hwAuthenAssociateAlarmRestrainedPeriod 详细描述.....	2490
127.4 MIB Table 详细描述.....	2490
127.4.1 hwUSACfgTable 详细描述.....	2490
127.4.2 hwAssociateUserTable 详细描述.....	2492
127.5 告警节点详细描述.....	2494
127.5.1 hwAuthenAssociateAccessLimitTrap 详细描述.....	2494
128 HUAWEI-USC-MIB.....	2496
128.1 功能简介.....	2496

128.2 表间关系.....	2496
128.3 单节点详细描述.....	2496
128.4 MIB Table 详细描述.....	2496
128.4.1 hwUSCConfigTable 详细描述.....	2496
128.5 告警节点详细描述.....	2499
129 HUAWEI-VBST-MIB.....	2500
129.1 功能简介.....	2500
129.2 表间关系.....	2500
129.3 单节点详细描述.....	2500
129.3.1 hwVbstMaxPVNum 详细描述.....	2500
129.3.2 hwVbstVlanNum 详细描述.....	2501
129.3.3 hwVbstTrapVlan 详细描述.....	2501
129.3.4 hwVbstTrapPort 详细描述.....	2501
129.3.5 hwVbstMaxTrunkPVNum 详细描述.....	2501
129.3.6 hwVbstConflictDescription 详细描述.....	2502
129.4 告警节点详细描述.....	2502
129.4.1 hwVbstPVNumExceeded 详细描述.....	2502
129.4.2 hwVbstPVNumResumed 详细描述.....	2502
129.4.3 hwVbstTrapInvalidPV 详细描述.....	2503
129.4.4 hwVbstTrunkPVNumExceeded 详细描述.....	2503
129.4.5 hwVbstTrunkPVNumResumed 详细描述.....	2503
129.4.6 hwVbstRspanCfgConflict 详细描述.....	2503
130 HUAWEI-VPLS-EXT-MIB.....	2504
130.1 功能简介.....	2504
130.2 表间关系.....	2504
130.3 MIB Table 详细描述.....	2506
130.3.1 hwVplsTable 详细描述.....	2506
130.3.2 hwVplsRtTable 详细描述.....	2512
130.3.3 hwVplsAcTable 详细描述.....	2513
130.3.4 hwVplsBgpInfoTable 详细描述.....	2515
130.3.5 hwVplsPwTable 详细描述.....	2516
130.3.6 hwVplsLdpStatisticsTable 详细描述.....	2518
130.3.7 hwVplsBgpStatisticsTable 详细描述.....	2522
130.3.8 hwVplsLdpPeerTable 详细描述.....	2526
130.4 单节点详细描述.....	2528
130.4.1 hwL2vpnTnlType 详细描述.....	2528
130.4.2 hwL2vpnTunnelIndex 详细描述.....	2528
130.4.3 hwVplsStateChangeReason 详细描述.....	2528
130.5 告警节点详细描述.....	2529
130.5.1 hwVplsVcDeleted 详细描述.....	2529
130.5.2 hwVplsVcDown 详细描述.....	2529
130.5.3 hwVplsVcUp 详细描述.....	2529

130.5.4 hwVplsVsiDeleted 详细描述.....	2530
130.5.5 hwVplsVsiDown 详细描述.....	2530
130.5.6 hwVplsVsiUp 详细描述.....	2530
130.5.7 hwVplsVcBackup 详细描述.....	2531
130.5.8 hwVplsVcStatusChange 详细描述.....	2531
130.6 附录.....	2531
130.6.1 hwVplsStateChangeReason.....	2531
130.6.2 HWL2VpnVcEncapsType.....	2533
131 HUAWEI-VPLS-TNL-MIB.....	2534
131.1 功能简介.....	2534
131.2 表间关系.....	2534
131.3 MIB Table 详细描述.....	2534
131.3.1 hwVplsTunnelTable 详细描述.....	2534
132 HUAWEI-VPN-DIAGNOSTICS-MIB.....	2538
132.1 功能简介.....	2538
132.2 表间关系.....	2539
132.3 单节点详细描述.....	2539
132.3.1 hwOamMacPopulateCount 详细描述.....	2539
132.3.2 hwOamMacPurgeCount 详细描述.....	2540
132.3.3 hwOamMacPurgeRegCount 详细描述.....	2540
132.3.4 hwOamMacCountReset 详细描述.....	2541
132.3.5 hwOamMacSwitch 详细描述.....	2541
132.3.6 hwOamMacEntryNum 详细描述.....	2541
132.4 MIB Table 详细描述.....	2542
132.4.1 hwOamMacOperTable 详细描述.....	2542
132.4.2 hwOamMacListTable 详细描述.....	2544
132.4.3 hwOamMacDisplayTable 详细描述.....	2544
132.4.4 hwVpnCfgPingTable 详细描述.....	2546
132.4.5 hwVpnCfgPingResultTable 详细描述.....	2550
132.4.6 hwVpnCfgPingResultIRtTable 详细描述.....	2560
132.4.7 hwVpnCfgPingResultERtTable 详细描述.....	2560
132.5 告警节点详细描述.....	2561
133 HUAWEI-VRRP-EXT-MIB.....	2562
133.1 功能简介.....	2562
133.2 表间关系.....	2562
133.3 单节点详细描述.....	2563
133.3.1 hwVrrpExtFreeArpInterval 详细描述.....	2563
133.3.2 hwVrrpExtVIPingCtr 详细描述.....	2563
133.3.3 hwVrrpExtSsTimer 详细描述.....	2564
133.3.4 hwVrrpExtLearnAdvIntervalFlag 详细描述.....	2564
133.3.5 hwVrrpExtStateChangeReasonString 详细描述.....	2565

133.3.6 hwVrrpExtProtocolVersion 详细描述.....	2565
133.3.7 hwVrrpExtSendV3AdverPktMode 详细描述.....	2566
133.4 MIB Table 详细描述.....	2566
133.4.1 hwVrrpTrackInterTable 详细描述.....	2566
133.4.2 hwVrrpTrackBfdTable 详细描述.....	2568
133.4.3 hwAdminVrrpCfgTable 详细描述.....	2570
133.4.4 hwAdminVrrpMemberTable 详细描述.....	2571
133.4.5 hwVrrpStatResetTable 详细描述.....	2572
133.4.6 hwVrrpStatExtTable 详细描述.....	2573
133.4.7 hwVrrpTrackNQATable 详细描述.....	2574
133.4.8 hwVrrpTrackRouteTable 详细描述.....	2576
133.5 告警节点详细描述.....	2577
133.5.1 hwVrrpExtTrapMasterDown 详细描述.....	2578
133.5.2 hwVrrpExtTrapNonMaster 详细描述.....	2578
134 HUAWEI-VXLAN-MIB.....	2579
134.1 功能简介.....	2579
134.2 表间关系.....	2579
134.3 单节点详细描述.....	2579
134.4 MIB Table 详细描述.....	2579
134.5 告警节点详细描述.....	2580
134.5.1 hwVxlanTunnelFull 详细描述.....	2580
135 HUAWEI-WLAN-CAPWAP-MIB.....	2581
135.1 功能简介.....	2581
135.2 表间关系.....	2581
135.3 单节点详细描述.....	2581
135.3.1 hwWlanCapwapSourceInterfaceValue 详细描述.....	2582
135.3.2 hwWlanCapwapSourceInterfaceMethod 详细描述.....	2582
135.3.3 hwWlanCapwapDtlsSwitch 详细描述.....	2582
135.3.4 hwWlanCapwapDtlsPsk 详细描述.....	2582
135.3.5 hwWlanCapwapInterControllerDtlsPsk 详细描述.....	2583
135.3.6 hwCapwapEchoInterval 详细描述.....	2583
135.3.7 hwCapwapEchoTimes 详细描述.....	2583
135.3.8 hwWlanCapwapControlPriorityLocal 详细描述.....	2584
135.3.9 hwWlanCapwapControlPriorityRemote 详细描述.....	2584
135.3.10 hwWlanCapwapSensitiveInfoPsk 详细描述.....	2584
135.3.11 hwWlanCapwapMessageIntegrityPsk 详细描述.....	2584
135.3.12 hwWlanCapwapMessageIntegrityPskMandatoryMatchSwitch 详细描述.....	2585
135.3.13 hwWlanCapwapMsgCheckSwitch 详细描述.....	2585
135.3.14 hwWlanCapwapDtlsVersion1Dot0Switch 详细描述.....	2586
135.3.15 hwWlanCapwapDtlsCbcSwitch 详细描述.....	2586
135.4 MIBTable 详细描述.....	2586
135.4.1 hwWlanCapwapSourceTable 详细描述.....	2586

135.5 告警节点详细描述.....	2589
135.6 不支持节点.....	2589
136 HUAWEI-WLAN-CONFIGURATION-MIB.....	2590
136.1 功能简介.....	2590
136.2 表间关系.....	2590
136.3 单节点详细描述.....	2595
136.3.1 hwWlanGlobalApUsername 详细描述.....	2595
136.3.2 hwWlanGlobalApPassword 详细描述.....	2595
136.3.3 hwWlanUsernamePasswordApMac 详细描述.....	2597
136.3.4 hwWlanGlobalApLldpSwitch 详细描述.....	2597
136.3.5 hwWlanApDataCollectionInterval 详细描述.....	2597
136.3.6 hwTestRtCollectOnoff 详细描述.....	2597
136.3.7 hwTestApNormalCollectCycle 详细描述.....	2598
136.3.8 hwTestApRtCollectCycle 详细描述.....	2598
136.3.9 hwWlanProtectIpAddress 详细描述.....	2598
136.3.10 hwWlanProtectPriority 详细描述.....	2598
136.3.11 hwWlanProtectSwitch 详细描述.....	2598
136.3.12 hwWlanProtectRestoreSwitch 详细描述.....	2599
136.3.13 hwUndoWlanProtectIpAddress 详细描述.....	2599
136.3.14 hwUndoWlanProtectPriority 详细描述.....	2599
136.3.15 hwWlanBLELowPowerWarningThreshold 详细描述.....	2599
136.3.16 hwWlanReportStaAssocInfo 详细描述.....	2600
136.3.17 hwWlanStaDelayOffLineSwitch 详细描述.....	2600
136.3.18 hwWlanStaDelayOffLineAgingTime 详细描述.....	2600
136.3.19 hwWlanStaDelayOffLineNewStaOnlineSwitch 详细描述.....	2601
136.3.20 hwWlanStaDelayOffLineMaxNum 详细描述.....	2601
136.3.21 hwWlanGlobalSpectrumAnalysisSourceIpAddress 详细描述.....	2601
136.3.22 hwWlanApAuthMode 详细描述.....	2602
136.3.23 hwWlanAPProvisionAddressMode 详细描述.....	2602
136.3.24 hwWlanAPProvisionIPv4Address 详细描述.....	2602
136.3.25 hwWlanAPProvisionIPv4Mask 详细描述.....	2602
136.3.26 hwWlanAPProvisionIPv4Gateway 详细描述.....	2603
136.3.27 hwWlanAPProvisionGroupName 详细描述.....	2603
136.3.28 hwWlanAPProvisionName 详细描述.....	2603
136.3.29 hwWlanAPProvisionIPv4ACLlist 详细描述.....	2603
136.3.30 hwWlanAPProvisionCommitAPName 详细描述.....	2604
136.3.31 hwWlanAPProvisionCommitAPMac 详细描述.....	2604
136.3.32 hwWlanAPProvisionCommitAPGroup 详细描述.....	2604
136.3.33 hwWlanAPProvisionManagementVlan 详细描述.....	2605
136.3.34 hwWlanRadioCalibrateMode 详细描述.....	2605
136.3.35 hwWlanRadioCalibrateScheduleTime 详细描述.....	2605
136.3.36 hwWlanRadioCalibrateManualStartup 详细描述.....	2605

136.3.37 hwWlanRadioCalibrateAutoInterval 详细描述.....	2606
136.3.38 hwWlanRadioCalibratePolicy 详细描述.....	2606
136.3.39 hwWlanRadioCalibrateSensitivity 详细描述.....	2607
136.3.40 hwWlanRadioCalibrateAutoStartTime 详细描述.....	2607
136.3.41 hwWlanRadioCalibrateManualApGroup 详细描述.....	2607
136.3.42 hwWlanRadioCalibrateManualApList 详细描述.....	2607
136.3.43 hwWlanRadioCalibrateManualProcess 详细描述.....	2608
136.3.44 hwWlanRadioCalibrateFlexibleRadio 详细描述.....	2608
136.3.45 hwWlanRadioCalibrateFlexRadioManualRecognize 详细描述.....	2608
136.3.46 hwWlanRadioCalibrateFlexibleRadioProcess 详细描述.....	2609
136.3.47 hwWlanRadioCalibrateFlexibleRadioRecognizeTime 详细描述.....	2609
136.3.48 hwWlanRadioCalibrateSensitivityCustomValue 详细描述.....	2609
136.3.49 hwWlanRadioCalibrateScheduleTimeRange 详细描述.....	2610
136.3.50 hwWlanRadioCalibrateReferenceDataAnalysis 详细描述.....	2610
136.3.51 hwWlanRadioCalibrateEnvironmentDeteriorateValue 详细描述.....	2610
136.3.52 hwWlanRadioCalibrateReferenceRogueInter 详细描述.....	2610
136.3.53 hwWlanRadioCalibrate2gSensitivity 详细描述.....	2611
136.3.54 hwWlanRadioCalibrate2gSensitivityCustomValue 详细描述.....	2611
136.3.55 hwWlanRadioCalibrate5gSensitivity 详细描述.....	2612
136.3.56 hwWlanRadioCalibrate5gSensitivityCustomValue 详细描述.....	2612
136.3.57 hwWlanRadioCalibrate6gSensitivity 详细描述.....	2612
136.3.58 hwWlanRadioCalibrate6gSensitivityCustomValue 详细描述.....	2613
136.3.59 hwWlanMobilityServerLocalIPv4 详细描述.....	2613
136.3.60 hwWlanLicenseCentralizedSwitch 详细描述.....	2613
136.3.61 hwWlanLicenseCentralizedServerIPv4Addr 详细描述.....	2613
136.3.62 hwWlanLicenseCentralizedServerIPv6Addr 详细描述.....	2614
136.3.63 hwWlanLicenseCentralizedClientIPv4Addr 详细描述.....	2614
136.3.64 hwWlanLicenseCentralizedClientIPv6Addr 详细描述.....	2614
136.3.65 hwWlanLicenseCentralizedRole 详细描述.....	2614
136.3.66 hwWlanLicensePoolUsed 详细描述.....	2615
136.3.67 hwWlanLicensePoolTotal 详细描述.....	2615
136.3.68 hwWlanGlobalRogueDeviceLogSwitch 详细描述.....	2615
136.3.69 hwWlanIotOperateTable 详细描述.....	2616
136.3.70 hwWlanGlobalAer scoutLocalIPv4 详细描述.....	2617
136.3.71 hwWlanGlobalApLoadRtuFileName 详细描述.....	2617
136.3.72 hwWlanGlobalStaProfilingSwitch 详细描述.....	2617
136.3.73 hwWlanBLEMonitorMode 详细描述.....	2618
136.4 MIBTable 详细描述.....	2618
136.4.1 hwWlanBLEMonitorListTable 详细描述.....	2618
136.4.2 hwWlanApMacWhitelistTable 详细描述.....	2619
136.4.3 hwWlanApSnWhitelistTable 详细描述.....	2619
136.4.4 hwWlanApMacBlacklistTable 详细描述.....	2620

136.4.5 hwAPGroupTable 详细描述.....	2621
136.4.6 hwAPGroupWiredPortTable 详细描述.....	2623
136.4.7 hwAPGroupRadioTable 详细描述.....	2624
136.4.8 hwAPGroupVapTable 详细描述.....	2630
136.4.9 hwAPSpecificTable 详细描述.....	2631
136.4.10 hwAPSpecificWiredPortTable 详细描述.....	2633
136.4.11 hwAPSpecificRadioTable 详细描述.....	2634
136.4.12 hwAPSpecificVapTable 详细描述.....	2641
136.4.13 hwRegulatoryDomainProfileTable 详细描述.....	2642
136.4.14 hwApSystemProfileTable 详细描述.....	2645
136.4.15 hwAPWiredPortProfileTable 详细描述.....	2661
136.4.16 hwAPWiredPortProfileTrafficFilterTable 详细描述.....	2666
136.4.17 hwAPPortLinkProfileTable 详细描述.....	2667
136.4.18 hw2gRadioProfileTable 详细描述.....	2671
136.4.19 hw5gRadioProfileTable 详细描述.....	2692
136.4.20 hwRrmProfileTable 详细描述.....	2713
136.4.21 hwAirScanProfileTable 详细描述.....	2728
136.4.22 hwVapProfileTable 详细描述.....	2729
136.4.23 hwSsidProfileTable 详细描述.....	2739
136.4.24 hwSecurityProfileTable 详细描述.....	2753
136.4.25 hwAPTrafficProfileTable 详细描述.....	2763
136.4.26 hwAPTrafficProfileFilterTable 详细描述.....	2771
136.4.27 hwWlanStaWhitelistProfileTable 详细描述.....	2774
136.4.28 hwWlanStaWhitelistProfileConfigTable 详细描述.....	2775
136.4.29 hwWlanStaWhitelistProfileOuiTable 详细描述.....	2776
136.4.30 hwWlanStaBlacklistProfileTable 详细描述.....	2777
136.4.31 hwWlanStaBlacklistProfileConfigTable 详细描述.....	2778
136.4.32 hwWidsProfileTable 详细描述.....	2782
136.4.33 hwWidsSpoofProfileTable 详细描述.....	2785
136.4.34 hwWidsWhitelistProfileMacTable 详细描述.....	2786
136.4.35 hwWidsWhitelistProfileOuiTable 详细描述.....	2787
136.4.36 hwWidsWhitelistProfileSsidTable 详细描述.....	2788
136.4.37 hwWlanMeshProfileTable 详细描述.....	2789
136.4.38 hwWlanMeshWhitelistProfileTable 详细描述.....	2798
136.4.39 hwWlanMeshWhitelistProfileConfigTable 详细描述.....	2799
136.4.40 hwWdsProfileTable 详细描述.....	2799
136.4.41 hwWdsWhitelistProfileTable 详细描述.....	2804
136.4.42 hwWdsWhitelistTable 详细描述.....	2804
136.4.43 hwSACProfileTable 详细描述.....	2805
136.4.44 hwLocationProfileTable 详细描述.....	2806
136.4.45 hwWlanGlobalConfig 详细描述.....	2813
136.4.46 hwWlanManualContainListTable 详细描述.....	2815

136.4.47 hwWidsSpoofProfileListTable 详细描述.....	2816
136.4.48 hwWidsWhitelistProfileListTable 详细描述.....	2816
136.4.49 hwWlanLoadBalanceStaticGroupTable 详细描述.....	2818
136.4.50 hwWlanLoadBalanceStaticGroupMemberTable 详细描述.....	2820
136.4.51 hwWlanCountryCodeTable 详细描述.....	2821
136.4.52 hwSoftgreProfileTable 详细描述.....	2822
136.4.53 hwWlanIDIndexedAPSpecificTable 详细描述.....	2824
136.4.54 hwIDIndexedAPSpecificWiredPortTable 详细描述.....	2827
136.4.55 hwIDIndexedAPSpecificRadioTable 详细描述.....	2828
136.4.56 hwIDIndexedAPSpecificVapTable 详细描述.....	2834
136.4.57 hwBleProfileTable 详细描述.....	2836
136.4.58 hwAPGroupCardTable 详细描述.....	2842
136.4.59 hwAPSpecificCardTable 详细描述.....	2844
136.4.60 hwloTProfileTable 详细描述.....	2847
136.4.61 hwloTProfileManagementServerTable 详细描述.....	2849
136.4.62 hwApProfIGMPSnoopingGroupTable 详细描述.....	2850
136.4.63 hwAPWiredPortProfileTrafficRemarkTable 详细描述.....	2851
136.4.64 hwAPTrafficProfileRemarkTable 详细描述.....	2853
136.4.65 hwWiredPortProfileTrafficFilterTable 详细描述.....	2854
136.4.66 hwWiredPortProfileTrafficRemarkTable 详细描述.....	2855
136.4.67 hwTrafficProfileTrafficFilterTable 详细描述.....	2858
136.4.68 hwTrafficProfileTrafficRemarkTable 详细描述.....	2860
136.4.69 hwWlanLicenseCentralizedTable 详细描述.....	2863
136.4.70 hwWmiProfileTable 详细描述.....	2865
136.4.71 hwApSystemWmiProfileTable 详细描述.....	2871
136.4.72 hwApSysBCMCSuppressionTable 详细描述.....	2872
136.4.73 hwVAPProfileAntiAttackTable 详细描述.....	2874
136.4.74 hwAPTrafficProfileRateLimitClientTable 详细描述.....	2876
136.4.75 hwVapServiceExpAnalysisAppTable 详细描述.....	2877
136.4.76 hwVapSlpFpmFlowTable 详细描述.....	2878
136.4.77 hwVapSlpFpmApplicationTable.....	2880
136.4.78 hwVapServiceExpAnalysisUserGroupAppTable 详细描述.....	2881
136.4.79 hwSsidWmmMuEdcaClientTable 详细描述.....	2882
136.4.80 hwWlanCountryChannelTable 详细描述.....	2884
136.4.81 hwWlanUserDefinedApplicationTable 详细描述.....	2885
136.4.82 hwWlanUserDefinedRuleTable 详细描述.....	2887
136.4.83 hwTrafficProfWlanSliceAclTable.....	2889
136.5 告警节点详细描述.....	2890
136.6 不支持节点.....	2890
137 HUAWEI-WLAN-GLOBAL-MIB.....	2911
137.1 功能简介.....	2911
137.2 表间关系.....	2911

137.3 单节点详细描述.....	2911
137.3.1 hwWlanAccessMaxApNumber 详细描述.....	2911
137.3.2 hwWlanAccessMaxStaNumber 详细描述.....	2912
137.3.3 hwWlanCurJointApNum 详细描述.....	2912
137.3.4 hwWlanCurAssocStaNum 详细描述.....	2912
137.3.5 hwWlanCurAuthSuccessStaNum 详细描述.....	2913
137.3.6 hwWlanReassocSuccessTimes 详细描述.....	2913
137.3.7 hwWlanCurAssoc2gStaNum 详细描述.....	2913
137.3.8 hwWlanCurAssoc5gStaNum 详细描述.....	2913
137.3.9 hwWlanDualBandStaNum 详细描述.....	2913
137.3.10 hwWlanGlobalUpSpeed 详细描述.....	2914
137.3.11 hwWlanGlobalDownSpeed 详细描述.....	2914
137.3.12 hwWlanCurAssoc2gStaType 详细描述.....	2914
137.3.13 hwWlanCurAssoc5gStaType 详细描述.....	2915
137.3.14 hwWlanCurAssoc6gStaNum 详细描述.....	2916
137.3.15 hwWlanCurAssoc6gStaType 详细描述.....	2917
137.3.16 hwWlanStaRateComplianceRate 详细描述.....	2917
137.3.17 hwWlanStaSnrComplianceRate 详细描述.....	2917
137.3.18 hwWlanStaResendRateComplianceRate 详细描述.....	2918
137.3.19 hwWlanStaDropRateComplianceRate 详细描述.....	2918
137.3.20 hwWlanStaComplianceRate 详细描述.....	2918
137.3.21 hwStaSnrNoncompliance2gCnt 详细描述.....	2919
137.3.22 hwStaRateNoncompliance2gCnt 详细描述.....	2919
137.3.23 hwStaResendRateNoncompliance2gCnt 详细描述.....	2919
137.3.24 hwStaDropRateNoncompliance2gCnt 详细描述.....	2920
137.3.25 hwStaThruputNoncompliance2gCnt 详细描述.....	2920
137.3.26 hwStaSnrNoncompliance5gCnt 详细描述.....	2920
137.3.27 hwStaRateNoncompliance5gCnt 详细描述.....	2920
137.3.28 hwStaResendRateNoncompliance5gCnt 详细描述.....	2921
137.3.29 hwStaDropRateNoncompliance5gCnt 详细描述.....	2921
137.3.30 hwStaThruputNoncompliance5gCnt 详细描述.....	2921
137.3.31 hwStaGlobalWirelessPacketDelay 详细描述.....	2922
137.3.32 hwStaGlobalWirelessPacketDropRate 详细描述.....	2922
137.3.33 hwStaGlobalTotalAccessTime 详细描述.....	2922
137.3.34 hwStaGlobalAccessExperience 详细描述.....	2923
137.3.35 hwStaGlobalAssocRate 详细描述.....	2923
137.3.36 hwStaGlobalAuthRateDot1x 详细描述.....	2924
137.3.37 hwStaGlobalAuthRatePortal 详细描述.....	2924
137.3.38 hwStaGlobalAuthRateMac 详细描述.....	2924
137.3.39 hwStaSnrNoncompliance6gCnt 详细描述.....	2925
137.3.40 hwStaRateNoncompliance6gCnt 详细描述.....	2925
137.3.41 hwStaResendRateNoncompliance6gCnt 详细描述.....	2926

137.3.42 hwStaDropRateNoncompliance6gCnt 详细描述.....	2926
137.3.43 hwStaThruputNoncompliance6gCnt 详细描述.....	2926
137.3.44 hwWlanRfChannelUtilRateComplianceRate 详细描述.....	2926
137.3.45 hwWlanRfNoiseComplianceRate 详细描述.....	2927
137.3.46 hwWlanRfChannelJamRateComplianceRate 详细描述.....	2927
137.3.47 hwWlanRfResendRateComplianceRate 详细描述.....	2927
137.3.48 hwWlanRfDropRateComplianceRate 详细描述.....	2928
137.3.49 hwWlanRfComplianceRate 详细描述.....	2928
137.3.50 hwWlanRfNoiseNoncompliance2gCnt 详细描述.....	2928
137.3.51 hwWlanRfChannelUtilRateNoncompliance2gCnt 详细描述.....	2929
137.3.52 hwWlanRfLoadNoncompliance2gCnt 详细描述.....	2929
137.3.53 hwWlanRfChannelJamRateNoncompliance2gCnt 详细描述.....	2929
137.3.54 hwWlanRfNoiseNoncompliance5gCnt 详细描述.....	2929
137.3.55 hwWlanRfChannelUtilRateNoncompliance5gCnt 详细描述.....	2930
137.3.56 hwWlanRfLoadNoncompliance5gCnt 详细描述.....	2930
137.3.57 hwWlanRfChannelJamRateNoncompliance5gCnt 详细描述.....	2930
137.3.58 hwWlanRfNoiseNoncompliance6gCnt 详细描述.....	2931
137.3.59 hwWlanRfChannelUtilRateNoncompliance6gCnt 详细描述.....	2931
137.3.60 hwWlanRfLoadNoncompliance6gCnt 详细描述.....	2932
137.3.61 hwWlanRfChannelJamRateNoncompliance6gCnt 详细描述.....	2932
137.3.62 hwWlanApNormalRatio 详细描述.....	2932
137.3.63 hwWlanApStaOnlineFailRateComplianceRate 详细描述.....	2932
137.3.64 hwWlanApStaOfflineRateComplianceRate 详细描述.....	2933
137.3.65 hwWlanApStaOnlineCntComplianceRate 详细描述.....	2933
137.3.66 hwWlanApComplianceRate 详细描述.....	2934
137.3.67 hwWlanServiceNormalAPCount 详细描述.....	2934
137.3.68 hwWlanApCount 详细描述.....	2934
137.3.69 hwWlanSecurityProfileName 详细描述.....	2934
137.3.70 hwWlanEncryptionAlgorithm 详细描述.....	2935
137.3.71 hwWlanSecurityPara 详细描述.....	2935
137.4 MIBTable 详细描述.....	2935
137.4.1 hwWlanOnlineStaCntHistoryTable 详细描述.....	2935
137.4.2 hwWlanSpeedHistoryTable 详细描述.....	2936
137.4.3 hwWlanApGroupStatisticsTable 详细描述.....	2937
137.5 告警节点详细描述.....	2938
137.5.1 hwWlanWapiCertificateNearlyExpiredTrap 详细描述.....	2938
137.5.2 hwWlanWapiCertificateNearlyExpiredTrapRestore 详细描述.....	2938
137.5.3 hwWlanWapiCertificateInvalidTrap 详细描述.....	2939
137.5.4 hwWlanWapiCertificateInvalidTrapRestore 详细描述.....	2939
137.5.5 hwWlanInsecureEncryptionAlgorithm 详细描述.....	2940
137.5.6 hwWlanSecurityParaNotSetTrap 详细描述.....	2940
137.5.7 hwWlanSecurityParaNotSetTrapRestore 详细描述.....	2940

137.6 不支持节点.....	2940
138 HUAWEI-WLAN-AP-MIB.....	2942
138.1 功能简介.....	2942
138.2 表间关系.....	2942
138.3 单节点详细描述.....	2944
138.3.1 hwWlanApPingApMac 详细描述.....	2944
138.3.2 hwWlanApPingAddress 详细描述.....	2945
138.3.3 hwWlanApPingCount 详细描述.....	2945
138.3.4 hwWlanApPingPacketSize 详细描述.....	2946
138.3.5 hwWlanApPingWaitTime 详细描述.....	2946
138.3.6 hwWlanApPingTimeOut 详细描述.....	2946
138.3.7 hwWlanApPingResultSuccessCount 详细描述.....	2947
138.3.8 hwWlanApPingResultFailureCount 详细描述.....	2947
138.3.9 hwWlanApPingResultAveResponseTime 详细描述.....	2947
138.3.10 hwWlanApPingResultMinResponseTime 详细描述.....	2948
138.3.11 hwWlanApPingResultMaxResponseTime 详细描述.....	2948
138.3.12 hwWlanApPingResultFlag 详细描述.....	2948
138.3.13 hwApPowerWorkMode 详细描述.....	2949
138.3.14 hwApExpectPowerWorkMode 详细描述.....	2949
138.3.15 hwWlanApTemperatureType 详细描述.....	2949
138.3.16 hwAlertReason 详细描述.....	2950
138.3.17 hwRemainTime 详细描述.....	2950
138.3.18 hwCurEmdiSessionRate 详细描述.....	2950
138.3.19 hwUpperEmdiSessionThreshold 详细描述.....	2951
138.3.20 hwLowerEmdiSessionThreshold 详细描述.....	2951
138.3.21 hwCurSipfpmFlowRate 详细描述.....	2952
138.3.22 hwUpperSipfpmFlowThreshold 详细描述.....	2952
138.3.23 hwLowerSipfpmFlowThreshold 详细描述.....	2952
138.3.24 hwApLicenseType 详细描述.....	2952
138.3.25 hwCurSACSessionRate.....	2953
138.3.26 hwUpperSACSessionThreshold.....	2953
138.3.27 hwLowerSACSessionThreshold.....	2953
138.3.28 hwWlanApPKICertStartTime 详细描述.....	2953
138.3.29 hwWlanApPKICertFinishTime 详细描述.....	2954
138.3.30 hwWlanApPKICertIssuer 详细描述.....	2954
138.3.31 hwWlanApPKICertSubject 详细描述.....	2954
138.3.32 hwWlanApWiredPortSupportedMaxRate 详细描述.....	2954
138.4 MIBTable 详细描述.....	2954
138.4.1 hwWlanApTypeTable 详细描述.....	2955
138.4.2 hwWlanApTypeRadioTable 详细描述.....	2956
138.4.3 hwWlanApTypeWiredPortTable 详细描述.....	2958
138.4.4 hwWlanApTypeUndefinedTable 详细描述.....	2959

138.4.5 hwWlanApTypeAttributesAbnormalCheckTable 详细描述.....	2960
138.4.6 hwWlanUnauthedApRecordTable 详细描述.....	2961
138.4.7 hwWlanApTable 详细描述.....	2962
138.4.8 hwWlanApWiredPortTable 详细描述.....	2975
138.4.9 hwWlanApWiredPortStatTable 详细描述.....	2977
138.4.10 hwWlanApWiredPortLldpTable 详细描述.....	2978
138.4.11 hwWlanApWiredPortLldpRemManAddrTable 详细描述.....	2980
138.4.12 hwWlanApOnlineFailTable 详细描述.....	2981
138.4.13 hwWlanApOfflineTable 详细描述.....	2982
138.4.14 hwWlanIdIndexedApTable 详细描述.....	2983
138.4.15 hwWlanApOnlineFailReasonTable 详细描述.....	2995
138.4.16 hwWlanApOfflineReasonTable 详细描述.....	2996
138.5 告警节点详细描述.....	2997
138.5.1 hwApFaultTrap 详细描述.....	2997
138.5.2 hwApNormalTrap 详细描述.....	2998
138.5.3 hwApPingResultTrap 详细描述.....	2999
138.5.4 hwApConfigCommitTrap 详细描述.....	3001
138.5.5 hwUnauthorizedApRecordExistTrap 详细描述.....	3001
138.5.6 hwUnauthorizedApRecordClearTrap 详细描述.....	3002
138.5.7 hwApCpuOverloadTrap 详细描述.....	3002
138.5.8 hwApCpuOverloadRestoreTrap 详细描述.....	3003
138.5.9 hwApMemoryOverloadTrap 详细描述.....	3004
138.5.10 hwApMemoryOverloadRestoreTrap 详细描述.....	3005
138.5.11 hwApStaFullTrap 详细描述.....	3006
138.5.12 hwApStaFullRecoverTrap 详细描述.....	3007
138.5.13 hwAcDevicesSwitchTrap 详细描述.....	3008
138.5.14 hwDyingGaspTrap 详细描述.....	3009
138.5.15 hwApTemperatureTooLowTrap 详细描述.....	3010
138.5.16 hwApTemperatureTooLowRestoreTrap 详细描述.....	3011
138.5.17 hwApTemperatureTooHighTrap 详细描述.....	3012
138.5.18 hwApTemperatureTooHighRestoreTrap 详细描述.....	3013
138.5.19 hwApOpticalRxPowerTooHighTrap 详细描述.....	3014
138.5.20 hwApOpticalRxPowerTooHighRestoreTrap 详细描述.....	3015
138.5.21 hwApOpticalRxPowerTooLowTrap 详细描述.....	3016
138.5.22 hwApOpticalRxPowerTooLowRestoreTrap 详细描述.....	3017
138.5.23 hwApOpticalTemperatureTooHighTrap 详细描述.....	3018
138.5.24 hwApOpticalTemperatureTooHighRestoreTrap 详细描述.....	3019
138.5.25 hwApOpticalTemperatureTooLowTrap 详细描述.....	3020
138.5.26 hwApOpticalTemperatureTooLowRestoreTrap 详细描述.....	3021
138.5.27 hwApNotSupportCountryCodeTrap 详细描述.....	3022
138.5.28 hwApColdBootTrap 详细描述.....	3023
138.5.29 hwApColdBootRestoreTrap 详细描述.....	3024

138.5.30 hwApHotBootTrap 详细描述.....	3025
138.5.31 hwApHotBootRestoreTrap 详细描述.....	3026
138.5.32 hwApCRCTooHighTrap 详细描述.....	3027
138.5.33 hwApCRCTooHighRestoreTrap 详细描述.....	3028
138.5.34 hwApConflictApNameTrap 详细描述.....	3029
138.5.35 hwApLicenseTrap 详细描述.....	3030
138.5.36 hwApFmeaIICFaultTrap 详细描述.....	3030
138.5.37 hwApFmeaIICFaultRestoreTrap 详细描述.....	3031
138.5.38 hwApFmeaPHYFaultTrap 详细描述.....	3031
138.5.39 hwApFmeaPHYFaultRestoreTrap 详细描述.....	3032
138.5.40 hwApFmeaFaultTrap 详细描述.....	3032
138.5.41 hwApFmeaFaultRestoreTrap 详细描述.....	3033
138.5.42 hwApOpticalInsertTrap 详细描述.....	3034
138.5.43 hwApOpticalRemoveTrap 详细描述.....	3035
138.5.44 hwApReceivedInvalidArpNewTrap 详细描述.....	3036
138.5.45 hwApVersionMismatchTrap 详细描述.....	3037
138.5.46 hwRadioUploadRemoteCaptureFileTrap 详细描述.....	3038
138.5.47 hwWlanBLELowPowerTrap 详细描述.....	3039
138.5.48 hwWlanBLELowPowerRestoreTrap 详细描述.....	3039
138.5.49 hwWlanBLEOfflineTrap 详细描述.....	3040
138.5.50 hwWlanBLEOfflineRestoreTrap 详细描述.....	3040
138.5.51 hwWlanBLEFaultyTrap 详细描述.....	3040
138.5.52 hwWlanBLEFaultyRestoreTrap 详细描述.....	3041
138.5.53 hwAPloTCardInsertTrap 详细描述.....	3041
138.5.54 hwAPloTCardRemoveTrap 详细描述.....	3042
138.5.55 hwAPloTServerStartFailTrap 详细描述.....	3042
138.5.56 hwAPloTServerStartFailResumeTrap 详细描述.....	3043
138.5.57 hwApConfigInconsistWithActualTrap 详细描述.....	3044
138.5.58 hwWlanBLEDetachedTrap 详细描述.....	3045
138.5.59 hwWlanBLEDetachedRestoreTrap 详细描述.....	3046
138.5.60 hwApPowerInsufficientTrap 详细描述.....	3047
138.5.61 hwApPowerInsufficientResumeTrap 详细描述.....	3048
138.5.62 hwPortVlanSecureMacTrap 详细描述.....	3049
138.5.63 hwWlanCableSnrNormalTrap 详细描述.....	3050
138.5.64 hwWlanCableSnrAbnormalTrap 详细描述.....	3051
138.5.65 hwWlanCableSnrDetectNotSupportTrap 详细描述.....	3052
138.5.66 hwApMcBcPktNumExceedTrap 详细描述.....	3053
138.5.67 hwApMcBcPktNumExceedRestoreTrap 详细描述.....	3053
138.5.68 hwAPSoftGreDownTrap 详细描述.....	3053
138.5.69 hwAPSoftGreDownTrapRestore 详细描述.....	3054
138.5.70 hwApVersionNotRecommendedTrap 详细描述.....	3055
138.5.71 hwApVersionNotRecommendedTrapRestore 详细描述.....	3055

138.5.72 hwApDiskOverloadTrap 详细描述.....	3056
138.5.73 hwApDiskOverloadRestoreTrap 详细描述.....	3056
138.5.74 hwApPowerLimitedTrap 详细描述.....	3057
138.5.75 hwApPowerLimitedResumeTrap 详细描述.....	3058
138.5.76 hwApIpConflictTrap 详细描述.....	3059
138.5.77 hwApNumReachMaxTrap 详细描述.....	3060
138.5.78 hwApNumReachMaxResumeTrap 详细描述.....	3060
138.5.79 hwApNumReachWarningTrap 详细描述.....	3060
138.5.80 hwApNumReachWarningResumeTrap 详细描述.....	3061
138.5.81 hwApIotCardConnectServerTrap 详细描述.....	3061
138.5.82 hwApIotCardDisconnectServerTrap 详细描述.....	3062
138.5.83 hwApIotCardTypeMatchTrap 详细描述.....	3063
138.5.84 hwApIotCardTypeMismatchTrap 详细描述.....	3064
138.5.85 hwAPFanRemoveTrap 详细描述.....	3065
138.5.86 hwAPFanInsertTrap 详细描述.....	3066
138.5.87 hwAPPowerRemoveTrap 详细描述.....	3067
138.5.88 hwAPPowerInsertTrap 详细描述.....	3068
138.5.89 hwAPPowerFailTrap 详细描述.....	3069
138.5.90 hwAPPowerFailResumeTrap 详细描述.....	3070
138.5.91 hwAPPowerInvalidTrap 详细描述.....	3071
138.5.92 hwAPPowerInvalidResumeTrap 详细描述.....	3072
138.5.93 hwApServiceInterruptAlertTrap 详细描述.....	3073
138.5.94 hwApServiceInterruptAlertResumeTrap 详细描述.....	3074
138.5.95 hwApEMDISessionOverloadTrap 详细信息.....	3074
138.5.96 hwApEMDISessionOverloadRestoreTrap 详细信息.....	3075
138.5.97 hwApSipfpmFlowOverloadTrap 详细信息.....	3076
138.5.98 hwApSipfpmFlowOverloadRestoreTrap 详细信息.....	3077
138.5.99 hwApSACSessionOverloadTrap.....	3078
138.5.100 hwApSACSessionOverloadRestoreTrap.....	3079
138.5.101 hwWlanApPKICACertNearlyExpiredTrap 详细信息.....	3080
138.5.102 hwWlanApPKILocalCertNearlyExpiredTrap 详细信息.....	3081
138.5.103 hwApPortRateAutoNegotiationEventTrap 详细描述.....	3082
138.6 不支持节点.....	3082
139 HUAWEI-WLAN-AP-UPDATE-MIB.....	3086
139.1 功能简介.....	3086
139.2 表间关系.....	3086
139.3 单节点详细描述.....	3086
139.3.1 hwWlanApUpdateFTPIPAddress 详细描述.....	3086
139.3.2 hwWlanApUpdateFTPUsername 详细描述.....	3087
139.3.3 hwWlanApUpdateFTPPassword 详细描述.....	3087
139.3.4 hwWlanApUpdateMode 详细描述.....	3087
139.3.5 hwWlanApUpdateSFTPIPAddress 详细描述.....	3088

139.3.6 hwWlanApUpdateSFTPUsername 详细描述.....	3088
139.3.7 hwWlanApUpdateSFTPPassword 详细描述.....	3088
139.3.8 hwWlanApUpdateFTPMaxConnectNum 详细描述.....	3089
139.3.9 hwWlanApUpdateSFTPMaxConnectNum 详细描述.....	3089
139.3.10 hwWlanApUpdateFTPIPV4Port 详细描述.....	3090
139.3.11 hwWlanApUpdateFTPIPV6Port 详细描述.....	3090
139.3.12 hwWlanApUpdateSFTPIPV4Port 详细描述.....	3090
139.3.13 hwWlanApUpdateSFTPIPV6Port 详细描述.....	3091
139.3.14 hwWlanApUpdateOperAdminOper 详细描述.....	3091
139.3.15 hwWlanApUpdateOperApType 详细描述.....	3092
139.3.16 hwWlanApUpdateOperApGroup 详细描述.....	3093
139.3.17 hwWlanApUpdateOperPercent 详细描述.....	3093
139.4 MIBTable 详细描述.....	3093
139.4.1 hwWlanApUpdateTable 详细描述.....	3093
139.4.2 hwWlanApUpdateProgressTable 详细描述.....	3095
139.4.3 hwWlanSingleApUpdateTable 详细描述.....	3102
139.4.4 hwWlanApTypeGroupUpdateTable 详细描述.....	3103
139.4.5 hwWlanApUpdateScheduleTaskTable 详细描述.....	3105
139.5 告警节点详细描述.....	3108
139.5.1 hwWlanApUpdateBeginTrap 详细描述.....	3108
139.5.2 hwWlanApUpdateResultTrap 详细描述.....	3108
139.5.3 hwWlanApUpdateUbootNotMatchTrap 详细描述.....	3110
139.6 不支持节点.....	3111
140 HUAWEI-WLAN-WIDS-SERVICE-MIB.....	3113
140.1 功能简介.....	3113
140.2 表间关系.....	3113
140.3 单节点详细描述.....	3114
140.3.1 hwWlanWidsResetRogueHistoryAll 详细描述.....	3114
140.3.2 hwWlanWidsResetRogueHistoryByDevType 详细描述.....	3114
140.3.3 hwWlanWidsResetAttackDev 详细描述.....	3115
140.3.4 hwWlanWidsResetAttackStat 详细描述.....	3116
140.3.5 hwWlanWidsResetDynamicBlacklist 详细描述.....	3117
140.3.6 hwWlanWidsResetDynamicBlacklistMac 详细描述.....	3117
140.3.7 hwWlanWidsResetAttackHistory 详细描述.....	3117
140.3.8 hwWlanWidsAttackStatProbeRequestFloodAttack 详细描述.....	3117
140.3.9 hwWlanWidsAttackStatAuthRequestFloodAttack 详细描述.....	3118
140.3.10 hwWlanWidsAttackStatDeAuthenFloodAttack 详细描述.....	3118
140.3.11 hwWlanWidsAttackStatAssocReqFloodAttack 详细描述.....	3118
140.3.12 hwWlanWidsAttackStatDisassocReqFloodAttack 详细描述.....	3119
140.3.13 hwWlanWidsAttackStatReassocReqFloodAttack 详细描述.....	3119
140.3.14 hwWlanWidsAttackStatActionFloodAttack 详细描述.....	3119
140.3.15 hwWlanWidsAttackStatNullDataFloodAttack 详细描述.....	3120

140.3.16 hwWlanWidsAttackStatWeakIvAttack 详细描述.....	3120
140.3.17 hwWlanWidsAttackStatDeauthSpoofAttack 详细描述.....	3120
140.3.18 hwWlanWidsAttackStatDisassocSpoofAttack 详细描述.....	3120
140.3.19 hwWlanWidsAttackStatWepShareKeyAttack 详细描述.....	3121
140.3.20 hwWlanWidsAttackStatWpaAttack 详细描述.....	3121
140.3.21 hwWlanWidsAttackStatWpa2Attack 详细描述.....	3121
140.3.22 hwWlanWidsAttackStatWapiAttack 详细描述.....	3121
140.3.23 hwWlanWidsAttackStatEAPOLStartFloodAttack 详细描述.....	3122
140.3.24 hwWlanWidsAttackStatEAPOLLogoffFloodAttack 详细描述.....	3122
140.3.25 hwWlanWidsAttackStatNullQosFloodAttack 详细描述.....	3122
140.3.26 hwWlanWidsAttackStatStartTime 详细描述.....	3122
140.3.27 hwWlanWidsAttackStatOthersSpoofAttack 详细描述.....	3123
140.4 MIBTable 详细描述.....	3123
140.4.1 hwWlanWidsDetDevTable 详细描述.....	3123
140.4.2 hwWlanWidsRogueHistoryTable 详细描述.....	3126
140.4.3 hwWlanWidsDetNonWifiDevTable 详细描述.....	3127
140.4.4 hwWlanWidsAttackHistoryTable 详细描述.....	3130
140.4.5 hwWlanWidsDynamicBlacklistTable 详细描述.....	3133
140.4.6 hwWlanWidsDetNonWifiDevHistTable 详细描述.....	3138
140.4.7 hwWlanWidsAttDevTable 详细描述.....	3142
140.4.8 hwWlanWidsDetDevMonitorTable 详细描述.....	3144
140.4.9 hwWlanWidsDynamicBlacklistAPTable 详细描述.....	3146
140.4.10 hwWlanWidsAttackDetorTable 详细描述.....	3149
140.4.11 hwWlanWidsApDetDevTable 详细描述.....	3153
140.5 告警节点详细描述.....	3156
140.5.1 hwWlanWidsRogueDeviceTrap 详细描述.....	3157
140.5.2 hwWlanWidsAttackDeviceTrap 详细描述.....	3157
140.5.3 hwWlanWidsNonWifiDeviceTrap 详细描述.....	3157
140.5.4 hwWlanWidsAttackDetectedTrap 详细描述.....	3157
140.5.5 hwWlanWidsProfMergeTrap 详细描述.....	3159
140.6 不支持节点.....	3159
141 HUAWEI-WLAN-AP-RADIO-MIB.....	3163
141.1 功能简介.....	3163
141.2 表间关系.....	3163
141.3 单节点详细描述.....	3163
141.4 MIBTable 详细描述.....	3164
141.4.1 hwWlanRadioInfoTable 详细描述.....	3164
141.5 告警节点详细描述.....	3173
141.5.1 hwRadioChannelChangedTrap 详细描述.....	3173
141.5.2 hwRadioSignalEnvDeteriorationTrap 详细描述.....	3175
141.5.3 hwRadioSignalEnvResumeTrap 详细描述.....	3176
141.5.4 hwApMonitorModeChangedTrap 详细描述.....	3177

141.5.5 hwAPCoInterfDetectedTrap 详细描述.....	3178
141.5.6 hwAPCoInterfClearTrap 详细描述.....	3179
141.5.7 hwNerborInterfDetectedTrap 详细描述.....	3180
141.5.8 hwNeiborInterfClearTrap 详细描述.....	3182
141.5.9 hwStaInterfDetectedTrap 详细描述.....	3183
141.5.10 hwStaInterfClearTrap 详细描述.....	3183
141.5.11 hwOtherDeviceInterfDetectedTrap 详细描述.....	3184
141.5.12 hwOtherDeviceInterfClearTrap 详细描述.....	3185
141.5.13 hwRadioDownTrap 详细描述.....	3186
141.5.14 hwRadioDownRecovTrap 详细描述.....	3187
141.5.15 hwWIDSDetectRogueTrap 详细描述.....	3188
141.5.16 hwRadioNotSupportChannelTrap 详细描述.....	3190
141.5.17 hwRadioAntennaGainIsUnlawfulTrap 详细描述.....	3193
141.5.18 hwRadioPowerChangedTrap 详细描述.....	3195
141.5.19 hwApAccessUserNumExceedThresholdTrap 详细描述.....	3195
141.5.20 hwApAccessUserNumExceedThresholdRecovTrap 详细描述.....	3196
141.5.21 hwApRoamUserNumExceedThresholdTrap 详细描述.....	3197
141.5.22 hwApRoamUserNumExceedThresholdRecovTrap 详细描述.....	3198
141.5.23 hwRadioReachMaxUserPhySpecTrap 详细描述.....	3199
141.5.24 hwRadioReachMaxUserPhySpecClearTrap 详细描述.....	3200
141.6 不支持节点.....	3201
142 HUAWEI-WLAN-VAP-MIB.....	3204
142.1 功能简介.....	3204
142.2 表间关系.....	3204
142.3 单节点详细描述.....	3204
142.4 MIBTable 详细描述.....	3204
142.4.1 hwWlanVapInfoTable 详细描述.....	3205
142.4.2 hwWlanSsidStatisticTable 详细描述.....	3207
142.4.3 hwWlanRfSsidStatisticTable 详细描述.....	3209
142.4.4 hwWlanMacRfSsidStatisticTable 详细描述.....	3211
142.4.5 hwWlanVapIGMPSnoopingCacInfoTable 详细描述.....	3213
142.4.6 hwVapCreateFailTrap 详细描述.....	3214
142.4.7 hwVapCreateFailTrapRestore 详细描述.....	3214
142.5 告警节点详细描述.....	3214
142.5.1 hwVapIGMPSnoopingBandwidthExceedTrap 详细描述.....	3214
142.5.2 hwVapIGMPSnoopingUserExceedTrap 详细描述.....	3215
142.6 不支持节点.....	3216
143 HUAWEI-WLAN-STATION-MIB.....	3218
143.1 功能简介.....	3218
143.2 表间关系.....	3218
143.3 单节点详细描述.....	3218
143.3.1 hwWlanConflictStaMac 详细描述.....	3218

143.3.2 hwMaxUserSipfpmFlowNum 详细描述.....	3219
143.3.3 hwCurUserSipfpmFlowNum 详细描述.....	3219
143.4 MIBTable 详细描述.....	3219
143.4.1 hwWlanStationTable 详细描述.....	3219
143.4.2 hwWlanStationApStatTable 详细描述.....	3237
143.4.3 hwWlanStaOnlineFailTable 详细描述.....	3241
143.4.4 hwWlanStaOnlineFailReasonTable 详细描述.....	3242
143.4.5 hwWlanStaOfflineTable 详细描述.....	3243
143.4.6 hwWlanStaOfflineReasonTable 详细描述.....	3245
143.4.7 hwWlanStaRoamTraceTable 详细描述.....	3245
143.5 告警节点详细描述.....	3248
143.5.1 hwWlanStaAuthErrorTrap 详细描述.....	3248
143.5.2 hwWlanStaAssoFailTrap 详细描述.....	3250
143.5.3 hwWlanUserInvalidCerficationTrap 详细描述.....	3252
143.5.4 hwWlanStaRepititiveAttackTrap 详细描述.....	3253
143.5.5 hwWlanStaTamperAttackTrap 详细描述.....	3254
143.5.6 hwWlanStaLowLevelSecAttackTrap 详细描述.....	3255
143.5.7 hwWlanStaAddressRedirectionAttackTrap 详细描述.....	3256
143.5.8 hwWlanStaWepldConflictTrap 详细描述.....	3257
143.5.9 hwStationIPConflictTrap 详细描述.....	3259
143.5.10 hwStationIPAddressConflictTrap 详细描述.....	3259
143.5.11 hwApSipfpmUserFlowFullTrap 详细描述.....	3261
143.5.12 hwApSipfpmUserFlowFullRestoreTrap 详细描述.....	3262
143.6 不支持节点.....	3262
144 HUAWEI-WLAN-AP-SERVICE-MIB.....	3265
144.1 功能简介.....	3265
144.2 表间关系.....	3265
144.3 单节点详细描述.....	3266
144.3.1 hwWlanRadioResetChannelSwitchRecord 详细描述.....	3266
144.4 MIBTable 详细描述.....	3266
144.4.1 hwWlanWdsVapInfoTable 详细描述.....	3266
144.4.2 hwWlanWdsLinkTable 详细描述.....	3267
144.4.3 hwWlanMeshVapInfoTable 详细描述.....	3270
144.4.4 hwWlanMeshLinkTable 详细描述.....	3271
144.4.5 hwWlanRadioCalibrateStatisticsTable 详细描述.....	3274
144.4.6 hwWlanRadioChannelSwitchRecordTable 详细描述.....	3276
144.4.7 hwWlanSpectrumReporterTable 详细描述.....	3277
144.4.8 hwWlanAplotCardTable 详细描述.....	3278
144.4.9 hwWlanBLESiteInfoTable 详细描述.....	3283
144.4.10 hwWlanRadioCalibrationSwitchRecordTable 详细描述.....	3285
144.5 告警节点详细描述.....	3288
144.5.1 hwWlanAeroscoutLocationViaAcTrap 详细描述.....	3288

144.5.2 hwWlanAeroscoutLocationViaAcRestoreTrap 详细描述.....	3288
144.6 不支持节点.....	3288
145 HUAWEI-XQoS-MIB.....	3291
145.1 功能简介.....	3291
145.2 表间关系.....	3291
145.3 单节点详细描述.....	3291
145.4 MIB Table 详细描述.....	3291
145.4.1 hwXQoSIfQueueRunInfoTable 详细描述.....	3292
145.4.2 hwXQoSCarTable 详细描述.....	3294
145.4.3 hwXQoSIfLrCfgInfoTable 详细描述.....	3296
145.4.4 hwXQoSVlanStatTable 详细描述.....	3297
145.4.5 hwXQoSVlanSlotStatTable 详细描述.....	3298
145.4.6 hwXQoSvlanCfgTable 详细描述.....	3300
145.4.7 hwXQoSTrafficSuppressionTable 详细描述.....	3300
145.5 告警节点详细描述.....	3302
145.5.1 hwXQoSStormControlTrap 详细描述.....	3302
145.5.2 hwXQoSStormControlTrapExt 详细描述.....	3302
145.5.3 hwXQoSTrafficSuppressionTrap 详细描述.....	3304
145.6 不支持节点.....	3304
146 IF-MIB.....	3328
146.1 功能简介.....	3328
146.2 表间关系.....	3328
146.3 单节点详细描述.....	3328
146.3.1 ifNumber 详细描述.....	3329
146.3.2 ifTableLastChange 详细描述.....	3329
146.4 MIB Table 详细描述.....	3329
146.4.1 ifTable 详细描述.....	3329
146.4.2 ifXTable 详细描述.....	3337
146.5 告警节点详细描述.....	3343
146.5.1 linkUp 详细描述.....	3343
146.5.2 linkDown 详细描述.....	3343
147 IP-FORWARD-MIB.....	3344
147.1 功能简介.....	3344
147.2 表间关系.....	3344
147.3 单节点详细描述.....	3344
147.3.1 ipCidrRouteNumber 详细描述.....	3345
147.3.2 inetCidrRouteNumber 详细描述.....	3345
147.3.3 inetCidrRouteDiscards 详细描述.....	3345
147.4 MIB Table 详细描述.....	3345
147.4.1 ipCidrRouteTable 详细描述.....	3346
147.4.2 inetCidrRouteTable 详细描述.....	3350

147.5 告警节点详细描述.....	3356
148 IP-MIB.....	3357
148.1 功能简介.....	3357
148.2 表间关系.....	3357
148.3 单节点详细描述.....	3357
148.4 MIB Table 详细描述.....	3358
148.4.1 ipNetToPhysicalTable 详细描述.....	3358
149 IPMCAST-MIB.....	3364
149.1 功能简介.....	3364
149.2 表间关系.....	3365
149.3 单节点详细描述.....	3365
149.3.1 ipMcastEnabled 详细描述.....	3365
149.3.2 ipMcastDeviceConfigStorageType 详细描述.....	3366
149.3.3 ipMcastRouteEntryCount 详细描述.....	3366
149.4 MIB Table 详细描述.....	3366
149.4.1 ipMcastRouteTable 详细描述.....	3366
149.4.2 ipMcastRouteNextHopTable 详细描述.....	3370
149.4.3 ipMcastBoundaryTable 详细描述.....	3374
150 IPV6-MIB.....	3377
150.1 功能简介.....	3377
150.2 表间关系.....	3378
150.3 单节点详细描述.....	3378
150.3.1 ipv6Forwarding 详细描述.....	3379
150.3.2 ipv6DefaultHopLimit 详细描述.....	3379
150.3.3 ipv6Interfaces 详细描述.....	3379
150.3.4 ipv6IfTableLastChange 详细描述.....	3380
150.3.5 ipv6RouteNumber 详细描述.....	3380
150.3.6 ipv6DiscardedRoutes 详细描述.....	3380
150.4 MIB Table 详细描述.....	3380
150.4.1 ipv6IfTable 详细描述.....	3380
150.4.2 ipv6IfStatsTable 详细描述.....	3384
150.4.3 ipv6AddrPrefixTable 详细描述.....	3388
150.4.4 ipv6AddrTable 详细描述.....	3390
150.4.5 ipv6RouteTable 详细描述.....	3391
150.4.6 ipv6NetToMediaTable 详细描述.....	3395
150.5 告警节点详细描述.....	3397
150.5.1 ipv6IfStateChange 详细描述.....	3398
151 ISIS-MIB.....	3399
151.1 功能简介.....	3399
151.2 表间关系.....	3400
151.3 MIB Table 详细描述.....	3402

151.3.1 isisSysTable 详细描述.....	3402
151.3.2 isisManAreaAddrTable 详细描述.....	3407
151.3.3 isisAreaAddrTable 详细描述.....	3408
151.3.4 isisSysProtSuppTable 详细描述.....	3408
151.3.5 isisSummAddrTable 详细描述.....	3409
151.3.6 isisRedistributeAddrTable 详细描述.....	3411
151.3.7 isisRouterTable 详细描述.....	3412
151.3.8 isisSysLevelTable 详细描述.....	3414
151.3.9 isisCircTable 详细描述.....	3416
151.3.10 isisCircLevelTable 详细描述.....	3421
151.3.11 isisSystemCounterTable 详细描述.....	3425
151.3.12 isisCircuitCounterTable 详细描述.....	3428
151.3.13 isisPacketCounterTable 详细描述.....	3430
151.3.14 isisISAdjTable 详细描述.....	3433
151.3.15 isisISAdjAreaAddrTable 详细描述.....	3435
151.3.16 isisISAdjIPAddrTable 详细描述.....	3436
151.3.17 isisISAdjProtSuppTable 详细描述.....	3437
151.3.18 isisIPRATable 详细描述.....	3438
151.3.19 isisLSPSummaryTable 详细描述.....	3442
151.3.20 isisNotificationTable 详细描述.....	3444
151.4 告警节点详细描述.....	3447
151.4.1 isisDatabaseOverload 详细描述.....	3447
151.4.2 isisManualAddressDrops 详细描述.....	3448
151.4.3 isisCorruptedLSPDetected 详细描述.....	3448
151.4.4 isisAttemptToExceedMaxSequence 详细描述.....	3449
151.4.5 isisIDLenMismatch 详细描述.....	3449
151.4.6 isisMaxAreaAddressesMismatch 详细描述.....	3450
151.4.7 isisOwnLSPPurge 详细描述.....	3450
151.4.8 isisSequenceNumberSkip 详细描述.....	3451
151.4.9 isisAuthenticationTypeFailure 详细描述.....	3451
151.4.10 isisAuthenticationFailure 详细描述.....	3452
151.4.11 isisVersionSkew 详细描述.....	3452
151.4.12 isisAreaMismatch 详细描述.....	3453
151.4.13 isisRejectedAdjacency 详细描述.....	3453
151.4.14 isisLSPTooLargeToPropagate 详细描述.....	3454
151.4.15 isisOrigLSPBuffSizeMismatch 详细描述.....	3454
151.4.16 isisProtocolsSupportedMismatch 详细描述.....	3455
151.4.17 isisAdjacencyChange 详细描述.....	3455
152 LAG-MIB.....	3456
152.1 功能简介.....	3456
152.2 表间关系.....	3457
152.3 单节点详细描述.....	3459

152.3.1 dot3adTablesLastChanged 详细描述.....	3459
152.4 MIB Table 详细描述.....	3459
152.4.1 dot3adAggTable 详细描述.....	3459
152.4.2 dot3adAggPortListTable 详细描述.....	3461
152.4.3 dot3adAggPortTable 详细描述.....	3462
152.4.4 dot3adAggPortStatsTable 详细描述.....	3468
153 LLDP-EXT-DOT1-MIB.....	3471
153.1 功能简介.....	3471
153.2 表间关系.....	3471
153.3 单节点详细描述.....	3471
153.4 MIB Table 详细描述.....	3472
153.4.1 lldpXdot1ConfigPortVlanTable 详细描述.....	3472
153.4.2 lldpXdot1ConfigVlanNameTable 详细描述.....	3472
153.4.3 lldpXdot1ConfigProtoVlanTable 详细描述.....	3473
153.4.4 lldpXdot1ConfigProtocolTable 详细描述.....	3473
153.4.5 lldpXdot1LocTable 详细描述.....	3474
153.4.6 lldpXdot1LocProtoVlanTable 详细描述.....	3475
153.4.7 lldpXdot1LocVlanNameTable 详细描述.....	3476
153.4.8 lldpXdot1LocProtocolTable 详细描述.....	3476
153.4.9 lldpXdot1RemTable 详细描述.....	3477
153.4.10 lldpXdot1RemProtoVlanTable 详细描述.....	3478
153.4.11 lldpXdot1RemVlanNameTable 详细描述.....	3479
153.4.12 lldpXdot1RemProtocolTable 详细描述.....	3479
153.5 告警节点详细描述.....	3480
154 LLDP-EXT-DOT3-MIB.....	3481
154.1 功能简介.....	3481
154.2 表间关系.....	3481
154.3 单节点详细描述.....	3481
154.4 MIB Table 详细描述.....	3482
154.4.1 lldpXdot3PortConfigTable 详细描述.....	3482
154.4.2 lldpXdot3LocPortTable 详细描述.....	3482
154.4.3 lldpXdot3LocPowerTable 详细描述.....	3483
154.4.4 lldpXdot3LocLinkAggTable 详细描述.....	3485
154.4.5 lldpXdot3LocMaxFrameSizeTable 详细描述.....	3485
154.4.6 lldpXdot3RemPortTable 详细描述.....	3486
154.4.7 lldpXdot3RemPowerTable 详细描述.....	3487
154.4.8 lldpXdot3RemLinkAggTable 详细描述.....	3488
154.4.9 lldpXdot3RemMaxFrameSizeTable 详细描述.....	3489
154.5 告警节点详细描述.....	3489
155 LLDP-MIB.....	3490
155.1 功能简介.....	3490

155.2 表间关系.....	3490
155.3 单节点详细描述.....	3490
155.3.1 lldpMessageTxInterval 详细描述.....	3491
155.3.2 lldpMessageTxHoldMultiplier 详细描述.....	3491
155.3.3 lldpReinitDelay 详细描述.....	3491
155.3.4 lldpTxDelay 详细描述.....	3491
155.3.5 lldpNotificationInterval 详细描述.....	3491
155.3.6 lldpStatsRemTablesLastChangeTime 详细描述.....	3492
155.3.7 lldpStatsRemTablesInserts 详细描述.....	3492
155.3.8 lldpStatsRemTablesDeletes 详细描述.....	3492
155.3.9 lldpStatsRemTablesDrops 详细描述.....	3492
155.3.10 lldpStatsRemTablesAgeouts 详细描述.....	3493
155.3.11 lldpLocChassisIdSubtype 详细描述.....	3493
155.3.12 lldpLocChassisId 详细描述.....	3494
155.3.13 lldpLocSysName 详细描述.....	3494
155.3.14 lldpLocSysDesc 详细描述.....	3494
155.3.15 lldpLocSysCapSupported 详细描述.....	3494
155.3.16 lldpLocSysCapEnabled 详细描述.....	3495
155.4 MIB Table 详细描述.....	3495
155.4.1 lldpPortConfigTable 详细描述.....	3496
155.4.2 lldpStatsTxPortTable 详细描述.....	3496
155.4.3 lldpStatsRxPortTable 详细描述.....	3497
155.4.4 lldpLocPortTable 详细描述.....	3498
155.4.5 lldpLocManAddrTable 详细描述.....	3500
155.4.6 lldpRemTable 详细描述.....	3501
155.4.7 lldpRemManAddrTable 详细描述.....	3504
155.5 告警节点详细描述.....	3505
155.5.1 lldpRemTablesChange 详细描述.....	3505
155.6 不支持节点.....	3505
156 MGMTD-STD-MIB.....	3507
156.1 功能简介.....	3507
156.2 表间关系.....	3508
156.3 MIB Table 详细描述.....	3508
156.3.1 mgmdRouterInterfaceTable 详细描述.....	3508
156.3.2 mgmdRouterCacheTable 详细描述.....	3515
156.3.3 mgmdInverseRouterCacheTable 详细描述.....	3517
156.3.4 mgmdRouterSrcListTable 详细描述.....	3518
156.3.5 mgmdHostInterfaceTable 详细描述.....	3519
156.3.6 mgmdHostCacheTable 详细描述.....	3521
156.3.7 mgmdInverseHostCacheTable 详细描述.....	3523
156.3.8 mgmdHostSrcListTable 详细描述.....	3524
157 MPLS-FTN-STD-MIB.....	3526

157.1 功能简介.....	3526
157.2 表间关系.....	3526
157.3 单节点详细描述.....	3526
157.4 MIB Table 详细描述.....	3526
157.4.1 mplsFTNTable 详细描述.....	3527
157.4.2 mplsFTNMapTable 详细描述.....	3530
157.5 告警节点详细描述.....	3531
158 MPLS-L3VPN-STD-MIB.....	3532
158.1 功能简介.....	3532
158.2 表间关系.....	3533
158.3 单节点详细描述.....	3533
158.3.1 mplsL3VpnScalars 详细描述.....	3534
158.4 MIB Table 详细描述.....	3535
158.4.1 mplsL3VpnIfConfTable 详细描述.....	3535
158.4.2 mplsL3VpnVrfTable 详细描述.....	3538
158.4.3 mplsL3VpnVrfRTTable 详细描述.....	3542
158.4.4 mplsL3VpnVrfSecTable 详细描述.....	3543
158.4.5 mplsL3VpnVrfPerfTable 详细描述.....	3544
158.4.6 mplsL3VpnVrfRteTable 详细描述.....	3545
158.5 告警节点详细描述.....	3554
158.5.1 mplsL3VpnVrfUp 详细描述.....	3554
158.5.2 mplsL3VpnVrfDown 详细描述.....	3555
158.5.3 mplsL3VpnVrfRouteMidThreshExceeded 详细描述.....	3556
158.5.4 mplsL3VpnVrfNumVrfRouteMaxThreshExceeded 详细描述.....	3557
158.5.5 mplsL3VpnNumVrfRouteMaxThreshCleared 详细描述.....	3558
158.6 不支持节点.....	3558
159 MPLS-LDP-GENERIC-STD-MIB.....	3560
159.1 功能简介.....	3560
159.2 表间关系.....	3560
159.3 单节点详细描述.....	3560
159.4 MIB Table 详细描述.....	3560
159.4.1 mplsLdpEntityGenericLRTTable 详细描述.....	3561
159.5 告警节点详细描述.....	3562
160 MPLS-LDP-STD-MIB.....	3563
160.1 功能简介.....	3563
160.2 表间关系.....	3563
160.3 单节点详细描述.....	3564
160.3.1 mplsLdpLsrId 详细描述.....	3565
160.3.2 mplsLdpLsrLoopDetectionCapable 详细描述.....	3565
160.3.3 mplsLdpEntityLastChange 详细描述.....	3566
160.3.4 mplsLdpEntityIndexNext 详细描述.....	3566

160.3.5 mplsLdpPeerLastChange 详细描述.....	3566
160.3.6 mplsFecLastChange 详细描述.....	3567
160.3.7 mplsFecIndexNext 详细描述.....	3567
160.3.8 mplsLdpLspFecLastChange 详细描述.....	3568
160.4 MIB Table 详细描述.....	3568
160.4.1 mplsLdpEntityTable 详细描述.....	3568
160.4.2 mplsLdpEntityStatsTable 详细描述.....	3578
160.4.3 mplsLdpPeerTable 详细描述.....	3582
160.4.4 mplsLdpSessionTable 详细描述.....	3583
160.4.5 mplsLdpHelloAdjacencyTable 详细描述.....	3585
160.4.6 mplsInSegmentLdpLspTable 详细描述.....	3587
160.4.7 mplsOutSegmentLdpLspTable 详细描述.....	3588
160.4.8 mplsFecTable 详细描述.....	3589
160.4.9 mplsLdpLspFecTable 详细描述.....	3591
160.4.10 mplsLdpSessionPeerAddrTable 详细描述.....	3593
160.4.11 mplsLdpSessionStatsTable 详细描述.....	3594
160.5 告警节点详细描述.....	3594
160.5.1 mplsLdpInitSessionThresholdExceeded 详细描述.....	3595
160.5.2 mplsLdpPathVectorLimitMismatch 详细描述.....	3595
160.5.3 mplsLdpSessionUp 详细描述.....	3596
160.5.4 mplsLdpSessionDown 详细描述.....	3596
161 MPLS-LSR-STD-MIB.....	3597
161.1 功能简介.....	3597
161.2 表间关系.....	3597
161.3 单节点详细描述.....	3598
161.3.1 mplsInSegmentIndexNext 详细描述.....	3598
161.3.2 mplsOutSegmentIndexNext 详细描述.....	3598
161.3.3 mplsXCIndexNext 详细描述.....	3599
161.3.4 mplsMaxLabelStackDepth 详细描述.....	3599
161.4 MIB Table 详细描述.....	3599
161.4.1 mplsInterfaceTable 详细描述.....	3600
161.4.2 mplsInterfacePerfTable 详细描述.....	3603
161.4.3 mplsInSegmentTable 详细描述.....	3604
161.4.4 mplsOutSegmentTable 详细描述.....	3608
161.4.5 mplsXCTable 详细描述.....	3612
161.4.6 mplsInSegmentMapTable 详细描述.....	3616
161.5 告警节点详细描述.....	3617
161.5.1 mplsXCUp 详细描述.....	3617
161.5.2 mplsXCDown 详细描述.....	3618
162 MPLS-TE-STD-MIB.....	3619
162.1 功能简介.....	3619
162.2 表间关系.....	3619

162.3 单节点详细描述.....	3619
162.3.1 mplsTunnelConfigured 详细描述.....	3620
162.3.2 mplsTunnelActive 详细描述.....	3620
162.3.3 mplsTunnelMaxHops 详细描述.....	3620
162.3.4 mplsTunnelTEDistProto 详细描述.....	3621
162.4 MIB Table 详细描述.....	3621
162.4.1 mplsTunnelTable 详细描述.....	3621
162.4.2 mplsTunnelHopTable 详细描述.....	3630
162.4.3 mplsTunnelResourceTable 详细描述.....	3633
162.4.4 mplsTunnelARHopTable 详细描述.....	3636
162.4.5 mplsTunnelCHopTable 详细描述.....	3637
162.5 告警节点详细描述.....	3639
162.5.1 mplsTunnelUp 详细描述.....	3640
162.5.2 mplsTunnelDown 详细描述.....	3640
162.5.3 mplsTunnelRerouted 详细描述.....	3640
162.5.4 mplsTunnelReoptimized 详细描述.....	3641
163 MSDP-MIB.....	3642
163.1 功能简介.....	3642
163.2 表间关系.....	3643
163.3 单节点详细描述.....	3643
163.3.1 msdpEnabled 详细描述.....	3643
163.3.2 msdpCacheLifetime 详细描述.....	3644
163.3.3 msdpNumSACacheEntries 详细描述.....	3644
163.3.4 msdpRPAAddress 详细描述.....	3645
163.4 MIB Table 详细描述.....	3645
163.4.1 msdpPeerTable 详细描述.....	3645
163.4.2 msdpSACacheTable 详细描述.....	3652
163.4.3 msdpMeshGroupTable 详细描述.....	3654
163.5 告警节点详细描述.....	3656
163.5.1 msdpEstablished 详细描述.....	3656
163.5.2 msdpBackwardTransition 详细描述.....	3656
164 NOTIFICATION-LOG-MIB.....	3657
164.1 功能简介.....	3657
164.2 表间关系.....	3657
164.3 单节点详细描述.....	3658
164.3.1 nlmConfigGlobalEntryLimit 详细描述.....	3658
164.3.2 nlmConfigGlobalAgeOut 详细描述.....	3659
164.3.3 nlmStatsGlobalNotificationsLogged 详细描述.....	3659
164.3.4 nlmStatsGlobalNotificationsBumped 详细描述.....	3660
164.4 MIB Table 详细描述.....	3660
164.4.1 nlmConfigLogTable 详细描述.....	3660
164.4.2 nlmStatsLogTable 详细描述.....	3664

164.4.3 nlmLogTable 详细描述.....	3665
164.4.4 nlmLogVariableTable 详细描述.....	3667
164.5 不支持节点.....	3669
165 NQA-MIB.....	3671
165.1 功能简介.....	3671
165.2 表间关系.....	3671
165.2.1 NQA 测试例配置信息表与 NQA 测试例配置参数表之间的关系.....	3671
165.2.2 NQA 测试例配置信息表与 NQA 测试例调度配置参数表之间的关系.....	3672
165.2.3 NQA 测试例配置信息表与 NQA 测试例结果统计表之间的关系.....	3673
165.2.4 NQA 测试例配置信息表与 HTTP 测试例结果统计表之间的关系.....	3673
165.2.5 NQA 测试例配置信息表与 Jitter 测试例结果统计表之间的关系.....	3674
165.2.6 NQA 测试例配置信息表与 FTP 测试例结果统计表之间的关系.....	3675
165.2.7 NQA 测试例配置信息表与 NQA 测试例历史结果统计表之间的关系.....	3676
165.3 单节点详细描述.....	3677
165.3.1 nqaVersion 详细描述.....	3677
165.3.2 nqaEnable 详细描述.....	3678
165.3.3 nqaReset 详细描述.....	3678
165.3.4 nqaTimeOfLastSetError 详细描述.....	3678
165.3.5 nqaLastSetError 详细描述.....	3679
165.3.6 nqaNumOfCurrentCtrlEntry 详细描述.....	3679
165.3.7 nqaMaxConcurrentRequests 详细描述.....	3679
165.3.8 nqaMaxNumOfRequests 详细描述.....	3679
165.3.9 nqaJitterVersion 详细描述.....	3680
165.3.10 nqaServerEnable 详细描述.....	3680
165.4 MIB Table 详细描述.....	3680
165.4.1 nqaAdminCtrlTable 详细描述.....	3680
165.4.2 nqaAdminParaTable 详细描述.....	3683
165.4.3 nqaScheduleTable 详细描述.....	3694
165.4.4 nqaTcpServerTable 详细描述.....	3697
165.4.5 nqaUdpServerTable 详细描述.....	3698
165.4.6 nqaResultsTable 详细描述.....	3700
165.4.7 nqaHTTPStatsTable 详细描述.....	3704
165.4.8 nqaJitterStatsTable 详细描述.....	3707
165.4.9 nqaFTPStatsTable 详细描述.....	3714
165.4.10 nqaPathMtuStatsTable 详细描述.....	3717
165.4.11 nqaPathJitterStatsTable 详细描述.....	3720
165.4.12 nqaHistoryTable 详细描述.....	3730
165.5 告警节点详细描述.....	3732
165.5.1 nqaResultsProbeFailed 详细描述.....	3732
165.5.2 nqaResultsTestFailed 详细描述.....	3733
165.5.3 nqaResultsTestCompleted 详细描述.....	3734
165.5.4 nqaResultsThresholdNotification 详细描述.....	3735

165.5.5 nqaHTTPStatsProbeFailed 详细描述.....	3736
165.5.6 nqaHTTPStatsTestFailed 详细描述.....	3737
165.5.7 nqaHTTPStatsTestCompleted 详细描述.....	3738
165.5.8 nqaHTTPStatsThresholdNotification 详细描述.....	3739
165.5.9 nqaJitterStatsTestFailed 详细描述.....	3740
165.5.10 nqaJitterStatsTestCompleted 详细描述.....	3741
165.5.11 nqaFTPStatsProbeFailed 详细描述.....	3742
165.5.12 nqaFTPStatsTestFailed 详细描述.....	3743
165.5.13 nqaFTPStatsTestCompleted 详细描述.....	3744
165.5.14 nqaFTPStatsThresholdNotification 详细描述.....	3744
165.5.15 nqaJitterStatsRTDThresholdNotification 详细描述.....	3745
165.5.16 nqaResultsTestResultChange 详细描述.....	3745
165.6 不支持节点.....	3745
166 OSPF-MIB.....	3747
166.1 功能简介.....	3747
166.2 表间关系.....	3748
166.3 单节点详细描述.....	3750
166.3.1 ospfRouterId 详细描述.....	3750
166.3.2 ospfAdminStat 详细描述.....	3750
166.3.3 ospfVersionNumber 详细描述.....	3750
166.3.4 ospfAreaBdrRtrStatus 详细描述.....	3751
166.3.5 ospfASBdrRtrStatus 详细描述.....	3751
166.3.6 ospfExternLsaCount 详细描述.....	3751
166.3.7 ospfExternLsaCksumSum 详细描述.....	3751
166.3.8 ospfTOSSupport 详细描述.....	3752
166.3.9 ospfOriginateNewLsas 详细描述.....	3752
166.3.10 ospfRxNewLsas 详细描述.....	3752
166.3.11 ospfExtLsdbLimit 详细描述.....	3753
166.3.12 ospfMulticastExtensions 详细描述.....	3754
166.3.13 ospfExitOverflowInterval 详细描述.....	3755
166.3.14 ospfDemandExtensions 详细描述.....	3755
166.3.15 ospfRFC1583Compatibility 详细描述.....	3756
166.3.16 ospfOpaqueLsaSupport 详细描述.....	3756
166.3.17 ospfReferenceBandwidth 详细描述.....	3757
166.3.18 ospfRestartSupport 详细描述.....	3757
166.3.19 ospfRestartInterval 详细描述.....	3757
166.3.20 ospfRestartStrictLsaChecking 详细描述.....	3758
166.3.21 ospfRestartStatus 详细描述.....	3758
166.3.22 ospfRestartAge 详细描述.....	3758
166.3.23 ospfRestartExitReason 详细描述.....	3759
166.3.24 ospfAsLsaCount 详细描述.....	3759
166.3.25 ospfAsLsaCksumSum 详细描述.....	3759

166.3.26 ospfStubRouterSupport 详细描述.....	3760
166.3.27 ospfStubRouterAdvertisement 详细描述.....	3760
166.3.28 ospfDiscontinuityTime 详细描述.....	3760
166.4 MIB Table 详细描述.....	3760
166.4.1 ospfAreaTable 详细描述.....	3760
166.4.2 ospfStubAreaTable 详细描述.....	3764
166.4.3 ospfLsdbTable 详细描述.....	3766
166.4.4 ospfIfTable 详细描述.....	3768
166.4.5 ospfIfMetricTable 详细描述.....	3775
166.4.6 ospfVirtIfTable 详细描述.....	3777
166.4.7 ospfNbrTable 详细描述.....	3781
166.4.8 ospfVirtNbrTable 详细描述.....	3784
166.4.9 ospfExtLsdbTable 详细描述.....	3786
166.4.10 ospfAreaAggregateTable 详细描述.....	3788
166.4.11 ospfLocalLsdbTable 详细描述.....	3790
166.4.12 ospfVirtLocalLsdbTable 详细描述.....	3791
166.4.13 ospfAsLsdbTable 详细描述.....	3793
166.4.14 ospfAreaLsaCountTable 详细描述.....	3795
166.5 告警节点详细描述.....	3796
167 OSPF-TRAP-MIB.....	3797
167.1 功能简介.....	3797
167.2 表间关系.....	3797
167.3 单节点详细描述.....	3797
167.3.1 ospfSetTrap 详细描述.....	3798
167.3.2 ospfConfigErrorType 详细描述.....	3799
167.4 告警节点详细描述.....	3799
167.4.1 ospfVirtIfStateChange 详细描述.....	3800
167.4.2 ospfNbrStateChange 详细描述.....	3801
167.4.3 ospfVirtNbrStateChange 详细描述.....	3802
167.4.4 ospfIfConfigError 详细描述.....	3802
167.4.5 ospfVirtIfConfigError 详细描述.....	3803
167.4.6 ospfIfAuthFailure 详细描述.....	3803
167.4.7 ospfVirtIfAuthFailure 详细描述.....	3803
167.4.8 ospfIfRxBadPacket 详细描述.....	3804
167.4.9 ospfVirtIfRxBadPacket 详细描述.....	3804
167.4.10 ospfTxRetransmit 详细描述.....	3804
167.4.11 ospfVirtIfTxRetransmit 详细描述.....	3805
167.4.12 ospfOriginateLsa 详细描述.....	3805
167.4.13 ospfMaxAgeLsa 详细描述.....	3806
167.4.14 ospfLsdbOverflow 详细描述.....	3806
167.4.15 ospfLsdbApproachingOverflow 详细描述.....	3806
167.4.16 ospfIfStateChange 详细描述.....	3807

167.4.17 ospfNssaTranslatorStatusChange 详细描述.....	3807
167.4.18 ospfRestartStatusChange 详细描述.....	3808
167.4.19 ospfNbrRestartHelperStatusChange 详细描述.....	3808
167.4.20 ospfVirtNbrRestartHelperStatusChange 详细描述.....	3809
168 P-BRIDGE-MIB.....	3810
168.1 功能简介.....	3810
168.2 表间关系.....	3810
168.3 单节点详细描述.....	3810
168.3.1 dot1dTrafficClassesEnabled 详细描述.....	3811
168.4 MIB Table 详细描述.....	3811
168.4.1 dot1dPortCapabilitiesTable 详细描述.....	3811
168.5 告警节点详细描述.....	3812
168.6 不支持节点.....	3812
169 PIM-BSR-MIB.....	3813
169.1 功能简介.....	3813
169.2 表间关系.....	3813
169.3 单节点详细描述.....	3813
169.4 MIB Table 详细描述.....	3814
169.4.1 pimBsrElectedBSRRPSetTable 详细描述.....	3814
169.5 告警节点详细描述.....	3815
170 PIM-STD-MIB.....	3816
170.1 功能简介.....	3816
170.2 表间关系.....	3816
170.3 单节点详细描述.....	3817
170.3.1 pimkeepalivePeriod 详细描述.....	3817
170.3.2 pimRegisterSuppressionTime 详细描述.....	3817
170.3.3 pimStarGEntries 详细描述.....	3818
170.3.4 pimStarGIEntries 详细描述.....	3818
170.3.5 pimSGEntries 详细描述.....	3818
170.3.6 pimSGIEntries 详细描述.....	3818
170.3.7 pimSGRptEntries 详细描述.....	3819
170.3.8 pimSGRptIEntries 详细描述.....	3819
170.3.9 pimOutAsserts 详细描述.....	3819
170.3.10 pimInAsserts 详细描述.....	3819
170.3.11 pimLastAssertInterface 详细描述.....	3820
170.3.12 pimLastAssertGroupAddressType 详细描述.....	3820
170.3.13 pimLastAssertGroupAddress 详细描述.....	3820
170.3.14 pimLastAssertSourceAddressType 详细描述.....	3821
170.3.15 pimLastAssertSourceAddress 详细描述.....	3821
170.3.16 pimNeighborLossNotificationPeriod 详细描述.....	3821
170.3.17 pimNeighborLossCount 详细描述.....	3822

170.3.18 pimInvalidRegisterNotificationPeriod 详细描述.....	3822
170.3.19 pimInvalidRegisterMsgsRcvd 详细描述.....	3822
170.3.20 pimInvalidRegisterAddressType 详细描述.....	3823
170.3.21 pimInvalidRegisterOrigin 详细描述.....	3823
170.3.22 pimInvalidRegisterGroup 详细描述.....	3823
170.3.23 pimInvalidRegisterRp 详细描述.....	3824
170.3.24 pimInvalidJoinPruneNotificationPeriod 详细描述.....	3824
170.3.25 pimInvalidJoinPruneMsgsRcvd 详细描述.....	3824
170.3.26 pimInvalidJoinPruneAddressType 详细描述.....	3825
170.3.27 pimInvalidJoinPruneOrigin 详细描述.....	3825
170.3.28 pimInvalidJoinPruneGroup 详细描述.....	3825
170.3.29 pimInvalidJoinPruneRp 详细描述.....	3826
170.3.30 pimRPMMappingNotificationPeriod 详细描述.....	3826
170.3.31 pimRPMMappingChangeCount 详细描述.....	3826
170.3.32 pimInterfaceElectionNotificationPeriod 详细描述.....	3826
170.3.33 pimInterfaceElectionWinCount 详细描述.....	3827
170.3.34 pimRefreshInterval 详细描述.....	3827
170.3.35 pimDeviceConfigStorageType 详细描述.....	3827
170.4 MIB Table 详细描述.....	3827
170.4.1 pimInterfaceTable 详细描述.....	3827
170.4.2 pimNeighborTable 详细描述.....	3832
170.4.3 pimNbrSecAddressTable 详细描述.....	3834
170.4.4 pimStarGTable 详细描述.....	3835
170.4.5 pimStarGITable 详细描述.....	3840
170.4.6 pimSGTable 详细描述.....	3843
170.4.7 pimSGITable 详细描述.....	3848
170.4.8 pimSGRptTable 详细描述.....	3850
170.4.9 pimSGRptITable 详细描述.....	3851
170.4.10 pimGroupMappingTable 详细描述.....	3852
170.5 告警节点详细描述.....	3854
170.5.1 pimNeighborLoss 详细描述.....	3854
170.5.2 pimInvalidRegister 详细描述.....	3855
170.5.3 pimInvalidJoinPrune 详细描述.....	3855
170.5.4 pimRPMMappingChange 详细描述.....	3855
170.5.5 pimInterfaceElection 详细描述.....	3856
170.6 不支持节点.....	3856
171 Q-BRIDGE-MIB.....	3857
171.1 功能简介.....	3857
171.2 表间关系.....	3858
171.3 单节点详细描述.....	3858
171.3.1 dot1qVlanVersionNumber 详细描述.....	3858
171.3.2 dot1qMaxVlanId 详细描述.....	3859

171.3.3 dot1qMaxSupportedVlans 详细描述.....	3859
171.3.4 dot1qNumVlans 详细描述.....	3859
171.3.5 dot1qGvrpStatus 详细描述.....	3860
171.3.6 dot1qVlanNumDeletes 详细描述.....	3860
171.3.7 dot1qNextFreeLocalVlanIndex 详细描述.....	3861
171.3.8 dot1qConstraintSetDefault 详细描述.....	3861
171.3.9 dot1qConstraintTypeDefault 详细描述.....	3862
171.4 MIB Table 详细描述.....	3862
171.4.1 dot1qVlanCurrentTable 详细描述.....	3862
171.4.2 dot1qVlanStaticTable 详细描述.....	3865
171.4.3 dot1qPortVlanTable 详细描述.....	3867
171.4.4 dot1qLearningConstraintsTable 详细描述.....	3869
171.5 告警节点详细描述.....	3870
172 RFC1213-MIB.....	3871
172.1 功能简介.....	3871
172.2 表间关系.....	3871
172.3 单节点详细描述.....	3872
172.3.1 ipForwarding 详细描述.....	3872
172.3.2 ipDefaultTTL 详细描述.....	3872
172.3.3 ipInReceives 详细描述.....	3873
172.3.4 ipInHdrErrors 详细描述.....	3873
172.3.5 ipInAddrErrors 详细描述.....	3873
172.3.6 ipForwDatagrams 详细描述.....	3874
172.3.7 ipInUnknownProtos 详细描述.....	3874
172.3.8 ipInDiscards 详细描述.....	3874
172.3.9 ipInDelivers 详细描述.....	3875
172.3.10 ipOutRequests 详细描述.....	3875
172.3.11 ipOutDiscards 详细描述.....	3875
172.3.12 ipOutNoRoutes 详细描述.....	3876
172.3.13 ipReasmTimeout 详细描述.....	3876
172.3.14 ipReasmReqds 详细描述.....	3876
172.3.15 ipReasmOKs 详细描述.....	3877
172.3.16 ipReasmFails 详细描述.....	3877
172.3.17 ipFragOKs 详细描述.....	3877
172.3.18 ipFragFails 详细描述.....	3878
172.3.19 ipFragCreates 详细描述.....	3878
172.3.20 ipRoutingDiscards 详细描述.....	3878
172.3.21 icmpInMsgs 详细描述.....	3878
172.3.22 icmpInErrors 详细描述.....	3879
172.3.23 icmpInDestUnreachs 详细描述.....	3879
172.3.24 icmpInTimeExcds 详细描述.....	3879
172.3.25 icmpInParmProbs 详细描述.....	3879

172.3.26 icmpInSrcQuenchs 详细描述.....	3880
172.3.27 icmpInRedirects 详细描述.....	3880
172.3.28 icmpInEchos 详细描述.....	3880
172.3.29 icmpInEchoReps 详细描述.....	3880
172.3.30 icmpInTimestamps 详细描述.....	3881
172.3.31 icmpInTimestampReps 详细描述.....	3881
172.3.32 icmpInAddrMasks 详细描述.....	3881
172.3.33 icmpInAddrMaskReps 详细描述.....	3881
172.3.34 icmpOutMsgs 详细描述.....	3882
172.3.35 icmpOutErrors 详细描述.....	3882
172.3.36 icmpOutDestUnreachs 详细描述.....	3882
172.3.37 icmpOutTimeExcds 详细描述.....	3883
172.3.38 icmpOutParmProbs 详细描述.....	3883
172.3.39 icmpOutSrcQuenchs 详细描述.....	3883
172.3.40 icmpOutRedirects 详细描述.....	3883
172.3.41 icmpOutEchos 详细描述.....	3884
172.3.42 icmpOutEchoReps 详细描述.....	3884
172.3.43 icmpOutTimestamps 详细描述.....	3884
172.3.44 icmpOutTimestampReps 详细描述.....	3884
172.3.45 icmpOutAddrMasks 详细描述.....	3885
172.3.46 icmpOutAddrMaskReps 详细描述.....	3885
172.3.47 tcpRtoAlgorithm 详细描述.....	3885
172.3.48 tcpRtoMin 详细描述.....	3886
172.3.49 tcpRtoMax 详细描述.....	3886
172.3.50 tcpMaxConn 详细描述.....	3886
172.3.51 tcpActiveOpens 详细描述.....	3887
172.3.52 tcpPassiveOpens 详细描述.....	3887
172.3.53 tcpAttemptFails 详细描述.....	3887
172.3.54 tcpEstabResets 详细描述.....	3888
172.3.55 tcpCurrEstab 详细描述.....	3888
172.3.56 tcpInSegs 详细描述.....	3888
172.3.57 tcpOutSegs 详细描述.....	3888
172.3.58 tcpRetransSegs 详细描述.....	3889
172.3.59 tcpInErrs 详细描述.....	3889
172.3.60 tcpOutRsts 详细描述.....	3889
172.3.61 udpInDatagrams 详细描述.....	3889
172.3.62 udpNoPorts 详细描述.....	3890
172.3.63 udpInErrors 详细描述.....	3890
172.3.64 udpOutDatagrams 详细描述.....	3890
172.4 MIB Table 详细描述.....	3890
172.4.1 ipAddrTable 详细描述.....	3890
172.4.2 ipRouteTable 详细描述.....	3892

172.4.3 ipNetToMediaTable 详细描述.....	3895
172.4.4 tcpConnTable 详细描述.....	3897
172.4.5 udpTable 详细描述.....	3898
172.4.6 atTable 详细描述.....	3899
172.5 告警节点详细描述.....	3900
173 RIPv2-MIB.....	3901
173.1 功能简介.....	3901
173.2 表间关系.....	3901
173.3 单节点详细描述.....	3901
173.3.1 rip2GlobalRouteChanges 详细描述.....	3902
173.3.2 rip2GlobalQueries 详细描述.....	3902
173.4 MIB Table 详细描述.....	3902
173.4.1 rip2IfStatTable 详细描述.....	3902
173.4.2 rip2IfConfTable 详细描述.....	3904
173.4.3 rip2PeerTable 详细描述.....	3907
173.5 告警节点详细描述.....	3908
174 RMON-MIB.....	3909
174.1 功能简介.....	3909
174.2 表间关系.....	3909
174.3 单节点详细描述.....	3910
174.4 MIB Table 详细描述.....	3910
174.4.1 etherStatsTable 详细描述.....	3910
174.4.2 historyControlTable 详细描述.....	3913
174.4.3 etherHistoryTable 详细描述.....	3915
174.4.4 alarmTable 详细描述.....	3918
174.4.5 eventTable 详细描述.....	3921
174.4.6 logTable 详细描述.....	3923
174.5 告警节点详细描述.....	3924
174.5.1 risingAlarm 详细描述.....	3924
174.5.2 fallingAlarm 详细描述.....	3925
175 RMON2-MIB.....	3926
175.1 功能简介.....	3926
175.2 表间关系.....	3926
175.3 单节点详细描述.....	3927
175.3.1 protocolDirLastChange 详细描述.....	3927
175.4 MIB Table 详细描述.....	3927
175.4.1 protocolDirTable 详细描述.....	3927
175.4.2 hlHostControlTable 详细描述.....	3932
175.4.3 nlHostTable 详细描述.....	3936
176 SAVI-MIB.....	3939
176.1 功能简介.....	3939

176.2 表间关系.....	3939
176.3 单节点详细描述.....	3939
176.4 MIB Table 详细描述.....	3939
176.4.1 saviObjectsSystemTable 详细描述.....	3939
176.4.2 saviObjectsIfTable 详细描述.....	3947
176.4.3 saviObjectsBindingTable 详细描述.....	3949
176.4.4 saviObjectsFilteringTable 详细描述.....	3951
176.5 告警节点详细描述.....	3952
177 SNMP-FRAMEWORK-MIB.....	3953
177.1 功能简介.....	3953
177.2 表间关系.....	3953
177.3 单节点详细描述.....	3953
177.3.1 snmpEngineID 详细描述.....	3954
177.3.2 snmpEngineBoots 详细描述.....	3954
177.3.3 snmpEngineTime 详细描述.....	3954
177.3.4 snmpEngineMaxMessageSize 详细描述.....	3955
177.4 告警节点详细描述.....	3955
178 SNMP-MPD-MIB.....	3956
178.1 功能简介.....	3956
178.2 表间关系.....	3956
178.3 单节点详细描述.....	3956
178.3.1 snmpUnknownSecurityModels 详细描述.....	3957
178.3.2 snmpInvalidMsgs 详细描述.....	3957
178.3.3 snmpUnknownPDUHandlers 详细描述.....	3958
178.4 MIB Table 详细描述.....	3958
178.5 告警节点详细描述.....	3958
179 SNMP-NOTIFICATION-MIB.....	3959
179.1 功能简介.....	3959
179.2 表间关系.....	3959
179.3 单节点详细描述.....	3960
179.4 MIB Table 详细描述.....	3960
179.4.1 snmpNotifyTable.....	3960
179.4.2 snmpNotifyFilterProfileTable.....	3962
179.4.3 snmpNotifyFilterTable.....	3964
179.5 告警节点详细描述.....	3966
180 SNMP-TARGET-MIB.....	3967
180.1 功能简介.....	3967
180.2 表间关系.....	3967
180.3 单节点详细描述.....	3968
180.3.1 snmpTargetSpinLock 详细描述.....	3969
180.3.2 snmpUnavailableContexts 详细描述.....	3970

180.3.3 snmpUnknownContexts 详细描述.....	3970
180.4 MIB Table 详细描述.....	3970
180.4.1 snmpTargetAddrTable 详细描述.....	3970
180.4.2 snmpTargetParamsTable 详细描述.....	3974
180.5 告警节点详细描述.....	3977
181 SNMP-USER-BASED-SM-MIB.....	3978
181.1 功能简介.....	3978
181.2 表间关系.....	3978
181.3 单节点详细描述.....	3978
181.3.1 usmStatsUnsupportedSecLevels 详细描述.....	3979
181.3.2 usmStatsNotInTimeWindows 详细描述.....	3979
181.3.3 usmStatsUnknownUserNames 详细描述.....	3979
181.3.4 usmStatsUnknownEngineIDs 详细描述.....	3980
181.3.5 usmUserSpinLock 详细描述.....	3980
181.3.6 usmStatsWrongDigests 详细描述.....	3980
181.3.7 usmStatsDecryptionErrors 详细描述.....	3981
181.4 MIB Table 详细描述.....	3981
181.4.1 usmUserTable 详细描述.....	3981
181.5 告警节点详细描述.....	3993
182 SNMP-VIEW-BASED-ACM-MIB.....	3994
182.1 功能简介.....	3994
182.2 表间关系.....	3994
182.3 单节点详细描述.....	3995
182.3.1 vacmViewSpinLock 详细描述.....	3995
182.4 MIB Table 详细描述.....	3995
182.4.1 vacmContextTable 详细描述.....	3995
182.4.2 vacmSecurityToGroupTable 详细描述.....	3996
182.4.3 vacmAccessTable 详细描述.....	3998
182.4.4 vacmViewTreeFamilyTable 详细描述.....	4002
182.5 告警节点详细描述.....	4005
183 SNMPv2-MIB.....	4006
183.1 功能简介.....	4006
183.2 表间关系.....	4006
183.3 单节点详细描述.....	4006
183.3.1 sysDescr 详细描述.....	4006
183.3.2 sysObjectID 详细描述.....	4007
183.3.3 sysUpTime 详细描述.....	4007
183.3.4 sysContact 详细描述.....	4007
183.3.5 sysName 详细描述.....	4008
183.3.6 sysLocation 详细描述.....	4009
183.3.7 sysServices 详细描述.....	4009

183.3.8 snmplnPkts 详细描述.....	4010
183.3.9 snmpOutPkts 详细描述.....	4010
183.3.10 snmplnBadVersions 详细描述.....	4010
183.3.11 snmplnBadCommunityNames 详细描述.....	4011
183.3.12 snmplnBadCommunityUses 详细描述.....	4011
183.3.13 snmplnASNParseErrs 详细描述.....	4011
183.3.14 snmplnTooBigs 详细描述.....	4011
183.3.15 snmplnNoSuchNames 详细描述.....	4012
183.3.16 snmplnBadValues 详细描述.....	4012
183.3.17 snmplnReadOnlys 详细描述.....	4013
183.3.18 snmplnGenErrs 详细描述.....	4013
183.3.19 snmplnTotalReqVars 详细描述.....	4014
183.3.20 snmplnTotalSetVars 详细描述.....	4014
183.3.21 snmplnGetRequests 详细描述.....	4014
183.3.22 snmplnGetNexts 详细描述.....	4015
183.3.23 snmplnSetRequests 详细描述.....	4015
183.3.24 snmplnGetResponses 详细描述.....	4015
183.3.25 snmplnTraps 详细描述.....	4015
183.3.26 snmpOutTooBigs 详细描述.....	4016
183.3.27 snmpOutNoSuchNames 详细描述.....	4016
183.3.28 snmpOutBadValues 详细描述.....	4017
183.3.29 snmpOutGenErrs 详细描述.....	4017
183.3.30 snmpOutGetRequests 详细描述.....	4017
183.3.31 snmpOutGetNexts 详细描述.....	4018
183.3.32 snmpOutSetRequests 详细描述.....	4018
183.3.33 snmpOutGetResponses 详细描述.....	4018
183.3.34 snmpOutTraps 详细描述.....	4019
183.3.35 snmpEnableAuthenTraps 详细描述.....	4019
183.3.36 snmpSilentDrops 详细描述.....	4020
183.3.37 snmpTrapOID 详细描述.....	4020
183.3.38 snmpTrapEnterprise 详细描述.....	4020
183.3.39 snmpSetSerialNo 详细描述.....	4021
183.4 告警节点详细描述.....	4021
183.4.1 coldStart 详细描述.....	4021
183.4.2 warmStart 详细描述.....	4021
183.4.3 authenticationFailure 详细描述.....	4022
184 StationSW-MIB.....	4023
184.1 功能简介.....	4023
184.2 表间关系.....	4023
184.3 单节点详细描述.....	4023
184.3.1 ucMacChange 详细描述.....	4024
184.4 MIB Table 详细描述.....	4024

184.4.1 userTable 详细描述.....	4024
184.4.2 userOperTable 详细描述.....	4026
184.5 告警节点详细描述.....	4026
184.5.1 ucMacChangeTrap 详细描述.....	4027
184.5.2 userTrap 详细描述.....	4027
184.5.3 userOperTrap 详细描述.....	4027
184.6 告警触发配置指导.....	4027
185 TCP-MIB.....	4030
185.1 功能简介.....	4030
185.2 表间关系.....	4031
185.3 单节点详细描述.....	4031
185.3.1 tcpRtoAlgorithm 详细描述.....	4032
185.3.2 tcpRtoMin 详细描述.....	4032
185.3.3 tcpRtoMax 详细描述.....	4033
185.3.4 tcpMaxConn 详细描述.....	4033
185.3.5 tcpActiveOpens 详细描述.....	4034
185.3.6 tcpPassiveOpens 详细描述.....	4034
185.3.7 tcpAttemptFails 详细描述.....	4035
185.3.8 tcpEstabResets 详细描述.....	4035
185.3.9 tcpCurrEstab 详细描述.....	4035
185.3.10 tcpInSegs 详细描述.....	4036
185.3.11 tcpOutSegs 详细描述.....	4036
185.3.12 tcpRetransSegs 详细描述.....	4036
185.3.13 tcpInErrs 详细描述.....	4036
185.3.14 tcpOutRsts 详细描述.....	4037
185.3.15 tcpHCInSegs 详细描述.....	4037
185.3.16 tcpHCOutSegs 详细描述.....	4037
185.4 MIB Table 详细描述.....	4037
185.4.1 tcpConnTable 详细描述.....	4037
185.4.2 tcpConnectionTable 详细描述.....	4039
185.4.3 tcpListenerTable 详细描述.....	4044
186 UDP-MIB.....	4049
186.1 功能简介.....	4049
186.2 表间关系.....	4049
186.3 单节点详细描述.....	4050
186.3.1 udpInDatagrams 详细描述.....	4050
186.3.2 udpNoPorts 详细描述.....	4050
186.3.3 udpInErrors 详细描述.....	4050
186.3.4 udpOutDatagrams 详细描述.....	4051
186.3.5 udpHCInDatagrams 详细描述.....	4051
186.3.6 udpHCOutDatagrams 详细描述.....	4051
186.4 MIB Table 详细描述.....	4052

186.4.1 udpTable 详细描述.....	4052
186.4.2 udpEndpointTable 详细描述.....	4052
187 VRRP-MIB.....	4059
187.1 功能简介.....	4059
187.2 表间关系.....	4060
187.3 单节点详细描述.....	4061
187.3.1 vrrpNodeVersion 详细描述.....	4061
187.3.2 vrrpTrapPacketSrc 详细描述.....	4061
187.3.3 vrrpTrapAuthErrorType 详细描述.....	4061
187.3.4 vrrpRouterChecksumErrors 详细描述.....	4062
187.3.5 vrrpRouterVersionErrors 详细描述.....	4062
187.3.6 vrrpRouterVrIdErrors 详细描述.....	4062
187.4 MIB Table 详细描述.....	4062
187.4.1 vrrpOperTable 详细描述.....	4062
187.4.2 vrrpAssolpAddrTable 详细描述.....	4067
187.4.3 vrrpRouterStatsTable 详细描述.....	4068
187.5 告警节点详细描述.....	4070
187.5.1 vrrpTrapNewMaster 详细描述.....	4071
187.5.2 vrrpTrapAuthFailure 详细描述.....	4071
188 VRRPV3-MIB.....	4072
188.1 功能简介.....	4072
188.2 表间关系.....	4072
188.3 单节点详细描述.....	4072
188.3.1 vrrpv3RouterChecksumErrors 详细描述.....	4073
188.3.2 vrrpv3RouterVersionErrors 详细描述.....	4073
188.3.3 vrrpv3RouterVrIdErrors 详细描述.....	4073
188.3.4 vrrpv3GlobalStatisticsDiscontinuityTime 详细描述.....	4074
188.4 MIB Table 详细描述.....	4074
188.4.1 vrrpv3OperationsTable 详细描述.....	4074
188.4.2 vrrpv3AssociatedIpAddrTable 详细描述.....	4077
188.4.3 vrrpv3StatisticsTable 详细描述.....	4078
188.5 告警节点详细描述.....	4081
188.5.1 vrrpv3NewMaster 详细描述.....	4081
188.5.2 vrrpv3ProtoError 详细描述.....	4081