

目 录

前言.....	ii
1 使用 MIB 查询工具查询产品 MIB 信息.....	1
2 MIB 简介.....	2
2.1 网络管理概述.....	2
2.2 基于 SNMP 的网络管理.....	2
2.3 SNMP 介绍.....	3
2.3.1 SNMP 版本.....	3
2.3.2 SNMP 协议数据单元.....	4
2.3.3 SNMP 报文处理过程.....	4
2.4 MIB 介绍.....	5
2.4.1 MIB 树结构.....	5
2.4.2 MIB 分类.....	6
2.4.3 MIB 的几个概念.....	7
3 MIB 典型使用实例.....	9
3.1 配置网管工具与交换机连接.....	9
3.2 MIB 文件下载.....	13
3.3 MIB 加载.....	13
3.4 常用 MIB 节点.....	20
3.5 通过 MIB 管理配置文件.....	23
3.6 通过 MIB 保存配置文件.....	27
3.7 通过 MIB 升级设备.....	32
3.8 MIB 典型查询和配置案例.....	38
3.8.1 设备物理信息查询和配置.....	38
3.8.1.1 查询 CPU 使用率.....	38
3.8.1.2 查询内存大小.....	39
3.8.1.3 查询内存使用率.....	41
3.8.1.4 查询温度.....	42
3.8.1.5 查询电源额定功率.....	43
3.8.1.6 查询设备功耗信息.....	44
3.8.1.7 查询序列号.....	45
3.8.1.8 查询光模块信息.....	46
3.8.1.9 查询电子标签信息.....	47

3.8.1.10 查询电压.....	49
3.8.1.11 查询风扇状态.....	50
3.8.1.12 配置系统节能模式.....	50
3.8.1.13 配置功耗数据统计周期.....	51
3.8.1.14 查询主备倒换的配置信息.....	52
3.8.2 接口信息查询.....	53
3.8.2.1 查询接口 Up/Down 信息.....	55
3.8.2.2 查询接口报文统计信息.....	56
3.8.2.3 查询接口的 MAC 地址.....	57
3.8.2.4 查询接口的速率信息.....	58
3.8.2.5 查询 Trunk 接口的最小 Up 接口数.....	60
3.8.3 MAC 地址表查询.....	61
3.8.3.1 查询 MAC 地址和接口的对应关系.....	61
3.8.3.2 根据指定条件查询动态 MAC.....	66
3.8.4 VLAN 信息查询.....	76
3.8.4.1 查询已经创建的 VLAN 信息.....	76
3.8.4.2 查询 VLAN 与加入该 VLAN 的接口信息.....	77
3.8.5 STP 查询.....	79
3.8.5.1 查询 STP 使能情况.....	79
3.8.5.2 查询 STP 的类型.....	81
3.8.5.3 查询当前接口的转发状态.....	82
3.8.6 IP 地址信息查询.....	82
3.8.6.1 查询所有接口的 IP 地址.....	83
3.8.6.2 查询某个接口的 IP 地址.....	83
3.8.7 路由总数查询案例.....	84
3.8.7.1 查询各种路由协议的 IP 路由总数.....	84
3.8.8 BFD 信息查询.....	85
3.8.8.1 查询 BFD 状态（UP/DOWN）信息.....	86
3.8.9 VRRP 信息查询.....	87
3.8.9.1 查询 VRRP 备份组的状态信息.....	87
3.8.9.2 查询 VRRP 备份组的虚拟 MAC 地址信息.....	89
3.8.10 QoS 查询.....	90
3.8.10.1 查询 Diff-Serv 模板及其应用状态.....	90
3.8.10.2 查询 Diff-Serv 模板入方向映射关系.....	90
3.8.10.3 查询 Diff-Serv 模板出方向映射关系.....	91
3.8.10.4 查询接口队列统计信息.....	92
3.8.10.5 查询流分类.....	93
3.8.10.6 查询流量监管配置信息.....	94
3.8.11 LLDP 信息查询.....	95
3.8.11.1 LLDP 基本信息查询.....	95
3.8.11.1.1 查询 LLDP 配置信息.....	96
3.8.11.1.2 查询 LLDP 远端设备信息.....	98

3.8.11.1.3 查询 LLDP 本地设备数据.....	99
3.8.11.1.4 查询 LLDP 远端设备数据.....	100
3.8.11.2 LLDP 扩展信息查询.....	101
3.8.11.2.1 查询 LLDP-EXT-DOT1-MIB 信息.....	102
3.8.11.2.2 查询 LLDP-EXT-DOT3-MIB 信息.....	102
3.8.11.3 LLDP 华为 MIB 信息查询.....	103
3.8.11.3.1 查询 HUAWEI-LLDP-MIB 信息.....	104
3.8.12 NQA 信息查询.....	104
3.8.12.1 查看 NQA 测试例的运行结果.....	105
3.8.13 RMON 信息查询.....	106
3.8.13.1 查询 RMON 以太网统计表信息.....	106
3.8.13.2 查询 RMON 历史控制表信息.....	107
3.8.13.3 查询 RMON 以太网历史表信息.....	107
3.8.13.4 查询 RMON 告警表信息.....	108
3.8.13.5 查询 RMON 事件表信息.....	108
3.8.13.6 查询 RMON 日志表信息.....	109
4 BGP4-MIB.....	110
4.1 功能简介.....	110
4.2 表间关系.....	110
4.3 单节点详细描述.....	110
4.3.1 bgpVersion 详细描述.....	111
4.3.2 bgpLocalAs 详细描述.....	111
4.3.3 bgpIdentifier 详细描述.....	112
4.4 MIB Table 详细描述.....	112
4.4.1 bgpPeerTable 详细描述.....	112
4.4.2 bgp4PathAttrTable 详细描述.....	118
4.5 告警节点详细描述.....	122
4.5.1 bgpEstablished 详细描述.....	123
4.5.2 bgpBackwardTransition 详细描述.....	123
5 BRIDGE-MIB.....	124
5.1 功能简介.....	124
5.2 表间关系.....	124
5.3 单节点详细描述.....	125
5.3.1 dot1dBaseBridgeAddress 详细描述.....	125
5.3.2 dot1dBaseNumPorts 详细描述.....	125
5.3.3 dot1dBaseType 详细描述.....	125
5.3.4 dot1dStpPriority 详细描述.....	126
5.3.5 dot1dStpTimeSinceTopologyChange 详细描述.....	126
5.3.6 dot1dStpDesignatedRoot 详细描述.....	126
5.3.7 dot1dStpRootCost 详细描述.....	126
5.3.8 dot1dStpRootPort 详细描述.....	127
5.3.9 dot1dStpMaxAge 详细描述.....	127

5.3.10 dot1dStpHelloTime 详细描述.....	127
5.3.11 dot1dStpHoldTime 详细描述.....	127
5.3.12 dot1dStpForwardDelay 详细描述.....	128
5.3.13 dot1dStpBridgeMaxAge 详细描述.....	128
5.3.14 dot1dStpBridgeHelloTime 详细描述.....	128
5.3.15 dot1dStpBridgeForwardDelay 详细描述.....	128
5.3.16 dot1dTpLearnedEntryDiscards 详细描述.....	129
5.3.17 dot1dTpAgingTime 详细描述.....	129
5.4 MIB Table 详细描述.....	129
5.4.1 dot1dBasePortTable 详细描述.....	129
5.4.2 dot1dStpPortTable 详细描述.....	130
5.4.3 dot1dTpPortTable 详细描述.....	133
5.4.4 dot1dTpFdbTable 详细描述.....	134
5.5 告警节点详细描述.....	135
5.5.1 newRoot 详细描述.....	136
5.5.2 topologyChange 详细描述.....	136
6 DISMAN-NSLOOKUP-MIB.....	137
6.1 功能简介.....	137
6.2 表间关系.....	137
6.3 单节点详细描述.....	138
6.3.1 lookupMaxConcurrentRequests 详细描述.....	138
6.3.2 lookupPurgeTime 详细描述.....	138
6.4 MIB Table 详细描述.....	138
6.4.1 lookupCtlTable 详细描述.....	138
6.4.2 lookupResultsTable 详细描述.....	140
7 DISMAN-PING-MIB.....	142
7.1 功能简介.....	142
7.2 表间关系.....	143
7.3 单节点详细描述.....	143
7.3.1 pingMaxConcurrentRequests 详细描述.....	144
7.4 MIB Table 详细描述.....	144
7.4.1 pingCtlTable 详细描述.....	145
7.4.2 pingResultsTable 详细描述.....	161
7.4.3 pingProbeHistoryTable 详细描述.....	164
7.5 告警节点详细描述.....	166
7.5.1 pingProbeFailed 详细描述.....	167
7.5.2 pingTestFailed 详细描述.....	168
7.5.3 pingTestCompleted 详细描述.....	169
8 DISMAN-TRACEROUTE-MIB.....	170
8.1 功能简介.....	170
8.2 表间关系.....	171

8.3 单节点详细描述.....	171
8.3.1 traceRouteMaxConcurrentRequests 详细描述.....	172
8.4 MIB Table 详细描述.....	172
8.4.1 traceRouteCtlTable 详细描述.....	172
8.4.2 traceRouteResultsTable 详细描述.....	184
8.4.3 traceRouteProbeHistoryTable 详细描述.....	186
8.4.4 traceRouteHopsTable 详细描述.....	189
8.5 告警节点详细描述.....	192
8.5.1 traceRoutePathChange 详细描述.....	192
8.5.2 traceRouteTestFailed 详细描述.....	193
8.5.3 traceRouteTestCompleted 详细描述.....	193
9 ENTITY-MIB.....	194
9.1 功能简介.....	194
9.2 表间关系.....	194
9.3 单节点详细描述.....	196
9.3.1 entLastChangeTime 详细描述.....	196
9.4 MIB Table 详细描述.....	197
9.4.1 entPhysicalTable 详细描述.....	197
9.4.2 entLogicalTable 详细描述.....	199
9.4.3 entLPMappingTable 详细描述.....	201
9.4.4 entAliasMappingTable 详细描述.....	201
9.4.5 entPhysicalContainsTable 详细描述.....	202
9.5 告警节点详细描述.....	202
9.5.1 entConfigChange 详细描述.....	203
9.6 不支持节点.....	203
10 EtherLike-MIB.....	204
10.1 功能简介.....	204
10.2 表间关系.....	204
10.3 单节点详细描述.....	204
10.4 MIB Table 详细描述.....	204
10.4.1 dot3StatsTable 详细描述.....	204
10.4.2 dot3CollTable 详细描述.....	207
10.4.3 dot3ControlTable 详细描述.....	208
10.4.4 dot3PauseTable 详细描述.....	209
10.4.5 dot3HCStatsTable 详细描述.....	211
10.5 告警节点详细描述.....	212
11 HUAWEI-AAA-MIB.....	213
11.1 功能简介.....	213
11.2 表间关系.....	213
11.3 单节点详细描述.....	213
11.4 MIB Table 详细描述.....	213

11.4.1 hwAuthenSchemeTable 详细描述.....	214
11.4.2 hwAcctSchemeTable 详细描述.....	230
11.4.3 hwAcctSchemeExtTable 详细描述.....	231
11.4.4 hwAAAOOfflineRecordTable 详细描述.....	232
11.4.5 hwAAASetting 详细描述.....	235
11.4.6 hwAAASState 详细描述.....	241
11.4.7 hwDomainTable 详细描述.....	242
11.4.8 hwDomainExtTable 详细描述.....	246
11.4.9 hwAuthorSchemeTable 详细描述.....	247
11.4.10 hwLocalUserTable 详细描述.....	260
11.4.11 hwLocalUserExtTable 详细描述.....	263
11.4.12 hwRecordSchemeTable 详细描述.....	264
11.4.13 hwServiceSchemeTable 详细描述.....	265
11.4.14 hwUserGroupTable 详细描述.....	268
11.4.15 hwAccessTable 详细描述.....	271
11.4.16 hwAccessExtTable 详细描述.....	277
11.4.17 hwCutAccessUserTable 详细描述.....	283
11.4.18 hwAuthEventCfgTable 详细描述.....	284
11.4.19 hwAuthorCmdTable 详细描述.....	286
11.4.20 hwOfflineReasonStatTable 详细描述.....	288
11.4.21 hwLocalUserPwPolicyAdmin 详细描述.....	288
11.4.22 hwLocalUserPwPolicyAcc 详细描述.....	289
11.4.23 userAuthenProfileTable 详细描述.....	290
11.4.24 userAuthenticationFreeRuleTable 详细描述.....	296
11.4.25 hwDot1xAccessProfileTable 详细描述.....	297
11.4.26 hwMACAuthenAccessProfileTable 详细描述.....	300
11.4.27 hwPortalAccessProfileTable 详细描述.....	303
11.4.28 userAuthenticationFreeRuleExtTable 详细描述.....	305
11.4.29 hwReAuthenUserTable 详细描述.....	308
11.4.30 hwAccessUserNumberTable 详细描述.....	308
11.4.31 hwWlanVlanPoolTable 详细描述.....	309
11.5 告警节点详细描述.....	310
11.5.1 hwMacMovedQuietMaxUserAlarm 详细描述.....	311
11.5.2 hwMacMovedQuietUserClearAlarm 详细描述.....	311
11.5.3 hwIpStaticUserMixedInsertAlarm 详细描述.....	312
11.5.4 hwNacUserClearAlarm 详细描述.....	312
11.5.5 hwNacMaxUserAlarm 详细描述.....	312
11.5.6 hwChangePasswordAlarm 详细描述.....	313
11.5.7 hwPPPMMaxUserAlarm 详细描述.....	313
11.5.8 hwPPPMMaxUserClearAlarm 详细描述.....	313
11.5.9 hwMacQuietMaxUserAlarm 详细描述.....	314
11.5.10 hwMacQuietUserClearAlarm 详细描述.....	314

11.5.11 hwQuietUserClearAlarm 详细描述.....	315
11.5.12 hwQuietUserMaxAlarm 详细描述.....	315
11.5.13 hwQuietPortClearAlarm 详细描述.....	316
11.5.14 hwQuietPortMaxAlarm 详细描述.....	316
11.5.15 hwMaxUclGroupIpNumAlarm 详细描述.....	317
11.5.16 hwMaxUclGroupIpNumClearAlarm 详细描述.....	317
11.5.17 hwIPGroupChannelUp 详细描述.....	317
11.5.18 hwIPGroupChannelDown 详细描述.....	318
11.5.19 hwHacaChannelUp 详细描述.....	318
11.5.20 hwHacaChannelDown 详细描述.....	318
11.5.21 hwAuthorDynAclRuleExceed 详细描述.....	319
11.5.22 hwAuthorAclRuleExceed 详细描述.....	319
11.5.23 hwDynmicUclGroupIpNumAlarm 详细描述.....	319
11.5.24 hwDynmicUclGroupIpNumResume 详细描述.....	320
11.5.25 hwWirelessUserNumExceedThresholdResume 详细描述.....	320
11.5.26 hwWirelessUserNumExceedThresholdAlarm 详细描述.....	320
11.6 不支持节点.....	320
12 HUAWEI-ACL-MIB.....	337
12.1 功能简介.....	337
12.2 表间关系.....	338
12.3 单节点详细描述.....	339
12.4 MIB Table 详细描述.....	339
12.4.1 hwAclNumGroupTable 详细描述.....	339
12.4.2 hwAclBasicRuleTable 详细描述.....	342
12.4.3 hwAclAdvancedRuleTable 详细描述.....	346
12.4.4 hwAclEthernetFrameRuleTable 详细描述.....	351
12.4.5 hwAclUserRuleTable 详细描述.....	355
12.4.6 hwAclIpv6BasicRuleTable 详细描述.....	361
12.4.7 hwAclIpv6AdvancedRuleTable 详细描述.....	364
12.4.8 hwAclIpv6NumGroupTable 详细描述.....	369
12.4.9 hwAclResourceTrapsTable 详细描述.....	370
12.4.10 hwCounterResourceTrapsTable 详细描述.....	371
12.4.11 hwMeterResourceTrapsTable 详细描述.....	372
12.5 告警节点详细描述.....	373
12.5.1 hwAclResThresholdExceedClearTrap 详细描述.....	373
12.5.2 hwAclResThresholdExceedTrap 详细描述.....	373
12.5.3 hwAclResTotalCountExceedClearTrap 详细描述.....	374
12.5.4 hwAclResTotalCountExceedTrap 详细描述.....	374
12.5.5 hwCounterResThresholdExceedClear 详细描述.....	374
12.5.6 hwCounterResThresholdExceed 详细描述.....	374
12.5.7 hwCounterResTotalCountExceedClear 详细描述.....	375
12.5.8 hwCounterResTotalCountExceed 详细描述.....	375

12.5.9 hwMeterResThresholdExceedClear 详细描述.....	375
12.5.10 hwMeterResThresholdExceed 详细描述.....	376
12.5.11 hwMeterResTotalCountExceedClear 详细描述.....	376
12.5.12 hwMeterResTotalCountExceed 详细描述.....	376
12.6 不支持节点.....	376
13 HUAWEI-ALARM-MIB.....	379
13.1 功能简介.....	379
13.2 表间关系.....	379
13.3 单节点详细描述.....	379
13.3.1 hwMinAlarmSyncIndex 详细描述.....	380
13.3.2 hwMaxAlarmSyncIndex 详细描述.....	380
13.3.3 hwMinEventSyncIndex 详细描述.....	380
13.3.4 hwMaxEventSyncIndex 详细描述.....	380
13.3.5 hwAlarmDateAndTime 详细描述.....	380
13.3.6 hwAlarmOrEventFlag 详细描述.....	381
13.3.7 hwAlarmReasonInfo 详细描述.....	381
13.3.8 hwAlarmSeverity 详细描述.....	382
13.4 MIB Table 详细描述.....	382
13.4.1 hwAlarmSyncTable 详细描述.....	382
13.4.2 hwEventSyncTable 详细描述.....	383
13.4.3 hwAlarmActiveTable 详细描述.....	384
13.4.4 hwEventTable 详细描述.....	385
13.4.5 hwSnmpTargetAddrExtTable 详细描述.....	387
13.4.6 hwSnmpTargetSyncIndexTable 详细描述.....	387
13.4.7 hwAlarmAttrTable 详细描述.....	389
13.4.8 hwEventAttrTable 详细描述.....	390
13.5 告警节点详细描述.....	391
13.5.1 hwAlarmTargetHostDel 详细描述.....	391
13.5.2 hwAlarmStorm 详细描述.....	391
14 HUAWEI-ALARM-RELIABILITY-MIB.....	392
14.1 功能简介.....	392
14.2 表间关系.....	392
14.3 单节点详细描述.....	392
14.3.1 hwARInformPendings 详细描述.....	393
14.3.2 hwARRetryCount 详细描述.....	393
14.3.3 hwARTimeout 详细描述.....	394
14.4 MIB Table 详细描述.....	394
14.5 告警节点详细描述.....	394
15 HUAWEI-AUTODIAGNOSE-MIB.....	395
15.1 功能简介.....	395
15.2 表间关系.....	395

15.3 单节点详细描述.....	396
15.4 MIB Table 详细描述.....	396
15.4.1 hwAutoDiagnoseTable 详细描述.....	396
15.4.2 hwAutoDiagnoseIssueResultTable 详细描述.....	398
15.4.3 hwAutoDiagnoseSubIssueResultTable 详细描述.....	399
15.4.4 hwAutoDiagnoseSubIssueDetailResultTable 详细描述.....	400
15.5 告警节点详细描述.....	401
15.6 不支持节点.....	402
16 HUAWEI-BASE-TRAP-MIB.....	403
16.1 功能简介.....	403
16.2 表间关系.....	403
16.3 单节点详细描述.....	403
16.3.1 hwBaseTrapSeverity 详细描述.....	404
16.3.2 hwBaseTrapProbableCause 详细描述.....	404
16.3.3 hwBaseTrapEventType 详细描述.....	404
16.3.4 hwBaseTrapRelativeResource 详细描述.....	405
16.3.5 hwBaseTrapReasonDescr 详细描述.....	405
16.3.6 hwFIBOverloadModule 详细描述.....	405
16.3.7 hwEntityRatedPower 详细描述.....	405
16.3.8 hwDevAvailablePower 详细描述.....	406
16.3.9 hwDeviceTotalPower 详细描述.....	406
16.3.10 hwBaseTrapCurPortType 详细描述.....	406
16.3.11 hwBaseTrapLastPortType 详细描述.....	406
16.4 MIB Table 详细描述.....	406
16.4.1 hwBaseThresholdTable 详细描述.....	407
16.4.2 hwBaseUsageTable 详细描述.....	409
16.5 告警节点详细描述.....	410
16.5.1 hwFIBOverloadSuspend 详细描述.....	411
16.5.2 hwFIBOverloadSusResume 详细描述.....	411
16.5.3 hwFIBOverloadForward 详细描述.....	412
16.5.4 hwFIBOverloadFwResume 详细描述.....	412
16.5.5 hwEntityRemove 详细描述.....	413
16.5.6 hwEntityInsert 详细描述.....	413
16.5.7 hwEntityReset 详细描述.....	414
16.5.8 hwEntityRegSuccess 详细描述.....	414
16.5.9 hwEntityCommunicateError 详细描述.....	415
16.5.10 hwEntityCommunicateResume 详细描述.....	415
16.5.11 hwEntityBecomeMaster 详细描述.....	416
16.5.12 hwProcessExitTrap 详细描述.....	416
16.5.13 hwTempRisingAlarm 详细描述.....	417
16.5.14 hwTempRisingResume 详细描述.....	418
16.5.15 hwVoltRisingAlarm 详细描述.....	419

16.5.16 hwVoltRisingResume 详细描述.....	420
16.5.17 hwPowerInsufficiencyAlarm 详细描述.....	421
16.5.18 hwPowerInsufficiencyResume 详细描述.....	421
16.5.19 hwPowerOff 详细描述.....	422
16.5.20 hwPowerOn 详细描述.....	422
16.5.21 hwCPUUtilizationRisingAlarm 详细描述.....	423
16.5.22 hwCPUUtilizationResume 详细描述.....	424
16.5.23 hwVoltFallingAlarm 详细描述.....	424
16.5.24 hwVoltFallingResume 详细描述.....	425
16.5.25 hwStorageUtilizationRisingAlarm 详细描述.....	425
16.5.26 hwStorageUtilizationResume 详细描述.....	426
16.5.27 hwEntityInvalid 详细描述.....	426
16.5.28 hwEntityResume 详细描述.....	426
16.5.29 hwEntityResetDone 详细描述.....	427
16.5.30 hwPortPhysicalPortTypeChange 详细描述.....	427
16.5.31 hwPortPhysicalEthHalfDuplexAlarm 详细描述.....	428
16.5.32 hwPortPhysicalEthFullDuplexClear 详细描述.....	428
16.5.33 hwOpticalPowerAbnormal 详细描述.....	429
16.5.34 hwOpticalPowerResume 详细描述.....	430
16.6 不支持节点.....	430
17 HUAWEI-BFD-MIB.....	434
17.1 功能简介.....	434
17.2 表间关系.....	434
17.3 单节点详细描述.....	435
17.3.1 hwBfdVersionNumber 详细描述.....	435
17.3.2 hwBfdAdminStatus 详细描述.....	435
17.3.3 hwBfdSessLimitNumber 详细描述.....	436
17.3.4 hwBfdSessInterfaceLimitNumber 详细描述.....	436
17.3.5 hwBfdSessStaticNumber 详细描述.....	436
17.3.6 hwBfdSessDynamicNumber 详细描述.....	437
17.3.7 hwBfdSessGlobalDefaultIpAddr 详细描述.....	437
17.3.8 hwBfdSessDynamicPingInterval 详细描述.....	437
17.3.9 hwBfdSessDynamicSupportPassive 详细描述.....	438
17.3.10 hwBfdSessDelayUpTime 详细描述.....	438
17.3.11 hwBfdSessMultiDstPort 详细描述.....	439
17.3.12 hwBfdTrapSendInterval 详细描述.....	439
17.4 MIB Table 详细描述.....	439
17.4.1 hwBfdIfConfTable 详细描述.....	439
17.4.2 hwBfdSessionConfTable 详细描述.....	441
17.4.3 hwBfdSessionTable 详细描述.....	456
17.4.4 hwBfdSessionPerTable 详细描述.....	479
17.4.5 hwBfdSlotTable 详细描述.....	481

17.4.6 hwBfdTtlConfTable 详细描述.....	482
17.5 告警节点详细描述.....	484
17.5.1 hwBfdSessDown 详细描述.....	484
17.5.2 hwBfdSessUp 详细描述.....	485
17.5.3 hwBfdSessReachLimit 详细描述.....	485
17.5.4 hwBfdSessReachLimitBindIf 详细描述.....	486
18 HUAWEI-BGP-VPN-MIB.....	487
18.1 功能简介.....	487
18.2 表间关系.....	487
18.3 单节点详细描述.....	488
18.3.1 hwBgpPeerSessionNum 详细描述.....	488
18.3.2 hwlBgpPeerSessionNum 详细描述.....	488
18.3.3 hwEBgpPeerSessionNum 详细描述.....	488
18.3.4 hwBgpPeerSessionMaxNum 详细描述.....	488
18.3.5 hwBgpDynamicPeerSessionNum 详细描述.....	489
18.3.6 hwBgpDynamicPeerSessionMaxNum 详细描述.....	489
18.4 MIB Table 详细描述.....	489
18.4.1 hwBgpPeerAddrFamilyTable 详细描述.....	489
18.4.2 hwBgpPeerTable 详细描述.....	491
18.4.3 hwBgpPeerRouteTable 详细描述.....	494
18.4.4 hwBgpPeerMessageTable 详细描述.....	495
18.4.5 hwBgpPeerConfigTable 详细描述.....	498
18.4.6 hwBgpVpnTunnelTable 详细描述.....	499
18.4.7 hwBgpVpnServiceIdTable 详细描述.....	502
18.4.8 hwTnl2VpnTrapTable 详细描述.....	503
18.4.9 hwBgpVpnScalars 详细描述.....	504
18.4.10 hwBgpRouteLimitTable 详细描述.....	505
18.5 告警节点详细描述.....	507
18.5.1 hwBgpPeerRouteNumThresholdExceed 详细描述.....	507
18.5.2 hwBgpPeerRouteNumThresholdClear 详细描述.....	507
18.5.3 hwBgpPeerGRStatusChange 详细描述.....	508
18.5.4 hwBgpPeerEstablished 详细描述.....	508
18.5.5 hwBgpPeerBackwardTransition 详细描述.....	508
18.5.6 hwBgpRouteThresholdExceed 详细描述.....	509
18.5.7 hwBgpRouteThresholdClear 详细描述.....	509
18.5.8 hwBgpRouteMaxExceed 详细描述.....	509
18.5.9 hwBgpRouteMaxClear 详细描述.....	510
18.5.10 hwTnl2VpnTrapEvent 详细描述.....	510
18.5.11 hwBgpDynamicPeerSessionExceed 详细描述.....	510
18.5.12 hwBgpDynamicPeerSessionExceedClear 详细描述.....	511
19 HUAWEI-BRAS-RADIUS-MIB.....	512
19.1 功能简介.....	512

19.2 表间关系.....	512
19.3 单节点详细描述.....	513
19.4 MIB Table 详细描述.....	513
19.4.1 hwRadiusAuthorServerTable 详细描述.....	513
19.4.2 hwRadiusGroupTable 详细描述.....	515
19.4.3 hwRadiusServerTable 详细描述.....	523
19.4.4 hwRadiusAttrCheckTable 详细描述.....	526
19.4.5 hwRadiusAttrDisableTable 详细描述.....	527
19.4.6 hwRadiusAttrTranslateTable 详细描述.....	528
19.4.7 hwRadiusAttrSetTable 详细描述.....	532
19.4.8 hwRadiusAccountTest 详细描述.....	533
19.5 告警节点详细描述.....	534
19.5.1 hwRadiusAuthServerUp 详细描述.....	535
19.5.2 hwRadiusAuthServerDown 详细描述.....	535
19.5.3 hwRadiusAcctServerUp 详细描述.....	535
19.5.4 hwRadiusAcctServerDown 详细描述.....	535
19.5.5 hwRadiusAuthServerForceUp 详细描述.....	536
19.5.6 hwRadiusAcctServerForceUp 详细描述.....	536
19.6 不支持节点.....	536
20 HUAWEI-BRAS-SRVCFG-EAP-MIB.....	538
20.1 功能简介.....	538
20.2 表间关系.....	538
20.3 单节点详细描述.....	538
20.3.1 hwDot1xGlobal 详细描述.....	538
20.3.2 hwDot1xAuthenMethod 详细描述.....	539
20.3.3 hwDot1xDhcpTrigger 详细描述.....	539
20.3.4 hwDot1xQuietPeriod 详细描述.....	540
20.3.5 hwDot1xRetry 详细描述.....	540
20.3.6 hwDot1xTimerQuietPeriod 详细描述.....	541
20.3.7 hwDot1xTimerClientTimeout 详细描述.....	541
20.3.8 hwDot1xTimerTxPeriod 详细描述.....	542
20.3.9 hwDot1xReauthenPeriod 详细描述.....	542
20.3.10 hwDot1xQuietFailTimes 详细描述.....	542
20.4 MIB Table 详细描述.....	543
20.4.1 hwDot1xPortConfigTable 详细描述.....	543
20.5 告警节点详细描述.....	547
20.5.1 hwSrvcfgEapMaxUserAlarm 详细描述.....	547
20.6 不支持节点.....	548
21 HUAWEI-BRAS-SRVCFG-STATICUSER-MIB.....	549
21.1 功能简介.....	549
21.2 表间关系.....	549
21.3 单节点详细描述.....	549

21.3.1 hwStaticUserPassword 详细描述.....	549
21.3.2 hwStaticUserNameFormatInclud 详细描述.....	550
21.4 MIB Table 详细描述.....	550
21.4.1 hwStaticUserTable 详细描述.....	550
21.5 告警节点详细描述.....	552
21.6 不支持节点.....	552
22 HUAWEI-BULKSTAT-MIB.....	553
22.1 功能简介.....	553
22.2 表间关系.....	554
22.3 单节点详细描述.....	554
22.3.1 hwBulkStatEnable 详细描述.....	554
22.3.2 hwBulkStatCollectCapability 详细描述.....	555
22.3.3 hwBulkStatDefineMaxFiles 详细描述.....	555
22.3.4 hwBulkStatDefineFiles 详细描述.....	555
22.3.5 hwBulkStatDefineObjects 详细描述.....	555
22.3.6 hwBulkStatDefineFileTableNextIndex 详细描述.....	556
22.3.7 hwBulkStatTrapEnable 详细描述.....	556
22.4 MIB Table 详细描述.....	556
22.4.1 hwBulkStatDefineFileTable 详细描述.....	556
22.4.2 hwBulkStatDefineObjectTable 详细描述.....	561
22.5 告警节点详细描述.....	562
22.5.1 hwBulkStatCollectIncomplete 详细描述.....	563
22.5.2 hwBulkStatCollectResume 详细描述.....	563
22.5.3 hwBulkStatURLConnectionFail 详细描述.....	563
22.5.4 hwBulkStatURLConnectionResume 详细描述.....	564
22.5.5 hwBulkStatTransferFileDiscard 详细描述.....	564
23 HUAWEI-CBQOS-MIB.....	565
23.1 功能简介.....	565
23.2 表间关系.....	565
23.3 单节点详细描述.....	568
23.3.1 hwCBQoSClassifierIndexNext 详细描述.....	568
23.3.2 hwCBQoSBehaviorIndexNext 详细描述.....	568
23.3.3 hwCBQoSPolicyIndexNext 详细描述.....	569
23.4 MIB Table 详细描述.....	569
23.4.1 hwCBQoSClassifierCfgInfoTable 详细描述.....	569
23.4.2 hwCBQoSMatchRuleCfgInfoTable 详细描述.....	570
23.4.3 hwCBQoSBehaviorCfgInfoTable 详细描述.....	576
23.4.4 hwCBQoSCarCfgInfoTable 详细描述.....	577
23.4.5 hwCBQoSRemarkCfgInfoTable 详细描述.....	580
23.4.6 hwCBQoSFirewallCfgInfoTable 详细描述.....	583
23.4.7 hwCBQoSMirrorCfgInfoTable 详细描述.....	584
23.4.8 hwCBQoSCountCfgInfoTable 详细描述.....	585

23.4.9 hwCBQoSPolicyCfgInfoTable 详细描述.....	586
23.4.10 hwCBQoSPolicyClassCfgInfoTable 详细描述.....	587
23.4.11 hwCBQoSIfApplyPolicyTable 详细描述.....	589
23.4.12 hwCBQoSvlanApplyPolicyTable 详细描述.....	590
23.4.13 hwCBQoSPolicyStatisticsTable 详细描述.....	591
23.4.14 hwCBQoSPolicyStatisticsClassifierTable 详细描述.....	593
23.5 告警节点详细描述.....	594
23.6 不支持节点.....	595
24 HUAWEI-CCC-MIB.....	598
24.1 功能简介.....	598
24.2 表间关系.....	598
24.3 单节点详细描述.....	598
24.3.1 hwCCCVcStateChangeReason 详细描述.....	599
24.4 MIB Table 详细描述.....	599
24.4.1 hwCCCVcTable 详细描述.....	599
24.5 告警节点详细描述.....	602
24.5.1 hwCCCVcDown 详细描述.....	603
24.5.2 hwCCCVcUp 详细描述.....	603
24.6 附录.....	603
24.6.1 hwCCCVcStateChangeReason.....	603
24.6.2 hwCCCVcEncapType.....	605
25 HUAWEI-CONFIG-MAN-MIB.....	606
25.1 功能简介.....	606
25.2 表间关系.....	607
25.3 单节点详细描述.....	609
25.3.1 hwCfgRunModifiedLast 详细描述.....	609
25.3.2 hwCfgRunSavedLast 详细描述.....	609
25.3.3 hwCfgStartModifiedLast 详细描述.....	610
25.3.4 hwCfgLogLimitedEntries 详细描述.....	610
25.3.5 hwCfgLogDeletedEntries 详细描述.....	610
25.3.6 hwCfgLogWantBackup 详细描述.....	611
25.3.7 hwCfgOperateGlobalEntryLimit 详细描述.....	611
25.3.8 hwCfgOperateEntryAgeOutTime 详细描述.....	611
25.3.9 hwCfgOperateResultGlobalEntryLimit 详细描述.....	612
25.3.10 hwCfgOperateCompareConfig 详细描述.....	612
25.3.11 hwCfgRestoreErrCode 详细描述.....	613
25.3.12 hwCfgOperateLockConfigDataStore 详细描述.....	614
25.3.13 hwCfgSaveAutoInterval 详细描述.....	615
25.3.14 hwCfgSaveAutoTime 详细描述.....	615
25.3.15 hwCfgSaveAutoCpuLimit 详细描述.....	616
25.3.16 hwCfgSaveAutoDelay 详细描述.....	616
25.3.17 hwCfgSaveManualTime 详细描述.....	616

25.4 MIB Table 详细描述.....	616
25.4.1 hwCfgLogTable 详细描述.....	616
25.4.2 hwCfgOperateTable 详细描述.....	622
25.4.3 hwCfgOperateResultTable 详细描述.....	626
25.4.4 hwCfgBackup2ServerTable 详细描述.....	630
25.4.5 hwCfgOperateLevelUsersTable 详细描述.....	633
25.5 告警节点详细描述.....	634
25.5.1 hwCfgManEventlog 详细描述.....	635
25.5.2 hwCfgB2STransferFail 详细描述.....	635
25.5.3 hwCfgB2SOperate 详细描述.....	636
25.5.4 hwCfgOperateCompletion 详细描述.....	636
25.5.5 hwCfgRestoreFail 详细描述.....	636
26 HUAWEI-CLOCK-MIB.....	637
26.1 功能简介.....	637
26.2 表间关系.....	637
26.3 单节点详细描述.....	637
26.3.1 hwClockSourceEthClkEnable 详细描述.....	638
26.3.2 hwClockSourceSsmUnknown 详细描述.....	638
26.3.3 hwClockSourceSysClkWorkMode 详细描述.....	638
26.3.4 hwClockSourceSsmControl 详细描述.....	639
26.3.5 hwClockSourceHoldMode 详细描述.....	639
26.3.6 hwClockSourceFreqCheckEnable 详细描述.....	639
26.3.7 hwClockSourceFreqCheckLeftRange 详细描述.....	639
26.3.8 hwClockSourceFreqCheckRightRange 详细描述.....	640
26.3.9 hwClockSourceRetrieveMode 详细描述.....	640
26.3.10 hwClockTimeUsedSource 详细描述.....	640
26.3.11 hwClockExtTimeInputType 详细描述.....	641
26.3.12 hwClockExtTimeOutputType 详细描述.....	641
26.4 MIB Table 详细描述.....	641
26.4.1 hwClockSourceSelTable 详细描述.....	641
26.4.2 hwClockSourceCfgTable 详细描述.....	643
26.4.3 hwClockBitsCfgTable 详细描述.....	646
26.4.4 hwClockPortCfgTable 详细描述.....	651
26.5 不支持节点.....	653
27 HUAWEI-CPU-MIB.....	654
27.1 功能简介.....	654
27.2 表间关系.....	654
27.3 单节点详细描述.....	654
27.4 MIB Table 详细描述.....	655
27.4.1 hwCpuDevTable 详细描述.....	655
27.5 告警节点详细描述.....	656

28 HUAWEI-DAD-MIB.....	657
28.1 功能简介.....	657
28.2 表间关系.....	657
28.3 单节点详细描述.....	657
28.4 MIB Table 详细描述.....	657
28.5 告警节点详细描述.....	657
28.5.1 hwMadConflictDetect 详细描述.....	658
28.5.2 hwMadConflictResume 详细描述.....	658
29 HUAWEI-DC-TRAP-MIB.....	659
29.1 功能简介.....	659
29.2 表间关系.....	659
29.3 单节点详细描述.....	659
29.4 MIB Table 详细描述.....	659
29.5 告警节点详细描述.....	659
29.5.1 hwSuperChangeSuccesful 详细描述.....	660
29.5.2 hwSuperChangeFailure 详细描述.....	660
29.6 不支持节点.....	660
30 HUAWEI-DATASYNC-MIB.....	666
30.1 功能简介.....	666
30.2 表间关系.....	666
30.3 单节点详细描述.....	666
30.3.1 hwCurrentCfgChgSeqID 详细描述.....	667
30.3.2 hwCfgChgSeqIDReveralCount 详细描述.....	667
30.3.3 hwCfgChgTableMaxItem 详细描述.....	667
30.4 MIB Table 详细描述.....	667
30.4.1 hwCfgChgTable 详细描述.....	667
30.4.2 hwCollectTable 详细描述.....	670
30.5 告警节点详细描述.....	672
30.5.1 hwCfgChgNotify 详细描述.....	672
31 HUAWEI-DEVICE-MIB.....	673
31.1 功能简介.....	673
31.2 表间关系.....	673
31.3 单节点详细描述.....	673
31.4 MIB Table 详细描述.....	673
31.4.1 hwFrameTable 详细描述.....	673
31.4.2 hwSlotTable 详细描述.....	674
31.5 告警节点详细描述.....	675
32 HUAWEI-DHCPR-MIB.....	676
32.1 功能简介.....	676
32.2 表间关系.....	676
32.3 单节点详细描述.....	676

32.3.1 hwdhCPRelayCycleStatus 详细描述.....	676
32.3.2 hwdhCPRRxBadPktNum 详细描述.....	677
32.3.3 hwdhCPRRxServerPktNum 详细描述.....	677
32.3.4 hwdhCPRTxServerPktNum 详细描述.....	677
32.3.5 hwdhCPRRxClientPktNum 详细描述.....	677
32.3.6 hwdhCPRTxClientPktNum 详细描述.....	678
32.3.7 hwdhCPRTxClientUniPktNum 详细描述.....	678
32.3.8 hwdhCPRTxClientBroPktNum 详细描述.....	678
32.3.9 hwdhCPRelayDiscoverPktNum 详细描述.....	678
32.3.10 hwdhCPRelayRequestPktNum 详细描述.....	679
32.3.11 hwdhCPRelayDeclinePktNum 详细描述.....	679
32.3.12 hwdhCPRelayReleasePktNum 详细描述.....	679
32.3.13 hwdhCPRelayInformPktNum 详细描述.....	679
32.3.14 hwdhCPRelayOfferPktNum 详细描述.....	680
32.3.15 hwdhCPRelayAckPktNum 详细描述.....	680
32.3.16 hwdhCPRelayNakPktNum 详细描述.....	680
32.3.17 hwdhCPRelayStatisticsReset 详细描述.....	680
32.4 MIB Table 详细描述.....	681
32.4.1 hwdhCPRIPTable 详细描述.....	681
32.4.2 hwdhCPRSeletAllocateModeTable 详细描述.....	682
32.5 告警节点详细描述.....	683
32.5.1 hwpDRouteExceed 详细描述.....	683
32.5.2 hwpDRouteExceedResume 详细描述.....	683
33 HUAWEI-DHCPS-MIB.....	684
33.1 功能简介.....	684
33.2 表间关系.....	684
33.3 单节点详细描述.....	687
33.3.1 hwdhCPSServiceStatus 详细描述.....	687
33.3.2 hwdhCPSDetectingServerStatus 详细描述.....	688
33.3.3 hwdhCPSPingNum 详细描述.....	688
33.3.4 hwdhCPSPingTimeout 详细描述.....	688
33.3.5 hwdhCPSWriteDataStatus 详细描述.....	688
33.3.6 hwdhCPSWriteDataDirection 详细描述.....	689
33.3.7 hwdhCPSWriteDataDelay 详细描述.....	689
33.3.8 hwdhCPSWriteDataRecover 详细描述.....	689
33.3.9 hwdhCPSIPInUseResetIP 详细描述.....	690
33.3.10 hwdhCPSConflictIPResetIP 详细描述.....	690
33.3.11 hwdhCPSIPResetFlag 详细描述.....	690
33.3.12 hwdhCPSGlobalPoolNumber 详细描述.....	691
33.3.13 hwdhCPSGlobalPoolAutoBindingNum 详细描述.....	691
33.3.14 hwdhCPSGlobalPoolManualBindingNum 详细描述.....	691
33.3.15 hwdhCPSGlobalPoolExpiredBindingNum 详细描述.....	692

33.3.16	hwDHCPsInterfacePoolNumber 详细描述.....	692
33.3.17	hwDHCPsInterfacePoolAutoBindingNum 详细描述.....	692
33.3.18	hwDHCPsInterfacePoolManualBindingNum 详细描述.....	693
33.3.19	hwDHCPsInterfacePoolExpiredBindingNum 详细描述.....	693
33.3.20	hwDHCPsBadPktNum 详细描述.....	693
33.3.21	hwDHCPsBootRequestPktNum 详细描述.....	694
33.3.22	hwDHCPsDiscoverPktNum 详细描述.....	694
33.3.23	hwDHCPsRequestPktNum 详细描述.....	694
33.3.24	hwDHCPsDeclinePktNum 详细描述.....	695
33.3.25	hwDHCPsReleasePktNum 详细描述.....	695
33.3.26	hwDHCPsInformPktNum 详细描述.....	695
33.3.27	hwDHCPsBootReplyPktNum 详细描述.....	696
33.3.28	hwDHCPsOfferPktNum 详细描述.....	696
33.3.29	hwDHCPsAckPktNum 详细描述.....	696
33.3.30	hwDHCPsNakPktNum 详细描述.....	697
33.3.31	hwDHCPsStatisticsReset 详细描述.....	697
33.4	MIB Table 详细描述.....	697
33.4.1	hwDHCPsGlobalPoolTable 详细描述.....	697
33.4.2	hwDHCPsGlobalPoolConfigTable 详细描述.....	698
33.4.3	hwDHCPsGlobalPoolParaTable 详细描述.....	701
33.4.4	hwDHCPsGlobalPoolOptionTable 详细描述.....	705
33.4.5	hwDHCPsInterfacePoolParaTable 详细描述.....	707
33.4.6	hwDHCPsInterfacePoolOptionTable 详细描述.....	711
33.4.7	hwDHCPsInterfacePoolStaticBindTable 详细描述.....	713
33.4.8	hwDHCPsIPInUseTable 详细描述.....	714
33.4.9	hwDHCPsIPPOOLForbiddenIPTable 详细描述.....	715
33.4.10	hwDHCPsIPPOOLConflictIPTable 详细描述.....	716
33.5	告警节点详细描述.....	717
33.6	不支持节点.....	718
34	HUAWEI-DHCP-SNOOPING-MIB.....	719
34.1	功能简介.....	719
34.2	表间关系.....	719
34.3	单节点详细描述.....	721
34.3.1	hwDhcpSnpGlobal 详细描述.....	721
34.3.2	hwDhcpPktRateCheck 详细描述.....	721
34.3.3	hwDhcpPktRate 详细描述.....	722
34.3.4	hwDhcpPktRateAlarmThreshold 详细描述.....	722
34.3.5	hwDhcpPktRateAlarmEnable 详细描述.....	722
34.3.6	hwDhcpSnpBindTblNomatchedArpGlobalAction 详细描述.....	723
34.3.7	hwDhcpSnpBindTblNomatchedIpGlobalAction 详细描述.....	723
34.3.8	hwDhcpSnpBindTblAutosaveFilename 详细描述.....	723
34.3.9	hwDhcpSnpBindTblAutosave 详细描述.....	723

34.3.10 hwDhcpSnpGlobalThreshold 详细描述.....	724
34.3.11 hwDhcpPktRateDiscardNum 详细描述.....	724
34.4 MIB Table 详细描述.....	724
34.4.1 hwDhcpSnpCfgTable 详细描述.....	724
34.4.2 hwDhcpSnpBindTable 详细描述.....	729
34.4.3 hwDhcpSnpFalsePktStatisticTable 详细描述.....	732
34.4.4 hwDhcpSnpGlobalOption82PktFormatTable 详细描述.....	733
34.5 告警节点详细描述.....	734
34.5.1 hwDhcpSnpChaddrAlarm 详细描述.....	734
34.5.2 hwUntrustedReplyPktAlarm 详细描述.....	735
34.5.3 hwNomatchSnpBindTblDhcpPktAlarm 详细描述.....	735
34.5.4 hwDhcpPktRateAlarm 详细描述.....	735
34.5.5 hwSnpUserNumberAlarmIf 详细描述.....	736
34.5.6 hwSnpUserNumberAlarmIfResume 详细描述.....	736
34.5.7 hwSnpUserNumberAlarmVlan 详细描述.....	736
34.5.8 hwSnpUserNumberAlarmVlanResume 详细描述.....	737
34.5.9 hwSnpUserNumberAlarmGlobal 详细描述.....	737
34.5.10 hwSnpUserNumberAlarmGlobalResume 详细描述.....	737
34.5.11 hwNdSnpUserNumberAlarmIf 详细描述.....	738
34.5.12 hwNdSnpUserNumberAlarmIfResume 详细描述.....	738
34.5.13 hwNdSnpUserNumberAlarmGlobal 详细描述.....	738
34.5.14 hwNdSnpUserNumberAlarmGlobalResume 详细描述.....	739
34.5.15 hwNomatchSnpBindTblDhcpv6PktAlarm 详细描述.....	739
34.5.16 hwNomatchSnpBindTblNDPktAlarm 详细描述.....	739
34.5.17 hwSnpRemoteBackupAlarm 详细描述.....	740
34.5.18 hwSnpRemoteBackupAlarmResume 详细描述.....	740
34.5.19 hwRequestNoTrustPktAlarm 详细描述.....	740
34.5.20 hwNomatchSnpBindTblNDPktAlarmBd 详细描述.....	741
34.5.21 hwDhcpSnpChaddrAlarmBd 详细信息.....	741
34.5.22 hwNomatchSnpBindTblDhcpPktAlarmBd 详细信息.....	741
34.5.23 hwUntrustedReplyPktAlarmBd 详细信息.....	742
34.5.24 hwDHCPv6SnpDetectAlarm 详细信息.....	742
34.5.25 hwRequestNoTrustPktAlarmBd 详细信息.....	742
34.6 不支持节点.....	743
35 HUAWEI-DIE-MIB.....	744
35.1 功能简介.....	744
35.2 表间关系.....	744
35.3 单节点详细描述.....	744
35.3.1 hwDeviceSensorDhcpOption 详细描述.....	744
35.3.2 hwDeviceSensorLLDPTlv 详细描述.....	745
35.4 MIB Table 详细描述.....	745
35.4.1 hwDIETable 详细描述.....	745

35.4.2 hwDIERuleTable 详细描述.....	747
35.5 告警节点详细描述.....	750
36 HUAWEI-DNS-MIB.....	751
36.1 功能简介.....	751
36.2 表间关系.....	751
36.3 单节点详细描述.....	751
36.4 MIB Table 详细描述.....	751
36.4.1 hwDnsHostsDynamicTable 详细描述.....	751
36.4.2 hwDns6HostsDynamicTable 详细描述.....	753
37 HUAWEI-DLDP-MIB.....	755
37.1 功能简介.....	755
37.2 表间关系.....	755
37.3 单节点详细描述.....	755
37.3.1 hwDldpEnable 详细描述.....	755
37.3.2 hwDldpUnidirectionalShutdown 详细描述.....	756
37.3.3 hwDldpWorkMode 详细描述.....	756
37.3.4 hwDldpAdvertInterval 详细描述.....	757
37.3.5 hwDelayDownTimer 详细描述.....	757
37.3.6 hwDldpAuthenMode 详细描述.....	757
37.3.7 hwDldpMd5Password 详细描述.....	758
37.3.8 hwDldpSimplePassword 详细描述.....	759
37.3.9 hwDldpShaPassword 详细描述.....	760
37.4 MIB Table 详细描述.....	760
37.4.1 hwDldpPortTable 详细描述.....	760
37.4.2 hwDldpNeighbourTable 详细描述.....	762
37.4.3 hwDldpIfTable 详细描述.....	763
37.4.4 hwDldpIfNeighbourTable 详细描述.....	765
37.4.5 hwDldpPortStatisticsTable 详细描述.....	766
37.4.6 hwDldpIfStatisticsTable 详细描述.....	768
37.5 告警节点详细描述.....	769
37.5.1 hwDldpUnidirectionalLink 详细描述.....	769
37.5.2 hwDldpLinkResume 详细描述.....	769
37.5.3 hwDldpLoopDetect 详细描述.....	770
37.5.4 hwDldpLoopResume 详细描述.....	770
37.5.5 hwDldpNeighborNum 详细描述.....	770
37.5.6 hwDldpNeighborNumResume 详细描述.....	771
38 HUAWEI-ERPS-MIB.....	772
38.1 功能简介.....	772
38.2 表间关系.....	773
38.3 单节点详细描述.....	775
38.3.1 hwErpsGlobalResetRapsPktCnt 详细描述.....	775

38.4 MIB Table 详细描述.....	775
38.4.1 hwErpsRingConfigTable 详细描述.....	775
38.4.2 hwErpsRingStatusTable 详细描述.....	778
38.4.3 hwErpsPortConfigTable 详细描述.....	780
38.4.4 hwErpsPortStatusTable 详细描述.....	782
38.4.5 hwErpsPortStatisticsTable 详细描述.....	783
38.4.6 hwErpsPortTrackTable 详细描述.....	784
38.5 告警节点详细描述.....	786
38.5.1 hwErpsFwStateForwarding 详细描述.....	786
38.5.2 hwErpsFwStateDiscarding 详细描述.....	787
39 HUAWEI-ERRORDOWN-MIB.....	788
39.1 功能简介.....	788
39.2 表间关系.....	788
39.3 单节点详细描述.....	788
39.3.1 hwErrordownCause 详细描述.....	789
39.3.2 hwErrordownRecoverType 详细描述.....	789
39.4 告警节点详细描述.....	789
39.4.1 hwErrordown 详细描述.....	789
39.4.2 hwErrordownRecovery 详细描述.....	790
40 HUAWEI-ENERGYMNGT-MIB.....	791
40.1 功能简介.....	791
40.2 表间关系.....	791
40.3 单节点详细描述.....	791
40.3.1 hwPowerConsumption 详细描述.....	792
40.3.2 hwPowerStatPeriod 详细描述.....	792
40.3.3 hwAveragePower 详细描述.....	792
40.3.4 hwRatedPower 详细描述.....	793
40.3.5 hwThresholdOfPower 详细描述.....	793
40.3.6 hwCurrentPower 详细描述.....	793
40.3.7 hwEnergySavingMode 详细描述.....	794
40.4 MIB Table 详细描述.....	794
40.4.1 hwBoardPowerMngtTable 详细描述.....	794
40.4.2 hwEnergySavingParameterTable 详细描述.....	795
40.4.3 hwEnergySavingCapabilityMngtTable 详细描述.....	796
40.5 告警节点详细描述.....	797
40.6 不支持节点.....	797
41 HUAWEI-EASY-OPERATION-MIB.....	798
41.1 功能简介.....	798
41.2 表间关系.....	798
41.3 单节点详细描述.....	799
41.3.1 hwEasyOperationCommanderEnable 详细描述.....	799

41.3.2 hwEasyOperationCommanderIpAddress 详细描述.....	799
41.3.3 hwEasyOperationCommanderIpAddressType 详细描述.....	799
41.3.4 hwEasyOperationCommanderUdpPort 详细描述.....	800
41.3.5 hwEasyOperationServerType 详细描述.....	800
41.3.6 hwEasyOperationServerIpAddress 详细描述.....	800
41.3.7 hwEasyOperationServerIpAddressType 详细描述.....	801
41.3.8 hwEasyOperationServerPort 详细描述.....	801
41.3.9 hwEasyOperationAutoClearEnable 详细描述.....	801
41.3.10 hwEasyOperationActivateMode 详细描述.....	801
41.3.11 hwEasyOperationActivateDelayTime 详细描述.....	802
41.3.12 hwEasyOperationActivateInTime 详细描述.....	802
41.3.13 hwEasyOperationBackupConfigMode 详细描述.....	802
41.3.14 hwEasyOperationBackupConfigInterval 详细描述.....	803
41.3.15 hwEasyOperationDefaultSysSoftware 详细描述.....	803
41.3.16 hwEasyOperationDefaultSysSoftwareVer 详细描述.....	803
41.3.17 hwEasyOperationDefaultConfig 详细描述.....	804
41.3.18 hwEasyOperationDefaultPatch 详细描述.....	804
41.3.19 hwEasyOperationDefaultWebfile 详细描述.....	804
41.3.20 hwEasyOperationDefaultLicense 详细描述.....	804
41.3.21 hwEasyOperationDefaultCustomfile1 详细描述.....	805
41.3.22 hwEasyOperationDefaultCustomfile2 详细描述.....	805
41.3.23 hwEasyOperationDefaultCustomfile3 详细描述.....	805
41.3.24 hwEasyOperationClientAutoJoinEnable 详细描述.....	806
41.3.25 hwEasyOperationTotalGroupNumber 详细描述.....	806
41.3.26 hwEasyOperationBuildInGroupNumber 详细描述.....	806
41.3.27 hwEasyOperationCustomGroupNumber 详细描述.....	806
41.3.28 hwEasyOperationClientNumber 详细描述.....	807
41.3.29 hwEasyOperationTopologyEnable 详细描述.....	807
41.3.30 hwEasyOperationClientAgingTime 详细描述.....	807
41.3.31 hwEasyOperationDtlsEnable 详细描述.....	808
41.4 MIB Table 详细描述.....	808
41.4.1 hwEasyOperationGroupTable 详细描述.....	808
41.4.2 hwEasyOperationGroupMatchTable 详细描述.....	810
41.4.3 hwEasyOperationClientInfoTable 详细描述.....	812
41.4.4 hwEasyOperationClientReplaceTable 详细描述.....	817
41.4.5 hwEasyOperationDevicePowerInfoTable 详细描述.....	819
41.4.6 hwEasyOperationPortPowerInfoTable 详细描述.....	820
41.4.7 hwEasyOperationNetPowerHistoryInfoTable 详细描述.....	822
41.4.8 hwEasyOperationTopologyTable 详细描述.....	822
41.4.9 hwEasyOperationSavedTopologyTable 详细描述.....	824
41.5 告警节点详细描述.....	825
41.5.1 hwEasyOperationClientAdded 详细描述.....	825

41.5.2 hwEasyOperationClientLost 详细描述.....	826
41.5.3 hwEasyOperationClientJoinNotPermit 详细描述.....	827
41.5.4 hwEasyOperationClientProcessFailed 详细描述.....	827
42 HUAWEI-ENTITY-EXTENT-MIB.....	829
42.1 功能简介.....	829
42.2 表间关系.....	829
42.3 单节点详细描述.....	832
42.3.1 hwAlarmResendInterval 详细描述.....	833
42.3.2 hwDevicePowerInfoTotalPower 详细描述.....	833
42.3.3 hwDevicePowerInfoUsedPower 详细描述.....	833
42.3.4 hwEntitySystemNetID 详细描述.....	833
42.3.5 hwEntitySystemModel 详细描述.....	834
42.3.6 hwEntityHeartbeatOnOff 详细描述.....	834
42.3.7 hwEntityHeartbeatPeriod 详细描述.....	834
42.3.8 hwDetectEngineOAMEnable 详细描述.....	835
42.3.9 hwEntityExtTrapBoardDropRuntPktStatistics 详细描述.....	835
42.3.10 hwEntityExtTrapBoardDropRuntPktTimeInterval 详细描述.....	835
42.4 MIB Table 详细描述.....	835
42.4.1 hwEntityStateTable 详细描述.....	835
42.4.2 hwRUModuleInfoTable 详细描述.....	840
42.4.3 hwOpticalModuleInfoTable 详细描述.....	843
42.4.4 hwEntPowerUsedInfoTable 详细描述.....	848
42.4.5 hwFanStatusTable 详细描述.....	849
42.4.6 hwSystemPowerTable 详细描述.....	850
42.4.7 hwPwrStatusTable 详细描述.....	851
42.4.8 hwPnpOperateTable 详细描述.....	853
42.5 告警节点详细描述.....	857
42.5.1 hwBoardSoftwareVersionIncompatible 详细描述.....	857
42.5.2 hwEntityHeartbeatTrap 详细描述.....	857
42.5.3 hwEntityHigErrorPacketThresholdAlarm 详细描述.....	857
42.5.4 hwEntityHigDiscardPacketNotify 详细描述.....	858
42.5.5 hwEntityHigStateChangeNotify 详细描述.....	859
42.5.6 hwEntityHigStateDownNotify 详细描述.....	860
42.5.7 hwEntityInputRateThresholdAlarm 详细描述.....	861
42.5.8 hwEntityInputRateThresholdAlarmResume 详细描述.....	862
42.5.9 hwEntityOutputRateThresholdAlarm 详细描述.....	862
42.5.10 hwEntityOutputRateThresholdAlarmResume 详细描述.....	863
42.5.11 hwEntityPositionMismatchNotify 详细描述.....	863
42.5.12 hwBoardDropRuntPacketNotify 详细描述.....	864
42.5.13 hwEntityHigCrcErrorAlarm 详细描述.....	864
42.5.14 hwEntityHigCrcErrorAlarmResume 详细描述.....	865
42.5.15 hwEntityHigDown 详细描述.....	865

42.5.16 hwEntityHigDownResume 详细描述.....	866
42.6 不支持节点.....	866
43 HUAWEI-ENTITY-TRAP-MIB.....	868
43.1 功能简介.....	868
43.2 表间关系.....	868
43.3 单节点详细描述.....	868
43.3.1 hwEntityPhysicalIndex 详细描述.....	869
43.3.2 hwEntityTrapEntType 详细描述.....	869
43.3.3 hwEntityTrapFaultID 详细描述.....	870
43.3.4 hwEntityCommunicateType 详细描述.....	885
43.3.5 hwUserDefAlarmName 详细描述.....	886
43.3.6 hwUserDefChannel 详细描述.....	886
43.3.7 hwEntityTrapReasonDescr 详细描述.....	886
43.4 MIB Table 详细描述.....	886
43.4.1 hwEntityThresholdTable 详细描述.....	887
43.5 告警节点详细描述.....	888
43.5.1 hwChassisInvalid 详细描述.....	888
43.5.2 hwChassisInvalidResume 详细描述.....	888
43.5.3 hwBoardRemove 详细描述.....	889
43.5.4 hwBoardInsert 详细描述.....	889
43.5.5 hwBoardBecomeMaster 详细描述.....	890
43.5.6 hwBoardFail 详细描述.....	890
43.5.7 hwBoardFailResume 详细描述.....	890
43.5.8 hwBoardInvalid 详细描述.....	891
43.5.9 hwBoardInvalidResume 详细描述.....	891
43.5.10 hwBoardOffline 详细描述.....	891
43.5.11 hwBoardSoftwareNotSupport 详细描述.....	892
43.5.12 hwBoardPowerOff 详细描述.....	892
43.5.13 hwBrdTempAlarm 详细描述.....	892
43.5.14 hwBrdTempResume 详细描述.....	893
43.5.15 hwCardInsert 详细描述.....	893
43.5.16 hwCardRemove 详细描述.....	894
43.5.17 hwCardFail 详细描述.....	894
43.5.18 hwCardInvalid 详细描述.....	894
43.5.19 hwCardInconsistent 详细描述.....	895
43.5.20 hwCommunicateError 详细描述.....	895
43.5.21 hwCommunicateResume 详细描述.....	896
43.5.22 hwCPUUtilizationRising 详细描述.....	896
43.5.23 hwCPUUtilizationResume 详细描述.....	897
43.5.24 hwMemUtilizationRising 详细描述.....	897
43.5.25 hwMemUtilizationResume 详细描述.....	898
43.5.26 hwFanInsert 详细描述.....	898

43.5.27 hwFanInvalid 详细描述.....	898
43.5.28 hwFanInvalidResume 详细描述.....	899
43.5.29 hwFanRemove 详细描述.....	899
43.5.30 hwOpticalBiasCurrentAlarm 详细描述.....	899
43.5.31 hwOpticalBiasCurrentAlarmResume 详细描述.....	900
43.5.32 hwOpticalRemove 详细描述.....	900
43.5.33 hwOpticalInsert 详细描述.....	900
43.5.34 hwOpticalInvalid 详细描述.....	901
43.5.35 hwOpticalInvalidResume 详细描述.....	901
43.5.36 hwOpticalFail 详细描述.....	901
43.5.37 hwOpticalFailResume 详细描述.....	902
43.5.38 hwPortNoSupportOETrap 详细描述.....	902
43.5.39 hwPowerInsert 详细描述.....	902
43.5.40 hwPowerInvalid 详细描述.....	903
43.5.41 hwPowerInvalidResume 详细描述.....	903
43.5.42 hwPowerRemove 详细描述.....	903
43.5.43 hwVoltAlarm 详细描述.....	904
43.5.44 hwVoltResume 详细描述.....	904
43.5.45 hwOpticalTunableNotMatch 详细描述.....	905
43.5.46 hwOpticalUnauthorized 详细描述.....	905
43.5.47 hwPatchDelNeedReStartTrap 详细描述.....	905
43.5.48 hwSystemConfigNotMatchTrap 详细描述.....	906
43.5.49 hwVirtualLicenseNearDeadline 详细描述.....	906
43.5.50 hwVirtualLicenseNearDeadlineResume 详细描述.....	906
43.5.51 hwVirtualLicenseExpire 详细描述.....	907
43.5.52 hwVirtualLicenseExpResume 详细描述.....	907
43.5.53 hwNetconfDatabaseAbnormal 详细描述.....	907
43.5.54 hwNetconfDatabaseRestore 详细描述.....	907
43.5.55 hwPeerDevPnPTrunkAggregationFailure 详细描述.....	908
43.6 不支持节点.....	908
44 HUAWEI-ESAP-HOT-STANDBY-MIB.....	912
44.1 功能简介.....	912
44.2 表间关系.....	912
44.3 单节点详细描述.....	912
44.3.1 hwEsapHsbMIBNotifications 详细描述.....	913
44.4 MIB Table 详细描述.....	913
44.4.1 hwHsbServiceTable 详细描述.....	913
44.4.2 hwHsbGroupTable 详细描述.....	915
44.4.3 hwHsbIfMapTable 详细描述.....	917
44.5 告警节点详细描述.....	918
44.5.1 hwEsapHsbStatusNotification 详细描述.....	918
44.6 不支持节点.....	918

45 HUAWEI-ESAP-MDNS-GATEWAY-MIB.....	919
45.1 功能简介.....	919
45.2 表间关系.....	919
45.3 单节点详细描述.....	919
45.4 MIB Table 详细描述.....	919
45.4.1 hwEsapMdnsGatewayGlobalTable 详细描述.....	920
45.4.2 hwEsapMdnsGatewayServiceProbeTable 详细描述.....	921
45.4.3 hwEsapMdnsGatewayServiceTable 详细描述.....	922
45.4.4 hwEsapMdnsGatewayGroupTable 详细描述.....	926
45.5 告警节点详细描述.....	928
46 HUAWEI-ETHARP-MIB.....	929
46.1 功能简介.....	929
46.2 表间关系.....	930
46.3 单节点详细描述.....	930
46.3.1 hwEthernetARPAntiAttackLog 详细描述.....	930
46.3.2 hwEthernetARPLearningStrict 详细描述.....	930
46.3.3 hwEthernetARPSpeedLimitIfIndex 详细描述.....	930
46.3.4 hwEthernetARPSpeedLimitConfigured 详细描述.....	931
46.3.5 hwEthernetARPSpeedLimitCurrent 详细描述.....	931
46.3.6 hwEthernetARPSpeedLimitType 详细描述.....	931
46.3.7 hwEthernetARPSpeedLimitSrcIPAddr 详细描述.....	931
46.3.8 hwEthernetARPSpeedLimitDstIPAddr 详细描述.....	932
46.3.9 hwEthernetARPSpeedLimitVPNInstance 详细描述.....	932
46.3.10 hwEthernetARPThresholdValue 详细描述.....	932
46.3.11 hwEthernetARPThresholdDynamicNumber 详细描述.....	932
46.3.12 hwEthernetARPThresholdStaticNumber 详细描述.....	933
46.3.13 hwEthernetARPConflictDetect 详细描述.....	933
46.3.14 hwEthernetARPEntrySpecValue 详细描述.....	933
46.3.15 hwEthernetARPEntrySpecDynamicNumber 详细描述.....	934
46.4 MIB Table 详细描述.....	934
46.4.1 hwEthernetARPSpeedLimitTable 详细描述.....	934
46.4.2 hwEthernetARPStaticsTable 详细描述.....	935
46.4.3 hwEthARPLimitTable 详细描述.....	937
46.4.4 hwEthernetARPLearningStrictInterfaceTable 详细描述.....	938
46.4.5 hwArpEntryExpireControlTable 详细描述.....	939
46.4.6 hwArpDynTable 详细描述.....	940
46.4.7 hwArpCfgTable 详细描述.....	944
46.4.8 hwArpSecValidateTable 详细描述.....	946
46.5 告警节点详细描述.....	947
46.5.1 hwEthernetARPSpeedLimitAlarm 详细描述.....	948
46.5.2 hwEthernetARPThresholdExceedAlarm 详细描述.....	948
46.5.3 hwEthernetARPThresholdResumeAlarm 详细描述.....	949

46.5.4 hwEthernetARPIPConflictEvent 详细描述.....	949
46.5.5 hwEthernetARPDynamicEntryExceedAlarm 详细描述.....	950
46.5.6 hwEthernetARPDynamicEntryResumeAlarm 详细描述.....	950
46.6 不支持节点.....	950
47 HUAWEI-ETHOAM-MIB.....	951
47.1 功能简介.....	951
47.2 表间关系.....	951
47.3 单节点详细描述.....	951
47.3.1 hwDot1agCfmGmacTraceEnabled 详细描述.....	952
47.3.2 hwDot3ahEfmEnabled 详细描述.....	952
47.3.3 hwTestMessageTableNextIndex 详细描述.....	952
47.3.4 hwY1731AisMaxPktNum 详细描述.....	953
47.4 MIB Table 详细描述.....	953
47.4.1 hwDot1agCfmGmacTraceTable 详细描述.....	953
47.4.2 hwDot1agCfmGmacTraceReplyTable 详细描述.....	956
47.4.3 hwDot3ahEfmTable 详细描述.....	958
47.4.4 hwDot3ahEfmPeerTable 详细描述.....	960
47.4.5 hwDot3ahEfmLoopbackTable 详细描述.....	961
47.4.6 hwDot3ahEfmEventConfigTable 详细描述.....	963
47.4.7 hwDot3ahEfmEventLogTable 详细描述.....	965
47.4.8 hwDot3ahEfmManagerTable 详细描述.....	968
47.4.9 hwDot3ahEvrrpTable 详细描述.....	969
47.4.10 hwTestMessageTable 详细描述.....	969
47.4.11 hwTestMessageResultTable 详细描述.....	971
47.4.12 hwDot1agCfmQueryMdIndexTable 详细描述.....	972
47.4.13 hwDot1agCfmQueryMaIndexTable 详细描述.....	973
47.4.14 hwCfmVlanOneDelayTrapLogTable 详细描述.....	974
47.4.15 hwCfmVlanOneDelayRcoverTrapLogTable 详细描述.....	975
47.4.16 hwCfmVlanTwoDelayTrapLogTable 详细描述.....	976
47.4.17 hwCfmVlanTwoDelayRcoverTrapLogTable 详细描述.....	976
47.4.18 hwY1731BaseConfigTable 详细描述.....	977
47.4.19 hwY1731ConfigTable 详细描述.....	979
47.4.20 hwY1731AisTable 详细描述.....	986
47.4.21 hwY1731AisLinkStatusTable 详细描述.....	987
47.4.22 hwY1731AisVlanConfigTable 详细描述.....	988
47.4.23 hwY1731ResetStatisticTable 详细描述.....	992
47.4.24 hwY1731StatisticTable 详细描述.....	995
47.5 告警节点详细描述.....	998
47.5.1 hwDot3ahEfmThresholdEvent 详细描述.....	998
47.5.2 hwDot3ahEfmNonthresholdEvent 详细描述.....	999
47.5.3 hwDot3ahEfmNonThresholdRecovery 详细描述.....	999
47.5.4 hwDot3ahEfmLoopbackFailed 详细描述.....	999

47.5.5 hwDot3ahEfmRemoteDyingGaspEvent 详细描述.....	1000
47.5.6 hwCfmVlanOnewayDelay 详细描述.....	1000
47.5.7 hwCfmVlanOnewayDelayRecovery 详细描述.....	1001
47.5.8 hwCfmVlanTwowayDelay 详细描述.....	1001
47.5.9 hwCfmVlanTwowayDelayRecovery 详细描述.....	1002
47.5.10 hwY1731AisDefectAlarm 详细描述.....	1002
47.5.11 hwY1731AisDefectAlarmRecovery 详细描述.....	1002
47.5.12 hwY1731AisExceedMaxPktNum 详细描述.....	1003
47.5.13 hwY1731AisExceedMaxPktNumCleared 详细描述.....	1003
47.5.14 hwDot1agCfmMismerge 详细描述.....	1003
47.5.15 hwDot1agCfmMismergeCleared 详细描述.....	1004
47.5.16 hwDot1agCfmUnexpectedMEP 详细描述.....	1004
47.5.17 hwDot1agCfmUnexpectedMEPCleared 详细描述.....	1005
47.5.18 hwDot1agCfmUnexpectedPeriod 详细描述.....	1005
47.5.19 hwDot1agCfmUnexpectedPeriodCleared 详细描述.....	1006
47.5.20 hwDot1agCfmUnexpectedMAC 详细描述.....	1007
47.5.21 hwDot1agCfmUnexpectedMACCleared 详细描述.....	1008
47.5.22 hwDot1agCfmLOC 详细描述.....	1009
47.5.23 hwDot1agCfmLOCCleared 详细描述.....	1009
47.5.24 hwDot1agCfmRDI 详细描述.....	1009
47.5.25 hwDot1agCfmRDICleared 详细描述.....	1010
47.6 不支持节点.....	1010
48 HUAWEI-E-TRUNK-MIB.....	1011
48.1 功能简介.....	1011
48.2 表间关系.....	1012
48.3 单节点详细描述.....	1012
48.4 MIB Table 详细描述.....	1012
48.4.1 hwETrunkTable 详细描述.....	1012
48.4.2 hwETrunkMemberTable 详细描述.....	1017
48.5 告警节点详细描述.....	1021
48.5.1 hwETrunkStatusChange 详细描述.....	1021
48.5.2 hwETrunkMemberStatusChange 详细描述.....	1021
49 HUAWEI-FLASH-MAN-MIB.....	1022
49.1 功能简介.....	1022
49.2 表间关系.....	1022
49.3 单节点详细描述.....	1022
49.3.1 hwFlhSupportNum 详细描述.....	1023
49.4 MIB Table 详细描述.....	1023
49.4.1 hwFlashTable 详细描述.....	1023
49.4.2 hwFlhChipTable 详细描述.....	1027
49.4.3 hwFlhPartitionTable 详细描述.....	1028
49.4.4 huaweiFlhFileTable 详细描述.....	1031

49.4.5 hwStorageTable 详细描述.....	1032
49.4.6 huaweiFlhOpTable 详细描述.....	1034
49.4.7 hwFlhSyncTable 详细描述.....	1041
49.5 告警节点详细描述.....	1042
49.5.1 hwFlhOperNotification 详细描述.....	1042
49.5.2 hwFlhStorageFullTrap 详细描述.....	1043
49.5.3 hwFlhSyncSuccessNotification 详细描述.....	1043
49.5.4 hwFlhSyncFailNotification 详细描述.....	1043

50 HUAWEI-FTP-MIB..... 1044

50.1 功能简介.....	1044
50.2 表间关系.....	1044
50.3 单节点详细描述.....	1044
50.3.1 hwFTPServerEnable 详细描述.....	1045
50.3.2 hwFtpUpperThreshold 详细描述.....	1045
50.3.3 hwFtpLowerThreshold 详细描述.....	1045
50.4 MIB Table 详细描述.....	1045
50.5 告警节点详细描述.....	1046
50.5.1 hwFtpNumThreshold 详细描述.....	1046
50.5.2 hwFtpNumThresholdResume 详细描述.....	1046

51 HUAWEI-FWD-RES-TRAP-MIB..... 1047

51.1 功能简介.....	1047
51.2 表间关系.....	1047
51.3 单节点详细描述.....	1047
51.3.1 hwEntPhysicalindex 详细描述.....	1048
51.3.2 hwFwdResLackSlotStr 详细描述.....	1048
51.3.3 hwFwdResLackReasonId 详细描述.....	1048
51.3.4 hwFwdResThreshold 详细描述.....	1048
51.3.5 hwL3FailedService 详细描述.....	1049
51.3.6 hwCommand 详细描述.....	1049
51.3.7 hwViewName 详细描述.....	1049
51.3.8 hwReasonDescription 详细描述.....	1049
51.3.9 hwNoSuppVxlanFragVni 详细描述.....	1050
51.3.10 hwNoSuppVxlanFragSourceIp 详细描述.....	1050
51.3.11 hwNoSuppVxlanFragPeerIp 详细描述.....	1050
51.3.12 hwL2mcGrpAddress 详细描述.....	1050
51.3.13 hwL2mcVlanIdx 详细描述.....	1051
51.4 MIB Table 详细描述.....	1051
51.5 告警节点详细描述.....	1051
51.5.1 hwWholeFwdResLack 详细描述.....	1051
51.5.2 hwWholeFwdResLackResume 详细描述.....	1051
51.5.3 hwBoardFwdResLack 详细描述.....	1052
51.5.4 hwBoardFwdResLackResume 详细描述.....	1052

51.5.5 hwBoardL3FwdResLack 详细描述.....	1052
51.5.6 hwBoardL3FwdResLackResume 详细描述.....	1053
51.5.7 hwBoardL3ACLResLack 详细描述.....	1053
51.5.8 hwBoardL2mcResLack 详细描述.....	1053
51.5.9 hwBoardL2mcResLackResume 详细描述.....	1053
51.5.10 hwBoardIpmcResLack 详细描述.....	1054
51.5.11 hwBoardIpmcResLackResume 详细描述.....	1054
51.5.12 hwBoardMplsPhpNonsupport 详细描述.....	1054
51.5.13 hwBoardServiceFailed 详细描述.....	1055
51.5.14 hwWholeFwdResThresholdExceed 详细描述.....	1055
51.5.15 hwWholeFwdResThresholdExceedResume 详细描述.....	1056
51.5.16 hwBoardFwdResThresholdExceed 详细描述.....	1056
51.5.17 hwBoardFwdResThresholdExceedResume 详细描述.....	1056
51.5.18 hwBoardMplsPhpResLack 详细描述.....	1056
51.5.19 hwBoardMplsFwdResLack 详细描述.....	1057
51.5.20 hwBoardMplsFwdResLackResume 详细描述.....	1057
51.5.21 hwNotSuppDecapVxlanFragPackets 详细描述.....	1058
51.5.22 hwVxlanTnlCfgFailed 详细描述.....	1058
51.5.23 hwNotSuppDecapVxlanPackets 详细描述.....	1058
51.5.24 hwBoardL3NDResLack 详细描述.....	1059
51.5.25 hwFwdEntryConflict 详细描述.....	1059
51.5.26 hwFwdEntryConflictResume 详细描述.....	1059
51.5.27 hwBoardMplsFlowLabelNonSupp 详细描述.....	1060
51.5.28 hwBoardMcResFull 详细描述.....	1060
51.5.29 hwBoardMplsFwdResFull 详细描述.....	1060
51.5.30 hwBoardL3ResFull 详细描述.....	1061
51.5.31 hwEMDIIndicatorOverThreshold 详细描述.....	1061
51.5.32 hwEMDIIndicatorOverThresholdResume 详细描述.....	1061
51.5.33 hwEMDIReceiveDuplicatePackets 详细描述.....	1062
51.5.34 hwEMDIReceiveDuplicatePacketsResume 详细描述.....	1062
51.5.35 hwEMDIResLack 详细描述.....	1062
51.5.36 hwEMDIResLackResume 详细描述.....	1062
51.5.37 hwVlanSrcExeedAlarm 详细描述.....	1063
51.5.38 hwVlanSrcExeedResume 详细描述.....	1063
51.5.39 hwSaidPingPktModifiedAlarm 详细描述.....	1063
51.5.40 hwNsOrigFlexFlowExceedAlarm 详细描述.....	1063
51.5.41 hwNsOrigFlexFlowExceedResume 详细描述.....	1064
51.5.42 hwNsAggFlowExceedAlarm 详细描述.....	1064
51.5.43 hwNsAggFlowExceedResume 详细描述.....	1064
51.5.44 hwCapwapNoFragmentAlarm 详细描述.....	1064
51.5.45 hwCapwapDiscardBroadcastAlarm 详细描述.....	1065
51.6 不支持节点.....	1065

52 HUAWEI-GARP-APP-MIB.....	1066
52.1 功能简介.....	1066
52.2 表间关系.....	1066
52.3 单节点详细描述.....	1067
52.3.1 hwGarpAppLeaveAllTime 详细描述.....	1067
52.4 MIB Table 详细描述.....	1068
52.4.1 hwGarpAppSwitchCountTable 详细描述.....	1068
52.4.2 hwGarpAppHoldTimeTable 详细描述.....	1069
52.4.3 hwGarpAppTrunkStatusTable 详细描述.....	1070
52.5 告警节点详细描述.....	1071
53 HUAWEI-GTL-MIB.....	1072
53.1 功能简介.....	1072
53.2 表间关系.....	1072
53.3 单节点详细描述.....	1072
53.3.1 hwGtlDefaultValueReason 详细描述.....	1072
53.3.2 hwGtlResourceItem 详细描述.....	1073
53.3.3 hwGtlFeatureName 详细描述.....	1073
53.3.4 hwGtlRemainTime 详细描述.....	1073
53.3.5 hwGtlActive 详细描述	1073
53.3.6 hwGtlShowActLCSName 详细描述	1074
53.4 MIB Table 详细描述.....	1074
53.4.1 hwGtlItemTable 详细描述.....	1074
53.5 告警节点详细描述.....	1075
53.5.1 hwGtlDefaultValue 详细描述.....	1075
53.5.2 hwGtlDefaultValueCleared 详细描述.....	1075
53.5.3 hwGtlResourceUsedUp 详细描述.....	1076
53.5.4 hwGtlResourceUsedUpCleared 详细描述.....	1076
53.5.5 hwGtlNearDeadline 详细描述.....	1076
53.5.6 hwGtlNearDeadlineCleared 详细描述.....	1077
53.5.7 hwGtlEsnMismatch 详细描述.....	1077
53.5.8 hwGtlEsnMismatchCleared 详细描述.....	1077
53.5.9 hwGtlItemInactive 详细描述.....	1078
53.5.10 hwGtlItemInactiveCleared 详细描述.....	1078
54 HUAWEI-GTSM-MIB.....	1079
54.1 功能简介.....	1079
54.2 表间关系.....	1079
54.3 单节点详细描述.....	1080
54.3.1 hwGTSMDefaultAction 详细描述.....	1080
54.4 MIB Table 详细描述.....	1080
54.4.1 hwGTSMPolicyTable 详细描述.....	1080
54.4.2 hwGTSMBgpPeergroupTable 详细描述.....	1083
54.4.3 hwGTSMStatisticsInfoTable 详细描述.....	1085

54.4.4 hwGTSMGlobalConfigInfoTable 详细描述.....	1086
54.5 告警节点详细描述.....	1087
55 HUAWEI-HGMP-MIB.....	1088
55.1 功能简介.....	1088
55.2 表间关系.....	1088
55.3 单节点详细描述.....	1088
55.3.1 hgmpNTDPCollectTopTime 详细描述.....	1089
55.3.2 hgmpNTDPHopRange 详细描述.....	1089
55.3.3 hgmpNTDPRun 详细描述.....	1089
55.3.4 hgmpNTDPPortDelay 详细描述.....	1090
55.3.5 hgmpNTDPHopDelay 详细描述.....	1090
55.3.6 hgmpNTDPExplore 详细描述.....	1090
55.3.7 hwNDPStatus 详细描述.....	1091
55.3.8 hwNDPHelloTimer 详细描述.....	1091
55.3.9 hwNDPAgingTime 详细描述.....	1091
55.3.10 hwNDPTrunkMemberEnable 详细描述.....	1092
55.4 MIB Table 详细描述.....	1092
55.4.1 hgmpNTDPIInterfaceTable 详细描述.....	1092
55.4.2 hgmpNTDPTopoLinkTable 详细描述.....	1093
55.4.3 hwNDPPortTable 详细描述.....	1094
55.5 告警节点详细描述.....	1095
55.5.1 hgmpNTDPTopoChange 详细描述.....	1095
56 HUAWEI-HTTP-MIB.....	1096
56.1 功能简介.....	1096
56.2 表间关系.....	1096
56.3 单节点详细描述.....	1096
56.4 MIB Table 详细描述.....	1096
56.4.1 hwHttpUserInfoTable 详细描述.....	1096
56.5 告警节点详细描述.....	1097
56.5.1 hwHttpUserLogin 详细描述.....	1098
56.5.2 hwHttpUserLoginFail 详细描述.....	1098
56.5.3 hwHttpUserLogout 详细描述.....	1098
57 HUAWEI-HQOS-MIB.....	1099
57.1 功能简介.....	1099
57.2 表间关系.....	1099
57.3 单节点详细描述.....	1100
57.4 MIB Table 详细描述.....	1100
57.4.1 hwhqosFlowMappingTable 详细描述.....	1100
57.4.2 hwhqosFlowMappingCfgTable 详细描述.....	1101
57.4.3 hwhqosFlowQueueTable 详细描述.....	1103
57.4.4 hwhqosFlowQueueCfgTable 详细描述.....	1104

57.4.5 hwhqosFlowWredTable 详细描述.....	1106
57.4.6 hwhqosFlowWredColorTable 详细描述.....	1107
57.4.7 hwhqosIfUserQueueTable 详细描述.....	1109
57.4.8 hwhqosIfUserQueueStatisticsTable 详细描述.....	1110
57.5 告警节点详细描述.....	1113
58 HUAWEI-HWTACACS-MIB.....	1114
58.1 功能简介.....	1114
58.2 表间关系.....	1114
58.3 单节点详细描述.....	1114
58.4 MIB Table 详细描述.....	1114
58.4.1 hwTACACSServerGroupTable 详细描述.....	1115
58.4.2 hwTacacsSetting 详细描述.....	1119
58.5 告警节点详细描述.....	1121
58.6 不支持节点.....	1121
59 HUAWEI-IF-EXT-MIB.....	1128
59.1 功能简介.....	1128
59.2 表间关系.....	1129
59.3 单节点详细描述.....	1130
59.3.1 hwIFExtPhyStatus 详细描述.....	1130
59.3.2 hwIFExtMemberOf 详细描述.....	1130
59.3.3 hwIFExtPhyNumber 详细描述.....	1130
59.3.4 hwTrunkIfMax 详细描述.....	1131
59.3.5 hwTrunkNextIndex 详细描述.....	1131
59.3.6 hwTrunkSystemPriority 详细描述.....	1131
59.3.7 hwTrunkETrunkSystemPriority 详细描述.....	1132
59.3.8 hwTrunkETrunkSystemID 详细描述.....	1132
59.3.9 hwIFFlowStatGlobalInterval 详细描述.....	1132
59.3.10 hwLinkDownReason 详细描述.....	1133
59.3.11 hwMainIfName 详细描述.....	1134
59.3.12 hwCfmOverPhysicalName 详细描述.....	1134
59.4 MIB Table 详细描述.....	1134
59.4.1 hwIFExtTable 详细描述.....	1134
59.4.2 hwIfIpTable 详细描述.....	1140
59.4.3 hwIfIpUnnumberedTable 详细描述.....	1142
59.4.4 hwIfIpAddrTable 详细描述.....	1144
59.4.5 hwIfQueryTable 详细描述.....	1147
59.4.6 hwLogicIfTable 详细描述.....	1148
59.4.7 hwTrunkIfTable 详细描述.....	1149
59.4.8 hwTrunkMapTable 详细描述.....	1158
59.4.9 hwTrunkMemTable 详细描述.....	1158
59.4.10 hwIfMonitorThresholdTable 详细描述.....	1161
59.4.11 hwIfEtherStatTable 详细描述.....	1162

59.5 告警节点详细描述.....	1166
59.5.1 hwIfFlowDown 详细描述.....	1166
59.5.2 hwIfFlowUp 详细描述.....	1167
59.5.3 hwLacpTotalLinkLoss 详细描述.....	1167
59.5.4 hwLacpTotalLinkLossResume 详细描述.....	1167
59.5.5 hwLacpPartialLinkLoss 详细描述.....	1167
59.5.6 hwLacpPartialLinkLossResume 详细描述.....	1168
59.5.7 hwLacpPartnerExpiredLoss 详细描述.....	1168
59.5.8 hwExtLinkDown 详细描述.....	1168
59.5.9 hwExtLinkUp 详细描述.....	1169
59.5.10 hwLacpNegotiateFailed 详细描述.....	1169
59.5.11 hwLacpNegotiateResume 详细描述.....	1169
59.5.12 hwLacpPDUChange 详细描述.....	1170
59.5.13 hwLacpPDUChangeResume 详细描述.....	1170
59.5.14 hwExtAllMemberDownNotify 详细描述.....	1170
59.5.15 hwExtAllMemberDownResume 详细描述.....	1171
59.5.16 hwEntityExtCfmOverSlot 详细描述.....	1171
59.5.17 hwExtInterfaceDelete 详细描述.....	1171
59.5.18 hwIfIpAddressChange 详细描述.....	1172
59.5.19 hwIfMonitorCrcErrorRising 详细描述.....	1172
59.5.20 hwIfMonitorCrcErrorResume 详细描述.....	1172
59.5.21 hwIfControlFlapSuppress 详细描述.....	1173
59.5.22 hwIfControlFlapResume 详细描述.....	1173
59.5.23 hwIfControlFlapSuppressIPv6 详细描述.....	1173
59.5.24 hwIfControlFlapResumeIPv6 详细描述.....	1174
59.5.25 hwIfMonitorInputRateRising 详细描述.....	1174
59.5.26 hwIfMonitorInputRateResume 详细描述.....	1174
59.5.27 hwIfMonitorOutputRateRising 详细描述.....	1175
59.5.28 hwIfMonitorOutputRateResume 详细描述.....	1175
59.6 不支持节点.....	1175

60 HUAWEI-INFOCENTER-MIB..... 1177

60.1 功能简介.....	1177
60.2 表间关系.....	1177
60.3 单节点详细描述.....	1178
60.3.1 hwICEnable 详细描述.....	1178
60.3.2 hwICLogFileName 详细描述.....	1178
60.3.3 hwICLoghostSourceInterface 详细描述.....	1178
60.4 MIB Table 详细描述.....	1178
60.4.1 hwICLoghostTable 详细描述.....	1178
60.4.2 hwICChannelTable 详细描述.....	1181
60.4.3 hwICModuleTable 详细描述.....	1182
60.4.4 hwICLogFilterTable 详细描述.....	1183

60.5 告警节点详细描述.....	1185
60.5.1 hwiCLogFileAging 详细描述.....	1185
60.5.2 hwiCLogBufferLose 详细描述.....	1185
61 HUAWEI-IPFPM-MIB.....	1186
61.1 功能简介.....	1186
61.2 表间关系.....	1187
61.3 单节点详细描述.....	1187
61.3.1 hwlpfpmMcpEnable 详细描述.....	1187
61.3.2 hwlpfpmMcpld 详细描述.....	1187
61.3.3 hwlpfpmMcpUdpPort 详细描述.....	1188
61.3.4 hwlpfpmMcpInstSpec 详细描述.....	1188
61.3.5 hwlpfpmMcpInstCurNum 详细描述.....	1188
61.3.6 hwlpfpmDcpEnable 详细描述.....	1188
61.3.7 hwlpfpmDcpld 详细描述.....	1189
61.3.8 hwlpfpmDcpMeasureColorFlag 详细描述.....	1189
61.3.9 hwlpfpmDcpMcpld 详细描述.....	1190
61.3.10 hwlpfpmDcpMcpPort 详细描述.....	1190
61.3.11 hwlpfpmDcpMcpVpnName 详细描述.....	1190
61.3.12 hwlpfpmDcpMcpVpnType 详细描述.....	1190
61.3.13 hwlpfpmTlpExceedBoardId 详细描述.....	1191
61.3.14 hwlpfpmTlpNumber 详细描述.....	1191
61.3.15 hwlpfpmTlpThreshold 详细描述.....	1191
61.4 MIB Table 详细描述.....	1191
61.4.1 hwlpfpmMcpAuthTable 详细描述.....	1191
61.4.2 hwlpfpmMcpInstTable 详细描述.....	1192
61.4.3 hwlpfpmMcpDcpTable 详细描述.....	1194
61.4.4 hwlpfpmMcpAchTable 详细描述.....	1195
61.4.5 hwlpfpmMcpTlpTable 详细描述.....	1196
61.4.6 hwlpfpmMcpInstAchIndexTable 详细描述.....	1197
61.4.7 hwlpfpmMcpLossStatsTable 详细描述.....	1197
61.4.8 hwlpfpmDcpAuthTable 详细描述.....	1203
61.4.9 hwlpfpmDcpInstTable 详细描述.....	1204
61.4.10 hwlpfpmDcpInstAuthTable 详细描述.....	1206
61.4.11 hwlpfpmDcpFlowTable 详细描述.....	1207
61.4.12 hwlpfpmDcpInstTlpTable 详细描述.....	1210
61.4.13 hwlpfpmDcpLossMeasTable 详细描述.....	1211
61.4.14 hwlpfpmDcpTlpTable 详细描述.....	1212
61.4.15 hwlpfpmDcpTlpQueryTable 详细描述.....	1213
61.5 告警节点详细描述.....	1214
61.5.1 hwlpfpmLossRatioExceed 详细描述.....	1215
61.5.2 hwlpfpmLossRatioRecovery 详细描述.....	1215
61.5.3 hwlpfpmTlpExceed 详细描述.....	1215

61.5.4 hwlpfpmTlpRecovery 详细描述.....	1216
61.5.5 hwlpfpmStreamResourceExceed 详细描述.....	1216
61.5.6 hwlpfpmStreamResourceRecovery 详细描述.....	1216
61.5.7 hwlpfpmBoardStreamResourceExceed 详细描述.....	1217
61.5.8 hwlpfpmBoardStreamResourceRecovery 详细描述.....	1217
61.5.9 hwlpfpmBoardPktDscpConflict 详细描述.....	1218
61.5.10 hwlpfpmBoardStreamCreateFail 详细描述.....	1219
61.5.11 hwlpfpmBoardAclResourceExceed 详细描述.....	1219
62 HUAWEI-IPLPM-MIB.....	1220
62.1 功能简介.....	1220
62.2 表间关系.....	1220
62.3 单节点详细描述.....	1220
62.3.1 hwlplpmLossMeasureEnable 详细描述.....	1221
62.3.2 hwlplpmLossMeasureColorFlag 详细描述.....	1221
62.3.3 hwlplpmLossMeasureInterval 详细描述.....	1222
62.3.4 hwlplpmLossMeasureAlarmEnable 详细描述.....	1222
62.3.5 hwlplpmGlobalLatestPeriodNo 详细描述.....	1222
62.3.6 hwlplpmGlobalLatestHisRecordNo 详细描述.....	1223
62.4 MIB Table 详细描述.....	1223
62.4.1 hwlplpmIntfConfigTable 详细描述.....	1223
62.4.2 hwlplpmBoardEntityTable 详细描述.....	1225
62.4.3 hwlplpmGlobalStatsTable 详细描述.....	1225
62.4.4 hwlplpmLinkPeriodNoTable 详细描述.....	1227
62.4.5 hwlplpmLinkLossStatsTable 详细描述.....	1227
62.4.6 hwlplpmPortQosQueStatsTable 详细描述.....	1229
62.4.7 hwlplpmPortFlowStatsTable 详细描述.....	1231
62.4.8 hwlplpmGlobalHisRecordTable 详细描述.....	1231
62.4.9 hwlplpmLinkHisRecordEntryTable 详细描述.....	1233
62.4.10 hwlplpmGateWaySearchTable 详细描述.....	1234
62.4.11 hwlplpmHostInfoSearchTable 详细描述.....	1237
62.4.12 hwlplpmLocalIpSearchTable 详细描述.....	1238
62.4.13 hwlplpmIpRouteSearchTable 详细描述.....	1239
62.5 告警节点详细描述.....	1240
62.5.1 hwlplpmGlobalLossRatioExceed 详细描述.....	1240
62.5.2 hwlplpmGlobalLossRatioRecovery 详细描述.....	1240
62.5.3 hwlplpmLinkForwardLossRatioExceed 详细描述.....	1241
62.5.4 hwlplpmLinkForwardLossRatioRecovery 详细描述.....	1241
62.5.5 hwlplpmGlobalLossRatioExceed 详细描述.....	1242
62.5.6 hwlplpmGlobalLossRatioRecovery 详细描述.....	1242
62.6 不支持节点.....	1242
63 HUAWEI-IPMCAST-MIB.....	1244
63.1 功能简介.....	1244

63.2 表间关系.....	1244
63.3 单节点详细描述.....	1245
63.3.1 hwIpMcastEnable 详细描述.....	1245
63.3.2 hwIpMcastRouteEntryCount 详细描述.....	1245
63.3.3 hwIpMcastChannelName 详细描述.....	1246
63.3.4 hwIpMcastChannelGroup 详细描述.....	1246
63.3.5 hwIpMcastChannelSource 详细描述.....	1246
63.3.6 hwIpMcastChannelDownstreamEntries 详细描述.....	1246
63.3.7 hwIpMcastChannelDownstreamBandWidth 详细描述.....	1247
63.3.8 hwIpMcastChannelGlobalEntries 详细描述.....	1247
63.3.9 hwIpMcastChannelInterfaceIfIndex 详细描述.....	1247
63.3.10 hwIpMcastChannelInterfaceName 详细描述.....	1247
63.3.11 hwIpMcastCfgTotalLimit 详细描述.....	1248
63.3.12 hwIpMcastCfgTotalThreshold 详细描述.....	1248
63.3.13 hwIpMcastTotalStat 详细描述.....	1248
63.3.14 hwIpMcastInstanceName 详细描述.....	1248
63.3.15 hwIpMcastSGCurrentCount 详细描述.....	1249
63.3.16 hwIpMcastSGThreshold 详细描述.....	1249
63.3.17 hwIpMcastSGTotalCount 详细描述.....	1249
63.4 MIB Table 详细描述.....	1249
63.4.1 hwIpMcastRouteTable 详细描述.....	1249
63.4.2 hwIpMcastRouteNextHopTable 详细描述.....	1253
63.4.3 hwIpMcastBoundaryTable 详细描述.....	1257
63.4.4 hwIpMcastDownstreamTotalTable 详细描述.....	1259
63.4.5 hwIpMcastDownstreamChannelTable 详细描述.....	1260
63.4.6 hwIpMcastChannelTable 详细描述.....	1261
63.5 告警节点详细描述.....	1262
63.5.1 hwIpMcastDownstreamChannelLimit 详细描述.....	1263
63.5.2 hwIpMcastDownstreamTotalLimit 详细描述.....	1263
63.5.3 hwIpMcastGlobalChannelLimit 详细描述.....	1264
63.5.4 hwIpMcastGlobalTotalLimit 详细描述.....	1264
63.5.5 hwIpMcastSGThresholdExceed 详细描述.....	1264
63.5.6 hwIpMcastSGThresholdExceedClear 详细描述.....	1265
63.5.7 hwIpMcastSGExceed 详细描述.....	1265
63.5.8 hwIpMcastSGExceedClear 详细描述.....	1265
63.6 不支持节点.....	1265
64 HUAWEI-IPPOOL-MIB.....	1266
64.1 功能简介.....	1266
64.2 表间关系.....	1266
64.3 单节点详细描述.....	1266
64.3.1 hwIPPoolNum 详细描述.....	1267
64.3.2 hwIPIdleTotalNum 详细描述.....	1267

64.3.3 hwIPUsedTotalNum 详细描述.....	1267
64.3.4 hwIPConflictTotalNum 详细描述.....	1267
64.3.5 hwIPExcludeTotalNum 详细描述.....	1268
64.4 MIB Table 详细描述.....	1268
64.4.1 hwIPPoolTable 详细描述.....	1268
64.4.2 hwIPPoolExtTable 详细描述.....	1272
64.4.3 hwDhcpSvrGroupTable 详细描述.....	1275
64.5 告警节点详细描述.....	1277
64.5.1 hwUsedIPReachThreshold 详细描述.....	1277
64.5.2 hwUsedIPReachThresholdResume 详细描述.....	1277
64.6 不支持节点.....	1278
65 HUAWEI-IPSESSION-MIB.....	1282
65.1 功能简介.....	1282
65.2 表间关系.....	1282
65.3 MIB Table 详细描述.....	1282
65.3.1 hwIpSessIfCfgTable 详细描述.....	1282
65.3.2 hwIpSessUserCfgTable 详细描述.....	1288
65.4 不支持节点.....	1293
66 HUAWEI-IPV6-MIB.....	1294
66.1 功能简介.....	1294
66.2 表间关系.....	1295
66.3 MIB Table 详细描述.....	1295
66.3.1 hwIpv6IfTable 详细描述.....	1295
66.3.2 hwIpv6LinklocalCfgTable 详细描述.....	1296
66.3.3 hwIpv6GlobalCfgTable 详细描述.....	1297
66.4 告警节点详细描述.....	1299
67 HUAWEI-ISOLATE-MIB.....	1300
67.1 功能简介.....	1300
67.2 表间关系.....	1300
67.3 单节点详细描述.....	1300
67.3.1 hwPortIsolateMode 详细描述.....	1300
67.4 MIB Table 详细描述.....	1301
67.4.1 hwPortIsolateTable 详细描述.....	1301
67.4.2 hwAmlIsolateTable 详细描述.....	1302
67.5 告警节点详细描述.....	1303
68 HUAWEI-KOMPELLA-MIB.....	1304
68.1 功能简介.....	1304
68.2 表间关系.....	1304
68.3 单节点详细描述.....	1305
68.3.1 hwKompellaVcStateChangeReason 详细描述.....	1306
68.3.2 hwKompellaSwitchRmtCEID 详细描述.....	1311

68.4 MIB Table 详细描述.....	1311
68.4.1 hwKompellaVpnTable 详细描述.....	1311
68.4.2 hwKompellaVpnTargetTable 详细描述.....	1315
68.4.3 hwKompellaCeTable 详细描述.....	1316
68.4.4 hwKompellaVcTable 详细描述.....	1318
68.4.5 hwKompellaVcTnlTable 详细描述.....	1327
68.5 告警节点详细描述.....	1328
68.5.1 hwKompellaVcDown 详细描述.....	1329
68.5.2 hwKompellaVcUp 详细描述.....	1329
68.5.3 hwKompellaSwitchWtoP 详细描述.....	1329
68.5.4 hwKompellaSwitchPtoW 详细描述.....	1330
68.6 附录.....	1330
68.6.1 hwKompellaVcStateChangeReason.....	1330
68.6.2 KompellaVpnVcType.....	1331
69 HUAWEI-L2IF-MIB.....	1333
69.1 功能简介.....	1333
69.2 表间关系.....	1334
69.3 单节点详细描述.....	1334
69.3.1 hwL2IfPortMax 详细描述.....	1335
69.3.2 hwL2TopologyDetect 详细描述.....	1335
69.4 MIB Table 详细描述.....	1335
69.4.1 hwL2IfTable 详细描述.....	1335
69.4.2 hwL2IfHybridPortTable 详细描述.....	1339
69.4.3 hwL2IfTrunkPortTable 详细描述.....	1341
69.4.4 hwL2IfDynPortVlanTable 详细描述.....	1342
69.5 告警节点详细描述.....	1343
69.6 不支持节点.....	1343
70 HUAWEI-L2MAM-MIB.....	1344
70.1 功能简介.....	1344
70.2 表间关系.....	1345
70.3 单节点详细描述.....	1345
70.3.1 hwL2MaxMacLimit 详细描述.....	1346
70.3.2 hwMacAgingTime 详细描述.....	1346
70.3.3 hwMacGlobalStatistics 详细描述.....	1346
70.3.4 hwMacflappingMac 详细描述.....	1346
70.3.5 hwMacflappingVlan 详细描述.....	1347
70.3.6 hwDiscardIllegalMacEnable 详细描述.....	1347
70.3.7 hwDiscardIllegalMacAlarm 详细描述.....	1347
70.4 MIB Table 详细描述.....	1347
70.4.1 hwdbCfgFdbTable 详细描述.....	1347
70.4.2 hwdbDynFdbTable 详细描述.....	1350
70.4.3 hwDynMacAddrQueryTable 详细描述.....	1352

70.4.4 hwL2ProtclTnlStdTable 详细描述.....	1358
70.4.5 hwL2ProtclTnlCusTable 详细描述.....	1360
70.4.6 hwL2ProtclTnlEnableTable 详细描述.....	1363
70.4.7 hwL2ProtclTnlStatisticsTable 详细描述.....	1364
70.4.8 hwMacInfoQueryTable 详细描述.....	1366
70.4.9 hwCfgMacAddrQueryTable 详细描述.....	1371
70.4.10 hwMacLimitTable 详细描述.....	1375
70.4.11 hwMacIfStatisticsTable 详细描述.....	1377
70.4.12 hwMacSlotStatisticsTable 详细描述.....	1377
70.4.13 hwMacVlanStatisticsTable 详细描述.....	1378
70.4.14 hwMacVsiStatisticsTable 详细描述.....	1379
70.4.15 hwPortSecurityTable 详细描述.....	1380
70.4.16 hwSlotMacLimitTable 详细描述.....	1381
70.5 告警节点详细描述.....	1383
70.5.1 hwSlotMacLimitNumRaisingThreshold 详细描述.....	1383
70.5.2 hwSlotMacLimitNumFallingThreshold 详细描述.....	1383
70.5.3 hwL2ProtocolTunnelDropThresholdRaising 详细描述.....	1384
70.5.4 hwL2ProtocolTunnelDropThresholdFalling 详细描述.....	1384
70.5.5 hwPortSecRcvInsecurePktAlarm 详细描述.....	1384
70.5.6 hwMacFlappingAlarm 详细描述.....	1385
70.5.7 hwMacLimitOverThresholdAlarm 详细描述.....	1386
70.5.8 hwMacLimitOverThresholdAlarmResume 详细描述.....	1387
70.6 不支持节点.....	1387
71 HUAWEI-L2MULTICAST-MIB.....	1389
71.1 功能简介.....	1389
71.2 表间关系.....	1389
71.3 单节点详细描述.....	1389
71.3.1 hwIgmpSnoopingEnabled 详细描述.....	1390
71.3.2 hwSendQueryEnabled 详细描述.....	1390
71.3.3 hwSendQuerySourceIpAddr 详细描述.....	1390
71.3.4 hwL2mcCacTrapInterval 详细描述.....	1391
71.4 MIB Table 详细描述.....	1391
71.4.1 hwL2mcCfgTable 详细描述.....	1391
71.4.2 hwL2mcStatisticsTable 详细描述.....	1394
71.4.3 hwL2mcFwdTable 详细描述.....	1396
71.4.4 hwL2mcGroupInfoTable 详细描述.....	1399
71.4.5 hwL2mcGroupCfgTable 详细描述.....	1402
71.4.6 hwL2mcSsmSourceTable 详细描述.....	1405
71.4.7 hwL2mcChnlCfgTable 详细描述.....	1406
71.4.8 hwL2mcLimitTable 详细描述.....	1407
71.4.9 hwL2mcPortLimitTable 详细描述.....	1408
71.4.10 hwL2mcRouterPortInfoTable 详细描述.....	1411

71.4.11 hwL2mcRouterPortCfgTable 详细描述.....	1414
71.4.12 hwL2mcChnlGroupCfgTable 详细描述.....	1416
71.4.13 hwL2mcGroupPolicyCfgTable 详细描述.....	1418
71.4.14 hwL2mcChnlDenyCfgTable 详细描述.....	1419
71.5 不支持节点.....	1420
72 HUAWEI-L2VC-STATISTIC-MIB.....	1423
72.1 功能简介.....	1423
72.2 表间关系.....	1423
72.3 单节点详细描述.....	1423
72.3.1 hwL2vcStatisticEnable 详细描述.....	1424
72.4 MIB Table 详细描述.....	1424
72.4.1 hwL2vcStatisticsTable 详细描述.....	1424
73 HUAWEI-L2VLAN-MIB.....	1426
73.1 功能简介.....	1426
73.2 表间关系.....	1427
73.3 单节点详细描述.....	1427
73.3.1 hwVcmpDeviceMac 详细描述.....	1427
73.3.2 hwL2VlanVoiceVlan8021p 详细描述.....	1428
73.3.3 hwL2VlanVoiceVlanDscp 详细描述.....	1428
73.4 MIB Table 详细描述.....	1428
73.4.1 hwL2VlanMIBTable 详细描述.....	1428
73.4.2 hwL2VlanStackingTable 详细描述.....	1433
73.4.3 hwL2VlanMappingTable 详细描述.....	1435
73.4.4 hwSuperVlanTable 详细描述.....	1436
73.4.5 hwL2UntagAddDTagTable 详细描述.....	1437
73.4.6 hwL2VlanIpSubnetVlanTable 详细描述.....	1439
73.4.7 hwL2VlanMacVlanNewTable 详细描述.....	1440
73.4.8 hwL2VlanProtocolVlanNewTable 详细描述.....	1441
73.4.9 hwL2VlanXlateTable 详细描述.....	1446
73.4.10 hwL2VlanProtocolVlanPortNewTable 详细描述.....	1448
73.4.11 hwL2VlanVoiceVlanPortTable 详细描述.....	1449
73.4.12 hwL2VlanVoiceVlanOuiTable 详细描述.....	1451
73.4.13 hwL2VlanSwitchExtTable 详细描述.....	1452
73.4.14 hwL2VlanPolicyVlanNewTable 详细描述.....	1455
73.4.15 hwL2QinQVlanTable 详细描述.....	1457
73.4.16 hwL2VlanMultiVoiceVlanPortTable 详细描述.....	1464
73.5 告警节点详细描述.....	1466
73.5.1 hwVcmpServerMacConflict 详细描述.....	1466
73.5.2 hwVcmpRevisionConflict 详细描述.....	1467
73.6 不支持节点.....	1467
74 HUAWEI-L2VPN-MIB.....	1473

74.1 功能简介.....	1473
74.2 表间关系.....	1473
74.3 单节点详细描述.....	1473
74.3.1 hwL2VpnEnable 详细描述.....	1473
74.3.2 hwL2VpnWorkingMode 详细描述.....	1474
74.3.3 hwL2VpnLocalCCCNumer 详细描述.....	1474
74.3.4 hwL2VpnRemoteCCCNumer 详细描述.....	1474
74.3.5 hwL2VpnSvcNumber 详细描述.....	1475
74.3.6 hwL2VpnLdpVcNumber 详细描述.....	1475
74.3.7 hwL2VpnBgpVcNumber 详细描述.....	1475
74.3.8 hwL2VpnVsiNumber 详细描述.....	1475
74.3.9 hwL2VpnBgpVsiNumber 详细描述.....	1476
74.3.10 hwL2VpnVsiVcNumber 详细描述.....	1476
74.3.11 hwVplsVcNumberMaxNum 详细描述.....	1476
74.3.12 hwVplsVcNumberUpperThreshold 详细描述.....	1476
74.3.13 hwL2VpnVcLimitClass 详细描述.....	1477
74.3.14 hwL2VpnSwitchVcNumber 详细描述.....	1477
75 HUAWEI-LDT-MIB.....	1478
75.1 功能简介.....	1478
75.2 表间关系.....	1478
75.3 单节点详细描述.....	1478
75.3.1 hwLdtEnable 详细描述.....	1478
75.3.2 hwLdtIntervalTime 详细描述.....	1479
75.3.3 hwLdtVlanListLow 详细描述.....	1479
75.3.4 hwLdtVlanListHigh 详细描述.....	1479
75.3.5 hwLdtPortLoopVlanListLow 详细描述.....	1480
75.3.6 hwLdtPortLoopVlanListHigh 详细描述.....	1480
75.3.7 hwLdtPortRecoverVlanListLow 详细描述.....	1480
75.3.8 hwLdtPortRecoverVlanListHigh 详细描述.....	1481
75.3.9 hwLdtPortLoopDetectVlanList 详细描述.....	1481
75.3.10 hwLdtPortLoopAutoTrapVlanList 详细描述.....	1481
75.3.11 hwPortLoopDetectL2vpnPeVlanList 详细描述.....	1482
75.3.12 hwPortLoopDetectL2vpnCeVlanList 详细描述.....	1482
75.3.13 hwLoopDetectSendingPacketInterval 详细描述.....	1482
75.4 MIB Table 详细描述.....	1482
75.4.1 hwLdtPortConfigTable 详细描述.....	1482
75.4.2 hwLdtPortStatusTable 详细描述.....	1486
75.4.3 hwPortLoopDetectTable 详细描述.....	1486
75.5 告警节点详细描述.....	1490
75.5.1 hwLdtPortLoop 详细描述.....	1490
75.5.2 hwLdtPortRecovery 详细描述.....	1490
75.5.3 hwLdtPortLoopDetect 详细描述.....	1491

75.5.4 hwLdtPortLoopDetectRecovery 详细描述.....	1491
75.5.5 hwPortL2vpnLoopDetect 详细描述.....	1492
75.5.6 hwPortL2vpnLoopDetectRecovery 详细描述.....	1492
75.6 不支持节点.....	1492
76 HUAWEI-LSP-PING-TRACE-TRAP-MIB.....	1494
76.1 功能简介.....	1494
76.2 表间关系.....	1494
76.3 单节点详细描述.....	1494
76.3.1 hwLspTunnelID 详细描述.....	1494
76.3.2 hwLspSenderAddress 详细描述.....	1495
76.3.3 hwLspEndPointAddress 详细描述.....	1495
76.3.4 hwLspTTL 详细描述.....	1495
76.3.5 hwLspHandle 详细描述.....	1495
76.4 告警节点详细描述.....	1495
76.4.1 hwLspPingProbe 详细描述.....	1496
76.4.2 hwLspTraceProbe 详细描述.....	1496
77 HUAWEI-LINE-MIB.....	1497
77.1 功能简介.....	1497
77.2 表间关系.....	1497
77.3 单节点详细描述.....	1497
77.3.1 hwMaxVtyNumber 详细描述.....	1497
77.4 MIB Table 详细描述.....	1498
77.4.1 hwUserInterfaceTable 详细描述.....	1498
77.4.2 hwLoginUserInfoTable 详细描述.....	1499
77.5 告警节点详细描述.....	1500
77.5.1 hwVtyNumExceed 详细描述.....	1500
77.5.2 hwUserLogin 详细描述.....	1501
77.5.3 hwUserLoginFail 详细描述.....	1501
77.5.4 hwUserLogout 详细描述.....	1501
78 HUAWEI-LLDP-MIB.....	1502
78.1 功能简介.....	1502
78.2 表间关系.....	1502
78.3 单节点详细描述.....	1502
78.3.1 hwLldpEnable 详细描述.....	1502
78.3.2 hwLldpLocManIPAddr 详细描述.....	1503
78.3.3 hwLldpCounterReset 详细描述.....	1503
78.3.4 hwLldpNotificationEnable 详细描述.....	1504
78.3.5 hwLldpTrapIfName 详细描述.....	1504
78.4 MIB Table 详细描述.....	1504
78.4.1 hwLldpPortConfigTable 详细描述.....	1505
78.4.2 hwLldpRemProtoTypeTable 详细描述.....	1505

78.5 告警节点详细描述.....	1506
78.5.1 hwLldpEnabled 详细描述.....	1506
78.5.2 hwLldpDisabled 详细描述.....	1506
78.5.3 hwLldpLocSysCapSupportedChange 详细描述.....	1507
78.5.4 hwLldpLocSysCapEnabledChange 详细描述.....	1507
78.5.5 hwLldpLocManIPAddrChange 详细描述.....	1507
78.5.6 hwLldpMdnRemTablesChange 详细描述.....	1507
78.5.7 hwLldpRateExcessive 详细描述.....	1508
79 HUAWEI-MAC-AUTHEN-MIB.....	1509
79.1 功能简介.....	1509
79.2 表间关系.....	1509
79.3 单节点详细描述.....	1509
79.3.1 hwMacAuthenGlobalEnable 详细描述.....	1509
79.3.2 hwMacAuthenModeUsername 详细描述.....	1511
79.3.3 hwMacAuthenPassword 详细描述.....	1512
79.3.4 hwMacAuthenUsername 详细描述.....	1513
79.3.5 hwMacAuthenDomain 详细描述.....	1513
79.3.6 hwMacAuthenTimerOfflineDetect 详细描述.....	1513
79.3.7 hwMacAuthenTimerQuiet 详细描述.....	1514
79.3.8 hwMacAuthenReauthInterval 详细描述.....	1514
79.3.9 hwMacAuthenPwdType 详细描述.....	1514
79.4 MIB Table 详细描述.....	1515
79.4.1 hwMacAuthenCfgTable 详细描述.....	1515
79.5 告警节点详细描述.....	1518
79.5.1 hwMacAuthenMaxUserAlarm 详细描述.....	1518
79.6 不支持节点.....	1518
80 HUAWEI-MDNS-RELAY-MIB.....	1520
80.1 功能简介.....	1520
80.2 表间关系.....	1520
80.3 单节点详细描述.....	1520
80.3.1 hwMdnsRelayGatewayIPGlobal 详细描述.....	1520
80.3.2 hwMdnsRelaySourceIPGlobal 详细描述.....	1521
80.4 MIB Table 详细描述.....	1521
80.4.1 hwMdnsRelayCfgTable 详细描述.....	1521
80.5 告警节点详细描述.....	1523
81 HUAWEI-MEMORY-MIB.....	1524
81.1 功能简介.....	1524
81.2 表间关系.....	1524
81.3 单节点详细描述.....	1524
81.4 MIB Table 详细描述.....	1524
81.4.1 hwMemoryDevTable 详细描述.....	1524

81.4.2 hwBufferTable 详细描述.....	1526
81.5 告警节点详细描述.....	1527
82 HUAWEI-MFF-MIB.....	1528
82.1 功能简介.....	1528
82.2 表间关系.....	1528
82.3 单节点详细描述.....	1528
82.3.1 hwMffGlobal 详细描述.....	1529
82.4 MIB Table 详细描述.....	1529
82.4.1 hwMffVlanCfgTable 详细描述.....	1529
82.4.2 hwMffNetworkPortTable 详细描述.....	1531
82.4.3 hwMffServerCfgTable 详细描述.....	1532
82.4.4 hwMffUserGatewayTable 详细描述.....	1533
82.4.5 hwMffModUserTable 详细描述.....	1534
82.5 告警节点详细描述.....	1536
83 HUAWEI-MFLP-MIB.....	1537
83.1 功能简介.....	1537
83.2 表间关系.....	1537
83.3 单节点详细描述.....	1537
83.3.1 hwMflpTrapEnable 详细描述.....	1537
83.3.2 hwMflpBdId 详细描述.....	1538
83.3.3 hwMflpIfName 详细描述.....	1538
83.3.4 hwMflpAlarmReason 详细描述.....	1538
83.4 MIB Table 详细描述.....	1538
83.4.1 hwMflpVlanCfgTable 详细描述.....	1538
83.5 告警节点详细描述.....	1541
83.5.1 hwMflpIfBlock 详细描述.....	1541
83.5.2 hwMflpIfResume 详细描述.....	1541
83.5.3 hwMflpVlanAlarm 详细描述.....	1542
83.5.4 hwMflpVsiAlarm 详细描述.....	1542
83.5.5 hwMflpMacAddrAlarm 详细描述.....	1542
83.5.6 hwMflpMacAddrResume 详细描述.....	1543
83.5.7 hwMflpQuitVlanAlarm 详细描述.....	1543
83.5.8 hwMflpQuitVlanResume 详细描述.....	1544
83.5.9 hwMflpBdAlarm 详细描述.....	1544
83.6 不支持节点.....	1544
84 HUAWEI-MGMD-STD-MIB.....	1546
84.1 功能简介.....	1546
84.2 表间关系.....	1546
84.3 单节点详细描述.....	1547
84.3.1 hwMgmdLimitInterfaceIfIndex 详细描述.....	1547
84.3.2 hwMgmdGlobalEntries 详细描述.....	1547

84.3.3 hwMgmdInterfaceEntries 详细描述.....	1547
84.3.4 hwMgmdTotalEntries 详细描述.....	1548
84.3.5 hwMgmdGmpJoinGrpAddr 详细描述.....	1548
84.3.6 hwMgmdGmpJoinSrcAddr 详细描述.....	1548
84.3.7 hwMgmdGmpJoinSenderId 详细描述.....	1548
84.3.8 hwMgmdGmpJoinVersion 详细描述.....	1549
84.3.9 hwMgmdGmplInterfaceIfIndex 详细描述.....	1549
84.3.10 hwMgmdGmplInterfaceName 详细描述.....	1549
84.3.11 hwMgmdGmpLimitGroupAddressType 详细描述.....	1550
84.3.12 hwMgmdGmpLimitGroup 详细描述.....	1550
84.3.13 hwMgmdGmpLimitSource 详细描述.....	1551
84.3.14 hwMgmdInstanceName 详细描述.....	1551
84.3.15 hwMgmdNotificationAddressType 详细描述.....	1551
84.3.16 hwMgmdTotalLimitCurrentCount 详细描述.....	1552
84.3.17 hwMgmdTotalLimitThreshold 详细描述.....	1552
84.3.18 hwMgmdHostStarGCurrentCount 详细描述.....	1552
84.3.19 hwMgmdHostStarGThreshold 详细描述.....	1552
84.3.20 hwMgmdHostStarGTotalCount 详细描述.....	1553
84.3.21 hwMgmdHostNotificationSrcAddr 详细描述.....	1553
84.3.22 hwMgmdHostNotificationGrpAddr 详细描述.....	1553
84.3.23 hwMgmdHostSGCurrentCount 详细描述.....	1553
84.3.24 hwMgmdHostSGThreshold 详细描述.....	1554
84.3.25 hwMgmdHostSGTotalCount 详细描述.....	1554
84.3.26 hwMgmdHostRerouteDelayPeriod 详细描述.....	1554
84.3.27 hwMgmdHostRerouteImmediate 详细描述.....	1554
84.3.28 hwMgmdTtlCheck 详细描述.....	1555
84.4 MIB Table 详细描述.....	1555
84.4.1 hwMgmdRouterInterfaceTable 详细描述.....	1555
84.4.2 hwMgmdRouterCacheTable 详细描述.....	1561
84.4.3 hwMgmdHostInterfaceTable 详细描述.....	1563
84.4.4 hwMgmdInverseRouterCacheTable 详细描述.....	1566
84.4.5 hwMgmdRouterSrcListTable 详细描述.....	1567
84.4.6 hwMgmdCtlMsgCountTable 详细描述.....	1568
84.5 告警节点详细描述.....	1570
84.5.1 hwMgmdGmpJoin 详细描述.....	1571
84.5.2 hwMgmdGmpLeave 详细描述.....	1571
84.5.3 hwMgmdGMPGlobalLimit 详细描述.....	1572
84.5.4 hwMgmdGMPIInterfaceLimit 详细描述.....	1572
84.5.5 hwMgmdGMPTotalLimit 详细描述.....	1573
84.5.6 hwMgmdGMPIInterfaceLimitClear 详细描述.....	1573
84.5.7 hwMgmdGMPGlobalLimitClear 详细描述.....	1574
84.5.8 hwMgmdGMPTotalLimitClear 详细描述.....	1574

84.5.9 hwMgmdTotalLimitThresholdExceed 详细描述.....	1575
84.5.10 hwMgmdTotalLimitThresholdExceedClear 详细描述.....	1575
84.5.11 hwMgmdHostStarGThresholdExceed 详细描述.....	1575
84.5.12 hwMgmdHostStarGThresholdExceedClear 详细描述.....	1576
84.5.13 hwMgmdHostStarGExceed 详细描述.....	1576
84.5.14 hwMgmdHostStarGExceedClear 详细描述.....	1576
84.5.15 hwMgmdHostSGThresholdExceed 详细描述.....	1577
84.5.16 hwMgmdHostSGThresholdExceedClear 详细描述.....	1577
84.5.17 hwMgmdHostSGExceed 详细描述.....	1578
84.5.18 hwMgmdHostSGExceedClear 详细描述.....	1578
85 HUAWEI-MPLS-EXTEND-MIB.....	1579
85.1 功能简介.....	1579
85.2 表间关系.....	1580
85.3 单节点详细描述.....	1581
85.3.1 hwStaticLspInIfIndex 详细描述.....	1581
85.3.2 hwStaticLspInIfName 详细描述.....	1581
85.3.3 hwMplsTunnelDownIfIpAddrType 详细描述.....	1581
85.3.4 hwStaticLspDownReason 详细描述.....	1582
85.3.5 hwMplsTunnelDownReason 详细描述.....	1583
85.3.6 hwMplsLspProtocol 详细描述.....	1584
85.3.7 hwMplsLspThreshold 详细描述.....	1585
85.3.8 hwMplsLspTotalCount 详细描述.....	1585
85.3.9 hwMplsLspCurrentCount 详细描述.....	1586
85.3.10 hwMplsTunnelDownLSRID 详细描述.....	1586
85.3.11 hwMplsTunnelDownIfIpAddr 详细描述.....	1586
85.3.12 hwMplsGlobalWorkMode 详细描述.....	1586
85.3.13 hwMplsGlobalBcModel 详细描述.....	1587
85.3.14 hwMplsDynamicLabelTotalCount 详细描述.....	1587
85.3.15 hwMplsDynamicLabelCurrentCount 详细描述.....	1587
85.3.16 hwMplsDynamicLabelThresholdUpperLimit 详细描述.....	1587
85.3.17 hwMplsDynamicLabelThresholdLowerLimit 详细描述.....	1588
85.3.18 hwMplsResourceType 详细描述.....	1589
85.3.19 hwMplsResourceCurrentCount 详细描述.....	1590
85.3.20 hwMplsResourceThreshold 详细描述.....	1590
85.3.21 hwMplsResourceTotalCount 详细描述.....	1590
85.3.22 hwMplsTunnelIfName 详细描述.....	1590
85.4 MIB Table 详细描述.....	1590
85.4.1 hwMplsTunnelTable 详细描述.....	1591
85.4.2 hwTunnelFrrBypassTable 详细描述.....	1597
85.4.3 hwTunnelFrrARHopTable 详细描述.....	1598
85.4.4 hwTunnelFrrRouteDBTable 详细描述.....	1599
85.4.5 hwStaticLspTable 详细描述.....	1601

85.4.6 hwMplsIfBcTable 详细描述.....	1603
85.4.7 hwStaticLspTnlTable 详细描述.....	1605
85.4.8 hwMplsTeVpnQosTable 详细描述.....	1605
85.4.9 hwMplsLspStatisticsTable 详细描述.....	1606
85.5 告警节点详细描述.....	1608
85.5.1 hwMplsStaticLspUp 详细描述.....	1608
85.5.2 hwMplsStaticLspDown 详细描述.....	1608
85.5.3 hwMplsStaticCRLspUp 详细描述.....	1609
85.5.4 hwMplsStaticCRLspDown 详细描述.....	1609
85.5.5 hwMplsTeFrrProtAval 详细描述.....	1610
85.5.6 hwMplsTeFrrProtNotAval 详细描述.....	1610
85.5.7 hwMplsTeFrrSwitch 详细描述.....	1611
85.5.8 hwMplsTeFrrResume 详细描述.....	1611
85.5.9 hwMplsTunnelHSBSwitch 详细描述.....	1612
85.5.10 hwMplsTunnelHSBResume 详细描述.....	1612
85.5.11 hwMplsTunnelOBSwitch 详细描述.....	1612
85.5.12 hwMplsTunnelOBResume 详细描述.....	1613
85.5.13 hwMplsTunnelChangeBw 详细描述.....	1613
85.5.14 hwMplsTunnelPrimaryUp 详细描述.....	1613
85.5.15 hwMplsTunnelPrimaryDown 详细描述.....	1614
85.5.16 hwMplsTunnelHotstandbyUp 详细描述.....	1614
85.5.17 hwMplsTunnelHotstandbyDown 详细描述.....	1615
85.5.18 hwMplsTunnelOrdinaryUp 详细描述.....	1615
85.5.19 hwMplsTunnelOrdinaryDown 详细描述.....	1616
85.5.20 hwMplsTunnelBesteffortUp 详细描述.....	1616
85.5.21 hwMplsTunnelBesteffortDown 详细描述.....	1617
85.5.22 hwMplsTeAutoTunnelDownClear 详细描述.....	1617
85.5.23 hwMplsTeAutoTunnelPrimaryDownClear 详细描述.....	1617
85.5.24 hwMplsExtTunnelDown 详细描述.....	1618
85.5.25 hwMplsExtTunnelDownClear 详细描述.....	1619
85.5.26 hwMplsTunnelBBSwitch 详细描述.....	1619
85.5.27 hwMplsTunnelBBResume 详细描述.....	1620
85.5.28 hwMplsLspThresholdExceed 详细描述.....	1620
85.5.29 hwMplsLspThresholdExceedClear 详细描述.....	1620
85.5.30 hwMplsLspTotalCountExceed 详细描述.....	1621
85.5.31 hwMplsLspTotalCountExceedClear 详细描述.....	1621
85.5.32 hwMplsTunnelDelete 详细描述.....	1621
85.5.33 hwMplsOamLocalLock 详细描述.....	1622
85.5.34 hwMplsOamLocalLockRecovery 详细描述.....	1622
85.5.35 hwMplsDynamicLabelThresholdExceed 详细描述.....	1623
85.5.36 hwMplsDynamicLabelThresholdExceedClear 详细描述.....	1624
85.5.37 hwMplsDynamicLabelTotalCountExceed 详细描述.....	1624

85.5.38 hwMplsDynamicLabelTotalCountExceedClear 详细描述.....	1625
85.5.39 hwMplsResourceThresholdExceed 详细描述.....	1625
85.5.40 hwMplsResourceThresholdExceedClear 详细描述.....	1625
85.5.41 hwMplsResourceTotalCountExceed 详细描述.....	1626
85.5.42 hwMplsResourceTotalCountExceedClear 详细描述.....	1626
85.5.43 hwMplsTunnelCommitLost 详细描述.....	1626
85.5.44 hwMplsTunnelCommitLostClear 详细描述.....	1626
85.5.45 hwMplsTunnelHotstandbySwitch 详细描述.....	1627
85.5.46 hwMplsTunnelHotstandbyResume 详细描述.....	1627
85.5.47 hwMplsTeLspBfdDown 详细描述.....	1627
85.5.48 hwMplsTeLspBfdDownClear 详细描述.....	1627
86 HUAWEI-MPLSLDP-MIB.....	1628
86.1 功能简介.....	1628
86.2 表间关系.....	1628
86.3 单节点详细描述.....	1628
86.3.1 hwMplsLdpProcessName 详细描述.....	1629
86.3.2 hwMplsLdpLspFec 详细描述.....	1629
86.3.3 hwMplsLdpLspInLabel 详细描述.....	1629
86.3.4 hwMplsLdpLspOutLabel 详细描述.....	1629
86.3.5 hwMplsLdpLspOutIfIndex 详细描述.....	1630
86.3.6 hwMplsLdpLspDownReason 详细描述.....	1630
86.3.7 hwLdpCapabilityConfig 详细描述.....	1630
86.3.8 hwLdpLsrId 详细描述.....	1631
86.3.9 hwLdpPropagatelpPrefix 详细描述.....	1631
86.3.10 hwLdpGlobalRemotePwe3 详细描述.....	1631
86.3.11 hwLdpMtuSignaling 详细描述.....	1632
86.3.12 hwLdpMtuApplyTlv 详细描述.....	1632
86.3.13 hwLdpGrCapabilityConfig 详细描述.....	1632
86.3.14 hwLdpGrNeighborLivenessTimer 详细描述.....	1633
86.3.15 hwLdpGrReconnectTimer 详细描述.....	1633
86.3.16 hwLdpGrRecoveryTimer 详细描述.....	1633
86.3.17 hwLdpLongestMatch 详细描述.....	1634
86.3.18 hwLdpRemotePeerAutoDodRequest 详细描述.....	1634
86.3.19 hwMplsLspTrigger 详细描述.....	1634
86.3.20 hwMplsLspTriggerIpPrefix 详细描述.....	1634
86.3.21 hwLdpReset 详细描述.....	1635
86.3.22 hwLdpOutBoundSplitHorizonAll 详细描述.....	1635
86.3.23 hwLdpDeleteGtsmAll 详细描述.....	1635
86.3.24 hwMplsFrrLspTrigger 详细描述.....	1636
86.3.25 hwMplsFrrLspTriggerIpPrefix 详细描述.....	1636
86.3.26 hwMplsLspTriggerBgpRoute 详细描述.....	1636
86.3.27 hwMplsLspTriggerBgpRouteIpPrefix 详细描述.....	1636

86.3.28 hwLdpBackOffTimerInit 详细描述.....	1637
86.3.29 hwLdpBackOffTimerMax 详细描述.....	1637
86.3.30 hwLdpInBoundPolicyPeerAllRange 详细描述.....	1637
86.3.31 hwLdpInBoundPolicyPeerAllIpPrefix 详细描述.....	1637
86.3.32 hwLdpLocalOperationalSessionNumber 详细描述.....	1638
86.3.33 hwLdpRemoteOperationalSessionNumber 详细描述.....	1638
86.3.34 hwLdpLocalAndRemoteOperationalSessionNumber 详细描述.....	1638
86.3.35 hwLdpTotalOperationalSessionNumber 详细描述.....	1639
86.4 MIB Table 详细描述.....	1639
86.4.1 hwMplsLdpSessionTable 详细描述.....	1639
86.4.2 hwMplsLdpSessionStateTable 详细描述.....	1642
86.4.3 hwLdpRemoteEntityTable 详细描述.....	1644
86.4.4 hwLdpPeerTable 详细描述.....	1646
86.4.5 hwLdpVpnPeerTable 详细描述.....	1649
86.4.6 hwLdpInterfaceTable 详细描述.....	1651
86.4.7 hwLdpPeerGroupTable 详细描述.....	1653
86.5 告警节点详细描述.....	1654
86.6 不支持节点.....	1654
87 HUAWEI-MPLSLSR-EXT-MIB.....	1655
87.1 功能简介.....	1655
87.2 表间关系.....	1655
87.3 单节点详细描述.....	1656
87.3.1 hwMplsLsrId 详细描述.....	1656
87.3.2 hwMplsCapabilityConfig 详细描述.....	1656
87.3.3 hwMplsLabelAdvertise 详细描述.....	1656
87.3.4 hwMplsBfdCapabilityConfig 详细描述.....	1657
87.3.5 hwMplsBfdMinTx 详细描述.....	1657
87.3.6 hwMplsBfdMinRx 详细描述.....	1657
87.3.7 hwMplsBfdDetectMultiplier 详细描述.....	1657
87.3.8 hwMplsFecListName 详细描述.....	1658
87.3.9 hwMplsBfdTrigger 详细描述.....	1658
87.3.10 hwMplsBfdTriggerNextHop 详细描述.....	1658
87.3.11 hwMplsBfdTriggerInterface 详细描述.....	1659
87.3.12 hwMplsBfdTriggerFecListName 详细描述.....	1659
87.3.13 hwLdpVirtualTunnelFEC 详细描述.....	1659
87.3.14 hwMplsBgpBfdCapabilityConfig 详细描述.....	1660
87.3.15 hwMplsBgpBfdMinTx 详细描述.....	1660
87.3.16 hwMplsBgpBfdMinRx 详细描述.....	1660
87.3.17 hwMplsBgpBfdDetectMultiplier 详细描述.....	1661
87.3.18 hwMplsBgpBfdTriggerTunnel 详细描述.....	1661
87.3.19 hwMplsBgpBfdTriggerTunnelIpprefix 详细描述.....	1661
87.4 MIB Table 详细描述.....	1662

87.4.1 hwMplsFecListTable 详细描述.....	1662
87.4.2 hwMplsInterfaceTable 详细描述.....	1663
87.4.3 hwLdpStaticFrrInterfaceTable 详细描述.....	1664
87.4.4 hwLdpVirtualTunnelTable 详细描述.....	1665
87.4.5 hwMplsStaticLspTable 详细描述.....	1666
87.5 告警节点详细描述.....	1667
87.5.1 hwMplsLdpVirtualTunnelUp 详细描述.....	1668
87.5.2 hwMplsLdpVirtualTunnelDown 详细描述.....	1668
88 HUAWEI-MPLSOAM-MIB.....	1669
88.1 功能简介.....	1669
88.2 表间关系.....	1669
88.3 单节点详细描述.....	1669
88.3.1 hwMplsOamCapability 详细描述.....	1670
88.4 MIB Table 详细描述.....	1670
88.4.1 hwMplsOamLgrTable 详细描述.....	1670
88.4.2 hwMplsOamEgrTable 详细描述.....	1673
88.4.3 hwMplsPsTable 详细描述.....	1679
88.5 告警节点详细描述.....	1686
88.5.1 hwMplsOamLgrLSPOutDefect 详细描述.....	1686
88.5.2 hwMplsOamLgrLSPInDefect 详细描述.....	1686
88.5.3 hwMplsOamLgrLSPAva 详细描述.....	1687
88.5.4 hwMplsOamLgrLSPUnAva 详细描述.....	1687
88.5.5 hwMplsOamEgrLSPOutDefect 详细描述.....	1687
88.5.6 hwMplsOamEgrLSPInDefect 详细描述.....	1688
88.5.7 hwMplsOamEgrLSPAva 详细描述.....	1688
88.5.8 hwMplsOamEgrLSPUnAva 详细描述.....	1689
88.5.9 hwMplsPsSwitchPtoW 详细描述.....	1689
88.5.10 hwMplsPsSwitchWtoP 详细描述.....	1690
88.5.11 hwMplsApsOutage 详细描述.....	1690
88.5.12 hwMplsApsOutageRecovery 详细描述.....	1690
88.6 不支持节点.....	1690
89 HUAWEI-MSDP-MIB.....	1692
89.1 功能简介.....	1692
89.2 表间关系.....	1692
89.3 单节点详细描述.....	1692
89.3.1 hwMsdplInstanceId 详细描述.....	1692
89.3.2 hwMsdplInstanceName 详细描述.....	1693
89.3.3 hwMsdpNotificationReason 详细描述.....	1694
89.4 MIB Table 详细描述.....	1694
89.5 告警节点详细描述.....	1695
90 HUAWEI-MSTP-MIB.....	1696

90.1 功能简介.....	1696
90.2 表间关系.....	1697
90.3 单节点详细描述.....	1698
90.3.1 hwMstpStatus 详细描述.....	1698
90.3.2 hwMstpForceVersion 详细描述.....	1698
90.3.3 hwMstpDiameter 详细描述.....	1699
90.3.4 hwMstpBridgeMaxHops 详细描述.....	1699
90.3.5 hwMstpMasterBridgeID 详细描述.....	1700
90.3.6 hwMstpMasterPathCost 详细描述.....	1700
90.3.7 hwMstpBpduGuard 详细描述.....	1701
90.3.8 hwMstpAdminFormatSelector 详细描述.....	1701
90.3.9 hwMstpAdminRegionName 详细描述.....	1702
90.3.10 hwMstpAdminRevisionLevel 详细描述.....	1702
90.3.11 hwMstpOperFormatSelector 详细描述.....	1702
90.3.12 hwMstpOperRegionName 详细描述.....	1703
90.3.13 hwMstpOperRevisionLevel 详细描述.....	1703
90.3.14 hwMstpRegionConfActive 详细描述.....	1704
90.3.15 hwMstpDefaultVlanAllo 详细描述.....	1704
90.3.16 hwMstpDefaultRegionName 详细描述.....	1705
90.3.17 hwMstpPathCostStandard 详细描述.....	1705
90.3.18 hwMstpTcGuard 详细描述.....	1706
90.3.19 hwMstpTcGuardThreshold 详细描述.....	1706
90.3.20 hwMstpEdgedPortDefault 详细描述.....	1707
90.3.21 hwMstpBpduFilterPortDefault 详细描述.....	1707
90.3.22 hwMstpTransmitLimitDefault 详细描述.....	1708
90.4 MIB Table 详细描述.....	1708
90.4.1 hwMstpVIDAllocationTable 详细描述.....	1708
90.4.2 hwMstpInstanceTable 详细描述.....	1709
90.4.3 hwMstpPortTable 详细描述.....	1713
90.4.4 hwMstpProTable 详细描述.....	1725
90.4.5 hwMstpPortBindTable 详细描述.....	1733
90.4.6 hwMstpProInstanceTable 详细描述.....	1736
90.4.7 hwMstpProNewPortTable 详细描述.....	1739
90.5 告警节点详细描述.....	1750
90.5.1 hwMstpiPortStateForwarding 详细描述.....	1751
90.5.2 hwMstpiPortStateDiscarding 详细描述.....	1751
90.5.3 hwMstpiBridgeLostRootPrimary 详细描述.....	1752
90.5.4 hwMstpiPortRootGuarded 详细描述.....	1752
90.5.5 hwMstpiPortBpduGuarded 详细描述.....	1753
90.5.6 hwMstpiPortLoopGuarded 详细描述.....	1753
90.5.7 hwMstpiEdgePortChanged 详细描述.....	1753
90.5.8 hwMstpiTcGuarded 详细描述.....	1754

90.5.9 hwMstpProTcGuarded 详细描述.....	1754
90.5.10 hwMstpProRootChanged 详细描述.....	1754
90.5.11 hwMstpProNewPortStateForwarding 详细描述.....	1755
90.5.12 hwMstpProNewPortStateDiscarding 详细描述.....	1755
90.5.13 hwMstpProNewBridgeLostRootPrimary 详细描述.....	1756
90.5.14 hwMstpProNewPortRootGuarded 详细描述.....	1756
90.5.15 hwMstpProNewPortBpduGuarded 详细描述.....	1757
90.5.16 hwMstpProNewPortLoopGuarded 详细描述.....	1757
90.5.17 hwMstpProNewEdgePortChanged 详细描述.....	1757
90.5.18 hwMstpProLoopbackDetected 详细描述.....	1758
90.5.19 hwMstpProRootLost 详细描述.....	1758
90.5.20 hwMstpProRootResume 详细描述.....	1758
91 HUAWEI-MULTICAST-MIB.....	1759
91.1 不支持节点.....	1759
92 HUAWEI-NETSTREAM-MIB.....	1765
92.1 功能简介.....	1765
92.2 表间关系.....	1765
92.3 单节点详细描述.....	1765
92.3.1 hwNetStreamlastchangedtime 详细描述.....	1766
92.3.2 hwNetStreamTemplateRefresh 详细描述.....	1766
92.4 MIB Table 详细描述.....	1766
92.4.1 hwNetStreamIfIndexTable 详细描述.....	1766
92.5 告警节点详细描述.....	1767
92.5.1 hwNetStreamIndexUsedUp 详细描述.....	1767
93 HUAWEI-NTPV3-MIB.....	1768
93.1 功能简介.....	1768
93.2 表间关系.....	1768
93.3 单节点详细描述.....	1768
93.3.1 hwNtpV3ServerIPAdd 详细描述.....	1769
93.3.2 hwNtpV3TimeSyncPeriod 详细描述.....	1769
93.3.3 hwNtpV3TimeAfterNTPCal 详细描述.....	1769
93.4 告警节点详细描述.....	1770
94 HUAWEI-NTP-TRAP-MIB.....	1771
94.1 功能简介.....	1771
94.2 表间关系.....	1771
94.3 单节点详细描述.....	1771
94.3.1 hwNtpState 详细描述.....	1771
94.3.2 hwNtpSource 详细描述.....	1772
94.3.3 hwNtpSourceVpnName 详细描述.....	1772
94.4 告警节点详细描述.....	1773
94.4.1 hwNtpStateChangeTrap 详细描述.....	1773

95 HUAWEI-OSPFV2-MIB	1774
95.1 功能简介	1774
95.2 表间关系	1775
95.3 单节点详细描述	1775
95.3.1 hwOspfV2MibBinding 详细描述	1775
95.3.2 hwOspfV2MIBObjectsChange 详细描述	1776
95.3.3 hwOspfV2ProcessChange 详细描述	1776
95.3.4 hwOspfV2AreaChange 详细描述	1776
95.3.5 hwOspfV2NetworkChange 详细描述	1777
95.3.6 hwOspfV2NbrChgReason 详细描述	1777
95.3.7 hwOspfV2IfChgReason 详细描述	1778
95.3.8 hwOspfV2AreaId 详细描述	1778
95.3.9 hwOspfV2NewRouterId 详细描述	1778
95.3.10 hwOspfV2PeerFlappingSuppressStatus 详细描述	1779
95.3.11 hwOspfV2PeerFlappingSuppressReason 详细描述	1780
95.4 MIB Table 详细描述	1780
95.4.1 hwOspfV2ProcessTable 详细描述	1780
95.4.2 hwOspfV2AreaTable 详细描述	1792
95.4.3 hwOspfV2NetworkTable 详细描述	1805
95.4.4 hwOspfV2NeighborTable 详细描述	1806
95.4.5 hwOspfV2InterfaceTable 详细描述	1809
95.5 告警节点详细描述	1810
95.5.1 hwOspfV2IntraAreaRouterIdConflict 详细描述	1810
95.5.2 hwOspfV2IntraAreaDRIPAddressConflict 详细描述	1811
95.5.3 hwOspfV2IntraAreaRouterIdConflictRecovered 详细描述	1811
95.5.4 hwOspfV2PeerFlappingSuppressStatusChange 详细描述	1811
96 HUAWEI-OSPFV3-MIB	1812
96.1 功能简介	1812
96.2 表间关系	1812
96.3 单节点详细描述	1812
96.3.1 hwOspfV3RouterId 详细描述	1813
96.3.2 hwOspfV3AdminStatus 详细描述	1813
96.3.3 hwOspfV3VersionNumber 详细描述	1813
96.3.4 hwOspfV3AreaBdrRtrStatus 详细描述	1814
96.3.5 hwOspfV3AsBdrRtrStatus 详细描述	1814
96.3.6 hwOspfV3AsScopeLsaCount 详细描述	1814
96.3.7 hwOspfV3AsScopeLsaCksumSum 详细描述	1814
96.3.8 hwOspfV3OriginateNewLsas 详细描述	1815
96.3.9 hwOspfV3RxNewLsas 详细描述	1815
96.3.10 hwOspfV3ExtLsaCount 详细描述	1815
96.3.11 hwOspfV3ExtAreaLsdbLimit 详细描述	1816
96.3.12 hwOspfV3RestartSupport 详细描述	1816

96.3.13 hwOspfV3RestartInterval 详细描述.....	1817
96.3.14 hwOspfV3RestartStatus 详细描述.....	1817
96.3.15 hwOspfV3RestartAge 详细描述.....	1817
96.3.16 hwOspfV3RestartExitRc 详细描述.....	1818
96.3.17 hwOspfV3NotificationEnable 详细描述.....	1818
96.3.18 hwOspfV3ReferenceBandwidth 详细描述.....	1818
96.3.19 hwOspfV3ConfigErrorType 详细描述.....	1819
96.3.20 hwOspfV3PacketType 详细描述.....	1819
96.3.21 hwOspfV3PacketSrc 详细描述.....	1820
96.3.22 hwOspfV3IfName 详细描述.....	1820
96.3.23 hwOspfV3IfStateChgReason 详细描述.....	1820
96.3.24 hwOspfV3NbrStateChgReason 详细描述.....	1821
96.3.25 hwOspfV3ProcessId 详细描述.....	1822
96.3.26 hwOspfV3AreaIdIndex 详细描述.....	1822
96.3.27 hwOspfV3NewRouterId 详细描述.....	1822
96.3.28 hwOspfV3PeerFlappingSuppressStatus 详细描述.....	1823
96.3.29 hwOspfV3PeerFlappingSuppressReason 详细描述.....	1824
96.4 MIB Table 详细描述.....	1824
96.4.1 hwOspfV3AreaTable 详细描述.....	1824
96.4.2 hwOspfV3AsLsdbTable 详细描述.....	1827
96.4.3 hwOspfV3AreaLsdbTable 详细描述.....	1829
96.4.4 hwOspfV3LinkLsdbTable 详细描述.....	1831
96.4.5 hwOspfV3IfTable 详细描述.....	1833
96.4.6 hwOspfV3VirtIfTable 详细描述.....	1837
96.4.7 hwOspfV3NbrTable 详细描述.....	1839
96.4.8 hwOspfV3CfgNbrTable 详细描述.....	1842
96.4.9 hwOspfV3VirtNbrTable 详细描述.....	1843
96.4.10 hwOspfV3AreaAggregateTable 详细描述.....	1846
96.5 告警节点详细描述.....	1848
96.5.1 hwOspfV3VirtIfStateChange 详细描述.....	1849
96.5.2 hwOspfV3NbrStateChange 详细描述.....	1849
96.5.3 hwOspfV3VirtNbrStateChange 详细描述.....	1849
96.5.4 hwOspfV3IfConfigError 详细描述.....	1850
96.5.5 hwOspfV3VirtIfConfigError 详细描述.....	1850
96.5.6 hwOspfV3IfRxBadPacket 详细描述.....	1851
96.5.7 hwOspfV3VirtIfRxBadPacket 详细描述.....	1851
96.5.8 hwOspfV3IfStateChange 详细描述.....	1851
96.5.9 hwOspfV3RestartStatusChange 详细描述.....	1852
96.5.10 hwOspfV3NbrRestartHelperStatusChange 详细描述.....	1852
96.5.11 hwOspfV3VirtNbrRestartHelperStatusChange 详细描述.....	1853
96.5.12 hwOspfV3NssaTranslatorStatusChange 详细描述.....	1853
96.5.13 hwOspfV3LastAuthKeyExpiry 详细描述.....	1853

96.5.14 hwOspfV3AuthSequenceNumWrap 详细描述.....	1854
96.5.15 hwOspfV3IntraAreaRouterIdConflictRecovered 详细描述.....	1854
96.5.16 hwOspfV3PeerFlappingSuppressStatusChange 详细描述.....	1855

97 HUAWEI-PERFMGMT-MIB..... 1856

97.1 功能简介.....	1856
97.2 表间关系.....	1857
97.3 单节点详细描述.....	1857
97.3.1 hwPMStatisticsEnable 详细描述.....	1858
97.3.2 hwPMStatisticsMaxFilesPerTask 详细描述.....	1858
97.3.3 hwPMStatisticsMaxTasks 详细描述.....	1859
97.3.4 hwPMStatisticsCurrentTasks 详细描述.....	1859
97.3.5 hwPMStatisticsTaskIndicateLowValue 详细描述.....	1859
97.3.6 hwPMStatisticsTaskIndicateHighValue 详细描述.....	1860
97.4 MIB Table 详细描述.....	1860
97.4.1 hwPMStatisticsTaskTable 详细描述.....	1860
97.4.2 hwPMStatisticsTaskInstanceTable 详细描述.....	1864
97.4.3 hwPMStatisticsTaskIndicatorTable 详细描述.....	1865
97.4.4 hwPMStatisticsTaskThresholdRuleTable 详细描述.....	1866
97.4.5 hwPMStatisticsTaskFileTable 详细描述.....	1868
97.4.6 hwPMServerTable 详细描述.....	1869
97.4.7 hwPMFileUploadCfgTable 详细描述.....	1874
97.4.8 hwPMFileUploadMgmtTable 详细描述.....	1875
97.4.9 hwPMHistoryDataTable 详细描述.....	1877
97.4.10 hwPMCurrentDataTable 详细描述.....	1879
97.4.11 hwPMIntervalTypeTable 详细描述.....	1882
97.4.12 hwPMInstanceTypeTable 详细描述.....	1884
97.4.13 hwPMIndicatorTable 详细描述.....	1885
97.5 告警节点详细描述.....	1886
97.5.1 hwPMStatisticsTaskThresholdClearAlarm 详细描述.....	1887
97.5.2 hwPMStatisticsTaskThresholdTriggerAlarm 详细描述.....	1888
97.5.3 hwPMMeasureExceed 详细描述.....	1889

98 HUAWEI-PERFORMANCE-MIB..... 1890

98.1 功能简介.....	1890
98.2 表间关系.....	1890
98.3 单节点详细描述.....	1890
98.4 MIB Table 详细描述.....	1890
98.4.1 priAlarmTable 详细描述.....	1890
98.5 告警节点详细描述.....	1895
98.5.1 priRisingAlarm 详细描述.....	1895
98.5.2 priFallingAlarm 详细描述.....	1895

99 HUAWEI-PIM-BSR-MIB..... 1896

99.1 功能简介.....	1896
99.2 表间关系.....	1896
99.3 单节点详细描述.....	1896
99.4 MIB Table 详细描述.....	1896
99.4.1 hwPimBsrElectedBsrRpSetTable 详细描述.....	1896
99.5 告警节点详细描述.....	1898
100 HUAWEI-PIM-STD-MIB.....	1899
100.1 功能简介.....	1899
100.2 表间关系.....	1899
100.3 单节点详细描述.....	1900
100.3.1 hwPimkeepalivePeriod 详细描述.....	1900
100.3.2 hwPimRegisterSuppressionTime 详细描述.....	1900
100.3.3 hwPimStarGEntries 详细描述.....	1900
100.3.4 hwPimStarGIEEntries 详细描述.....	1901
100.3.5 hwPimSGEntries 详细描述.....	1901
100.3.6 hwPimSGIEEntries 详细描述.....	1901
100.3.7 hwPimSGRpEntries 详细描述.....	1901
100.3.8 hwPimSGRpIEEntries 详细描述.....	1902
100.3.9 hwPimOutAsserts 详细描述.....	1902
100.3.10 hwPimInAsserts 详细描述.....	1902
100.3.11 hwPimLastAssertInterface 详细描述.....	1902
100.3.12 hwPimLastAssertGroupAddressType 详细描述.....	1903
100.3.13 hwPimLastAssertGroupAddress 详细描述.....	1903
100.3.14 hwPimLastAssertSourceAddressType 详细描述.....	1903
100.3.15 hwPimLastAssertSourceAddress 详细描述.....	1904
100.3.16 hwPimNeighborLossNotificationPeriod 详细描述.....	1904
100.3.17 hwPimNeighborLossCount 详细描述.....	1904
100.3.18 hwPimInvalidRegisterNotificationPeriod 详细描述.....	1905
100.3.19 hwPimInvalidRegisterMsgsRcvd 详细描述.....	1905
100.3.20 hwPimInvalidRegisterAddressType 详细描述.....	1905
100.3.21 hwPimInvalidRegisterOrigin 详细描述.....	1906
100.3.22 hwPimInvalidRegisterGroup 详细描述.....	1906
100.3.23 hwPimInvalidRegisterRp 详细描述.....	1906
100.3.24 hwPimInvalidJoinPruneNotificationPeriod 详细描述.....	1906
100.3.25 hwPimInvalidJoinPruneMsgsRcvd 详细描述.....	1907
100.3.26 hwPimInvalidJoinPruneAddressType 详细描述.....	1907
100.3.27 hwPimInvalidJoinPruneOrigin 详细描述.....	1907
100.3.28 hwPimInvalidJoinPruneGroup 详细描述.....	1908
100.3.29 hwPimInvalidJoinPruneRp 详细描述.....	1908
100.3.30 hwPimRpMappingNotificationPeriod 详细描述.....	1908
100.3.31 hwPimRpMappingChangeCount 详细描述.....	1908
100.3.32 hwPimInterfaceElectionNotificationPeriod 详细描述.....	1909

100.3.33 hwPimInterfaceElectionWinCount 详细描述.....	1909
100.3.34 hwPimRefreshInterval 详细描述.....	1909
100.3.35 hwPimDeviceConfigStorageType 详细描述.....	1910
100.3.36 hwPimNeighborAddCount 详细描述.....	1910
100.3.37 hwPimNeighborAddNotificationPeriod 详细描述.....	1910
100.3.38 hwPimMrtLimitAddressType 详细描述.....	1911
100.3.39 hwPimMrtLimitSource 详细描述.....	1911
100.3.40 hwPimMrtLimitGroup 详细描述.....	1911
100.3.41 hwPimInstanceId 详细描述.....	1912
100.3.42 hwPimInstanceName 详细描述.....	1912
100.3.43 hwPimNeighborNotificationReason 详细描述.....	1913
100.3.44 hwPimNotificationAddressType 详细描述.....	1914
100.3.45 hwPimStarGCurrentCount 详细描述.....	1914
100.3.46 hwPimStarGTotalCount 详细描述.....	1914
100.3.47 hwPimStarGThreshold 详细描述.....	1914
100.3.48 hwPimSGCurrentCount 详细描述.....	1915
100.3.49 hwPimSGTotalCount 详细描述.....	1915
100.3.50 hwPimSGThreshold 详细描述.....	1915
100.3.51 hwPimNotificationSrcAddr 详细描述.....	1915
100.3.52 hwPimNotificationGrpAddr 详细描述.....	1916
100.4 MIB Table 详细描述.....	1916
100.4.1 hwPimInterfaceTable 详细描述.....	1916
100.4.2 hwPimNeighborTable 详细描述.....	1921
100.4.3 hwPimNbrSecAddressTable 详细描述.....	1924
100.4.4 hwPimStarGTable 详细描述.....	1926
100.4.5 hwPimStarGTable 详细描述.....	1931
100.4.6 hwPimSGTable 详细描述.....	1934
100.4.7 hwPimSGTable 详细描述.....	1940
100.4.8 hwPimSGRptTable 详细描述.....	1943
100.4.9 hwPimSGRptTable 详细描述.....	1944
100.4.10 hwPimGroupMappingTable 详细描述.....	1945
100.4.11 hwPimGlobalCtlMsgCountTable 详细描述.....	1947
100.4.12 hwPimInterfaceCtlMsgCountTable 详细描述.....	1948
100.5 告警节点详细描述.....	1950
100.5.1 hwPimNeighborLoss 详细描述.....	1950
100.5.2 hwPimInvalidRegister 详细描述.....	1951
100.5.3 hwPimInvalidJoinPrune 详细描述.....	1951
100.5.4 hwPimRpMappingChange 详细描述.....	1952
100.5.5 hwPimInterfaceElection 详细描述.....	1952
100.5.6 hwPimNeighborAdd 详细描述.....	1953
100.5.7 hwPimGRStart 详细描述.....	1953
100.5.8 hwPimGREnd 详细描述.....	1953

100.5.9 hwPimMrtLimit 详细描述.....	1953
100.5.10 hwPimMrtLimitClear 详细描述.....	1954
100.5.11 hwPimStarGThresholdExceed 详细描述.....	1954
100.5.12 hwPimStarGThresholdExceedClear 详细描述.....	1954
100.5.13 hwPimStarGExceed 详细描述.....	1955
100.5.14 hwPimStarGExceedClear 详细描述.....	1955
100.5.15 hwPimSGThresholdExceed 详细描述.....	1955
100.5.16 hwPimSGThresholdExceedClear 详细描述.....	1956
100.5.17 hwPimSGExceed 详细描述.....	1956
100.5.18 hwPimSGExceedClear 详细描述.....	1956
101 HUAWEI-POE-MIB.....	1957
101.1 功能简介.....	1957
101.2 表间关系.....	1957
101.3 单节点详细描述.....	1958
101.3.1 hwPoePower 详细描述.....	1958
101.3.2 hwPoePowerRsvPercent 详细描述.....	1958
101.3.3 hwPoePowerUtilizationThreshold 详细描述.....	1958
101.4 MIB Table 详细描述.....	1958
101.4.1 hwPoeSlotTable 详细描述.....	1958
101.4.2 hwPoePortTable 详细描述.....	1960
101.4.3 hwPoePowerInfoTable 详细描述.....	1964
101.4.4 hwPoePortJudgeTable 详细描述.....	1966
101.5 告警节点详细描述.....	1966
101.5.1 hwPoePowerOff 详细描述.....	1966
101.5.2 hwPoePowerOn 详细描述.....	1967
101.5.3 hwPoePdConnected 详细描述.....	1967
101.5.4 hwPoePdDisconnected 详细描述.....	1967
101.5.5 hwPoePdClassInvalid 详细描述.....	1968
101.5.6 hwPoePdClassOvercurrent 详细描述.....	1968
101.5.7 hwPoePdPriorityDifferent 详细描述.....	1968
101.5.8 hwPoePowerOverUtilizationThreshold 详细描述.....	1969
101.5.9 hwPoePowerOverUtilizationThresholdResume 详细描述.....	1969
101.5.10 hwPoeBoardInsertedWrongFrame 详细描述.....	1969
101.5.11 hwPoePowerAbsent 详细描述.....	1970
101.5.12 hwPoeNotAvailable 详细描述.....	1970
101.5.13 hwPoeNotAvailableResume 详细描述.....	1970
101.5.14 hwPoePortFail 详细描述.....	1971
101.5.15 hwPoePortFailResume 详细描述.....	1971
101.5.16 hwPoePdOvercurrentPoweroff 详细描述.....	1971
101.5.17 hwPoePdOverloadPoweroff 详细描述.....	1972
101.6 不支持节点.....	1972
102 HUAWEI-PORT-MIB.....	1974

102.1 功能简介.....	1974
102.2 表间关系.....	1974
102.3 单节点详细描述.....	1974
102.3.1 hwUUHashRiskReason 详细描述.....	1975
102.4 MIB Table 详细描述.....	1975
102.4.1 hwEthernetTable 详细描述.....	1975
102.4.2 hwPhysicalPortTable 详细描述.....	1978
102.4.3 hwPortAlarmThresholdTable 详细描述.....	1981
102.4.4 hwPortProtectGroupCfgTable 详细描述.....	1982
102.4.5 hwPortDescriptionTable 详细描述.....	1983
102.4.6 hwIPIfStatTable 详细描述.....	1984
102.5 告警节点详细描述.....	1986
102.5.1 hwBoardNotSupportAssignTrunk 详细描述.....	1986
102.5.2 hwInputDiscardNotice 详细描述.....	1987
102.5.3 hwOutputDiscardNotice 详细描述.....	1987
102.5.4 hwInputRateChangeOverThresholdNotice 详细描述.....	1988
102.5.5 hwOutputRateChangeOverThresholdNotice 详细描述.....	1988
102.5.6 hwNotSameBoardInTrunk 详细描述.....	1989
102.5.7 hwPortSfpNotSupportSingleFiber 详细描述.....	1989
102.5.8 hwPhysicalPortCrcRatioExceed 详细描述.....	1989
102.5.9 hwPhysicalPortCrcRatioResume 详细描述.....	1990
102.5.10 hwPhysicalPortInBroadcastRapidChange 详细描述.....	1990
102.5.11 hwSubIfNumExceededSpecAlarm 详细描述.....	1991
102.5.12 hwSubIfNumExceededSpecAlarmResume 详细描述.....	1991
102.5.13 hwTunnellfNumExceededSpecAlarm 详细描述.....	1991
102.5.14 hwVxlanTrunkHashNotSupport 详细描述.....	1992
102.5.15 hwTrunkUUHashRisk 详细描述.....	1992
103 HUAWEI-PORTAL-MIB.....	1993
103.1 功能简介.....	1993
103.2 表间关系.....	1993
103.3 单节点详细描述.....	1993
103.3.1 hwWebAuthServerListeningPort 详细描述.....	1994
103.3.2 hwWebAuthServerReplyMessage 详细描述.....	1994
103.3.3 hwWebAuthServerVersione 详细描述.....	1994
103.3.4 hwPortalOfflineDetect 详细描述.....	1994
103.3.5 hwPortalMaxUser 详细描述.....	1995
103.3.6 hwPortalUserAlarmPercentageLower 详细描述.....	1995
103.3.7 hwPortalUserAlarmPercentageUpper 详细描述.....	1995
103.3.8 hwPortalCaptiveBypassEnable 详细描述.....	1995
103.3.9 hwPortalCaptiveAdaptiveEnable 详细描述.....	1996
103.4 MIB Table 详细描述.....	1996
103.4.1 hwPortalConfigPara 详细描述.....	1996

103.4.2 hwPortalFreeRuleTable 详细描述.....	1997
103.4.3 hwWebAuthServerCfgTable 详细描述.....	1999
103.4.4 hwWebAuthServerIpCfgTable 详细描述.....	2008
103.4.5 hwWebAuthenCfgTable 详细描述.....	2008
103.4.6 hwWebAuthenAuthNetWorkCfgTable 详细描述.....	2009
103.4.7 hwPortalUrlTemplateCfgTable 详细描述.....	2010
103.4.8 hwUrlTemplateUrlCfgTable 详细描述.....	2013
103.5 告警节点详细描述.....	2015
103.5.1 hwPortalServerUp 详细描述.....	2015
103.5.2 hwPortalServerDown 详细描述.....	2015
103.5.3 hwPortalMaxUserAlarm 详细描述.....	2016
103.5.4 hwPortalUserClearAlarm 详细描述.....	2016
103.5.5 hwPortalPassDNS 详细描述.....	2016
103.6 不支持节点.....	2016
104 HUAWEI-PWE3-MIB.....	2019
104.1 功能简介.....	2019
104.2 表间关系.....	2020
104.3 单节点详细描述.....	2021
104.3.1 hwPWVcStateChangeReason 详细描述.....	2022
104.3.2 hwSvcStateChangeReason 详细描述.....	2028
104.4 MIB Table 详细描述.....	2033
104.4.1 hwPWVcTable 详细描述.....	2033
104.4.2 hwPWVcTnlTable 详细描述.....	2050
104.4.3 hwPWRemoteVcTable 详细描述.....	2051
104.4.4 hwSvcTable 详细描述.....	2054
104.4.5 hwSvcTnlTable 详细描述.....	2061
104.4.6 hwSvcExtTable 详细描述.....	2062
104.4.7 hwPWTemplateTable 详细描述.....	2068
104.5 告警节点详细描述.....	2072
104.5.1 hwPwVcSwitchWtoP 详细描述.....	2072
104.5.2 hwPwVcSwitchPtoW 详细描述.....	2072
104.5.3 hwPWVcDeleted 详细描述.....	2073
104.5.4 hwPwVcDown 详细描述.....	2074
104.5.5 hwPwVcUp 详细描述.....	2075
104.5.6 hwPWVcBackup 详细描述.....	2076
104.5.7 hwSvcDeleted 详细描述.....	2076
104.5.8 hwSvcDown 详细描述.....	2077
104.5.9 hwSvcUp 详细描述.....	2078
104.5.10 hwSvcSwitchWtoP 详细描述.....	2078
104.5.11 hwSvcSwitchPtoW 详细描述.....	2079
104.5.12 hwPWVcStatusChange 详细描述.....	2079
104.5.13 hwVpwsPwRedundancyDegraded 详细描述.....	2079

104.5.14 hwVpwsPwRedundancyDegradedClear 详细描述.....	2079
104.6 附录.....	2080
104.6.1 hwPwStateChangeReason.....	2080
104.6.2 hwPwVcType.....	2081
105 HUAWEI-PWE3-TNL-MIB.....	2083
105.1 功能简介.....	2083
105.2 表间关系.....	2083
105.3 MIB Table 详细描述.....	2083
105.3.1 hwPwe3TunnelTable 详细描述.....	2083
105.3.2 hwPwe3ExtTunnelTable 详细描述.....	2088
106 HUAWEI-QINQ-MIB.....	2094
106.1 功能简介.....	2094
106.2 表间关系.....	2095
106.3 单节点详细描述.....	2096
106.3.1 hwQinqSystemBridgeRole 详细描述.....	2096
106.3.2 hwQinqSystemWellKnowMac 详细描述.....	2096
106.4 MIB Table 详细描述.....	2096
106.4.1 hwQinqBpduTunnelTable 详细描述.....	2097
106.4.2 hwQinqModeCfgTable 详细描述.....	2098
106.4.3 hwQinqSubIfStackingStatTable 详细描述.....	2099
106.4.4 hwQinqSubIfTermTable 详细描述.....	2102
106.4.5 hwQinqSubIfVlanStackingTable 详细描述.....	2103
106.4.6 hwQinqStaticARPCfgTable 详细描述.....	2105
106.4.7 hwQinqStaticMACCfgTable 详细描述.....	2106
106.4.8 hwQinqSubIfDot1qTermTable 详细描述.....	2109
106.4.9 hwQinqSubIfMapTable 详细描述.....	2110
106.5 告警节点详细描述.....	2112
106.6 不支持节点.....	2112
107 HUAWEI-RIPV2-EXT-MIB.....	2113
107.1 功能简介.....	2113
107.2 表间关系.....	2113
107.3 单节点详细描述.....	2113
107.4 MIB Table 详细描述.....	2113
107.4.1 hwRip2ProcInstTable 详细描述.....	2114
107.5 告警节点详细描述.....	2115
107.5.1 hwRip2DBOverFlow 详细描述.....	2115
107.5.2 hwRip2DBOverFlowResume 详细描述.....	2115
108 HUAWEI-RM-EXT-MIB.....	2116
108.1 功能简介.....	2116
108.2 表间关系.....	2116
108.3 单节点详细描述.....	2116

108.3.1 hwTnlDestination 详细描述.....	2116
108.3.2 hwTnlPolicy 详细描述.....	2117
108.3.3 hwCurlpv4PrefixNum 详细描述.....	2117
108.3.4 hwIpv4PrefixLimitValue 详细描述.....	2117
108.3.5 hwCurlpv6PrefixNum 详细描述.....	2117
108.3.6 hwIpv6PrefixLimitValue 详细描述.....	2118
108.3.7 hwIpv6PrefixLimitVpnName 详细描述.....	2118
108.4 MIB Table 详细描述.....	2118
108.4.1 hwRouteStatTable 详细描述.....	2118
108.4.2 hwIpv6RouteStatTable 详细描述.....	2120
108.4.3 hwStaticRouteExtTable 详细描述.....	2121
108.4.4 hwIpv6StaticRouteTable 详细描述.....	2123
108.4.5 hwRmInfo 详细描述.....	2126
108.4.6 hwTnl2L3vpnTable 详细描述.....	2126
108.4.7 hwTnl2VplsTable 详细描述.....	2127
108.4.8 hwTnl2Pwe3VllTable 详细描述.....	2129
108.4.9 hwTnlIf2TnldTable 详细描述.....	2132
108.4.10 hwTnl2MultiHopPwe3Table 详细描述.....	2133
108.5 告警节点详细描述.....	2134
108.5.1 hwTunnelGroupUp 详细描述.....	2135
108.5.2 hwTunnelGroupDown 详细描述.....	2135
108.5.3 hwIpv4PrefixExceed 详细描述.....	2135
108.5.4 hwIpv4PrefixExceedClear 详细描述.....	2135
108.5.5 hwIpv4PrefixThresholdExceed 详细描述.....	2136
108.5.6 hwIpv4PrefixThresholdExceedClear 详细描述.....	2136
108.5.7 hwIpv6PrefixExceed 详细描述.....	2136
108.5.8 hwIpv6PrefixExceedClear 详细描述.....	2136
108.5.9 hwIpv6PrefixThresholdExceed 详细描述.....	2137
108.5.10 hwIpv6PrefixThresholdExceedClear 详细描述.....	2137
108.5.11 hwPublicIpv4PrefixExceed 详细描述.....	2137
108.5.12 hwPublicIpv4PrefixExceedClear 详细描述.....	2137
108.5.13 hwPublicIpv4PrefixThresholdExceed 详细描述.....	2138
108.5.14 hwPublicIpv4PrefixThresholdExceedClear 详细描述.....	2138
108.5.15 hwPublicIpv6PrefixExceed 详细描述.....	2138
108.5.16 hwPublicIpv6PrefixExceedClear 详细描述.....	2138
108.5.17 hwPublicIpv6PrefixThresholdExceed 详细描述.....	2139
108.5.18 hwPublicIpv6PrefixThresholdExceedClear 详细描述.....	2139
108.5.19 hwL3vpnIpv6PrefixExceed 详细描述.....	2139
108.5.20 hwL3vpnIpv6PrefixExceedClear 详细描述.....	2140
108.5.21 hwL3vpnIpv6PrefixThresholdExceed 详细描述.....	2140
109 HUAWEI-RRPP-MIB.....	2141
109.1 功能简介.....	2141

109.2 表间关系.....	2142
109.3 单节点详细描述.....	2142
109.3.1 hwRrppEnableStatus 详细描述.....	2142
109.3.2 hwRrppLinkupDelayTime 详细描述.....	2143
109.4 MIB Table 详细描述.....	2143
109.4.1 hwRrppDomainTable 详细描述.....	2143
109.4.2 hwRrppRingTable 详细描述.....	2145
109.4.3 hwRrppPortTable 详细描述.....	2149
109.4.4 hwRrppRingGroupTable 详细描述.....	2153
109.4.5 hwRrppRingGroupMemberTable 详细描述.....	2154
109.4.6 hwRrppSnoopingInterfaceTable 详细描述.....	2155
109.4.7 hwRrppSnoopingVsiTable 详细描述.....	2157
109.5 告警节点详细描述.....	2158
109.5.1 hwRrppRingRecover 详细描述.....	2158
109.5.2 hwRrppRingFail 详细描述.....	2158
109.5.3 hwRrppMultiMaster 详细描述.....	2158
110 HUAWEI-RSVPTE-MIB.....	2159
110.1 功能简介.....	2159
110.2 表间关系.....	2160
110.3 单节点详细描述.....	2163
110.3.1 hwRsvpTeNbr 详细描述.....	2163
110.3.2 hwRsvpTelfNbrCurrentCount 详细描述.....	2163
110.3.3 hwRsvpTelfNbrThreshold 详细描述.....	2163
110.3.4 hwRsvpTelfNbrTotalCount 详细描述.....	2164
110.3.5 hwRsvpTelfName 详细描述.....	2164
110.4 MIB Table 详细描述.....	2164
110.4.1 hwRsvpTeSessionTable 详细描述.....	2164
110.4.2 hwRsvpTeSenderTable 详细描述.....	2167
110.4.3 hwRsvpTeResvTable 详细描述.....	2184
110.4.4 hwRsvpTeResvFwdTable 详细描述.....	2190
110.4.5 hwRsvpTelfTable 详细描述.....	2196
110.4.6 hwRsvpTeNbrTable 详细描述.....	2199
110.4.7 hwRsvpTeMessageldTable 详细描述.....	2202
110.4.8 hwRsvpTeFilterSpecTable 详细描述.....	2203
110.4.9 hwRsvpTeRroTable 详细描述.....	2204
110.4.10 hwRsvpTeEroTable 详细描述.....	2206
110.5 告警节点详细描述.....	2207
110.5.1 hwRsvpTeHelloLost 详细描述.....	2207
110.5.2 hwRsvpTeHelloLostRecovery 详细描述.....	2207
110.5.3 hwRsvpTeAuthFail 详细描述.....	2207
110.5.4 hwRsvpTeAuthSuccess 详细描述.....	2207
110.5.5 hwRsvpTelfNbrThresholdExceed 详细描述.....	2208

110.5.6 hwRsvpTelfNbrThresholdExceedClear 详细描述.....	2208
110.5.7 hwRsvpTelfNbrTotalCountExceed 详细描述.....	2208
110.5.8 hwRsvpTelfNbrTotalCountExceedClear 详细描述.....	2209
111 HUAWEI-RUMNG-MIB.....	2210
111.1 功能简介.....	2210
111.2 表间关系.....	2210
111.3 单节点详细描述.....	2210
111.4 MIB Table 详细描述.....	2210
111.4.1 hwRuMngDevTable 详细描述.....	2211
111.4.2 hwRuMngPortTable 详细描述.....	2213
111.4.3 hwRuMngSfpTable 详细描述.....	2215
111.5 告警节点详细描述.....	2217
111.5.1 hwRuMngRuLinkAbnormal 详细描述.....	2217
111.5.2 hwRuMngRuLinkNormal 详细描述.....	2217
111.5.3 hwRuMngRuPortLinkDown 详细描述.....	2218
111.5.4 hwRuMngRuPortLinkUp 详细描述.....	2218
111.5.5 hwRuPortInputDiscardNotice 详细描述.....	2218
111.5.6 hwRuPortOutputDiscardNotice 详细描述.....	2219
111.5.7 hwRuPortCrcErrorRising 详细描述.....	2220
111.5.8 hwRuPortCrcErrorResume 详细描述.....	2220
111.5.9 hwRuPortInputRateRising 详细描述.....	2221
111.5.10 hwRuPortInputRateResume 详细描述.....	2221
111.5.11 hwRuPortOutputRateRising 详细描述.....	2221
111.5.12 hwRuPortOutputRateResume 详细描述.....	2222
111.5.13 hwRuPortOpticalPowerAbnormal 详细描述.....	2222
111.5.14 hwRuPortOpticalPowerResume 详细描述.....	2223
111.5.15 hwRuMngDevFull 详细描述.....	2223
111.5.16 hwRuMngFirmwareUpdateFail 详细描述.....	2223
111.5.17 hwRuMngPortRuFull 详细描述.....	2224
111.5.18 hwRuMngOnline 详细描述.....	2224
111.5.19 hwRuMngOffline 详细描述.....	2224
111.5.20 hwRuPseV33Abnormal 详细描述.....	2225
111.5.21 hwRuPseV33Resume 详细描述.....	2225
111.5.22 hwRuPsePowerStatAbnormal 详细描述.....	2225
111.5.23 hwRuPsePowerStatResume 详细描述.....	2225
111.5.24 hwRuTemperatureAbnormal 详细描述.....	2226
111.5.25 hwRuTemperatureResume 详细描述.....	2226
111.5.26 hwRuPhyStatAbnormal 详细描述.....	2226
111.5.27 hwRuPhyStatResume 详细描述.....	2226
111.5.28 hwRuIICFault 详细描述.....	2227
111.5.29 hwRuAuthFail 详细描述.....	2227
111.5.30 hwRuAuthSuccess 详细描述.....	2227

111.5.31 hwRuPortCongestAlarm 详细描述.....	2227
111.5.32 hwRuPortCongestResume 详细描述.....	2228
111.5.33 hwRuUartStatAbnormal 详细描述.....	2228
111.5.34 hwRuUartStatResume 详细描述.....	2228
112 HUAWEI-SECURITY-MIB.....	2229
112.1 功能简介.....	2229
112.2 表间关系.....	2229
112.3 单节点详细描述.....	2229
112.3.1 hwOlcSlotStr 详细描述.....	2230
112.3.2 hwOlcThreshold1 详细描述.....	2230
112.3.3 hwOlcCurrentCpuUsage 详细描述.....	2230
112.3.4 hwOlcCpuSampleCycle 详细描述.....	2230
112.4 MIB Table 详细描述.....	2230
112.5 告警节点详细描述.....	2231
112.5.1 hwStrackUserInfo 详细描述.....	2231
112.5.2 hwStrackIfVlanInfo 详细描述.....	2231
112.5.3 hwStrackDenyPacket 详细描述.....	2232
112.5.4 hwStrackErrorDown 详细描述.....	2232
112.5.5 hwStrackIpInfo 详细描述.....	2232
112.5.6 hwArpsGatewayConflict 详细描述.....	2233
112.5.7 hwArpsEntryCheck 详细描述.....	2233
112.5.8 hwArpsPacketCheck 详细描述.....	2233
112.5.9 hwArpsDaiDropALarm 详细描述.....	2234
112.5.10 hwArpGlobeSpeedLimitALarm 详细描述.....	2234
112.5.11 hwArpIfSpeedLimitALarm 详细描述.....	2234
112.5.12 hwArpVlanSpeedLimitALarm 详细描述.....	2234
112.5.13 hwArpMissGlobeSpeedLimitALarm 详细描述.....	2235
112.5.14 hwArpMissIfSpeedLimitALarm 详细描述.....	2235
112.5.15 hwArpMissVlanSpeedLimitALarm 详细描述.....	2235
112.5.16 hwArpSourceIpSpeedLimitALarm 详细描述.....	2235
112.5.17 hwArpMissSourceIpSpeedLimitALarm 详细描述.....	2236
112.5.18 hwArpIfRateLimitBlockALarm 详细描述.....	2236
112.5.19 hwArpSourceMacSpeedLimitAlarm 详细描述.....	2236
112.5.20 hwArpsDaiBDDropALarm 详细描述.....	2237
112.5.21 hwArpsDaiVlanDropALarm 详细描述.....	2237
112.5.22 hwIPSGDropALarm 详细描述.....	2237
112.5.23 hwIPSGVlanDropALarm 详细描述.....	2238
112.5.24 hwIPSGv4ResourceALarm 详细描述.....	2238
112.5.25 hwIPSGv4ResourceResume 详细描述.....	2238
112.5.26 hwIPSGv6ResourceALarm 详细描述.....	2238
112.5.27 hwIPSGv6ResourceResume 详细描述.....	2239
112.5.28 hwIcmpGlobalDropALarm 详细描述.....	2239

112.5.29 hwIcmpIfDropAlarm 详细描述.....	2239
112.5.30 hwCpcarDropPacketAlarm 详细描述.....	2239
112.5.31 hwStrackPortAtk 详细描述.....	2240
112.5.32 hwOlcStartAlarm 详细描述.....	2240
112.5.33 hwOlcStopAlarm 详细描述.....	2241
112.5.34 hwWeakEAConfigAlarm 详细描述.....	2241
112.5.35 hwSSHAttackAlarm 详细描述.....	2241
112.6 不支持节点.....	2241
113 HUAWEI-SECURITY-PKI-MIB.....	2243
113.1 功能简介.....	2243
113.2 表间关系.....	2243
113.3 单节点详细描述.....	2243
113.3.1 hwPKICrlUrl 详细描述.....	2243
113.3.2 hwPKILdapIP 详细描述.....	2244
113.3.3 hwPKILdapPort 详细描述.....	2244
113.3.4 hwPKILdapVersion 详细描述.....	2244
113.3.5 hwPKICrlAttribute 详细描述.....	2244
113.3.6 hwPKICrlDN 详细描述.....	2245
113.3.7 hwPKICertUrl 详细描述.....	2245
113.3.8 hwPKICertSaveName 详细描述.....	2245
113.3.9 hwPKICertAttribute 详细描述.....	2245
113.3.10 hwPKICertDN 详细描述.....	2246
113.3.11 hwCACertStartTime 详细描述.....	2246
113.3.12 hwPKICACertFinishTime 详细描述.....	2246
113.3.13 hwPKICACertIssuer 详细描述.....	2246
113.3.14 hwPKICACertSubject 详细描述.....	2247
113.3.15 hwPKILocalCertStartTime 详细描述.....	2247
113.3.16 hwPKILocalCertFinishTime 详细描述.....	2247
113.3.17 hwPKILocalCertIssuer 详细描述.....	2247
113.3.18 hwPKILocalCertSubject 详细描述.....	2248
113.3.19 hwPKICrlStartTime 详细描述.....	2248
113.3.20 hwPKICrlFinishTime 详细描述.....	2248
113.3.21 hwPKICrlIssuer 详细描述.....	2248
113.3.22 hwPKICMPUrl 详细描述.....	2249
113.3.23 hwPKICASubject 详细描述.....	2249
113.3.24 hwPKICMPSessionName 详细描述.....	2249
113.3.25 hwPKISCEPUrl 详细描述.....	2249
113.3.26 hwPKIRealmName 详细描述.....	2250
113.3.27 hwPKIKeyName 详细描述.....	2250
113.3.28 hwPKIKeyBit 详细描述.....	2250
113.3.29 hwPKICrlFileName 详细描述.....	2250
113.3.30 hwPKICrlFileLength 详细描述.....	2251

113.3.31 hwPKICrlMaxLength 详细描述.....	2251
113.4 MIB Table 表详细描述.....	2251
113.5 告警节点详细描述.....	2251
113.5.1 hwPKIGetCrlSucHttp 详细描述.....	2251
113.5.2 hwPKIGetCrlFailHttp 详细描述.....	2252
113.5.3 hwPKIGetCrlSucLdap 详细描述.....	2252
113.5.4 hwPKIGetCrlFailLdap 详细描述.....	2252
113.5.5 hwPKIGetCertSucHttp 详细描述.....	2253
113.5.6 hwPKIGetCertFailHttp 详细描述.....	2253
113.5.7 hwPKIGetCertSucLdap 详细描述.....	2253
113.5.8 hwPKIGetCertFailLdap 详细描述.....	2254
113.5.9 hwPKICACertInvalid 详细描述.....	2254
113.5.10 hwPKICACertValid 详细描述.....	2255
113.5.11 hwPKICACertNearlyExpired 详细描述.....	2255
113.5.12 hwPKILocalCertInvalid 详细描述.....	2256
113.5.13 hwPKILocalCertValid 详细描述.....	2256
113.5.14 hwPKILocalCertNearlyExpired 详细描述.....	2257
113.5.15 hwPKICrlInvalid 详细描述.....	2257
113.5.16 hwPKICrlValid 详细描述.....	2258
113.5.17 hwPKICrlNearlyExpired 详细描述.....	2258
113.5.18 hwPKIRequestCertSucCmp 详细描述.....	2258
113.5.19 hwPKIRequestCertFailCmp 详细描述.....	2259
113.5.20 hwPKIRequestCertSucScep 详细描述.....	2259
113.5.21 hwPKIRequestCertFailScep 详细描述.....	2259
113.5.22 hwPKIRsaHrpBackFail 详细描述.....	2260
113.5.23 hwPKIUpdateLocalCertSucCmp 详细描述.....	2260
113.5.24 hwPKIUpdateLocalCertFailCmp 详细描述.....	2260
113.5.25 hwPKIUpdateLocalCertSucScep 详细描述.....	2261
113.5.26 hwPKIUpdateLocalCertFailScep 详细描述.....	2261
113.5.27 hwPKIGetCrlSucScep 详细描述.....	2261
113.5.28 hwPKIGetCrlFailScep 详细描述.....	2262
113.5.29 hwPKICrlLengthExceedThreshold 详细描述.....	2262
114 HUAWEI-SEP-MIB.....	2263
114.1 功能简介.....	2263
114.2 表间关系.....	2264
114.3 单节点详细描述.....	2266
114.3.1 hwSepResetPktCnt 详细描述.....	2266
114.4 MIB Table 详细描述.....	2266
114.4.1 hwSepSegmentTable 详细描述.....	2266
114.4.2 hwSepTopologyTable 详细描述.....	2270
114.4.3 hwSepPortTable 详细描述.....	2274
115 HUAWEI-SMARTLINK-MIB.....	2282

115.1 功能简介.....	2282
115.2 表间关系.....	2282
115.3 单节点详细描述.....	2282
115.3.1 hwSmartLinkRevFlushTotal 详细描述.....	2282
115.3.2 hwSmartLinkRevLastFlushIfIndex 详细描述.....	2283
115.3.3 hwSmartLinkRevLastFlushTime 详细描述.....	2283
115.3.4 hwSmartLinkRevLastFlushSourceMacAddr 详细描述.....	2283
115.3.5 hwSmartLinkRevLastFlushVlan 详细描述.....	2283
115.3.6 hwSmartLinkResetFlushStatistics 详细描述.....	2284
115.4 MIB Table 详细描述.....	2284
115.4.1 hwSmartLinkRevPortCfgTable 详细描述.....	2284
115.4.2 hwSmartLinkMulRevPortCfgTable 详细描述.....	2285
115.4.3 hwSmartLinkGroupCfgTable 详细描述.....	2287
115.4.4 hwSmartLinkPortCfgTable 详细描述.....	2290
115.4.5 hwMonitorLinkGroupCfgTable 详细描述.....	2291
115.4.6 hwMonitorLinkUpLinkPortTable 详细描述.....	2292
115.4.7 hwMonitorLinkDownLinkPortTable 详细描述.....	2294
115.5 告警节点详细描述.....	2295
115.5.1 hwSmartLinkLinkSwitch 详细描述.....	2295
115.5.2 hwSmartLinkInactiveLinkFail 详细描述.....	2296
115.5.3 hwSmartLinkInactiveLinkResume 详细描述.....	2296
115.5.4 hwSmartLinkGroupEnable 详细描述.....	2296
115.5.5 hwSmartLinkGroupDisable 详细描述.....	2296
115.5.6 hwSmartLinkPcIfName 详细描述.....	2297
115.6 不支持节点.....	2297
116 HUAWEI-SNMP-EXT-MIB.....	2298
116.1 功能简介.....	2298
116.2 表间关系.....	2298
116.3 单节点详细描述.....	2298
116.3.1 hwSnmpExtErrorCodeEnable 详细描述.....	2299
116.3.2 hwSnmpListenPort 详细描述.....	2299
116.3.3 hwSnmpRemotIpAddressType 详细描述.....	2299
116.3.4 hwSnmpRemotIpAddress 详细描述.....	2300
116.3.5 hwSnmpRaisingThreshold 详细描述.....	2300
116.3.6 hwSnmpFallingThreshold 详细描述.....	2300
116.4 MIB Table 详细描述.....	2300
116.5 告警节点详细描述.....	2301
116.5.1 hwSNMPLockThreshold 详细描述.....	2301
116.5.2 hwSNMPLockThresholdResume 详细描述.....	2301
117 HUAWEI-SSH-MIB.....	2302
117.1 功能简介.....	2302
117.2 表间关系.....	2302

117.3 单节点详细描述.....	2302
117.3.1 hwStelnetServerEnable 详细描述.....	2303
117.3.2 hwSftpServerEnable 详细描述.....	2303
117.3.3 hwSSHServerComp1x 详细描述.....	2303
117.3.4 hwSSHServerTimeOut 详细描述.....	2304
117.3.5 hwSSHServerRetry 详细描述.....	2304
117.3.6 hwSSHServerPort 详细描述.....	2304
117.3.7 hwSSHServerKeyTimeOut 详细描述.....	2304
117.3.8 hwSftpMaxUserNum 详细描述.....	2305
117.3.9 hwSftpOnLineUserNum 详细描述.....	2305
117.3.10 hwSSHPv4ServerPort 详细描述.....	2305
117.3.11 hwSSHPv6ServerPort 详细描述.....	2305
117.3.12 hwStelnetIPv4ServerEnable 详细描述.....	2306
117.3.13 hwStelnetIPv6ServerEnable 详细描述.....	2306
117.3.14 hwSftpIPv4ServerEnable 详细描述.....	2306
117.3.15 hwSftpIPv6ServerEnable 详细描述.....	2306
117.3.16 hwSSHFirstTimeAuthEnable 详细描述.....	2307
117.4 MIB Table 详细描述.....	2307
117.4.1 hwSSHUserTable 详细描述.....	2307
117.4.2 hwSSHServerSessionTable 详细描述.....	2312
117.4.3 hwSSHServerInfoTable 详细描述.....	2315
117.5 告警节点详细描述.....	2317
117.5.1 hwSSHsftpUserNumExceedMax 详细描述.....	2317
118 HUAWEI-STACK-MIB.....	2318
118.1 功能简介.....	2318
118.2 表间关系.....	2318
118.3 单节点详细描述.....	2318
118.3.1 hwCssEnable 详细描述.....	2319
118.4 MIB Table 详细描述.....	2319
118.4.1 hwCssMemberInfoTable 详细描述.....	2319
118.4.2 hwCssPortInfoTable 详细描述.....	2322
118.4.3 hwCssLinkInfoTable 详细描述.....	2326
118.4.4 hwCssMemberPortEnableTable 详细描述.....	2327
118.5 告警节点详细描述.....	2328
118.5.1 hwCssLinkDown 详细描述.....	2328
118.5.2 hwCssLinkDownResume 详细描述.....	2328
118.5.3 hwCssLinkUp 详细描述.....	2329
118.5.4 hwCssSwitchOver 详细描述.....	2329
118.5.5 hwCssConnectError 详细描述.....	2330
118.5.6 hwCssSplit 详细描述.....	2330
118.5.7 hwCssEstablish 详细描述.....	2330
118.5.8 hwCssFastUpgradeFail 详细描述.....	2331

118.5.9 hwCssPhyCsuConnectError 详细描述.....	2331
118.5.10 hwCssPortConfigureFailed 详细描述.....	2331
118.5.11 hwCssPortUpDownAlarm 详细描述.....	2331
118.5.12 hwCssPortCrcErrorAlarm 详细描述.....	2332
118.5.13 hwCssPortErrorDown 详细描述.....	2332
118.5.14 hwCssPortErrorDownRecover 详细描述.....	2332
118.5.15 hwCssStandbyError 详细描述.....	2332
118.5.16 hwCssStandbyErrorRestore 详细描述.....	2333
118.5.17 hwCssPortStateError 详细描述.....	2333
118.5.18 hwCssPhyCardConnectError 详细描述.....	2334
118.6 不支持节点.....	2334
119 HUAWEI-SWITCH-L2MAM-EXT-MIB.....	2338
119.1 功能简介.....	2338
119.2 单节点详细描述.....	2338
119.2.1 hwMacTrapInterval 详细描述.....	2338
119.3 MIB Table 详细描述.....	2339
119.3.1 hwMacTrapPortCfgTable 详细描述.....	2339
119.4 告警节点详细描述.....	2339
119.4.1 hwMacTrapAlarm 详细描述.....	2340
119.4.2 hwPortVlanSecureMacAlarm 详细描述.....	2340
119.4.3 hwSlotMacUsageRaisingThreshold 详细描述.....	2341
119.4.4 hwSlotMacUsageFallingThreshold 详细描述.....	2341
119.4.5 hwMacTrapHashConflictAlarm 详细描述.....	2341
119.4.6 hwTrunkMemSpeedDifferentAlarm 详细描述.....	2342
119.4.7 hwTrunkMemSpeedDifferentResume 详细描述.....	2342
119.4.8 hwPortsecStaticFlpAlarm 详细描述.....	2342
119.4.9 hwSlotMuxMacUsageAlarm 详细描述.....	2343
119.4.10 hwSlotMuxMacUsageResume 详细描述.....	2343
120 HUAWEI-SWITCH-SRV-RES-TRAP-MIB.....	2344
120.1 功能简介.....	2344
120.2 表间关系.....	2344
120.3 单节点详细描述.....	2344
120.3.1 hwSrvServiceId 详细描述.....	2344
120.3.2 hwSrvServiceDescr 详细描述.....	2345
120.3.3 hwSrvRecommendThreshold 详细描述.....	2345
120.3.4 hwSrvServiceFailDescr 详细描述.....	2345
120.4 MIB Table 详细描述.....	2345
120.5 告警节点详细描述.....	2346
120.5.1 hwSrvServiceExceedThreshould 详细描述.....	2346
120.5.2 hwSrvServiceExceedThreshouldResume 详细描述.....	2346
120.5.3 hwSrvServiceConfigFailed 详细描述.....	2346

121 HUAWEI-SYS-CLOCK-MIB.....	2347
121.1 功能简介.....	2347
121.2 表间关系.....	2347
121.3 单节点详细描述.....	2347
121.3.1 hwUTClock 详细描述.....	2347
122 HUAWEI-SYS-MAN-MIB.....	2348
122.1 功能简介.....	2348
122.2 表间关系.....	2348
122.2.1 表间关系.....	2349
122.3 单节点详细描述.....	2349
122.3.1 hwSysLocalClock 详细描述.....	2349
122.3.2 hwSysReloadSchedule 详细描述.....	2350
122.3.3 hwSysReloadAction 详细描述.....	2350
122.3.4 hwSysReboot 详细描述.....	2351
122.3.5 hwSysRebootTimes 详细描述.....	2351
122.3.6 hwSysSlaveSwitchEnable 详细描述.....	2351
122.3.7 hwSysLatestRebootErrorInfo 详细描述.....	2352
122.3.8 hwSysDelayReboot 详细描述.....	2352
122.3.9 hwSysImageNum 详细描述.....	2352
122.3.10 hwSysCFGFileNum 详细描述.....	2352
122.3.11 hwPatchFileNum 详细描述.....	2353
122.3.12 hwPatchRecordReset 详细描述.....	2353
122.3.13 hwPatchErrorTableMax 详细描述.....	2353
122.3.14 hwPatchFailReason 详细描述.....	2354
122.4 MIB Table 详细描述.....	2354
122.4.1 hwSysCurTable 详细描述.....	2354
122.4.2 hwSysReloadScheduleTable 详细描述.....	2355
122.4.3 hwSysCFGFileTable 详细描述.....	2359
122.4.4 hwSysImageTable 详细描述.....	2360
122.4.5 hwSysSlaveSwitchTable 详细描述.....	2361
122.4.6 hwPatchFileTable 详细描述.....	2362
122.4.7 hwLoadPatchTable 详细描述.....	2363
122.4.8 hwPatchTable 详细描述.....	2365
122.4.9 hwPatchStateTable 详细描述.....	2367
122.4.10 hwPatchHistoryTable 详细描述.....	2367
122.4.11 hwPatchErrorTable 详细描述.....	2368
122.4.12 hwBootRomTable 详细描述.....	2382
122.4.13 hwSysSourceIndexTable 详细描述.....	2384
122.4.14 hwSysRebootRecordTable 详细描述.....	2385
122.5 告警节点详细描述.....	2386
122.5.1 hwSysClockChangedNotification 详细描述.....	2386
122.5.2 hwSysReloadNotification 详细描述.....	2386

122.5.3 hwSysMasterHDError 详细描述.....	2387
122.5.4 hwSysSlaveHDError 详细描述.....	2387
122.5.5 hwPatchErrorTrap 详细描述.....	2387
122.5.6 hwPatchActiveOverTimeTrap 详细描述.....	2387
122.5.7 hwPatchMalfunctionComebackTrap 详细描述.....	2388
122.5.8 hwSysSlaveSwitchSuccessNotification 详细描述.....	2388
122.5.9 hwSysSlaveSwitchFailNotification 详细描述.....	2388
122.5.10 hwSysIssuNotification 详细描述.....	2388
122.6 不支持节点.....	2389
123 HUAWEI-SYS-RES-TRAP-MIB.....	2391
123.1 功能简介.....	2391
123.2 表间关系.....	2391
123.3 单节点详细描述.....	2391
123.4 MIB Table 详细描述.....	2391
123.4.1 hwSysResTrapTable 详细描述.....	2391
123.5 告警节点详细描述.....	2392
123.5.1 hwSysResourceExceed 详细描述.....	2393
123.5.2 hwSysResourceExceedResume 详细描述.....	2393
123.5.3 hwSysResourceThresholdExceed 详细描述.....	2393
123.5.4 hwSysResourceThresholdExceedResume 详细描述.....	2394
123.5.5 hwSysSecureRiskWarning 详细描述.....	2394
123.5.6 hwSysSecureRiskWarningClear 详细描述.....	2394
124 HUAWEI-TASK-MIB.....	2395
124.1 功能简介.....	2395
124.2 表间关系.....	2395
124.3 单节点详细描述.....	2396
124.4 MIB Table 详细描述.....	2396
124.4.1 hwTaskTable 详细描述.....	2396
124.5 告警节点详细描述.....	2398
125 HUAWEI-TCP-MIB.....	2399
125.1 功能简介.....	2399
125.2 表间关系.....	2399
125.3 单节点详细描述.....	2399
125.4 MIB Table 详细描述.....	2399
125.5 告警节点详细描述.....	2400
125.5.1 hwTCPMD5AuthenFail 详细描述.....	2400
125.5.2 hwTCPBindPort 详细描述.....	2400
126 HUAWEI-TFTPC-MIB.....	2401
126.1 功能简介.....	2401
126.2 表间关系.....	2401
126.3 单节点详细描述.....	2401

126.3.1 hwTftpClientSourceAddress 详细描述.....	2402
126.3.2 hwTftpClientSourceInterfaceName 详细描述.....	2402
126.4 MIB Table 详细描述.....	2402
126.5 告警节点详细描述.....	2402
127 HUAWEI-TRNG-MIB.....	2403
127.1 功能简介.....	2403
127.2 表间关系.....	2403
127.3 单节点详细描述.....	2404
127.4 MIB Table 详细描述.....	2404
127.4.1 hwTrngCreateTimerangeTable 详细描述.....	2404
127.4.2 hwTrngAbsoluteTable 详细描述.....	2405
127.4.3 hwTrngPeriodicTable 详细描述.....	2407
127.5 告警节点详细描述.....	2409
128 HUAWEI-TUNNEL-MIB.....	2410
128.1 功能简介.....	2410
128.2 表间关系.....	2410
128.3 MIB Table 详细描述.....	2410
128.3.1 hwTunnelCfgTable 详细描述.....	2411
128.3.2 hwIpv6Tunnel4Over6CfgTable 详细描述.....	2413
129 HUAWEI-TUNNEL-TE-MIB.....	2416
129.1 功能简介.....	2416
129.2 表间关系.....	2417
129.3 单节点详细描述.....	2417
129.4 MIB Table 详细描述.....	2417
129.4.1 hwTunnelTeStatisticsTable 详细描述.....	2417
129.5 不支持节点.....	2418
130 HUAWEI-TWAMP-MIB.....	2422
130.1 功能简介.....	2422
130.2 表间关系.....	2422
130.3 单节点详细描述.....	2422
130.3.1 hwTwampResponderEnable 详细描述.....	2423
130.4 MIB Table 详细描述.....	2423
130.4.1 hwTwampResponderTable 详细描述.....	2423
130.5 告警节点详细描述.....	2427
131 HUAWEI-UNIMNG-MIB.....	2428
131.1 功能简介.....	2428
131.2 表间关系.....	2429
131.3 单节点详细描述.....	2430
131.3.1 hwUniMngEnable 详细描述.....	2431
131.3.2 hwAsAutoReplaceEnable 详细描述.....	2431

131.3.3 hwAsAuthMode 详细描述.....	2431
131.3.4 hwTopomngExploreTime 详细描述.....	2431
131.3.5 hwTopomngLastCollectDuration 详细描述.....	2432
131.3.6 hwVermngFileServerType 详细描述.....	2432
131.3.7 hwTplmConfigCommitAll 详细描述.....	2432
131.3.8 hwAsVpnInstance 详细描述.....	2432
131.4 MIB Table 详细描述.....	2433
131.4.1 hwAsTable 详细描述.....	2433
131.4.2 hwAuthenUserTable 详细描述.....	2436
131.4.3 hwAsIfTable 详细描述.....	2437
131.4.4 hwAsifXTable 详细描述.....	2438
131.4.5 hwAsSlotTable 详细描述.....	2440
131.4.6 hwAsMacWhitelistTable 详细描述.....	2441
131.4.7 hwAsMacBlacklistTable 详细描述.....	2442
131.4.8 hwAsEntityPhysicalTable 详细描述.....	2443
131.4.9 hwAsEntityStateTable 详细描述.....	2445
131.4.10 hwAsEntityAliasMappingTable 详细描述.....	2446
131.4.11 hwTopomngTopoTable 详细描述.....	2447
131.4.12 hwMbrMngFabricPortTable 详细描述.....	2449
131.4.13 hwVermngUpgradeInfoTable 详细描述.....	2450
131.4.14 hwVermngAsTypeCfgInfoTable 详细描述.....	2453
131.4.15 hwTplmASGroupTable 详细描述.....	2455
131.4.16 hwTplmASTable 详细描述.....	2455
131.4.17 hwTplmPortGroupTable 详细描述.....	2456
131.4.18 hwTplmPortTable 详细描述.....	2458
131.4.19 hwTplmConfigManagementTable 详细描述.....	2458
131.4.20 hwUnAuthenUserTable 详细描述.....	2459
131.5 告警节点详细描述.....	2460
131.5.1 hwTopomngLinkNormal 详细描述.....	2460
131.5.2 hwTopomngLinkAbnormal 详细描述.....	2461
131.5.3 hwAsFaultNotify 详细描述.....	2461
131.5.4 hwAsNormalNotify 详细描述.....	2462
131.5.5 hwAsAddOffLineNotify 详细描述.....	2462
131.5.6 hwAsDelOffLineNotify 详细描述.....	2463
131.5.7 hwAsPortStateChangeToDownNotify 详细描述.....	2463
131.5.8 hwAsPortStateChangeToUpNotify 详细描述.....	2463
131.5.9 hwAsModelNotMatchNotify 详细描述.....	2464
131.5.10 hwAsVersionNotMatchNotify 详细描述.....	2464
131.5.11 hwAsNameConflictNotify 详细描述.....	2465
131.5.12 hwAsSlotModelNotMatchNotify 详细描述.....	2465
131.5.13 hwAsFullNotify 详细描述.....	2466
131.5.14 hwUnimngModeNotMatchNotify 详细描述.....	2466

131.5.15 hwAsBoardAddNotify 详细描述.....	2466
131.5.16 hwAsBoardDeleteNotify 详细描述.....	2467
131.5.17 hwAsBoardPlugInNotify 详细描述.....	2467
131.5.18 hwAsBoardPlugOutNotify 详细描述.....	2468
131.5.19 hwAsBlacklistNotify 详细描述.....	2468
131.5.20 hwAsUnconfirmedNotify 详细描述.....	2468
131.5.21 hwAsComboPortTypeChangeNotify 详细描述.....	2468
131.5.22 hwAsOnlineFailNotify 详细描述.....	2469
131.5.23 hwAsSlotIdInvalidNotify 详细描述.....	2470
131.5.24 hwAsSysmacSwitchCfgErrNotify 详细描述.....	2470
131.5.25 hwAsSlotOnlineFailNotify 详细描述.....	2471
131.5.26 hwUniMbrConnectError 详细描述.....	2471
131.5.27 hwUniMbrAsDiscoverAttack 详细描述.....	2471
131.5.28 hwUniMbrFabricPortMemberDelete 详细描述.....	2472
131.5.29 hwUniMbrIllegalFabricConfig 详细描述.....	2472
131.5.30 hwVermngUpgradeFail 详细描述.....	2472
131.5.31 hwTplmCmdExecuteFailedNotify 详细描述.....	2473
131.5.32 hwTplmCmdExecuteSuccessfulNotify 详细描述.....	2473
131.5.33 hwTplmDirectCmdRecoverFail 详细描述.....	2473
131.5.34 hwASBrdTempAlarm 详细描述.....	2474
131.5.35 hwASBrdTempResume 详细描述.....	2474
131.5.36 hwASBoardFail 详细描述.....	2475
131.5.37 hwASBoardFailResume 详细描述.....	2475
131.5.38 hwASOpticalInvalid 详细描述.....	2476
131.5.39 hwASOpticalInvalidResume 详细描述.....	2476
131.5.40 hwASPowerRemove 详细描述.....	2477
131.5.41 hwASPowerInsert 详细描述.....	2477
131.5.42 hwASPowerInvalid 详细描述.....	2478
131.5.43 hwASPowerInvalidResume 详细描述.....	2478
131.5.44 hwASFanRemove 详细描述.....	2479
131.5.45 hwASFanInsert 详细描述.....	2479
131.5.46 hwASFanInvalid 详细描述.....	2480
131.5.47 hwASFanInvalidResume 详细描述.....	2480
131.5.48 hwASCommunicateError 详细描述.....	2481
131.5.49 hwASCommunicateResume 详细描述.....	2481
131.5.50 hwASCPUUtilizationRising 详细描述.....	2482
131.5.51 hwASCPUUtilizationResume 详细描述.....	2483
131.5.52 hwASMemUtilizationRising 详细描述.....	2483
131.5.53 hwASMemUtilizationResume 详细描述.....	2484
131.5.54 hwASMadConflictDetect 详细描述.....	2485
131.5.55 hwASMadConflictResume 详细描述.....	2485
132 HUAWEI-USA-MIB.....	2486

132.1 功能简介.....	2486
132.2 表间关系.....	2486
132.3 单节点详细描述.....	2486
132.3.1 hwUserDetectInterval 详细描述.....	2486
132.3.2 hwUserDetectRetry 详细描述.....	2487
132.3.3 hwUserSyncInterval 详细描述.....	2487
132.3.4 hwGlobalLinkDownOffline 详细描述.....	2487
132.3.5 hwGlobalControlDownOffline 详细描述.....	2488
132.3.6 hwAuthenSpeedLimitMaxNum 详细描述.....	2488
132.3.7 hwAuthenSpeedLimitInterval 详细描述.....	2488
132.3.8 hwAuthenAssociateAlarmRestrained 详细描述.....	2488
132.3.9 hwAuthenAssociateAlarmRestrainedPeriod 详细描述.....	2489
132.4 MIB Table 详细描述.....	2489
132.4.1 hwUSACfgTable 详细描述.....	2489
132.4.2 hwAssociateUserTable 详细描述.....	2491
132.5 告警节点详细描述.....	2493
132.5.1 hwAuthenAssociateAccessLimitTrap 详细描述.....	2493
133 HUAWEI-USC-MIB.....	2495
133.1 功能简介.....	2495
133.2 表间关系.....	2495
133.3 单节点详细描述.....	2495
133.4 MIB Table 详细描述.....	2495
133.4.1 hwUSCCfgTable 详细描述.....	2495
133.5 告警节点详细描述.....	2498
134 HUAWEI-VBST-MIB.....	2499
134.1 功能简介.....	2499
134.2 表间关系.....	2499
134.3 单节点详细描述.....	2499
134.3.1 hwVbstMaxPVNum 详细描述.....	2499
134.3.2 hwVbstVlanNum 详细描述.....	2500
134.3.3 hwVbstTrapVlan 详细描述.....	2500
134.3.4 hwVbstTrapPort 详细描述.....	2500
134.3.5 hwVbstMaxTrunkPVNum 详细描述.....	2500
134.3.6 hwVbstConflictDescription 详细描述.....	2501
134.4 告警节点详细描述.....	2501
134.4.1 hwVbstPVNumExceeded 详细描述.....	2501
134.4.2 hwVbstPVNumResumed 详细描述.....	2501
134.4.3 hwVbstTrapInvalidPV 详细描述.....	2501
134.4.4 hwVbstTrunkPVNumExceeded 详细描述.....	2502
134.4.5 hwVbstTrunkPVNumResumed 详细描述.....	2502
134.4.6 hwVbstRspanCfgConflict 详细描述.....	2502

135 HUAWEI-VPLS-EXT-MIB.....	2503
135.1 功能简介.....	2503
135.2 表间关系.....	2503
135.3 MIB Table 详细描述.....	2505
135.3.1 hwVplsTable 详细描述.....	2505
135.3.2 hwVplsRtTable 详细描述.....	2511
135.3.3 hwVplsAcTable 详细描述.....	2512
135.3.4 hwVplsBgpInfoTable 详细描述.....	2514
135.3.5 hwVplsPwTable 详细描述.....	2515
135.3.6 hwVplsLdpStatisticsTable 详细描述.....	2517
135.3.7 hwVplsBgpStatisticsTable 详细描述.....	2521
135.3.8 hwVplsLdpPeerTable 详细描述.....	2525
135.4 单节点详细描述.....	2527
135.4.1 hwL2vpnTnlType 详细描述.....	2527
135.4.2 hwL2vpnTunnelIndex 详细描述.....	2527
135.4.3 hwVplsStateChangeReason 详细描述.....	2527
135.5 告警节点详细描述.....	2527
135.5.1 hwVplsVcDeleted 详细描述.....	2528
135.5.2 hwVplsVcDown 详细描述.....	2528
135.5.3 hwVplsVcUp 详细描述.....	2528
135.5.4 hwVplsVsiDeleted 详细描述.....	2529
135.5.5 hwVplsVsiDown 详细描述.....	2529
135.5.6 hwVplsVsiUp 详细描述.....	2529
135.5.7 hwVplsVcBackup 详细描述.....	2530
135.5.8 hwVplsVcStatusChange 详细描述.....	2530
135.6 附录.....	2530
135.6.1 hwVplsStateChangeReason.....	2530
135.6.2 HWL2VpnVcEncapsType.....	2532
136 HUAWEI-VPLS-TNL-MIB.....	2533
136.1 功能简介.....	2533
136.2 表间关系.....	2533
136.3 MIB Table 详细描述.....	2533
136.3.1 hwVplsTunnelTable 详细描述.....	2533
137 HUAWEI-VPN-DIAGNOSTICS-MIB.....	2537
137.1 功能简介.....	2537
137.2 表间关系.....	2538
137.3 单节点详细描述.....	2538
137.3.1 hwOamMacPopulateCount 详细描述.....	2538
137.3.2 hwOamMacPurgeCount 详细描述.....	2539
137.3.3 hwOamMacPurgeRegCount 详细描述.....	2539
137.3.4 hwOamMacCountReset 详细描述.....	2540
137.3.5 hwOamMacSwitch 详细描述.....	2540

137.3.6 hwOamMacEntryNum 详细描述.....	2540
137.4 MIB Table 详细描述.....	2541
137.4.1 hwOamMacOperTable 详细描述.....	2541
137.4.2 hwOamMacListTable 详细描述.....	2543
137.4.3 hwOamMacDisplayTable 详细描述.....	2543
137.4.4 hwVpnCfgPingTable 详细描述.....	2545
137.4.5 hwVpnCfgPingResultTable 详细描述.....	2549
137.4.6 hwVpnCfgPingResultIRtTable 详细描述.....	2559
137.4.7 hwVpnCfgPingResultERtTable 详细描述.....	2559
137.5 告警节点详细描述.....	2560
138 HUAWEI-VRRP-EXT-MIB.....	2561
138.1 功能简介.....	2561
138.2 表间关系.....	2561
138.3 单节点详细描述.....	2562
138.3.1 hwVrrpExtFreeArpInterval 详细描述.....	2562
138.3.2 hwVrrpExtVIPingCtr 详细描述.....	2562
138.3.3 hwVrrpExtSsTimer 详细描述.....	2563
138.3.4 hwVrrpExtLearnAdvIntervalFlag 详细描述.....	2563
138.3.5 hwVrrpExtStateChangeReasonString 详细描述.....	2564
138.3.6 hwVrrpExtProtocolVersion 详细描述.....	2564
138.3.7 hwVrrpExtSendV3AdverPktMode 详细描述.....	2565
138.4 MIB Table 详细描述.....	2565
138.4.1 hwVrrpTrackInterTable 详细描述.....	2565
138.4.2 hwVrrpTrackBfdTable 详细描述.....	2567
138.4.3 hwAdminVrrpCfgTable 详细描述.....	2568
138.4.4 hwAdminVrrpMemberTable 详细描述.....	2569
138.4.5 hwVrrpStatResetTable 详细描述.....	2571
138.4.6 hwVrrpStatExtTable 详细描述.....	2572
138.4.7 hwVrrpTrackNQATable 详细描述.....	2573
138.4.8 hwVrrpTrackRouteTable 详细描述.....	2574
138.5 告警节点详细描述.....	2576
138.5.1 hwVrrpExtTrapMasterDown 详细描述.....	2576
138.5.2 hwVrrpExtTrapNonMaster 详细描述.....	2577
139 HUAWEI-VXLAN-MIB.....	2578
139.1 功能简介.....	2578
139.2 表间关系.....	2578
139.3 单节点详细描述.....	2578
139.4 MIB Table 详细描述.....	2578
139.5 告警节点详细描述.....	2579
139.5.1 hwVxlanTunnelFull 详细描述.....	2579
140 HUAWEI-WLAN-CAPWAP-MIB.....	2580

140.1 功能简介.....	2580
140.2 表间关系.....	2580
140.3 单节点详细描述.....	2580
140.3.1 hwWlanCapwapSourceInterfaceValue 详细描述.....	2581
140.3.2 hwWlanCapwapSourceInterfaceMethod 详细描述.....	2581
140.3.3 hwWlanCapwapDtlsSwitch 详细描述.....	2581
140.3.4 hwWlanCapwapDtlsPsk 详细描述.....	2581
140.3.5 hwWlanCapwapInterControllerDtlsPsk 详细描述.....	2582
140.3.6 hwCapwapEchoInterval 详细描述.....	2582
140.3.7 hwCapwapEchoTimes 详细描述.....	2582
140.3.8 hwWlanCapwapControlPriorityLocal 详细描述.....	2583
140.3.9 hwWlanCapwapControlPriorityRemote 详细描述.....	2583
140.3.10 hwWlanCapwapSensitiveInfoPsk 详细描述.....	2583
140.3.11 hwWlanCapwapMessageIntegrityPsk 详细描述.....	2583
140.3.12 hwWlanCapwapMessageIntegrityPskMandatoryMatchSwitch 详细描述.....	2584
140.3.13 hwWlanCapwapMsgCheckSwitch 详细描述.....	2584
140.3.14 hwWlanCapwapDtlsVersion1Dot0Switch 详细描述.....	2585
140.3.15 hwWlanCapwapDtlsCbcSwitch 详细描述.....	2585
140.4 MIBTable 详细描述.....	2585
140.4.1 hwWlanCapwapSourceTable 详细描述.....	2585
140.5 告警节点详细描述.....	2588
140.6 不支持节点.....	2588
141 HUAWEI-WLAN-CONFIGURATION-MIB.....	2589
141.1 功能简介.....	2589
141.2 表间关系.....	2589
141.3 单节点详细描述.....	2594
141.3.1 hwWlanGlobalApUsername 详细描述.....	2594
141.3.2 hwWlanGlobalApPassword 详细描述.....	2594
141.3.3 hwWlanUsernamePasswordApMac 详细描述.....	2596
141.3.4 hwWlanGlobalApLldpSwitch 详细描述.....	2596
141.3.5 hwWlanApDataCollectionInterval 详细描述.....	2596
141.3.6 hwTestRtCollectOnoff 详细描述.....	2596
141.3.7 hwTestApNormalCollectCycle 详细描述.....	2597
141.3.8 hwTestApRtCollectCycle 详细描述.....	2597
141.3.9 hwWlanProtectIpAddress 详细描述.....	2597
141.3.10 hwWlanProtectPriority 详细描述.....	2597
141.3.11 hwWlanProtectSwitch 详细描述.....	2597
141.3.12 hwWlanProtectRestoreSwitch 详细描述.....	2598
141.3.13 hwUndoWlanProtectIpAddress 详细描述.....	2598
141.3.14 hwUndoWlanProtectPriority 详细描述.....	2598
141.3.15 hwWlanBLELowPowerWarningThreshold 详细描述.....	2598
141.3.16 hwWlanReportStaAssocInfo 详细描述.....	2599

141.3.17 hwWlanStaDelayOffLineSwitch 详细描述.....	2599
141.3.18 hwWlanStaDelayOffLineAgingTime 详细描述.....	2599
141.3.19 hwWlanStaDelayOffLineNewStaOnlineSwitch 详细描述.....	2600
141.3.20 hwWlanStaDelayOffLineMaxNum 详细描述.....	2600
141.3.21 hwWlanGlobalSpectrumAnalysisSourceIPAddress 详细描述.....	2600
141.3.22 hwWlanApAuthMode 详细描述.....	2601
141.3.23 hwWlanAPProvisionAddressMode 详细描述.....	2601
141.3.24 hwWlanAPProvisionIPv4Address 详细描述.....	2601
141.3.25 hwWlanAPProvisionIPv4Mask 详细描述.....	2601
141.3.26 hwWlanAPProvisionIPv4Gateway 详细描述.....	2602
141.3.27 hwWlanAPProvisionGroupName 详细描述.....	2602
141.3.28 hwWlanAPProvisionName 详细描述.....	2602
141.3.29 hwWlanAPProvisionIPv4ACLlist 详细描述.....	2602
141.3.30 hwWlanAPProvisionCommitAPName 详细描述.....	2603
141.3.31 hwWlanAPProvisionCommitAPMac 详细描述.....	2603
141.3.32 hwWlanAPProvisionCommitAPGroup 详细描述.....	2603
141.3.33 hwWlanAPProvisionManagementVlan 详细描述.....	2604
141.3.34 hwWlanRadioCalibrateMode 详细描述.....	2604
141.3.35 hwWlanRadioCalibrateScheduleTime 详细描述.....	2604
141.3.36 hwWlanRadioCalibrateManualStartup 详细描述.....	2604
141.3.37 hwWlanRadioCalibrateAutoInterval 详细描述.....	2605
141.3.38 hwWlanRadioCalibratePolicy 详细描述.....	2605
141.3.39 hwWlanRadioCalibrateSensitivity 详细描述.....	2606
141.3.40 hwWlanRadioCalibrateAutoStartTime 详细描述.....	2606
141.3.41 hwWlanRadioCalibrateManualApGroup 详细描述.....	2606
141.3.42 hwWlanRadioCalibrateManualApList 详细描述.....	2606
141.3.43 hwWlanRadioCalibrateManualProcess 详细描述.....	2607
141.3.44 hwWlanRadioCalibrateFlexibleRadio 详细描述.....	2607
141.3.45 hwWlanRadioCalibrateFlexRadioManualRecognize 详细描述.....	2607
141.3.46 hwWlanRadioCalibrateFlexibleRadioProcess 详细描述.....	2608
141.3.47 hwWlanRadioCalibrateFlexibleRadioRecognizeTime 详细描述.....	2608
141.3.48 hwWlanRadioCalibrateSensitivityCustomValue 详细描述.....	2608
141.3.49 hwWlanRadioCalibrateScheduleTimeRange 详细描述.....	2609
141.3.50 hwWlanRadioCalibrateReferenceDataAnalysis 详细描述.....	2609
141.3.51 hwWlanRadioCalibrateEnvironmentDeteriorateValue 详细描述.....	2609
141.3.52 hwWlanRadioCalibrateReferenceRogueInter 详细描述.....	2609
141.3.53 hwWlanRadioCalibrate2gSensitivity 详细描述.....	2610
141.3.54 hwWlanRadioCalibrate2gSensitivityCustomValue 详细描述.....	2610
141.3.55 hwWlanRadioCalibrate5gSensitivity 详细描述.....	2611
141.3.56 hwWlanRadioCalibrate5gSensitivityCustomValue 详细描述.....	2611
141.3.57 hwWlanRadioCalibrate6gSensitivity 详细描述.....	2611
141.3.58 hwWlanRadioCalibrate6gSensitivityCustomValue 详细描述.....	2612

141.3.59 hwWlanMobilityServerLocalIPv4 详细描述.....	2612
141.3.60 hwWlanLicenseCentralizedSwitch 详细描述.....	2612
141.3.61 hwWlanLicenseCentralizedServerIPv4Addr 详细描述.....	2612
141.3.62 hwWlanLicenseCentralizedServerIPv6Addr 详细描述.....	2613
141.3.63 hwWlanLicenseCentralizedClientIPv4Addr 详细描述.....	2613
141.3.64 hwWlanLicenseCentralizedClientIPv6Addr 详细描述.....	2613
141.3.65 hwWlanLicenseCentralizedRole 详细描述.....	2613
141.3.66 hwWlanLicensePoolUsed 详细描述.....	2614
141.3.67 hwWlanLicensePoolTotal 详细描述.....	2614
141.3.68 hwWlanGlobalRogueDeviceLogSwitch 详细描述.....	2614
141.3.69 hwWlanlotOperateTable 详细描述.....	2615
141.3.70 hwWlanGlobalAeroscoutLocalIPv4 详细描述.....	2616
141.3.71 hwWlanGlobalApLoadRtuFileName 详细描述.....	2616
141.3.72 hwWlanGlobalStaProfilingSwitch 详细描述.....	2616
141.3.73 hwWlanBLEMonitorMode 详细描述.....	2617
141.4 MIBTable 详细描述.....	2617
141.4.1 hwWlanBLEMonitorListTable 详细描述.....	2617
141.4.2 hwWlanApMacWhitelistTable 详细描述.....	2618
141.4.3 hwWlanApSnWhitelistTable 详细描述.....	2618
141.4.4 hwWlanApMacBlacklistTable 详细描述.....	2619
141.4.5 hwAPGroupTable 详细描述.....	2620
141.4.6 hwAPGroupWiredPortTable 详细描述.....	2622
141.4.7 hwAPGroupRadioTable 详细描述.....	2623
141.4.8 hwAPGroupVapTable 详细描述.....	2629
141.4.9 hwAPSpecificTable 详细描述.....	2630
141.4.10 hwAPSpecificWiredPortTable 详细描述.....	2632
141.4.11 hwAPSpecificRadioTable 详细描述.....	2633
141.4.12 hwAPSpecificVapTable 详细描述.....	2640
141.4.13 hwRegulatoryDomainProfileTable 详细描述.....	2641
141.4.14 hwApSystemProfileTable 详细描述.....	2644
141.4.15 hwAPWiredPortProfileTable 详细描述.....	2660
141.4.16 hwAPWiredPortProfileTrafficFilterTable 详细描述.....	2665
141.4.17 hwAPPortLinkProfileTable 详细描述.....	2666
141.4.18 hw2gRadioProfileTable 详细描述.....	2670
141.4.19 hw5gRadioProfileTable 详细描述.....	2691
141.4.20 hwRrmProfileTable 详细描述.....	2712
141.4.21 hwAirScanProfileTable 详细描述.....	2727
141.4.22 hwVapProfileTable 详细描述.....	2728
141.4.23 hwSsidProfileTable 详细描述.....	2738
141.4.24 hwSecurityProfileTable 详细描述.....	2752
141.4.25 hwAPTrafficProfileTable 详细描述.....	2762
141.4.26 hwAPTrafficProfileFilterTable 详细描述.....	2770

141.4.27 hwWlanStaWhitelistProfileTable 详细描述.....	2773
141.4.28 hwWlanStaWhitelistProfileConfigTable 详细描述.....	2774
141.4.29 hwWlanStaWhitelistProfileOuiTable 详细描述.....	2775
141.4.30 hwWlanStaBlacklistProfileTable 详细描述.....	2776
141.4.31 hwWlanStaBlacklistProfileConfigTable 详细描述.....	2777
141.4.32 hwWidsProfileTable 详细描述.....	2781
141.4.33 hwWidsSpoofProfileTable 详细描述.....	2784
141.4.34 hwWidsWhitelistProfileMacTable 详细描述.....	2785
141.4.35 hwWidsWhitelistProfileOuiTable 详细描述.....	2786
141.4.36 hwWidsWhitelistProfileSsidTable 详细描述.....	2787
141.4.37 hwWlanMeshProfileTable 详细描述.....	2788
141.4.38 hwWlanMeshWhitelistProfileTable 详细描述.....	2797
141.4.39 hwWlanMeshWhitelistProfileConfigTable 详细描述.....	2798
141.4.40 hwWdsProfileTable 详细描述.....	2798
141.4.41 hwWdsWhitelistProfileTable 详细描述.....	2803
141.4.42 hwWdsWhitelistTable 详细描述.....	2803
141.4.43 hwSACProfileTable 详细描述.....	2804
141.4.44 hwLocationProfileTable 详细描述.....	2805
141.4.45 hwWlanGlobalConfig 详细描述.....	2812
141.4.46 hwWlanManualContainListTable 详细描述.....	2814
141.4.47 hwWidsSpoofProfileListTable 详细描述.....	2815
141.4.48 hwWidsWhitelistProfileListTable 详细描述.....	2815
141.4.49 hwWlanLoadBalanceStaticGroupTable 详细描述.....	2817
141.4.50 hwWlanLoadBalanceStaticGroupMemberTable 详细描述.....	2819
141.4.51 hwWlanCountryCodeTable 详细描述.....	2820
141.4.52 hwSoftgreProfileTable 详细描述.....	2821
141.4.53 hwWlanIDIndexedAPSpecificTable 详细描述.....	2823
141.4.54 hwlDIndexedAPSpecificWiredPortTable 详细描述.....	2826
141.4.55 hwlDIndexedAPSpecificRadioTable 详细描述.....	2827
141.4.56 hwlDIndexedAPSpecificVapTable 详细描述.....	2833
141.4.57 hwBleProfileTable 详细描述.....	2835
141.4.58 hwAPGroupCardTable 详细描述.....	2841
141.4.59 hwAPSpecificCardTable 详细描述.....	2843
141.4.60 hwloTProfileTable 详细描述.....	2846
141.4.61 hwloTProfileManagementServerTable 详细描述.....	2848
141.4.62 hwApProfIGMPSnoopingGroupTable 详细描述.....	2849
141.4.63 hwAPWiredPortProfileTrafficRemarkTable 详细描述.....	2850
141.4.64 hwAPTrafficProfileRemarkTable 详细描述.....	2852
141.4.65 hwWiredPortProfileTrafficFilterTable 详细描述.....	2853
141.4.66 hwWiredPortProfileTrafficRemarkTable 详细描述.....	2854
141.4.67 hwTrafficProfileTrafficFilterTable 详细描述.....	2857
141.4.68 hwTrafficProfileTrafficRemarkTable 详细描述.....	2859

141.4.69 hwWlanLicenseCentralizedTable 详细描述.....	2862
141.4.70 hwWmiProfileTable 详细描述.....	2864
141.4.71 hwApSystemWmiProfileTable 详细描述.....	2870
141.4.72 hwApSysBCMCSuppressionTable 详细描述.....	2871
141.4.73 hwVAPProfileAntiAttackTable 详细描述.....	2873
141.4.74 hwAPTrafficProfileRateLimitClientTable 详细描述.....	2875
141.4.75 hwVapServiceExpAnalysisAppTable 详细描述.....	2876
141.4.76 hwVapSlpFpmFlowTable 详细描述.....	2877
141.4.77 hwVapSlpFpmApplicationTable.....	2879
141.4.78 hwVapServiceExpAnalysisUserGroupAppTable 详细描述.....	2880
141.4.79 hwSsidWmmMuEdcaClientTable 详细描述.....	2881
141.4.80 hwWlanCountryChannelTable 详细描述.....	2883
141.4.81 hwWlanUserDefinedApplicationTable 详细描述.....	2884
141.4.82 hwWlanUserDefinedRuleTable 详细描述.....	2886
141.4.83 hwTrafficProfWlanSliceAclTable.....	2888
141.5 告警节点详细描述.....	2889
141.6 不支持节点.....	2889
142 HUAWEI-WLAN-GLOBAL-MIB.....	2910
142.1 功能简介.....	2910
142.2 表间关系.....	2910
142.3 单节点详细描述.....	2910
142.3.1 hwWlanAccessMaxApNumber 详细描述.....	2910
142.3.2 hwWlanAccessMaxStaNumber 详细描述.....	2911
142.3.3 hwWlanCurJointApNum 详细描述.....	2911
142.3.4 hwWlanCurAssocStaNum 详细描述.....	2911
142.3.5 hwWlanCurAuthSuccessStaNum 详细描述.....	2912
142.3.6 hwWlanReassocSuccessTimes 详细描述.....	2912
142.3.7 hwWlanCurAssoc2gStaNum 详细描述.....	2912
142.3.8 hwWlanCurAssoc5gStaNum 详细描述.....	2912
142.3.9 hwWlanDualBandStaNum 详细描述.....	2912
142.3.10 hwWlanGlobalUpSpeed 详细描述.....	2913
142.3.11 hwWlanGlobalDownSpeed 详细描述.....	2913
142.3.12 hwWlanCurAssoc2gStaType 详细描述.....	2913
142.3.13 hwWlanCurAssoc5gStaType 详细描述.....	2914
142.3.14 hwWlanCurAssoc6gStaNum 详细描述.....	2915
142.3.15 hwWlanCurAssoc6gStaType 详细描述.....	2916
142.3.16 hwWlanStaRateComplianceRate 详细描述.....	2916
142.3.17 hwWlanStaSnrComplianceRate 详细描述.....	2916
142.3.18 hwWlanStaResendRateComplianceRate 详细描述.....	2917
142.3.19 hwWlanStaDropRateComplianceRate 详细描述.....	2917
142.3.20 hwWlanStaComplianceRate 详细描述.....	2917
142.3.21 hwStaSnrNoncompliance2gCnt 详细描述.....	2918

142.3.22 hwStaRateNoncompliance2gCnt 详细描述.....	2918
142.3.23 hwStaResendRateNoncompliance2gCnt 详细描述.....	2918
142.3.24 hwStaDropRateNoncompliance2gCnt 详细描述.....	2919
142.3.25 hwStaThruputNoncompliance2gCnt 详细描述.....	2919
142.3.26 hwStaSnrNoncompliance5gCnt 详细描述.....	2919
142.3.27 hwStaRateNoncompliance5gCnt 详细描述.....	2919
142.3.28 hwStaResendRateNoncompliance5gCnt 详细描述.....	2920
142.3.29 hwStaDropRateNoncompliance5gCnt 详细描述.....	2920
142.3.30 hwStaThruputNoncompliance5gCnt 详细描述.....	2920
142.3.31 hwStaGlobalWirelessPacketDelay 详细描述.....	2921
142.3.32 hwStaGlobalWirelessPacketDropRate 详细描述.....	2921
142.3.33 hwStaGlobalTotalAccessTime 详细描述.....	2921
142.3.34 hwStaGlobalAccessExperience 详细描述.....	2922
142.3.35 hwStaGlobalAssocRate 详细描述.....	2922
142.3.36 hwStaGlobalAuthRateDot1x 详细描述.....	2923
142.3.37 hwStaGlobalAuthRatePortal 详细描述.....	2923
142.3.38 hwStaGlobalAuthRateMac 详细描述.....	2923
142.3.39 hwStaSnrNoncompliance6gCnt 详细描述.....	2924
142.3.40 hwStaRateNoncompliance6gCnt 详细描述.....	2924
142.3.41 hwStaResendRateNoncompliance6gCnt 详细描述.....	2925
142.3.42 hwStaDropRateNoncompliance6gCnt 详细描述.....	2925
142.3.43 hwStaThruputNoncompliance6gCnt 详细描述.....	2925
142.3.44 hwWlanRfChannelUtilRateComplianceRate 详细描述.....	2925
142.3.45 hwWlanRfNoiseComplianceRate 详细描述.....	2926
142.3.46 hwWlanRfChannelJamRateComplianceRate 详细描述.....	2926
142.3.47 hwWlanRfResendRateComplianceRate 详细描述.....	2926
142.3.48 hwWlanRfDropRateComplianceRate 详细描述.....	2927
142.3.49 hwWlanRfComplianceRate 详细描述.....	2927
142.3.50 hwWlanRfNoiseNoncompliance2gCnt 详细描述.....	2927
142.3.51 hwWlanRfChannelUtilRateNoncompliance2gCnt 详细描述.....	2928
142.3.52 hwWlanRfLoadNoncompliance2gCnt 详细描述.....	2928
142.3.53 hwWlanRfChannelJamRateNoncompliance2gCnt 详细描述.....	2928
142.3.54 hwWlanRfNoiseNoncompliance5gCnt 详细描述.....	2928
142.3.55 hwWlanRfChannelUtilRateNoncompliance5gCnt 详细描述.....	2929
142.3.56 hwWlanRfLoadNoncompliance5gCnt 详细描述.....	2929
142.3.57 hwWlanRfChannelJamRateNoncompliance5gCnt 详细描述.....	2929
142.3.58 hwWlanRfNoiseNoncompliance6gCnt 详细描述.....	2930
142.3.59 hwWlanRfChannelUtilRateNoncompliance6gCnt 详细描述.....	2930
142.3.60 hwWlanRfLoadNoncompliance6gCnt 详细描述.....	2931
142.3.61 hwWlanRfChannelJamRateNoncompliance6gCnt 详细描述.....	2931
142.3.62 hwWlanApNormalRatio 详细描述.....	2931
142.3.63 hwWlanApStaOnlineFailRateComplianceRate 详细描述.....	2931

142.3.64 hwWlanApStaOfflineRateComplianceRate 详细描述.....	2932
142.3.65 hwWlanApStaOnlineCntComplianceRate 详细描述.....	2932
142.3.66 hwWlanApComplianceRate 详细描述.....	2933
142.3.67 hwWlanServiceNormalAPCount 详细描述.....	2933
142.3.68 hwWlanApCount 详细描述.....	2933
142.3.69 hwWlanSecurityProfileName 详细描述.....	2933
142.3.70 hwWlanEncryptionAlgorithm 详细描述.....	2934
142.3.71 hwWlanSecurityPara 详细描述.....	2934
142.4 MIBTable 详细描述.....	2934
142.4.1 hwWlanOnlineStaCntHistoryTable 详细描述.....	2934
142.4.2 hwWlanSpeedHistoryTable 详细描述.....	2935
142.4.3 hwWlanApGroupStatisticsTable 详细描述.....	2936
142.5 告警节点详细描述.....	2937
142.5.1 hwWlanWapiCertificateNearlyExpiredTrap 详细描述.....	2937
142.5.2 hwWlanWapiCertificateNearlyExpiredTrapRestore 详细描述.....	2937
142.5.3 hwWlanWapiCertificateInvalidTrap 详细描述.....	2938
142.5.4 hwWlanWapiCertificateInvalidTrapRestore 详细描述.....	2938
142.5.5 hwWlanInsecureEncryptionAlgorithm 详细描述.....	2939
142.5.6 hwWlanSecurityParaNotSetTrap 详细描述.....	2939
142.5.7 hwWlanSecurityParaNotSetTrapRestore 详细描述.....	2939
142.6 不支持节点.....	2939
143 HUAWEI-WLAN-AP-MIB.....	2941
143.1 功能简介.....	2941
143.2 表间关系.....	2941
143.3 单节点详细描述.....	2943
143.3.1 hwWlanApPingApMac 详细描述.....	2943
143.3.2 hwWlanApPingAddress 详细描述.....	2944
143.3.3 hwWlanApPingCount 详细描述.....	2944
143.3.4 hwWlanApPingPacketSize 详细描述.....	2945
143.3.5 hwWlanApPingWaitTime 详细描述.....	2945
143.3.6 hwWlanApPingTimeOut 详细描述.....	2945
143.3.7 hwWlanApPingResultSuccessCount 详细描述.....	2946
143.3.8 hwWlanApPingResultFailureCount 详细描述.....	2946
143.3.9 hwWlanApPingResultAveResponseTime 详细描述.....	2946
143.3.10 hwWlanApPingResultMinResponseTime 详细描述.....	2947
143.3.11 hwWlanApPingResultMaxResponseTime 详细描述.....	2947
143.3.12 hwWlanApPingResultFlag 详细描述.....	2947
143.3.13 hwApPowerWorkMode 详细描述.....	2948
143.3.14 hwApExpectPowerWorkMode 详细描述.....	2948
143.3.15 hwWlanApTemperatureType 详细描述.....	2948
143.3.16 hwAlertReason 详细描述.....	2949
143.3.17 hwRemainTime 详细描述.....	2949

143.3.18 hwCurEmdiSessionRate 详细描述.....	2949
143.3.19 hwUpperEmdiSessionThreshold 详细描述.....	2950
143.3.20 hwLowerEmdiSessionThreshold 详细描述.....	2950
143.3.21 hwCurSipfpmFlowRate 详细描述.....	2951
143.3.22 hwUpperSipfpmFlowThreshold 详细描述.....	2951
143.3.23 hwLowerSipfpmFlowThreshold 详细描述.....	2951
143.3.24 hwApLicenseType 详细描述.....	2951
143.3.25 hwCurSACSessionRate.....	2952
143.3.26 hwUpperSACSessionThreshold.....	2952
143.3.27 hwLowerSACSessionThreshold.....	2952
143.3.28 hwWlanApPKICertStartTime 详细描述.....	2952
143.3.29 hwWlanApPKICertFinishTime 详细描述.....	2953
143.3.30 hwWlanApPKICertIssuer 详细描述.....	2953
143.3.31 hwWlanApPKICertSubject 详细描述.....	2953
143.3.32 hwWlanApWiredPortSupportedMaxRate 详细描述.....	2953
143.4 MIBTable 详细描述.....	2953
143.4.1 hwWlanApTypeTable 详细描述.....	2954
143.4.2 hwWlanApTypeRadioTable 详细描述.....	2955
143.4.3 hwWlanApTypeWiredPortTable 详细描述.....	2957
143.4.4 hwWlanApTypeUndefinedTable 详细描述.....	2958
143.4.5 hwWlanApTypeAttributesAbnormalCheckTable 详细描述.....	2959
143.4.6 hwWlanUnauthedApRecordTable 详细描述.....	2960
143.4.7 hwWlanApTable 详细描述.....	2961
143.4.8 hwWlanApWiredPortTable 详细描述.....	2974
143.4.9 hwWlanApWiredPortStatTable 详细描述.....	2976
143.4.10 hwWlanApWiredPortLldpTable 详细描述.....	2977
143.4.11 hwWlanApWiredPortLldpRemManAddrTable 详细描述.....	2979
143.4.12 hwWlanApOnlineFailTable 详细描述.....	2980
143.4.13 hwWlanApOfflineTable 详细描述.....	2981
143.4.14 hwWlanIDIndexedApTable 详细描述.....	2982
143.4.15 hwWlanApOnlineFailReasonTable 详细描述.....	2994
143.4.16 hwWlanApOfflineReasonTable 详细描述.....	2995
143.5 告警节点详细描述.....	2996
143.5.1 hwApFaultTrap 详细描述.....	2996
143.5.2 hwApNormalTrap 详细描述.....	2997
143.5.3 hwApPingResultTrap 详细描述.....	2998
143.5.4 hwApConfigCommitTrap 详细描述.....	3000
143.5.5 hwUnauthorizedApRecordExistTrap 详细描述.....	3000
143.5.6 hwUnauthorizedApRecordClearTrap 详细描述.....	3001
143.5.7 hwApCpuOverloadTrap 详细描述.....	3001
143.5.8 hwApCpuOverloadRestoreTrap 详细描述.....	3002
143.5.9 hwApMemoryOverloadTrap 详细描述.....	3003

143.5.10 hwApMemoryOverloadRestoreTrap 详细描述.....	3004
143.5.11 hwApStaFullTrap 详细描述.....	3005
143.5.12 hwApStaFullRecoverTrap 详细描述.....	3006
143.5.13 hwAcDevicesSwitchTrap 详细描述.....	3007
143.5.14 hwDyingGaspTrap 详细描述.....	3008
143.5.15 hwApTemperatureTooLowTrap 详细描述.....	3009
143.5.16 hwApTemperatureTooLowRestoreTrap 详细描述.....	3010
143.5.17 hwApTemperatureTooHighTrap 详细描述.....	3011
143.5.18 hwApTemperatureTooHighRestoreTrap 详细描述.....	3012
143.5.19 hwApOpticalRxPowerTooHighTrap 详细描述.....	3013
143.5.20 hwApOpticalRxPowerTooHighRestoreTrap 详细描述.....	3014
143.5.21 hwApOpticalRxPowerTooLowTrap 详细描述.....	3015
143.5.22 hwApOpticalRxPowerTooLowRestoreTrap 详细描述.....	3016
143.5.23 hwApOpticalTemperatureTooHighTrap 详细描述.....	3017
143.5.24 hwApOpticalTemperatureTooHighRestoreTrap 详细描述.....	3018
143.5.25 hwApOpticalTemperatureTooLowTrap 详细描述.....	3019
143.5.26 hwApOpticalTemperatureTooLowRestoreTrap 详细描述.....	3020
143.5.27 hwApNotSupportCountryCodeTrap 详细描述.....	3021
143.5.28 hwApColdBootTrap 详细描述.....	3022
143.5.29 hwApColdBootRestoreTrap 详细描述.....	3023
143.5.30 hwApHotBootTrap 详细描述.....	3024
143.5.31 hwApHotBootRestoreTrap 详细描述.....	3025
143.5.32 hwApCRCTooHighTrap 详细描述.....	3026
143.5.33 hwApCRCTooHighRestoreTrap 详细描述.....	3027
143.5.34 hwApConflictApNameTrap 详细描述.....	3028
143.5.35 hwApLicenseTrap 详细描述.....	3029
143.5.36 hwApFmeaIICFaultTrap 详细描述.....	3029
143.5.37 hwApFmeaIICFaultRestoreTrap 详细描述.....	3030
143.5.38 hwApFmeaPHYFaultTrap 详细描述.....	3030
143.5.39 hwApFmeaPHYFaultRestoreTrap 详细描述.....	3031
143.5.40 hwApFmeaFaultTrap 详细描述.....	3031
143.5.41 hwApFmeaFaultRestoreTrap 详细描述.....	3032
143.5.42 hwApOpticalInsertTrap 详细描述.....	3033
143.5.43 hwApOpticalRemoveTrap 详细描述.....	3034
143.5.44 hwApReceivedInvalidArpNewTrap 详细描述.....	3035
143.5.45 hwApVersionMismatchTrap 详细描述.....	3036
143.5.46 hwRadioUploadRemoteCaptureFileTrap 详细描述.....	3037
143.5.47 hwApOnLineNumExceedCardSpecTrap 详细描述.....	3038
143.5.48 hwWlanBLELowPowerTrap 详细描述.....	3038
143.5.49 hwWlanBLELowPowerRestoreTrap 详细描述.....	3039
143.5.50 hwWlanBLEOfflineTrap 详细描述.....	3039
143.5.51 hwWlanBLEOfflineRestoreTrap 详细描述.....	3039

143.5.52 hwWlanBLEFaultyTrap 详细描述.....	3040
143.5.53 hwWlanBLEFaultyRestoreTrap 详细描述.....	3040
143.5.54 hwAPloTCardInsertTrap 详细描述.....	3041
143.5.55 hwAPloTCardRemoveTrap 详细描述.....	3041
143.5.56 hwAPloTServerStartFailTrap 详细描述.....	3042
143.5.57 hwAPloTServerStartFailResumeTrap 详细描述.....	3043
143.5.58 hwApConfigInconsistWithActualTrap 详细描述.....	3044
143.5.59 hwWlanBLEDetachedTrap 详细描述.....	3045
143.5.60 hwWlanBLEDetachedRestoreTrap 详细描述.....	3046
143.5.61 hwApPowerInsufficientTrap 详细描述.....	3047
143.5.62 hwApPowerInsufficientResumeTrap 详细描述.....	3048
143.5.63 hwPortVlanSecureMacTrap 详细描述.....	3049
143.5.64 hwWlanCableSnrNormalTrap 详细描述.....	3050
143.5.65 hwWlanCableSnrAbnormalTrap 详细描述.....	3051
143.5.66 hwWlanCableSnrDetectNotSupportTrap 详细描述.....	3052
143.5.67 hwApMcBcPktNumExceedTrap 详细描述.....	3053
143.5.68 hwApMcBcPktNumExceedRestoreTrap 详细描述.....	3053
143.5.69 hwAPSoftGreDownTrap 详细描述.....	3053
143.5.70 hwAPSoftGreDownTrapRestore 详细描述.....	3054
143.5.71 hwApVersionNotRecommendedTrap 详细描述.....	3055
143.5.72 hwApVersionNotRecommendedTrapRestore 详细描述.....	3055
143.5.73 hwApDiskOverloadTrap 详细描述.....	3056
143.5.74 hwApDiskOverloadRestoreTrap 详细描述.....	3056
143.5.75 hwApPowerLimitedTrap 详细描述.....	3057
143.5.76 hwApPowerLimitedResumeTrap 详细描述.....	3058
143.5.77 hwAPIpConflictTrap 详细描述.....	3059
143.5.78 hwApNumReachMaxTrap 详细描述.....	3060
143.5.79 hwApNumReachMaxResumeTrap 详细描述.....	3060
143.5.80 hwApNumReachWarningTrap 详细描述.....	3060
143.5.81 hwApNumReachWarningResumeTrap 详细描述.....	3061
143.5.82 hwAPlotCardConnectServerTrap 详细描述.....	3061
143.5.83 hwAPlotCardDisconnectServerTrap 详细描述.....	3062
143.5.84 hwAPlotCardTypeMatchTrap 详细描述.....	3063
143.5.85 hwAPlotCardTypeMismatchTrap 详细描述.....	3064
143.5.86 hwAPFanRemoveTrap 详细描述.....	3065
143.5.87 hwAPFanInsertTrap 详细描述.....	3066
143.5.88 hwAPPowerRemoveTrap 详细描述.....	3067
143.5.89 hwAPPowerInsertTrap 详细描述.....	3068
143.5.90 hwAPPowerFailTrap 详细描述.....	3069
143.5.91 hwAPPowerFailResumeTrap 详细描述.....	3070
143.5.92 hwAPPowerInvalidTrap 详细描述.....	3071
143.5.93 hwAPPowerInvalidResumeTrap 详细描述.....	3072

143.5.94 hwApServiceInterruptAlertTrap 详细描述.....	3073
143.5.95 hwApServiceInterruptAlertResumeTrap 详细描述.....	3074
143.5.96 hwApEMDISessionOverloadTrap 详细信息.....	3074
143.5.97 hwApEMDISessionOverloadRestoreTrap 详细信息.....	3075
143.5.98 hwApSipfpmFlowOverloadTrap 详细信息.....	3076
143.5.99 hwApSipfpmFlowOverloadRestoreTrap 详细信息.....	3077
143.5.100 hwApSACSessionOverloadTrap.....	3078
143.5.101 hwApSACSessionOverloadRestoreTrap.....	3079
143.5.102 hwWlanApPKICACertNearlyExpiredTrap 详细信息.....	3080
143.5.103 hwWlanApPKILocalCertNearlyExpiredTrap 详细信息.....	3081
143.5.104 hwApPortRateAutoNegotiationEventTrap 详细描述.....	3082
143.6 不支持节点.....	3082
144 HUAWEI-WLAN-AP-UPDATE-MIB.....	3086
144.1 功能简介.....	3086
144.2 表间关系.....	3086
144.3 单节点详细描述.....	3086
144.3.1 hwWlanApUpdateFTPIPAddress 详细描述.....	3086
144.3.2 hwWlanApUpdateFTPUsername 详细描述.....	3087
144.3.3 hwWlanApUpdateFTPPassword 详细描述.....	3087
144.3.4 hwWlanApUpdateMode 详细描述.....	3087
144.3.5 hwWlanApUpdateSFTPIPAddress 详细描述.....	3088
144.3.6 hwWlanApUpdateSFTPUsername 详细描述.....	3088
144.3.7 hwWlanApUpdateSFTPPassword 详细描述.....	3088
144.3.8 hwWlanApUpdateFTPMaxConnectNum 详细描述.....	3089
144.3.9 hwWlanApUpdateSFTPMMaxConnectNum 详细描述.....	3089
144.3.10 hwWlanApUpdateFTPIIPv4Port 详细描述.....	3090
144.3.11 hwWlanApUpdateFTPIIPv6Port 详细描述.....	3090
144.3.12 hwWlanApUpdateSFTPIIPv4Port 详细描述.....	3090
144.3.13 hwWlanApUpdateSFTPIIPv6Port 详细描述.....	3091
144.3.14 hwWlanApUpdateOperAdminOper 详细描述.....	3091
144.3.15 hwWlanApUpdateOperApType 详细描述.....	3092
144.3.16 hwWlanApUpdateOperApGroup 详细描述.....	3093
144.3.17 hwWlanApUpdateOperPercent 详细描述.....	3093
144.4 MIBTable 详细描述.....	3093
144.4.1 hwWlanApUpdateTable 详细描述.....	3093
144.4.2 hwWlanApUpdateProgressTable 详细描述.....	3095
144.4.3 hwWlanSingleApUpdateTable 详细描述.....	3102
144.4.4 hwWlanApTypeGroupUpdateTable 详细描述.....	3103
144.4.5 hwWlanApUpdateScheduleTaskTable 详细描述.....	3105
144.5 告警节点详细描述.....	3108
144.5.1 hwWlanApUpdateBeginTrap 详细描述.....	3108
144.5.2 hwWlanApUpdateResultTrap 详细描述.....	3108

144.5.3 hwWlanApUpdateUbootNotMatchTrap 详细描述.....	3110
144.6 不支持节点.....	3111
145 HUAWEI-WLAN-WIDS-SERVICE-MIB.....	3113
145.1 功能简介.....	3113
145.2 表间关系.....	3113
145.3 单节点详细描述.....	3114
145.3.1 hwWlanWidsResetRogueHistoryAll 详细描述.....	3114
145.3.2 hwWlanWidsResetRogueHistoryByDevType 详细描述.....	3114
145.3.3 hwWlanWidsResetAttackDev 详细描述.....	3115
145.3.4 hwWlanWidsResetAttackStat 详细描述.....	3116
145.3.5 hwWlanWidsResetDynamicBlacklist 详细描述.....	3117
145.3.6 hwWlanWidsResetDynamicBlacklistMac 详细描述.....	3117
145.3.7 hwWlanWidsResetAttackHistory 详细描述.....	3117
145.3.8 hwWlanWidsAttackStatProbeRequestFloodAttack 详细描述.....	3117
145.3.9 hwWlanWidsAttackStatAuthRequestFloodAttack 详细描述.....	3118
145.3.10 hwWlanWidsAttackStatDeAuthenFloodAttack 详细描述.....	3118
145.3.11 hwWlanWidsAttackStatAssocReqFloodAttack 详细描述.....	3118
145.3.12 hwWlanWidsAttackStatDisassocReqFloodAttack 详细描述.....	3119
145.3.13 hwWlanWidsAttackStatReassocReqFloodAttack 详细描述.....	3119
145.3.14 hwWlanWidsAttackStatActionFloodAttack 详细描述.....	3119
145.3.15 hwWlanWidsAttackStatNullDataFloodAttack 详细描述.....	3120
145.3.16 hwWlanWidsAttackStatWeakIvAttack 详细描述.....	3120
145.3.17 hwWlanWidsAttackStatDeauthSpoofAttack 详细描述.....	3120
145.3.18 hwWlanWidsAttackStatDisassocSpoofAttack 详细描述.....	3120
145.3.19 hwWlanWidsAttackStatWepShareKeyAttack 详细描述.....	3121
145.3.20 hwWlanWidsAttackStatWpaAttack 详细描述.....	3121
145.3.21 hwWlanWidsAttackStatWpa2Attack 详细描述.....	3121
145.3.22 hwWlanWidsAttackStatWapiAttack 详细描述.....	3121
145.3.23 hwWlanWidsAttackStatEAPOLStartFloodAttack 详细描述.....	3122
145.3.24 hwWlanWidsAttackStatEAPOLLogoffFloodAttack 详细描述.....	3122
145.3.25 hwWlanWidsAttackStatNullQosFloodAttack 详细描述.....	3122
145.3.26 hwWlanWidsAttackStatStartTime 详细描述.....	3122
145.3.27 hwWlanWidsAttackStatOthersSpoofAttack 详细描述.....	3123
145.4 MIBTable 详细描述.....	3123
145.4.1 hwWlanWidsDetDevTable 详细描述.....	3123
145.4.2 hwWlanWidsRogueHistoryTable 详细描述.....	3126
145.4.3 hwWlanWidsDetNonWifiDevTable 详细描述.....	3127
145.4.4 hwWlanWidsAttackHistoryTable 详细描述.....	3130
145.4.5 hwWlanWidsDynamicBlacklistTable 详细描述.....	3133
145.4.6 hwWlanWidsDetNonWifiDevHistTable 详细描述.....	3138
145.4.7 hwWlanWidsAttDevTable 详细描述.....	3142
145.4.8 hwWlanWidsDetDevMonitorTable 详细描述.....	3144

145.4.9 hwWlanWidsDynamicBlacklistAPTable 详细描述.....	3146
145.4.10 hwWlanWidsAttackDetorTable 详细描述.....	3149
145.4.11 hwWlanWidsApDetDevTable 详细描述.....	3153
145.5 告警节点详细描述.....	3156
145.5.1 hwWlanWidsRogueDeviceTrap 详细描述.....	3157
145.5.2 hwWlanWidsAttackDeviceTrap 详细描述.....	3157
145.5.3 hwWlanWidsNonWifiDeviceTrap 详细描述.....	3157
145.5.4 hwWlanWidsAttackDetectedTrap 详细描述.....	3157
145.5.5 hwWlanWidsProfMergeTrap 详细描述.....	3159
145.6 不支持节点.....	3159
146 HUAWEI-WLAN-AP-RADIO-MIB.....	3163
146.1 功能简介.....	3163
146.2 表间关系.....	3163
146.3 单节点详细描述.....	3163
146.4 MIBTable 详细描述.....	3164
146.4.1 hwWlanRadioInfoTable 详细描述.....	3164
146.5 告警节点详细描述.....	3173
146.5.1 hwRadioChannelChangedTrap 详细描述.....	3173
146.5.2 hwRadioSignalEnvDeteriorationTrap 详细描述.....	3175
146.5.3 hwRadioSignalEnvResumeTrap 详细描述.....	3176
146.5.4 hwApMonitorModeChangedTrap 详细描述.....	3177
146.5.5 hwAPCoInterfDetectedTrap 详细描述.....	3178
146.5.6 hwAPCoInterfClearTrap 详细描述.....	3179
146.5.7 hwNerborInterfDetectedTrap 详细描述.....	3180
146.5.8 hwNeiborInterfClearTrap 详细描述.....	3182
146.5.9 hwStaInterfDetectedTrap 详细描述.....	3183
146.5.10 hwStaInterfClearTrap 详细描述.....	3183
146.5.11 hwOtherDeviceInterfDetectedTrap 详细描述.....	3184
146.5.12 hwOtherDeviceInterfClearTrap 详细描述.....	3185
146.5.13 hwRadioDownTrap 详细描述.....	3186
146.5.14 hwRadioDownRecovTrap 详细描述.....	3187
146.5.15 hwWIDSDetectRogueTrap 详细描述.....	3188
146.5.16 hwRadioNotSupportChannelTrap 详细描述.....	3190
146.5.17 hwRadioAntennaGainIsUnlawfulTrap 详细描述.....	3193
146.5.18 hwRadioPowerChangedTrap 详细描述.....	3195
146.5.19 hwApAccessUserNumExceedThresholdTrap 详细描述.....	3195
146.5.20 hwApAccessUserNumExceedThresholdRecovTrap 详细描述.....	3196
146.5.21 hwApRoamUserNumExceedThresholdTrap 详细描述.....	3197
146.5.22 hwApRoamUserNumExceedThresholdRecovTrap 详细描述.....	3198
146.5.23 hwRadioReachMaxUserPhySpecTrap 详细描述.....	3199
146.5.24 hwRadioReachMaxUserPhySpecClearTrap 详细描述.....	3200
146.6 不支持节点.....	3201

147 HUAWEI-WLAN-VAP-MIB.....	3204
147.1 功能简介.....	3204
147.2 表间关系.....	3204
147.3 单节点详细描述.....	3204
147.4 MIBTable 详细描述.....	3204
147.4.1 hwWlanVapInfoTable 详细描述.....	3205
147.4.2 hwWlanSsidStatisticTable 详细描述.....	3207
147.4.3 hwWlanRfSsidStatisticTable 详细描述.....	3209
147.4.4 hwWlanMacRfSsidStatisticTable 详细描述.....	3211
147.4.5 hwWlanVapIGMPSnoopingCacInfoTable 详细描述.....	3213
147.4.6 hwVapCreateFailTrap 详细描述.....	3214
147.4.7 hwVapCreateFailTrapRestore 详细描述.....	3214
147.5 告警节点详细描述.....	3214
147.5.1 hwVapIGMPSnoopingBandwidthExceedTrap 详细描述.....	3214
147.5.2 hwVapIGMPSnoopingUserExceedTrap 详细描述.....	3215
147.5.3 hwVapNumExceedCardSpecTrap 详细描述.....	3216
147.5.4 hwVapNumExceedCardSpecTrapRestore 详细描述.....	3217
147.6 不支持节点.....	3217
148 HUAWEI-WLAN-STATION-MIB.....	3219
148.1 功能简介.....	3219
148.2 表间关系.....	3219
148.3 单节点详细描述.....	3219
148.3.1 hwWlanConflictStaMac 详细描述.....	3219
148.3.2 hwMaxUserSipfpmFlowNum 详细描述.....	3220
148.3.3 hwCurUserSipfpmFlowNum 详细描述.....	3220
148.4 MIBTable 详细描述.....	3220
148.4.1 hwWlanStationTable 详细描述.....	3220
148.4.2 hwWlanStationApStatTable 详细描述.....	3238
148.4.3 hwWlanStaOnlineFailTable 详细描述.....	3242
148.4.4 hwWlanStaOnlineFailReasonTable 详细描述.....	3243
148.4.5 hwWlanStaOfflineTable 详细描述.....	3244
148.4.6 hwWlanStaOfflineReasonTable 详细描述.....	3246
148.4.7 hwWlanStaRoamTraceTable 详细描述.....	3246
148.5 告警节点详细描述.....	3249
148.5.1 hwWlanStaAuthErrorTrap 详细描述.....	3249
148.5.2 hwWlanStaAssoFailTrap 详细描述.....	3251
148.5.3 hwWlanUserInvalidCerficationTrap 详细描述.....	3253
148.5.4 hwWlanStaRepititiveAttackTrap 详细描述.....	3254
148.5.5 hwWlanStaTamperAttackTrap 详细描述.....	3255
148.5.6 hwWlanStaLowLevelSecAttackTrap 详细描述.....	3256
148.5.7 hwWlanStaAddressRedirectionAttackTrap 详细描述.....	3257
148.5.8 hwWlanStaWepldConflictTrap 详细描述.....	3258

148.5.9 hwStationIPConflictTrap 详细描述.....	3260
148.5.10 hwStationIPAddressConflictTrap 详细描述.....	3260
148.5.11 hwApSipfpmUserFlowFullTrap 详细描述.....	3262
148.5.12 hwApSipfpmUserFlowFullRestoreTrap 详细描述.....	3263
148.6 不支持节点.....	3263
149 HUAWEI-WLAN-AP-SERVICE-MIB.....	3266
149.1 功能简介.....	3266
149.2 表间关系.....	3266
149.3 单节点详细描述.....	3267
149.3.1 hwWlanRadioResetChannelSwitchRecord 详细描述.....	3267
149.4 MIBTable 详细描述.....	3267
149.4.1 hwWlanWdsVapInfoTable 详细描述.....	3267
149.4.2 hwWlanWdsLinkTable 详细描述.....	3268
149.4.3 hwWlanMeshVapInfoTable 详细描述.....	3271
149.4.4 hwWlanMeshLinkTable 详细描述.....	3272
149.4.5 hwWlanRadioCalibrateStatisticsTable 详细描述.....	3275
149.4.6 hwWlanRadioChannelSwitchRecordTable 详细描述.....	3277
149.4.7 hwWlanSpectrumReporterTable 详细描述.....	3278
149.4.8 hwWlanAplotCardTable 详细描述.....	3279
149.4.9 hwWlanBLESiteInfoTable 详细描述.....	3284
149.4.10 hwWlanRadioCalibrationSwitchRecordTable 详细描述.....	3286
149.5 告警节点详细描述.....	3289
149.5.1 hwWlanAeroscoutLocationViaAcTrap 详细描述.....	3289
149.5.2 hwWlanAeroscoutLocationViaAcRestoreTrap 详细描述.....	3289
149.6 不支持节点.....	3289
150 HUAWEI-XQoS-MIB.....	3292
150.1 功能简介.....	3292
150.2 表间关系.....	3292
150.3 单节点详细描述.....	3293
150.4 MIB Table 详细描述.....	3293
150.4.1 hwXQoSbaCfgInfoTable 详细描述.....	3293
150.4.2 hwXQoSIfDiffDomainTable 详细描述.....	3294
150.4.3 hwXQoSbaPhbCfgInfoTable 详细描述.....	3296
150.4.4 hwXQoSbaMapCfgInfoTable 详细描述.....	3297
150.4.5 hwXQoSIfTrustTable 详细描述.....	3299
150.4.6 hwXQoSIfQueueRunInfoTable 详细描述.....	3300
150.4.7 hwXQoSCarTable 详细描述.....	3302
150.4.8 hwXQoSIfLrCfgInfoTable 详细描述.....	3303
150.4.9 hwXQoSVlanStatTable 详细描述.....	3304
150.4.10 hwXQoSVlanSlotStatTable 详细描述.....	3306
150.4.11 hwXQoSvlanCfgTable 详细描述.....	3307
150.4.12 hwXQoSTrafficSuppressionTable 详细描述.....	3308

150.5 告警节点详细描述.....	3309
150.5.1 hwXqoSStormControlTrap 详细描述.....	3309
150.5.2 hwXqoSStormControlTrapExt 详细描述.....	3310
150.5.3 hwXqoSTrafficSuppressionTrap 详细描述.....	3312
150.6 不支持节点.....	3312
151 IF-MIB.....	3336
151.1 功能简介.....	3336
151.2 表间关系.....	3336
151.3 单节点详细描述.....	3336
151.3.1 ifNumber 详细描述.....	3337
151.3.2 ifTableLastChange 详细描述.....	3337
151.3.3 ifStackLastChange 详细描述.....	3337
151.4 MIB Table 详细描述.....	3337
151.4.1 ifTable 详细描述.....	3338
151.4.2 ifXTable 详细描述.....	3345
151.4.3 ifStackTable 详细描述.....	3351
151.5 告警节点详细描述.....	3352
151.5.1 linkUp 详细描述.....	3352
151.5.2 linkDown 详细描述.....	3352
152 IP-FORWARD-MIB.....	3353
152.1 功能简介.....	3353
152.2 表间关系.....	3353
152.3 单节点详细描述.....	3353
152.3.1 ipCidrRouteNumber 详细描述.....	3354
152.3.2 inetCidrRouteNumber 详细描述.....	3354
152.3.3 inetCidrRouteDiscards 详细描述.....	3354
152.4 MIB Table 详细描述.....	3354
152.4.1 ipCidrRouteTable 详细描述.....	3354
152.4.2 inetCidrRouteTable 详细描述.....	3359
152.5 告警节点详细描述.....	3365
153 IP-MIB.....	3366
153.1 功能简介.....	3366
153.2 表间关系.....	3366
153.3 单节点详细描述.....	3367
153.3.1 ipv4InterfaceTableLastChange 详细描述.....	3367
153.3.2 ipIfStatsTableLastChange 详细描述.....	3367
153.4 MIB Table 详细描述.....	3367
153.4.1 ipSystemStatsTable 详细描述.....	3367
153.4.2 ipIfStatsTable 详细描述.....	3380
154 IPMCAST-MIB.....	3391
154.1 功能简介.....	3391

154.2 表间关系.....	3391
154.3 单节点详细描述.....	3392
154.3.1 ipMcastEnabled 详细描述.....	3392
154.3.2 ipMcastDeviceConfigStorageType 详细描述.....	3392
154.3.3 ipMcastRouteEntryCount 详细描述.....	3393
154.4 MIB Table 详细描述.....	3393
154.4.1 ipMcastRouteTable 详细描述.....	3393
154.4.2 ipMcastRouteNextHopTable 详细描述.....	3397
154.4.3 ipMcastBoundaryTable 详细描述.....	3401
154.5 不支持节点.....	3403
155 IPv6-ICMP-MIB.....	3404
155.1 功能简介.....	3404
155.2 表间关系.....	3404
155.3 单节点详细描述.....	3404
155.4 MIB Table 详细描述.....	3404
155.4.1 ipv6IcmpTable 详细描述.....	3404
155.5 告警节点详细描述.....	3409
156 IPV6-MIB.....	3410
156.1 功能简介.....	3410
156.2 表间关系.....	3411
156.3 单节点详细描述.....	3411
156.3.1 ipv6Forwarding 详细描述.....	3412
156.3.2 ipv6DefaultHopLimit 详细描述.....	3412
156.3.3 ipv6Interfaces 详细描述.....	3412
156.3.4 ipv6IfTableLastChange 详细描述.....	3413
156.3.5 ipv6RouteNumber 详细描述.....	3413
156.3.6 ipv6DiscardedRoutes 详细描述.....	3413
156.4 MIB Table 详细描述.....	3413
156.4.1 ipv6IfTable 详细描述.....	3413
156.4.2 ipv6IfStatsTable 详细描述.....	3417
156.4.3 ipv6AddrPrefixTable 详细描述.....	3421
156.4.4 ipv6AddrTable 详细描述.....	3423
156.4.5 ipv6RouteTable 详细描述.....	3424
156.4.6 ipv6NetToMediaTable 详细描述.....	3428
156.5 告警节点详细描述.....	3430
156.5.1 ipv6IfStateChange 详细描述.....	3431
157 IPv6-TCP-MIB.....	3432
157.1 功能简介.....	3432
157.2 表间关系.....	3432
157.3 单节点详细描述.....	3432
157.4 MIB Table 详细描述.....	3432

157.4.1 ipv6TcpConnTable 详细描述.....	3432
157.5 告警节点详细描述.....	3434
158 IPv6-UDP-MIB.....	3435
158.1 功能简介.....	3435
158.2 表间关系.....	3435
158.3 单节点详细描述.....	3435
158.4 MIB Table 详细描述.....	3435
158.4.1 ipv6UdpTable 详细描述.....	3435
158.5 告警节点详细描述.....	3437
159 ISIS-MIB.....	3438
159.1 功能简介.....	3438
159.2 表间关系.....	3439
159.3 MIB Table 详细描述.....	3441
159.3.1 isisSysTable 详细描述.....	3441
159.3.2 isisManAreaAddrTable 详细描述.....	3446
159.3.3 isisAreaAddrTable 详细描述.....	3447
159.3.4 isisSysProtSuppTable 详细描述.....	3447
159.3.5 isisSummAddrTable 详细描述.....	3448
159.3.6 isisRedistributeAddrTable 详细描述.....	3450
159.3.7 isisRouterTable 详细描述.....	3451
159.3.8 isisSysLevelTable 详细描述.....	3453
159.3.9 isisCircTable 详细描述.....	3455
159.3.10 isisCircLevelTable 详细描述.....	3460
159.3.11 isisSystemCounterTable 详细描述.....	3464
159.3.12 isisCircuitCounterTable 详细描述.....	3467
159.3.13 isisPacketCounterTable 详细描述.....	3469
159.3.14 isisISAdjTable 详细描述.....	3472
159.3.15 isisISAdjAreaAddrTable 详细描述.....	3474
159.3.16 isisISAdjIPAddrTable 详细描述.....	3475
159.3.17 isisISAdjProtSuppTable 详细描述.....	3476
159.3.18 isisIPRATable 详细描述.....	3477
159.3.19 isisLSPSummaryTable 详细描述.....	3481
159.3.20 isisNotificationTable 详细描述.....	3483
159.4 告警节点详细描述.....	3486
159.4.1 isisDatabaseOverload 详细描述.....	3486
159.4.2 isisManualAddressDrops 详细描述.....	3487
159.4.3 isisCorruptedLSPDetected 详细描述.....	3487
159.4.4 isisAttemptToExceedMaxSequence 详细描述.....	3488
159.4.5 isisIDLenMismatch 详细描述.....	3488
159.4.6 isisMaxAreaAddressesMismatch 详细描述.....	3489
159.4.7 isisOwnLSPPurge 详细描述.....	3489
159.4.8 isisSequenceNumberSkip 详细描述.....	3490

159.4.9 isisAuthenticationTypeFailure 详细描述.....	3490
159.4.10 isisAuthenticationFailure 详细描述.....	3491
159.4.11 isisVersionSkew 详细描述.....	3491
159.4.12 isisAreaMismatch 详细描述.....	3492
159.4.13 isisRejectedAdjacency 详细描述.....	3492
159.4.14 isisLSPTooLargeToPropagate 详细描述.....	3493
159.4.15 isisOrigLSPBuffSizeMismatch 详细描述.....	3493
159.4.16 isisProtocolsSupportedMismatch 详细描述.....	3494
159.4.17 isisAdjacencyChange 详细描述.....	3494
160 LAG-MIB.....	3495
160.1 功能简介.....	3495
160.2 表间关系.....	3496
160.3 单节点详细描述.....	3498
160.3.1 dot3adTablesLastChanged 详细描述.....	3498
160.4 MIB Table 详细描述.....	3498
160.4.1 dot3adAggTable 详细描述.....	3498
160.4.2 dot3adAggPortListTable 详细描述.....	3500
160.4.3 dot3adAggPortTable 详细描述.....	3501
160.4.4 dot3adAggPortStatsTable 详细描述.....	3507
161 LLDP-EXT-DOT1-MIB.....	3510
161.1 功能简介.....	3510
161.2 表间关系.....	3510
161.3 单节点详细描述.....	3510
161.4 MIB Table 详细描述.....	3511
161.4.1 lldpXdot1ConfigPortVlanTable 详细描述.....	3511
161.4.2 lldpXdot1ConfigVlanNameTable 详细描述.....	3511
161.4.3 lldpXdot1ConfigProtoVlanTable 详细描述.....	3512
161.4.4 lldpXdot1ConfigProtocolTable 详细描述.....	3512
161.4.5 lldpXdot1LocTable 详细描述.....	3513
161.4.6 lldpXdot1LocProtoVlanTable 详细描述.....	3514
161.4.7 lldpXdot1LocVlanNameTable 详细描述.....	3515
161.4.8 lldpXdot1LocProtocolTable 详细描述.....	3515
161.4.9 lldpXdot1RemTable 详细描述.....	3516
161.4.10 lldpXdot1RemProtoVlanTable 详细描述.....	3517
161.4.11 lldpXdot1RemVlanNameTable 详细描述.....	3518
161.4.12 lldpXdot1RemProtocolTable 详细描述.....	3518
161.5 告警节点详细描述.....	3519
162 LLDP-EXT-DOT3-MIB.....	3520
162.1 功能简介.....	3520
162.2 表间关系.....	3520
162.3 单节点详细描述.....	3520

162.4 MIB Table 详细描述.....	3521
162.4.1 lldpXdot3PortConfigTable 详细描述.....	3521
162.4.2 lldpXdot3LocPortTable 详细描述.....	3521
162.4.3 lldpXdot3LocPowerTable 详细描述.....	3522
162.4.4 lldpXdot3LocLinkAggTable 详细描述.....	3524
162.4.5 lldpXdot3LocMaxFrameSizeTable 详细描述.....	3524
162.4.6 lldpXdot3RemPortTable 详细描述.....	3525
162.4.7 lldpXdot3RemPowerTable 详细描述.....	3526
162.4.8 lldpXdot3RemLinkAggTable 详细描述.....	3527
162.4.9 lldpXdot3RemMaxFrameSizeTable 详细描述.....	3528
162.5 告警节点详细描述.....	3528
163 LLDP-MIB.....	3529
163.1 功能简介.....	3529
163.2 表间关系.....	3529
163.3 单节点详细描述.....	3529
163.3.1 lldpMessageTxInterval 详细描述.....	3530
163.3.2 lldpMessageTxHoldMultiplier 详细描述.....	3530
163.3.3 lldpReinitDelay 详细描述.....	3530
163.3.4 lldpTxDelay 详细描述.....	3530
163.3.5 lldpNotificationInterval 详细描述.....	3530
163.3.6 lldpStatsRemTablesLastChangeTime 详细描述.....	3531
163.3.7 lldpStatsRemTablesInserts 详细描述.....	3531
163.3.8 lldpStatsRemTablesDeletes 详细描述.....	3531
163.3.9 lldpStatsRemTablesDrops 详细描述.....	3531
163.3.10 lldpStatsRemTablesAgeouts 详细描述.....	3532
163.3.11 lldpLocChassisIdSubtype 详细描述.....	3532
163.3.12 lldpLocChassisId 详细描述.....	3533
163.3.13 lldpLocSysName 详细描述.....	3533
163.3.14 lldpLocSysDesc 详细描述.....	3533
163.3.15 lldpLocSysCapSupported 详细描述.....	3533
163.3.16 lldpLocSysCapEnabled 详细描述.....	3534
163.4 MIB Table 详细描述.....	3534
163.4.1 lldpPortConfigTable 详细描述.....	3535
163.4.2 lldpStatsTxPortTable 详细描述.....	3535
163.4.3 lldpStatsRxPortTable 详细描述.....	3536
163.4.4 lldpLocPortTable 详细描述.....	3537
163.4.5 lldpLocManAddrTable 详细描述.....	3539
163.4.6 lldpRemTable 详细描述.....	3540
163.4.7 lldpRemManAddrTable 详细描述.....	3543
163.5 告警节点详细描述.....	3544
163.5.1 lldpRemTablesChange 详细描述.....	3544
163.6 不支持节点.....	3544

164 MGMD-STD-MIB.....	3546
164.1 功能简介.....	3546
164.2 表间关系.....	3547
164.3 MIB Table 详细描述.....	3547
164.3.1 mgmdRouterInterfaceTable 详细描述.....	3547
164.3.2 mgmdRouterCacheTable 详细描述.....	3554
164.3.3 mgmdInverseRouterCacheTable 详细描述.....	3556
164.3.4 mgmdRouterSrcListTable 详细描述.....	3557
164.3.5 mgmdHostInterfaceTable 详细描述.....	3558
164.3.6 mgmdHostCacheTable 详细描述.....	3560
164.3.7 mgmdInverseHostCacheTable 详细描述.....	3562
164.3.8 mgmdHostSrcListTable 详细描述.....	3562
165 MPLS-FTN-STD-MIB.....	3564
165.1 功能简介.....	3564
165.2 表间关系.....	3564
165.3 单节点详细描述.....	3564
165.4 MIB Table 详细描述.....	3564
165.4.1 mplsFTNTable 详细描述.....	3564
165.4.2 mplsFTNMapTable 详细描述.....	3568
165.5 告警节点详细描述.....	3569
166 MPLS-L3VPN-STD-MIB.....	3570
166.1 功能简介.....	3570
166.2 表间关系.....	3571
166.3 单节点详细描述.....	3571
166.3.1 mplsL3VpnScalars 详细描述.....	3572
166.4 MIB Table 详细描述.....	3573
166.4.1 mplsL3VpnIfConfTable 详细描述.....	3573
166.4.2 mplsL3VpnVrfTable 详细描述.....	3576
166.4.3 mplsL3VpnVrfRTTable 详细描述.....	3580
166.4.4 mplsL3VpnVrfSecTable 详细描述.....	3581
166.4.5 mplsL3VpnVrfPerfTable 详细描述.....	3582
166.4.6 mplsL3VpnVrfRteTable 详细描述.....	3583
166.5 告警节点详细描述.....	3592
166.5.1 mplsL3VpnVrfUp 详细描述.....	3592
166.5.2 mplsL3VpnVrfDown 详细描述.....	3593
166.5.3 mplsL3VpnVrfRouteMidThreshExceeded 详细描述.....	3593
166.5.4 mplsL3VpnVrfNumVrfRouteMaxThreshExceeded 详细描述.....	3594
166.5.5 mplsL3VpnNumVrfRouteMaxThreshCleared 详细描述.....	3595
166.6 不支持节点.....	3595
167 MPLS-LDP-GENERIC-STD-MIB.....	3597
167.1 功能简介.....	3597

167.2 表间关系.....	3597
167.3 单节点详细描述.....	3597
167.4 MIB Table 详细描述.....	3597
167.4.1 mplsLdpEntityGenericLRTTable 详细描述.....	3597
167.5 告警节点详细描述.....	3599
168 MPLS-LDP-STD-MIB.....	3600
168.1 功能简介.....	3600
168.2 表间关系.....	3600
168.3 单节点详细描述.....	3601
168.3.1 mplsLdpLsrId 详细描述.....	3601
168.3.2 mplsLdpLsrLoopDetectionCapable 详细描述.....	3602
168.3.3 mplsLdpEntityLastChange 详细描述.....	3603
168.3.4 mplsLdpEntityIndexNext 详细描述.....	3603
168.3.5 mplsLdpPeerLastChange 详细描述.....	3603
168.3.6 mplsFecLastChange 详细描述.....	3604
168.3.7 mplsFecIndexNext 详细描述.....	3604
168.3.8 mplsLdpLspFecLastChange 详细描述.....	3605
168.4 MIB Table 详细描述.....	3605
168.4.1 mplsLdpEntityTable 详细描述.....	3605
168.4.2 mplsLdpEntityStatsTable 详细描述.....	3615
168.4.3 mplsLdpPeerTable 详细描述.....	3619
168.4.4 mplsLdpSessionTable 详细描述.....	3620
168.4.5 mplsLdpHelloAdjacencyTable 详细描述.....	3622
168.4.6 mplsInSegmentLdpLspTable 详细描述.....	3624
168.4.7 mplsOutSegmentLdpLspTable 详细描述.....	3625
168.4.8 mplsFecTable 详细描述.....	3626
168.4.9 mplsLdpLspFecTable 详细描述.....	3628
168.4.10 mplsLdpSessionPeerAddrTable 详细描述.....	3630
168.4.11 mplsLdpSessionStatsTable 详细描述.....	3631
168.5 告警节点详细描述.....	3631
168.5.1 mplsLdpInitSessionThresholdExceeded 详细描述.....	3632
168.5.2 mplsLdpPathVectorLimitMismatch 详细描述.....	3632
168.5.3 mplsLdpSessionUp 详细描述.....	3633
168.5.4 mplsLdpSessionDown 详细描述.....	3633
169 MPLS-LSR-STD-MIB.....	3634
169.1 功能简介.....	3634
169.2 表间关系.....	3634
169.3 单节点详细描述.....	3634
169.3.1 mplsInSegmentIndexNext 详细描述.....	3635
169.3.2 mplsOutSegmentIndexNext 详细描述.....	3635
169.3.3 mplsXCIndexNext 详细描述.....	3636
169.3.4 mplsMaxLabelStackDepth 详细描述.....	3636

169.4 MIB Table 详细描述.....	3636
169.4.1 mplsInterfaceTable 详细描述.....	3637
169.4.2 mplsInterfacePerfTable 详细描述.....	3640
169.4.3 mplsInSegmentTable 详细描述.....	3641
169.4.4 mplsOutSegmentTable 详细描述.....	3645
169.4.5 mplsXCTable 详细描述.....	3649
169.4.6 mplsInSegmentMapTable 详细描述.....	3653
169.5 告警节点详细描述.....	3654
169.5.1 mplsXCUp 详细描述.....	3654
169.5.2 mplsXCDown 详细描述.....	3655
170 MPLS-TE-STD-MIB.....	3656
170.1 功能简介.....	3656
170.2 表间关系.....	3656
170.3 单节点详细描述.....	3656
170.3.1 mplsTunnelConfigured 详细描述.....	3657
170.3.2 mplsTunnelActive 详细描述.....	3657
170.3.3 mplsTunnelMaxHops 详细描述.....	3657
170.3.4 mplsTunnelTEDistProto 详细描述.....	3658
170.4 MIB Table 详细描述.....	3658
170.4.1 mplsTunnelTable 详细描述.....	3658
170.4.2 mplsTunnelHopTable 详细描述.....	3667
170.4.3 mplsTunnelResourceTable 详细描述.....	3670
170.4.4 mplsTunnelARHopTable 详细描述.....	3673
170.4.5 mplsTunnelCHopTable 详细描述.....	3674
170.5 告警节点详细描述.....	3676
170.5.1 mplsTunnelUp 详细描述.....	3677
170.5.2 mplsTunnelDown 详细描述.....	3677
170.5.3 mplsTunnelRerouted 详细描述.....	3677
170.5.4 mplsTunnelReoptimized 详细描述.....	3678
171 MSDP-MIB.....	3679
171.1 功能简介.....	3679
171.2 表间关系.....	3679
171.3 单节点详细描述.....	3680
171.3.1 msdpEnabled 详细描述.....	3680
171.3.2 msdpCacheLifetime 详细描述.....	3680
171.3.3 msdpNumSACacheEntries 详细描述.....	3681
171.3.4 msdpRAddress 详细描述.....	3681
171.4 MIB Table 详细描述.....	3681
171.4.1 msdpPeerTable 详细描述.....	3682
171.4.2 msdpSACacheTable 详细描述.....	3688
171.4.3 msdpMeshGroupTable 详细描述.....	3690
171.5 告警节点详细描述.....	3692

171.5.1 msdpEstablished 详细描述.....	3692
171.5.2 msdpBackwardTransition 详细描述.....	3692
172 NOTIFICATION-LOG-MIB.....	3693
172.1 功能简介.....	3693
172.2 表间关系.....	3693
172.3 单节点详细描述.....	3694
172.3.1 nlmConfigGlobalEntryLimit 详细描述.....	3694
172.3.2 nlmConfigGlobalAgeOut 详细描述.....	3695
172.3.3 nlmStatsGlobalNotificationsLogged 详细描述.....	3695
172.3.4 nlmStatsGlobalNotificationsBumped 详细描述.....	3696
172.4 MIB Table 详细描述.....	3696
172.4.1 nlmConfigLogTable 详细描述.....	3696
172.4.2 nlmStatsLogTable 详细描述.....	3700
172.4.3 nlmLogTable 详细描述.....	3701
172.4.4 nlmLogVariableTable 详细描述.....	3703
172.5 不支持节点.....	3705
173 NQA-MIB.....	3707
173.1 功能简介.....	3707
173.2 表间关系.....	3707
173.2.1 NQA 测试例配置信息表与 NQA 测试例配置参数表之间的关系.....	3707
173.2.2 NQA 测试例配置信息表与 NQA 测试例调度配置参数表之间的关系.....	3708
173.2.3 NQA 测试例配置信息表与 NQA 测试例结果统计表之间的关系.....	3709
173.2.4 NQA 测试例配置信息表与 HTTP 测试例结果统计表之间的关系.....	3709
173.2.5 NQA 测试例配置信息表与 Jitter 测试例结果统计表之间的关系.....	3710
173.2.6 NQA 测试例配置信息表与 FTP 测试例结果统计表之间的关系.....	3711
173.2.7 NQA 测试例配置信息表与组播 trace 测试例结果统计表之间的关系.....	3712
173.2.8 NQA 测试例配置信息表与 NQA 测试例历史结果统计表之间的关系.....	3713
173.2.9 NQA 测试例配置信息表与组播 trace 测试例历史统计表之间的关系.....	3714
173.2.10 NQA 告警表与事件表之间的关系.....	3715
173.2.11 NQA 测试例配置信息表与 JitterCollect 统计表之间的关系.....	3715
173.3 单节点详细描述.....	3716
173.3.1 nqaVersion 详细描述.....	3716
173.3.2 nqaEnable 详细描述.....	3717
173.3.3 nqaReset 详细描述.....	3717
173.3.4 nqaTimeOfLastSetError 详细描述.....	3717
173.3.5 nqaLastSetError 详细描述.....	3718
173.3.6 nqaNumOfCurrentCtrlEntry 详细描述.....	3718
173.3.7 nqaMaxConcurrentRequests 详细描述.....	3718
173.3.8 nqaMaxNumOfRequests 详细描述.....	3718
173.3.9 nqaJitterVersion 详细描述.....	3719
173.3.10 nqaSupportTestType 详细描述.....	3720
173.3.11 nqaSupportServerType 详细描述.....	3721

173.3.12 nqaRtpptestMaxConcurrentNumber 详细描述.....	3722
173.3.13 nqaRtpsnoopMaxConcurrentNumber 详细描述.....	3722
173.3.14 nqaRtpudpMaxConcurrentNumber 详细描述.....	3722
173.3.15 nqaRtp tcpMaxConcurrentNumber 详细描述.....	3722
173.3.16 nqaServerEnable 详细描述.....	3723
173.3.17 nqaMaxAlarmNum 详细描述.....	3723
173.3.18 nqaMaxEventNum 详细描述.....	3723
173.3.19 nqaFtpSaveRecordEnable 详细描述.....	3724
173.3.20 nqaFtpSaveRecordIpAddr 详细描述.....	3724
173.3.21 nqaFtpSaveRecordVrfName 详细描述.....	3725
173.3.22 nqaFtpSaveRecordUserName 详细描述.....	3725
173.3.23 nqaFtpSaveRecordPassword 详细描述.....	3725
173.3.24 nqaFtpSaveRecordFileName 详细描述.....	3726
173.3.25 nqaFtpSaveRecordItemNum 详细描述.....	3726
173.3.26 nqaFtpSaveRecordTime 详细描述.....	3726
173.3.27 nqaFtpSaveRecordNotificationEnable 详细描述.....	3727
173.3.28 nqaFtpSaveRecordLastFileName 详细描述.....	3727
173.4 MIB Table 详细描述.....	3727
173.4.1 nqaAdminCtrlTable 详细描述.....	3727
173.4.2 nqaAdminParaTable 详细描述.....	3730
173.4.3 nqaScheduleTable 详细描述.....	3743
173.4.4 nqaAdminParaExtTable 详细描述.....	3745
173.4.5 nqaTcpServerTable 详细描述.....	3750
173.4.6 nqaUdpServerTable 详细描述.....	3751
173.4.7 nqaResultsTable 详细描述.....	3752
173.4.8 nqaHTTPStatsTable 详细描述.....	3756
173.4.9 nqaJitterStatsTable 详细描述.....	3760
173.4.10 nqaFTPStatsTable 详细描述.....	3768
173.4.11 nqaMtracertStatsTable 详细描述.....	3771
173.4.12 nqaPathMtuStatsTable 详细描述.....	3774
173.4.13 nqaPathJitterStatsTable 详细描述.....	3776
173.4.14 nqaRtpptestStatsTable 详细描述.....	3787
173.4.15 nqaRtp listenStatsTable 详细描述.....	3789
173.4.16 nqaHistoryTable 详细描述.....	3791
173.4.17 nqaMtracertHistoryTable 详细描述.....	3794
173.4.18 nqaJitterCollectStatsTable 详细描述.....	3800
173.4.19 nqaAlarmTable 详细描述.....	3808
173.4.20 nqaEventTable 详细描述.....	3813
173.4.21 nqaRtpUdpServerTable 详细描述.....	3816
173.4.22 nqaRtpTcpServerTable 详细描述.....	3817
173.5 告警节点详细描述.....	3818
173.5.1 nqaResultsProbeFailed 详细描述.....	3819

173.5.2 nqaResultsTestFailed 详细描述.....	3820
173.5.3 nqaResultsTestCompleted 详细描述.....	3821
173.5.4 nqaResultsThresholdNotification 详细描述.....	3822
173.5.5 nqaHTTPStatsProbeFailed 详细描述.....	3823
173.5.6 nqaHTTPStatsTestFailed 详细描述.....	3824
173.5.7 nqaHTTPStatsTestCompleted 详细描述.....	3825
173.5.8 nqaHTTPStatsThresholdNotification 详细描述.....	3826
173.5.9 nqaJitterStatsTestFailed 详细描述.....	3827
173.5.10 nqaJitterStatsTestCompleted 详细描述.....	3828
173.5.11 nqaFTPStatsProbeFailed 详细描述.....	3829
173.5.12 nqaFTPStatsTestFailed 详细描述.....	3830
173.5.13 nqaFTPStatsTestCompleted 详细描述.....	3831
173.5.14 nqaFTPStatsThresholdNotification 详细描述.....	3831
173.5.15 nqaJitterStatsRTDThresholdNotification 详细描述.....	3832
173.5.16 nqaJitterStatsOWDThresholdNotificationSD 详细描述.....	3832
173.5.17 nqaJitterStatsOWDThresholdNotificationDS 详细描述.....	3833
173.5.18 nqaRisingAlarmNotification 详细描述.....	3833
173.5.19 nqaFallingAlarmNotification 详细描述.....	3834
173.5.20 nqaFtpSaveRecordNotification 详细描述.....	3834
173.5.21 nqaResultsTestResultChange 详细描述.....	3834
173.6 不支持节点.....	3834
174 OSPF-MIB.....	3836
174.1 功能简介.....	3836
174.2 表间关系.....	3837
174.3 单节点详细描述.....	3839
174.3.1 ospfRouterId 详细描述.....	3839
174.3.2 ospfAdminStat 详细描述.....	3839
174.3.3 ospfVersionNumber 详细描述.....	3839
174.3.4 ospfAreaBdrRtrStatus 详细描述.....	3840
174.3.5 ospfASBdrRtrStatus 详细描述.....	3840
174.3.6 ospfExternLsaCount 详细描述.....	3840
174.3.7 ospfExternLsaCksumSum 详细描述.....	3840
174.3.8 ospfTOSSupport 详细描述.....	3841
174.3.9 ospfOriginateNewLsas 详细描述.....	3841
174.3.10 ospfRxNewLsas 详细描述.....	3841
174.3.11 ospfExtLsdbLimit 详细描述.....	3842
174.3.12 ospfMulticastExtensions 详细描述.....	3843
174.3.13 ospfExitOverflowInterval 详细描述.....	3844
174.3.14 ospfDemandExtensions 详细描述.....	3844
174.3.15 ospfRFC1583Compatibility 详细描述.....	3845
174.3.16 ospfOpaqueLsaSupport 详细描述.....	3845
174.3.17 ospfReferenceBandwidth 详细描述.....	3846

174.3.18 ospfRestartSupport 详细描述.....	3846
174.3.19 ospfRestartInterval 详细描述.....	3846
174.3.20 ospfRestartStrictLsaChecking 详细描述.....	3847
174.3.21 ospfRestartStatus 详细描述.....	3847
174.3.22 ospfRestartAge 详细描述.....	3847
174.3.23 ospfRestartExitReason 详细描述.....	3848
174.3.24 ospfAsLsaCount 详细描述.....	3848
174.3.25 ospfAsLsaCksumSum 详细描述.....	3848
174.3.26 ospfStubRouterSupport 详细描述.....	3849
174.3.27 ospfStubRouterAdvertisement 详细描述.....	3849
174.3.28 ospfDiscontinuityTime 详细描述.....	3849
174.4 MIB Table 详细描述.....	3849
174.4.1 ospfAreaTable 详细描述.....	3849
174.4.2 ospfStubAreaTable 详细描述.....	3853
174.4.3 ospfLsdbTable 详细描述.....	3855
174.4.4 ospfIfTable 详细描述.....	3857
174.4.5 ospfIfMetricTable 详细描述.....	3864
174.4.6 ospfVirtIfTable 详细描述.....	3866
174.4.7 ospfNbrTable 详细描述.....	3870
174.4.8 ospfVirtNbrTable 详细描述.....	3873
174.4.9 ospfExtLsdbTable 详细描述.....	3875
174.4.10 ospfAreaAggregateTable 详细描述.....	3877
174.4.11 ospfLocalLsdbTable 详细描述.....	3879
174.4.12 ospfVirtLocalLsdbTable 详细描述.....	3880
174.4.13 ospfAsLsdbTable 详细描述.....	3882
174.4.14 ospfAreaLsaCountTable 详细描述.....	3884
174.5 告警节点详细描述.....	3885
175 OSPF-TRAP-MIB.....	3886
175.1 功能简介.....	3886
175.2 表间关系.....	3886
175.3 单节点详细描述.....	3886
175.3.1 ospfSetTrap 详细描述.....	3887
175.3.2 ospfConfigErrorType 详细描述.....	3888
175.4 告警节点详细描述.....	3888
175.4.1 ospfVirtIfStateChange 详细描述.....	3889
175.4.2 ospfNbrStateChange 详细描述.....	3890
175.4.3 ospfVirtNbrStateChange 详细描述.....	3891
175.4.4 ospfIfConfigError 详细描述.....	3891
175.4.5 ospfVirtIfConfigError 详细描述.....	3892
175.4.6 ospfIfAuthFailure 详细描述.....	3892
175.4.7 ospfVirtIfAuthFailure 详细描述.....	3892
175.4.8 ospfIfRxBadPacket 详细描述.....	3893

175.4.9 ospfVirtIfRxBadPacket 详细描述.....	3893
175.4.10 ospfTxRetransmit 详细描述.....	3893
175.4.11 ospfVirtIfTxRetransmit 详细描述.....	3894
175.4.12 ospfOriginateLsa 详细描述.....	3894
175.4.13 ospfMaxAgeLsa 详细描述.....	3895
175.4.14 ospfLsdbOverflow 详细描述.....	3895
175.4.15 ospfLsdbApproachingOverflow 详细描述.....	3895
175.4.16 ospfIfStateChange 详细描述.....	3896
175.4.17 ospfNssaTranslatorStatusChange 详细描述.....	3896
175.4.18 ospfRestartStatusChange 详细描述.....	3897
175.4.19 ospfNbrRestartHelperStatusChange 详细描述.....	3897
175.4.20 ospfVirtNbrRestartHelperStatusChange 详细描述.....	3898
176 P-BRIDGE-MIB.....	3899
176.1 功能简介.....	3899
176.2 表间关系.....	3899
176.3 单节点详细描述.....	3899
176.3.1 dot1dTrafficClassesEnabled 详细描述.....	3900
176.4 MIB Table 详细描述.....	3900
176.4.1 dot1dPortCapabilitiesTable 详细描述.....	3900
176.5 告警节点详细描述.....	3901
176.6 不支持节点.....	3901
177 PIM-BSR-MIB.....	3902
177.1 功能简介.....	3902
177.2 表间关系.....	3902
177.3 单节点详细描述.....	3902
177.4 MIB Table 详细描述.....	3902
177.4.1 pimBsrElectedBSRRPSetTable 详细描述.....	3902
177.5 告警节点详细描述.....	3904
178 PIM-STD-MIB.....	3905
178.1 功能简介.....	3905
178.2 表间关系.....	3905
178.3 单节点详细描述.....	3906
178.3.1 pimkeepalivePeriod 详细描述.....	3906
178.3.2 pimRegisterSuppressionTime 详细描述.....	3906
178.3.3 pimStarGEntries 详细描述.....	3906
178.3.4 pimStarGIEEntries 详细描述.....	3907
178.3.5 pimSGEntries 详细描述.....	3907
178.3.6 pimSGIEEntries 详细描述.....	3907
178.3.7 pimSGRptEntries 详细描述.....	3907
178.3.8 pimSGRptIEEntries 详细描述.....	3908
178.3.9 pimOutAsserts 详细描述.....	3908

178.3.10 pimInAsserts 详细描述.....	3908
178.3.11 pimLastAssertInterface 详细描述.....	3908
178.3.12 pimLastAssertGroupAddressType 详细描述.....	3909
178.3.13 pimLastAssertGroupAddress 详细描述.....	3909
178.3.14 pimLastAssertSourceAddressType 详细描述.....	3909
178.3.15 pimLastAssertSourceAddress 详细描述.....	3910
178.3.16 pimNeighborLossNotificationPeriod 详细描述.....	3910
178.3.17 pimNeighborLossCount 详细描述.....	3910
178.3.18 pimInvalidRegisterNotificationPeriod 详细描述.....	3911
178.3.19 pimInvalidRegisterMsgsRcvd 详细描述.....	3911
178.3.20 pimInvalidRegisterAddressType 详细描述.....	3911
178.3.21 pimInvalidRegisterOrigin 详细描述.....	3912
178.3.22 pimInvalidRegisterGroup 详细描述.....	3912
178.3.23 pimInvalidRegisterRp 详细描述.....	3912
178.3.24 pimInvalidJoinPruneNotificationPeriod 详细描述.....	3912
178.3.25 pimInvalidJoinPruneMsgsRcvd 详细描述.....	3913
178.3.26 pimInvalidJoinPruneAddressType 详细描述.....	3913
178.3.27 pimInvalidJoinPruneOrigin 详细描述.....	3913
178.3.28 pimInvalidJoinPruneGroup 详细描述.....	3914
178.3.29 pimInvalidJoinPruneRp 详细描述.....	3914
178.3.30 pimRPMMappingNotificationPeriod 详细描述.....	3914
178.3.31 pimRPMMappingChangeCount 详细描述.....	3914
178.3.32 pimInterfaceElectionNotificationPeriod 详细描述.....	3915
178.3.33 pimInterfaceElectionWinCount 详细描述.....	3915
178.3.34 pimRefreshInterval 详细描述.....	3915
178.3.35 pimDeviceConfigStorageType 详细描述.....	3916
178.4 MIB Table 详细描述.....	3916
178.4.1 pimInterfaceTable 详细描述.....	3916
178.4.2 pimNeighborTable 详细描述.....	3921
178.4.3 pimNbrSecAddressTable 详细描述.....	3923
178.4.4 pimStarGTable 详细描述.....	3924
178.4.5 pimStarGTable 详细描述.....	3929
178.4.6 pimSGTable 详细描述.....	3932
178.4.7 pimSGTable 详细描述.....	3937
178.4.8 pimSGRptTable 详细描述.....	3939
178.4.9 pimSGRptTable 详细描述.....	3940
178.4.10 pimGroupMappingTable 详细描述.....	3941
178.5 告警节点详细描述.....	3943
178.5.1 pimNeighborLoss 详细描述.....	3943
178.5.2 pimInvalidRegister 详细描述.....	3944
178.5.3 pimInvalidJoinPrune 详细描述.....	3944
178.5.4 pimRPMMappingChange 详细描述.....	3944

178.5.5 pimInterfaceElection 详细描述.....	3945
178.6 不支持节点.....	3945
179 Q-BRIDGE-MIB.....	3946
179.1 功能简介.....	3946
179.2 表间关系.....	3947
179.3 单节点详细描述.....	3947
179.3.1 dot1qVlanVersionNumber 详细描述.....	3947
179.3.2 dot1qMaxVlanId 详细描述.....	3948
179.3.3 dot1qMaxSupportedVlans 详细描述.....	3948
179.3.4 dot1qNumVlans 详细描述.....	3948
179.3.5 dot1qGvrpStatus 详细描述.....	3949
179.3.6 dot1qVlanNumDeletes 详细描述.....	3949
179.3.7 dot1qNextFreeLocalVlanIndex 详细描述.....	3950
179.3.8 dot1qConstraintSetDefault 详细描述.....	3950
179.3.9 dot1qConstraintTypeDefault 详细描述.....	3951
179.4 MIB Table 详细描述.....	3951
179.4.1 dot1qVlanCurrentTable 详细描述.....	3951
179.4.2 dot1qVlanStaticTable 详细描述.....	3954
179.4.3 dot1qPortVlanTable 详细描述.....	3956
179.4.4 dot1qLearningConstraintsTable 详细描述.....	3958
179.5 告警节点详细描述.....	3959
180 RFC1213-MIB.....	3960
180.1 功能简介.....	3960
180.2 表间关系.....	3960
180.3 单节点详细描述.....	3961
180.3.1 ipForwarding 详细描述.....	3961
180.3.2 ipDefaultTTL 详细描述.....	3961
180.3.3 ipInReceives 详细描述.....	3962
180.3.4 ipInHdrErrors 详细描述.....	3962
180.3.5 ipInAddrErrors 详细描述.....	3962
180.3.6 ipForwDatagrams 详细描述.....	3963
180.3.7 ipInUnknownProtos 详细描述.....	3963
180.3.8 ipInDiscards 详细描述.....	3963
180.3.9 ipInDelivers 详细描述.....	3964
180.3.10 ipOutRequests 详细描述.....	3964
180.3.11 ipOutDiscards 详细描述.....	3964
180.3.12 ipOutNoRoutes 详细描述.....	3965
180.3.13 ipReasmTimeout 详细描述.....	3965
180.3.14 ipReasmReqds 详细描述.....	3965
180.3.15 ipReasmOKs 详细描述.....	3966
180.3.16 ipReasmFails 详细描述.....	3966
180.3.17 ipFragOKs 详细描述.....	3966

180.3.18 ipFragFails 详细描述.....	3967
180.3.19 ipFragCreates 详细描述.....	3967
180.3.20 ipRoutingDiscards 详细描述.....	3967
180.3.21 icmpInMsgs 详细描述.....	3967
180.3.22 icmpInErrors 详细描述.....	3968
180.3.23 icmpInDestUnreachs 详细描述.....	3968
180.3.24 icmpInTimeExcds 详细描述.....	3968
180.3.25 icmpInParmProbs 详细描述.....	3968
180.3.26 icmpInSrcQuenchs 详细描述.....	3969
180.3.27 icmpInRedirects 详细描述.....	3969
180.3.28 icmpInEchos 详细描述.....	3969
180.3.29 icmpInEchoReps 详细描述.....	3969
180.3.30 icmpInTimestamps 详细描述.....	3970
180.3.31 icmpInTimestampReps 详细描述.....	3970
180.3.32 icmpInAddrMasks 详细描述.....	3970
180.3.33 icmpInAddrMaskReps 详细描述.....	3970
180.3.34 icmpOutMsgs 详细描述.....	3971
180.3.35 icmpOutErrors 详细描述.....	3971
180.3.36 icmpOutDestUnreachs 详细描述.....	3971
180.3.37 icmpOutTimeExcds 详细描述.....	3972
180.3.38 icmpOutParmProbs 详细描述.....	3972
180.3.39 icmpOutSrcQuenchs 详细描述.....	3972
180.3.40 icmpOutRedirects 详细描述.....	3972
180.3.41 icmpOutEchos 详细描述.....	3973
180.3.42 icmpOutEchoReps 详细描述.....	3973
180.3.43 icmpOutTimestamps 详细描述.....	3973
180.3.44 icmpOutTimestampReps 详细描述.....	3973
180.3.45 icmpOutAddrMasks 详细描述.....	3974
180.3.46 icmpOutAddrMaskReps 详细描述.....	3974
180.3.47 tcpRtoAlgorithm 详细描述.....	3974
180.3.48 tcpRtoMin 详细描述.....	3975
180.3.49 tcpRtoMax 详细描述.....	3975
180.3.50 tcpMaxConn 详细描述.....	3975
180.3.51 tcpActiveOpens 详细描述.....	3976
180.3.52 tcpPassiveOpens 详细描述.....	3976
180.3.53 tcpAttemptFails 详细描述.....	3976
180.3.54 tcpEstabResets 详细描述.....	3977
180.3.55 tcpCurrEstab 详细描述.....	3977
180.3.56 tcpInSegs 详细描述.....	3977
180.3.57 tcpOutSegs 详细描述.....	3977
180.3.58 tcpRetransSegs 详细描述.....	3978
180.3.59 tcpInErrs 详细描述.....	3978

180.3.60 tcpOutRsts 详细描述.....	3978
180.3.61 udpInDatagrams 详细描述.....	3978
180.3.62 udpNoPorts 详细描述.....	3979
180.3.63 udpInErrors 详细描述.....	3979
180.3.64 udpOutDatagrams 详细描述.....	3979
180.4 MIB Table 详细描述.....	3979
180.4.1 ipAddrTable 详细描述.....	3979
180.4.2 ipRouteTable 详细描述.....	3981
180.4.3 ipNetToMediaTable 详细描述.....	3984
180.4.4 tcpConnTable 详细描述.....	3986
180.4.5 udpTable 详细描述.....	3987
180.4.6 atTable 详细描述.....	3988
180.5 告警节点详细描述.....	3989
181 RIPv2-MIB.....	3990
181.1 功能简介.....	3990
181.2 表间关系.....	3990
181.3 单节点详细描述.....	3990
181.3.1 rip2GlobalRouteChanges 详细描述.....	3991
181.3.2 rip2GlobalQueries 详细描述.....	3991
181.4 MIB Table 详细描述.....	3991
181.4.1 rip2IfStatTable 详细描述.....	3991
181.4.2 rip2IfConfTable 详细描述.....	3993
181.4.3 rip2PeerTable 详细描述.....	3996
181.5 告警节点详细描述.....	3997
182 RMON-MIB.....	3998
182.1 功能简介.....	3998
182.2 表间关系.....	3998
182.3 单节点详细描述.....	3999
182.4 MIB Table 详细描述.....	3999
182.4.1 etherStatsTable 详细描述.....	3999
182.4.2 historyControlTable 详细描述.....	4002
182.4.3 etherHistoryTable 详细描述.....	4004
182.4.4 alarmTable 详细描述.....	4007
182.4.5 eventTable 详细描述.....	4010
182.4.6 logTable 详细描述.....	4012
182.5 告警节点详细描述.....	4013
182.5.1 risingAlarm 详细描述.....	4013
182.5.2 fallingAlarm 详细描述.....	4014
183 RMON2-MIB.....	4015
183.1 功能简介.....	4015
183.2 表间关系.....	4015

183.3 单节点详细描述.....	4016
183.3.1 protocolDirLastChange 详细描述.....	4016
183.4 MIB Table 详细描述.....	4016
183.4.1 protocolDirTable 详细描述.....	4016
183.4.2 hlHostControlTable 详细描述.....	4021
183.4.3 nlHostTable 详细描述.....	4025
184 SAVI-MIB.....	4028
184.1 功能简介.....	4028
184.2 表间关系.....	4028
184.3 单节点详细描述.....	4028
184.4 MIB Table 详细描述.....	4028
184.4.1 saviObjectsSystemTable 详细描述.....	4028
184.4.2 saviObjectsIfTable 详细描述.....	4036
184.4.3 saviObjectsBindingTable 详细描述.....	4038
184.4.4 saviObjectsFilteringTable 详细描述.....	4040
184.5 告警节点详细描述.....	4041
185 SNMP-FRAMEWORK-MIB.....	4042
185.1 功能简介.....	4042
185.2 表间关系.....	4042
185.3 单节点详细描述.....	4042
185.3.1 snmpEngineID 详细描述.....	4043
185.3.2 snmpEngineBoots 详细描述.....	4043
185.3.3 snmpEngineTime 详细描述.....	4043
185.3.4 snmpEngineMaxMessageSize 详细描述.....	4044
185.4 告警节点详细描述.....	4044
186 SNMP-MPD-MIB.....	4045
186.1 功能简介.....	4045
186.2 表间关系.....	4045
186.3 单节点详细描述.....	4045
186.3.1 snmpUnknownSecurityModels 详细描述.....	4046
186.3.2 snmpInvalidMsgs 详细描述.....	4046
186.3.3 snmpUnknownPDUHandlers 详细描述.....	4047
186.4 MIB Table 详细描述.....	4047
186.5 告警节点详细描述.....	4047
187 SNMP-NOTIFICATION-MIB.....	4048
187.1 功能简介.....	4048
187.2 表间关系.....	4048
187.3 单节点详细描述.....	4049
187.4 MIB Table 详细描述.....	4049
187.4.1 snmpNotifyTable.....	4049
187.4.2 snmpNotifyFilterProfileTable.....	4051

187.4.3 snmpNotifyFilterTable.....	4053
187.5 告警节点详细描述.....	4055
188 SNMP-TARGET-MIB.....	4056
188.1 功能简介.....	4056
188.2 表间关系.....	4056
188.3 单节点详细描述.....	4057
188.3.1 snmpTargetSpinLock 详细描述.....	4058
188.3.2 snmpUnavailableContexts 详细描述.....	4059
188.3.3 snmpUnknownContexts 详细描述.....	4059
188.4 MIB Table 详细描述.....	4059
188.4.1 snmpTargetAddrTable 详细描述.....	4059
188.4.2 snmpTargetParamsTable 详细描述.....	4063
188.5 告警节点详细描述.....	4066
189 SNMP-USER-BASED-SM-MIB.....	4067
189.1 功能简介.....	4067
189.2 表间关系.....	4067
189.3 单节点详细描述.....	4067
189.3.1 usmStatsUnsupportedSecLevels 详细描述.....	4068
189.3.2 usmStatsNotInTimeWindows 详细描述.....	4068
189.3.3 usmStatsUnknownUserNames 详细描述.....	4068
189.3.4 usmStatsUnknownEngineIDs 详细描述.....	4069
189.3.5 usmUserSpinLock 详细描述.....	4069
189.3.6 usmStatsWrongDigests 详细描述.....	4069
189.3.7 usmStatsDecryptionErrors 详细描述.....	4070
189.4 MIB Table 详细描述.....	4070
189.4.1 usmUserTable 详细描述.....	4070
189.5 告警节点详细描述.....	4082
190 SNMP-VIEW-BASED-ACM-MIB.....	4083
190.1 功能简介.....	4083
190.2 表间关系.....	4083
190.3 单节点详细描述.....	4084
190.3.1 vacmViewSpinLock 详细描述.....	4084
190.4 MIB Table 详细描述.....	4084
190.4.1 vacmContextTable 详细描述.....	4084
190.4.2 vacmSecurityToGroupTable 详细描述.....	4085
190.4.3 vacmAccessTable 详细描述.....	4087
190.4.4 vacmViewTreeFamilyTable 详细描述.....	4091
190.5 告警节点详细描述.....	4094
191 SNMPv2-MIB.....	4095
191.1 功能简介.....	4095
191.2 表间关系.....	4095

191.3 单节点详细描述.....	4095
191.3.1 sysDescr 详细描述.....	4095
191.3.2 sysObjectID 详细描述.....	4096
191.3.3 sysUpTime 详细描述.....	4096
191.3.4 sysContact 详细描述.....	4096
191.3.5 sysName 详细描述.....	4097
191.3.6 sysLocation 详细描述.....	4097
191.3.7 sysServices 详细描述.....	4098
191.3.8 snmplnPkts 详细描述.....	4098
191.3.9 snmpOutPkts 详细描述.....	4099
191.3.10 snmplnBadVersions 详细描述.....	4099
191.3.11 snmplnBadCommunityNames 详细描述.....	4099
191.3.12 snmplnBadCommunityUses 详细描述.....	4100
191.3.13 snmplnASNParseErrs 详细描述.....	4100
191.3.14 snmplnTooBigs 详细描述.....	4100
191.3.15 snmplnNoSuchNames 详细描述.....	4101
191.3.16 snmplnBadValues 详细描述.....	4101
191.3.17 snmplnReadOnlyls 详细描述.....	4101
191.3.18 snmplnGenErrs 详细描述.....	4102
191.3.19 snmplnTotalReqVars 详细描述.....	4102
191.3.20 snmplnTotalSetVars 详细描述.....	4102
191.3.21 snmplnGetRequests 详细描述.....	4103
191.3.22 snmplnGetNexts 详细描述.....	4103
191.3.23 snmplnSetRequests 详细描述.....	4103
191.3.24 snmplnGetResponses 详细描述.....	4104
191.3.25 snmplnTraps 详细描述.....	4104
191.3.26 snmpOutTooBigs 详细描述.....	4104
191.3.27 snmpOutNoSuchNames 详细描述.....	4105
191.3.28 snmpOutBadValues 详细描述.....	4105
191.3.29 snmpOutGenErrs 详细描述.....	4105
191.3.30 snmpOutGetRequests 详细描述.....	4106
191.3.31 snmpOutGetNexts 详细描述.....	4106
191.3.32 snmpOutSetRequests 详细描述.....	4106
191.3.33 snmpOutGetResponses 详细描述.....	4107
191.3.34 snmpOutTraps 详细描述.....	4107
191.3.35 snmpEnableAuthenTraps 详细描述.....	4107
191.3.36 snmpSilentDrops 详细描述.....	4108
191.3.37 snmpTrapOID 详细描述.....	4108
191.3.38 snmpTrapEnterprise 详细描述.....	4108
191.3.39 snmpSetSerialNo 详细描述.....	4109
191.4 告警节点详细描述.....	4109
191.4.1 coldStart 详细描述.....	4109

191.4.2 warmStart 详细描述.....	4109
191.4.3 authenticationFailure 详细描述.....	4110
192 TCP-MIB.....	4111
192.1 功能简介.....	4111
192.2 表间关系.....	4112
192.3 单节点详细描述.....	4112
192.3.1 tcpRtoAlgorithm 详细描述.....	4113
192.3.2 tcpRtoMin 详细描述.....	4113
192.3.3 tcpRtoMax 详细描述.....	4114
192.3.4 tcpMaxConn 详细描述.....	4114
192.3.5 tcpActiveOpens 详细描述.....	4115
192.3.6 tcpPassiveOpens 详细描述.....	4115
192.3.7 tcpAttemptFails 详细描述.....	4116
192.3.8 tcpEstabResets 详细描述.....	4116
192.3.9 tcpCurrEstab 详细描述.....	4116
192.3.10 tcpInSegs 详细描述.....	4117
192.3.11 tcpOutSegs 详细描述.....	4117
192.3.12 tcpRetransSegs 详细描述.....	4117
192.3.13 tcpInErrs 详细描述.....	4117
192.3.14 tcpOutRsts 详细描述.....	4118
192.3.15 tcpHCInSegs 详细描述.....	4118
192.3.16 tcpHCOutSegs 详细描述.....	4118
192.4 MIB Table 详细描述.....	4118
192.4.1 tcpConnTable 详细描述.....	4118
192.4.2 tcpConnectionTable 详细描述.....	4120
192.4.3 tcpListenerTable 详细描述.....	4125
193 UDP-MIB.....	4130
193.1 功能简介.....	4130
193.2 表间关系.....	4130
193.3 单节点详细描述.....	4131
193.3.1 udpInDatagrams 详细描述.....	4131
193.3.2 udpNoPorts 详细描述.....	4131
193.3.3 udpInErrors 详细描述.....	4131
193.3.4 udpOutDatagrams 详细描述.....	4132
193.3.5 udpHCInDatagrams 详细描述.....	4132
193.3.6 udpHCOutDatagrams 详细描述.....	4132
193.4 MIB Table 详细描述.....	4133
193.4.1 udpTable 详细描述.....	4133
193.4.2 udpEndpointTable 详细描述.....	4133
194 VRRP-MIB.....	4140
194.1 功能简介.....	4140

194.2 表间关系.....	4141
194.3 单节点详细描述.....	4142
194.3.1 vrrpNodeVersion 详细描述.....	4142
194.3.2 vrrpTrapPacketSrc 详细描述.....	4142
194.3.3 vrrpTrapAuthErrorType 详细描述.....	4142
194.3.4 vrrpRouterChecksumErrors 详细描述.....	4143
194.3.5 vrrpRouterVersionErrors 详细描述.....	4143
194.3.6 vrrpRouterVrIdErrors 详细描述.....	4143
194.4 MIB Table 详细描述.....	4143
194.4.1 vrrpOperTable 详细描述.....	4143
194.4.2 vrrpAssolpAddrTable 详细描述.....	4148
194.4.3 vrrpRouterStatsTable 详细描述.....	4149
194.5 告警节点详细描述.....	4151
194.5.1 vrrpTrapNewMaster 详细描述.....	4152
194.5.2 vrrpTrapAuthFailure 详细描述.....	4152
195 VRRPV3-MIB.....	4153
195.1 功能简介.....	4153
195.2 表间关系.....	4153
195.3 单节点详细描述.....	4153
195.3.1 vrrpv3RouterChecksumErrors 详细描述.....	4154
195.3.2 vrrpv3RouterVersionErrors 详细描述.....	4154
195.3.3 vrrpv3RouterVrIdErrors 详细描述.....	4154
195.3.4 vrrpv3GlobalStatisticsDiscontinuityTime 详细描述.....	4155
195.4 MIB Table 详细描述.....	4155
195.4.1 vrrpv3OperationsTable 详细描述.....	4155
195.4.2 vrrpv3AssociatedIpAddrTable 详细描述.....	4158
195.4.3 vrrpv3StatisticsTable 详细描述.....	4159
195.5 告警节点详细描述.....	4162
195.5.1 vrrpv3NewMaster 详细描述.....	4162
195.5.2 vrrpv3ProtoError 详细描述.....	4162