oDesktop

AddMessageClearMessagesCloseAllWindowsCloseProjectCloseProjectNoForceDeleteProjectDoesRegistryValueExistDownloadJobResultsEnableAutoSaveExportOptionsFilesGetActiveProjectGetAutoSaveEnabled

GetBuildDateTimeString GetDefaultUnit GetDistributedAnalysisMachines

GetDistributedAnalysisMachinesForDesignType GetExeDir GetGDIObjectCount

GetLibraryDirectory GetLocalizationHelper GetMessages

GetPersonalLibDirectoryGetProcessIDGetProjectDirectoryGetProjectListGetProjectsGetRegistryIntGetRegistryStringGetScriptingToolsHelperGetSysLibDirectory

GetTempDirectory

GetTool

GetUserLibDirectory

GetTool

GetVersion LaunchJobMonitor NewProject
OpenAndConvertProject OpenMultipleProjects OpenProject
OpenProjectWithConversion PageSetup PageSecuring

OpenProjectWithConversionPageSetupPauseRecordingPauseScriptPrintQuitApplicationRefreshJobMonitorResetLoggingRestoreProjectArchiveRestoreWindowResumeRecordingRunACTWizardScript

Restore window
Restore Window
Restore Window
Restore Window
RunProgram
RunScript
RunScript
RunScript
SelectScheduler
SetActiveProject
SetActiveProjectByPath
SetLibraryDirectory
SetProjectDirectory
SetRegistryFromFile

SetRegistryInt SetRegistryString SetTempDirectory

ShowDockingWindow Sleep SubmitJob

oProject

TileWindows

AddDatasetAddMaterialAnalyzeAllChangePropertyClearMessagesCloneMaterialCloseCopyDesignCutDesign

DeleteDatasetDeleteDesignDeleteToolObjectEditDatasetEditMaterialExportDatasetExportMaterialGetActiveDesignGetArrayVariablesGetConfigurableDataGetDefinitionManagerGetDependentFilesGetDesignGetDesignsGetEDBHandle

GetLegacyNameGetNameGetPathGetPropertiesGetPropertyValueGetTopDesignListGetVariableValueGetVariablesImportDataset

InsertDesign InsertDesignWithWorkflow InsertToolObject
Paste PasteDesignBlock Redo

RemoveAllUnusedDefinitions RemoveMaterial RemoveUnusedDefinitions

Rename Save SaveAs

SaveAsStandAloneProject SaveProjectArchive SetActiveDefinitionEditor

SetActiveDesign SetPropertyValue SetVariableValue
SimulateAll Undo UpdateDefinitions

oDefinitionManager

AddComponent AddDataset AddFootprint

AddMaterial AddPadstack AddScript AddSurfaceMaterial AddSymbol ChangeProperty CloneMaterial CreateComponentData DeleteDataset DoesMaterialExist DoesSurfaceMaterialExist EditComponent EditDataset **EditFootprint EditMaterial**

EditPadstack EditScript EditSurfaceMaterial EditSymbol ExportComponent ExportDataset **ExportFootprint ExportMaterial** ExportPadstack **ExportScript** ExportSurfaceMaterial ExportSymbol

GetInUseProjectMaterialNames GetManager GetMaterialNamesInConfiguredLibraries

GetProjectMaterialNames GetProperties GetPropertyValue ModifyLibraries **ImportDataset** RemoveComponent RemoveFootprint RemoveMaterial RemovePadstack RemoveScript RemoveSurfaceMaterial RemoveSymbol

SetPropertyValue UpdateDefinition UpdateDefinitionFromLib

oDesign

AddDataset Analyze **AnalyzeAll** AnalyzeAllNominal ApplyMeshOps ChangeProperty ConstructVariationString Create2DDesign DeleteDataset

DeleteFieldVariation DeleteFullVariation DeleteLinkedDataVariation

DeleteVariation EditDataset EditNotes

ExportConvergence ExportDataset ExportMatrixData ExportMeshStats ExportNMFData ExportNetworkData ExportProfile GenerateMesh **GetArrayVariables** GetConfigurableData GetData GetDataVersion GetDesignType GetDesignValidationInfo GetModule GetName **GetNominalVariation** GetNoteText GetPostProcessingVariables GetProperties GetPropertyValue

GetVariableValue **GetVariables** GetVariationVariableValue

ImportDataset Paste Redo

RenameDesignInstance RunToolkit SetActiveEditor SetAllowMaterialOverride SetBackgroundMaterial SetDesignSettings **SetObjectTemperature SetPropertyValue** SetVariableValue SimulateLink Solve StopSimLink Undo ValidateDesign ValidateLink

Editor

CreateEllipse

AddViewOrientation AlignFaces AssignMaterial AssignSurfaceMaterial BreakUDMConnection Chamfer

CloseAllWindows ChangeProperty CleanUpModel CoverLines Connect Copy CoverSurfaces Create3DComponent CreateBondwire CreateBox CreateCircle CreateComponent CreateCone CreateCutplane CreateCylinder

CreateEntityList CreateEquationSurface CreateFaceCS CreateGroup

CreateHelix CreateObjectCS

CreateObjectFromEdges CreateObjectFromFace CreateObjectFromFaces CreatePoint

CreateEquationCurve

CreatePolyline CreateRectangle CreateRegion CreateRegularPolygon CreateRegularPolyhedron CreateRelativeCS
CreateSphere CreateSpiral CreateTorus

CreateUserDefinedModel CreateUserDefinedPart CustomGeometryOperation

Defeature DeletPolylinePoint Delete

DeleteEmptyGroupsDeleteLastOperationDeleteOperationDeletePolylinePointDetachEdgeDetachEdges

DetachFace DetachFaces DoModalValidationForTest

DoesGeometryMatchForTest DuplicateAlongLine DuplicateAroundAxis

DuplicateMirrorEdit3DComponentEdit3DComponentDefinitionEditEntityListEditFaceCSEditNativeComponentDefinition

EditObjectCS EditPolyline EditRelativeCS

Export ExportGDSII ExportModelImageToFile

Fillet FitAll FlattenGroup
GenerateAllUserDefinedModels GenerateFacetDataForModel GenerateHistory

GenerateUserDefinedModel Get3DComponentDefinitionNames Get3DComponentInstanceNames
Get3DComponentMaterialNames Get3DComponentMaterialProperties Get3DComponentParameters
Get3DComponentPartNames GetActiveCoordinateSystem GetBodyNamesByPosition

GetCoordinateSystems GetEdgeByPosition GetEdgeIDFromNameForFirstOperation

GetEdgeIDsFromFace GetEdgeIDsFromObject GetEdgeLength
GetEdgePositionAtNormalizedParameter GetEntityListIDByName GetFaceArea

GetFaceByPosition GetFaceCenter GetFaceIDFromNameForFirstOperation

GetFaceIDs GetFaceIDsOfSheet GetFullGeometry
GetGeometryModelerMode GetGroupSubmodelNames GetMatchedObjectName

GetModelBoundingBox GetModelDrawAttributes GetModelUnits
GetNumObjects GetObjectIDByName GetObjectNameByEdgeID GetObjectNameByFaceID GetObjectNameByID
GetObjectNameByVertexID GetObjectShapeType GetObjectsByMaterial

GetObjectsInGroup GetOperationIndex GetPartsForUserDefinedModel

GetPointsGetPropertiesGetPropertyValueGetRelativeCoordinateSystemsGetSelectionsGetSubGroupsInGroupGetUserPositionGetVertexIDFromNameForFirstOperationGetVertexIDsFromEdgeGetVertexIDsFromFaceGetVertexIDsFromObjectGetVertexPosition

GetWireBodyNames HealObject Import
ImportDXF ImportFromClipboard ImportGDSII
Imprint ImprintProjection Insert3DComponent

InsertComponent InsertNativeComponent InsertPolylineSegment
Intersect Make3DComponentIndenpendent Mirror

MoveMoveCSToEndMoveEdgesMoveEntityToGroupMoveFacesObjectExistsOffsetFacesOpenExternalEditorPageSetupPastePerformExplicitSubtractionsProjectSheetProjectUDPParametersToValidPlaneProjectUDPParametersToValidPlane2PurgeHistory

 $Refresh All User Defined Model From \\ Refresh User Defined Model From \\$

RemoveBadEdges RemoveBadFaces RemoveBadVertices

RenamePart ReplaceWith3DComponent Rotate

Scale Section SendParametersAndGenerateUserDefineModel

SeparateBody SetModelUnits SetModelValidationSettings

SetPropertyValue SetTopDownViewDirectionForActiveView SetTopDownViewDirectionForAllViews

SetWCSShowWindowSimplifySplitStitchSubtract

SweepAlongPath SweepAlongVector SweepAroundAxis SweepFacesAlongNormal SweepFacesAlongNormalWithAttributes ThickenSheet UncoverFaces

Update Component Definition

Validate3DComponent

Write History Tree Layout For Test

Ungroup

Update Priority List

WrapSheet

Unite

UpgradeVersion

WriteAttributesBlockForTest

oTool-NdExplorer

CheckCausality ExportNetworkData ExportFullWaveSpice ExtractImpulseResponse ExportNMFData

Set Export Touch stone Options

oTool-ImportExport

ImportANF

ImportAutoCAD
ImportGDSII
ImportIDFandMerge

ImportXFL

ImportANFV2
ImportEDB
ImportGerber

ImportIPC

ImportAWRMicrowaveOffice

ImportExtracta
ImportIDF
ImportODB

oModule-BoundarySetup

AddAssignmentToBoundary

AssignGroundNet AssignSignalNet AssignTerminals DeleteAllBoundaries EditInfiniteGround EditThinConductor

GetNumExcitations RenameBoundary

SetMaterialThresholds

Assign2DTerminals AssignInfiniteGround

AssignSink

AssignThinConductor DeleteAllExcitations

EditNet

GetExcitationAssignment ReassignBoundary

ReprioritizeNetTypes

ToggleNet

AssignFloatingNet

AssignNet
AssignSource
AutoIdentifyNets
DeleteBoundaries
EditTerminal

GetExcitations

RemoveAssignmentFromBoundary SetConductivityThreshold

ToggleTerminal

oModule-MeshSetup

AssignApplyCurvlinearElementsOp

AssignCylindricalGapOp AssignEdgeCutLayerOp AssignRotationalLayerOp AssignTrueSurfOp EditCloneOp

EditDefeatureOp
EditLengthOp
EditSkinDepthOp
GetOperationNames

RenameOp

AssignCloneOp
AssignDefeatureOp
AssignLengthOp
AssignSkinDepthOp
DeleteOp

DeleteOp EditCurvatureExtractionOp EditDensityControlOp EditModelResolutionOp EditSurfPriorityOp

EditApplyCurvlinearElementsOp EditCylindricalGapOp EditEdgeCutLayerOp EditRotationalLayerOp

AssignCurvatureExtractionOp

AssignDensityControlOp

AssignModelResolutionOp

AssignSurfPriorityForTauOp

EditTrueSurfOp ReassignOp

oModule-AnalysisSetup

CopySetup
DeleteSweep
EditSweep
GetSetups

CopySweep EditCircuitSettings ExportCircuit GetSweepCount

InitialMeshSettings

DeleteSetups EditSetup GetProblemTypes GetSweeps InsertSetup
PasteSweep
RevertAllToInitial

Revert Setup To Initial Temperature

InsertSweep RenameSetup RevertAllToInitialTemperature PasteSetup RenameSweep RevertSetupToInitial

oModule-Optimetrics

CopySetup
EditSetup
ExportDOELocalSensitivityCurve
ExportDOEResponseSurface
ExportOptimetricsResult
ExportRespSurfacePlotToFile

ExportRespSurfaceVerificationPoints GetOptimetricResultRowCount

ImportSetup RenameSetup DeleteSetups DistributedAnalyzeSetup
EnableSetup ExportDOELocalSensitivity
ExportDOEResponseCurve ExportDOEResponseCurveSlices
ExportDXConfigFile ExportOptimetricsProfile
ExportParametricResults ExportRespSurfaceMinMaxTable

ExportRespSurfaceRefinePoints ExportRespSurfaceResponsePoints
GenerateVariationData GetOptimetricResult
GetSetupNames GetSetupNamesByType

InsertSetup PasteSetup SolveAllSetup SolveSetup

oModule-Solutions

DeleteSolutionVariation GetAvailableVariations

Get Network Data Solution Definition

HasMatrixData TDROnReport EditSources FFTOnReport

GetEditSourcesCount GetNetworkDataSolution

GetValidISolutionList HasFields HasMesh ListVariations

oModule-FieldsReporter

AddMarkerAddMarkerToPlotAddNamedExprAddNamedExpressionCalcOpCalcReadCalcStackCalcWriteCalculatorReadCalculatorWriteChangeGeomSettingsClcEval

ClcMaterialClcMaterialValueClearAllMarkersClearAllNamedExprCopyNamedExprToStackCreateFieldPlotDeleteFieldPlotDeleteMarkerDeleteNamedExprDeleteUneditablePlotDoesNamedExpressionExistsDumpCalculatorStack

EnterComplexEnterComplexVectorEnterCoordEnterEdgeEnterLineEnterOutputVarEnterPointEnterQtyEnterScalarEnterScalarFuncEnterSurfEnterVectorEnterVectorFuncEnterVolExportFieldPlot

ExportMarkerTableExportOnGridExportPlotImageToFileExportToFileGetFieldFolderNamesGetFieldPlotNames

GetMeshPlotNames GetTopEntryValue HideAntennaParameterOverlay
HidePolarPlot HideRadiatedPlotOverlay LoadNamedExpressions
ModifyFieldPlot ReassignFieldPlot RenameFieldPlot

RenamePlotFolder SaveFieldsPlots SaveNamedExpressions
SetFieldPlotSettings SetFieldTypeSettings SetPlotFolderSettings

SetPlotsSolutionContext SetPlotsViewSolutionContext ShowAntennaParameterOverlay

ShowPolarPlot ShowRadiatedPlotOverlay Test
UpdateAllFieldsPlots UpdateQuantityFieldsPlots XForm

oModule-ReduceMatrix

AlphaNumericMatrixDeleteRMDeleteRMODupRMDupRMAddOpEditRMInsertRMRMAddOpRenameRM

RenameRMO ReorderMatrix

oModule-ReportSetup

AddAllEyeMeasurements AddCartesianLimitLine AddCartesianLimitLineFromCurve

AddCartesianLimitLineFromEquation AddCartesianXMarker AddCartesianYMarker

AddCartesianYMarkerToStackAddDeltaMarkerAddMarkerAddNoteAddTraceCharacteristicsAddTracesApplyReportTemplateChangePropertyClearAllMarkers

ClearAllTraceCharacteristics CloneReportsFromDatasetSolution CompareReportDataForRegressionTesting CompareTracesForRegressionTesting CompareTracesForRegressionTesting CompareTracesForRegressionTesting2

CopyPlotSettingsCopyReportDefinitionsCopyReportsDataCopyTraceDefinitionsCopyTracesDataCreateReport

CreateReportFromFileCreateReportFromTemplateCreateReportOfAllQuantitiesDeleteAllReportsDeleteReportsDeleteTraceCharacteristicsDeleteTracesDoesSupportTraceCharacteristicsDumpAllReportsData

DumpReportDataForRegressionTestingEditCartesianXMarkerEditCartesianYMarkerEditMarkerExportEyeMaskViolationExportImageToFileExportReportDataToFileExportTableToFileExportToFile

ExportReportDataToFile ExportTableToFile ExportToFile

ExportUniformPointsToFile GetAllCategories GetAllQuantities

ContableToFile ExportToFile ContableToFile GetAllQuantities

GetAllReportNames GetAvailableDisplayTypes GetAvailableReportTypes
GetAvailableSolutions GetDisplayType GetDynLinkIntrinsicVariables

GetDynLinkQtyData GetDynLinkQtyValueState GetDynLinkTraces

GetDynLinkVariableValues GetPropertyValue GetQtyExpressionsForSourceTrace

GetReportSummaryForRegressionTesting GetReportTraceNames GetSolutionContexts
GetSolutionDataPerVariation GroupPlotCurvesByGroupingStrategy ImportIntoReport

 $ImportReportDataIntoReport \\ MovePlotCurvesToGroup \\ MovePlotCurvesToNewGroup \\$

 OpenWindowForAllReports
 OpenWindowForReports
 PastePlotSettings

 PasteReports
 PasteReportsWithLegacyNames
 PasteTraces

 PasteTracesWithLegacyNames
 RenameReport
 RenameTrace

 PasteTracesWithLegacyNames
 RenameTrace

ResetPlotSettings SavePlotSettingsAsDefault SetLinkOutputTraces
UngroupPlotCurvesInGroup UpdateAllReports UpdateReports

UpdateTracesContextAndSweeps

oModule-OutputVariable

CreateOutputVariable DeleteOutputVariable DoesOutputVariableExist
EditOutputVariable ExportOutputVariables GetOutputVariableValue
GetOutputVariables ImportOutputVariables

oModule-UserDefinedSolutionModule

CreateUserDefinedSolution DeleteUserDefinedSolutions EditUserDefinedSolution

GetUserDefinedSolutionProperties