

Button 1 : cycle preset times
15 / 20 / 25 / 30
Selecting :
blue button
Start
hand goes
from 15 → 0
button 2
short press
: Preset selected /
start timer
button 2
hold
(reset)
button 2
hold (reset)
running :
green led
button 2
short
Press
/
button 2
hold (reset)
button 2
short
button 2
short
Countdown
reaches 0
Paused :
blue led
finished :
red led