| Rango de direcciones |     |     |     |     |     |     |     |     |  |
|----------------------|-----|-----|-----|-----|-----|-----|-----|-----|--|
| A15                  | A14 | A13 | A12 | A11 | A10 | A09 | A08 | A07 |  |
| 0                    | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   |  |
| 1                    | 1   | 1   | 1   | 1   | 1   | 1   | 1   | 1   |  |
| 0                    | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   |  |
| 1                    | 1   | 1   | 1   | 1   | 1   | 1   | 1   | 1   |  |
| 0                    | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   |  |
| 1                    | 1   | 1   | 1   | 1   | 1   | 1   | 1   | 1   |  |
| 0                    | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   |  |
| 1                    | 1   | 1   | 1   | 1   | 1   | 1   | 1   | 1   |  |

| Componente       |     |     |     |     |     |     |     |
|------------------|-----|-----|-----|-----|-----|-----|-----|
| Componente       | A00 | A01 | A02 | A03 | A04 | A05 | A06 |
| Módulo RAM 1     | 0   | 0   | 0   | 0   | 0   | 0   | 0   |
| IVIOGGIO RAIVI I | 1   | 1   | 1   | 1   | 1   | 1   | 1   |
| Módulo RAM 2     | 0   | 0   | 0   | 0   | 0   | 0   | 0   |
|                  | 1   | 1   | 1   | 1   | 1   | 1   | 1   |
| Módulo RAM 3     | 0   | 0   | 0   | 0   | 0   | 0   | 0   |
| IVIOUUIO RAIVI 3 | 1   | 1   | 1   | 1   | 1   | 1   | 1   |
| LIBRE            | 0   | 0   | 0   | 0   | 0   | 0   | 0   |
| LIBRE            | 1   | 1   | 1   | 1   | 1   | 1   | 1   |