

## **1.1.2** EXTI lab



## Objective

- Learn how to setup input pin with EXTI in CubeMX
- How to Generate Code in CubeMX and use HAL functions


## Goal


- Configure GPIO and EXTI pin in CubeMX and Generate Code
- Add into project Callback function and function which turn on led
- Verify the correct functionality by pressing button which turns on LED



### Configure EXTI to turn on LED 24 1.1.2


- Create project in CubeMX
  - Menu > File > New Project
  - Select STM32F4 > STM32F429/439 > LQFP144 > STM32F439ZITx
- Configure LED pin as GPIO Output
- Configure Button pin as GPIO\_EXTIX









- Create project in CubeMX
  - Menu > File > New Project
  - Select STM32F4 > STM32F429/439 > LQFP144 > STM32F439ZITx
- Configure LED pin as GPIO Output
- Configure Button pin as GPIO\_EXTIX








- In order to run on maximum frequency, setup clock system
- Details in lab 0






- GPIO Configuration
  - TAB>Configuration>System>GPIO



#### GPIO(Pin) Configuration


Select External Interrupt Mode with Rising edge trigger detection

- No pull-up or pull-down
- PG14 can be let in default settings
- Button OK






- NVIC Configuration
  - We need to enable interrupts for EXTI
  - TAB>Configuration>System>NVIC




- NVIC Configuration
  - Enable interrupt for **EXTI Line0**
  - Button OK







- Now we set the project details for generation
  - Menu > Project > Project Settings
  - Set the project name
  - Project location
  - Type of toolchain
- Now we can Generate Code
  - Menu > Project > Generate Code





























- Now we open the project in our IDE
  - The functions we want to put into main.c
  - Between /\* USER CODE BEGIN 4 \*/ and /\* USER CODE END 4 \*/ tags
  - We create function which will handle the EXTI interrupts
- The HAL callback function for EXTI
  - void HAL GPIO EXTI Callback(uint16 t GPIO Pin)
- For LED turn on we need to use this functions
  - HAL GPIO WritePin



- Now we open the project in our IDE
  - The functions we want to put into main.c
  - Between /\* USER CODE BEGIN 4 \*/ and /\* USER CODE END 4 \*/ tags
  - We create function which will handle the EXTI interrupts
- The HAL callback function for EXTI
  - void HAL GPIO EXTI Callback(uint16 t GPIO Pin)
- For LED turn on we need to use this functions
  - HAL GPIO WritePin

```
/* USER CODE BEGIN 4 */
void HAL_GPIO_EXTI_Callback(uint16_t GPIO_Pin)
  if(GPIO Pin == GPIO PIN 0) {
    HAL_GPIO_WritePin(GPIOG, GPIO_PIN_14, GPIO_PIN_SET);
  } else {
       NOP();
  USER CODE END 4 */
```

