

#### Lecture #8

#### **MIPS**

Part II: More Instructions



#### **Details**

- Notes Credit:
  - All notes are by A/P Aaron Tan
- Lecture Link (Please bookmark):

https://nus-

sg.zoom.us/j/84884962542?pwd=NEF6SVdQUUgwWmRw UmgvSy9WTINDQT09

Meeting ID: 848 8496 2542

Passcode: 111761

#### Lecture #8: MIPS Part 2: More Instructions

- 1. Memory Organisation (General)
  - 1.1 Memory: Transfer Unit
  - 1.2 Memory: Word Alignment
- 2. MIPS Memory Instructions
  - 2.1 Memory Instruction: Load Word
  - 2.2 Memory Instruction: Store Word
  - 2.3 Load and Store Instructions
  - 2.4 Memory Instruction: Others
  - 2.5 Example: Array
  - 2.6 Common Questions
  - 2.7 Example: Swapping Elements

#### Lecture #8: MIPS Part 2: More Instructions

- 3. Making Decisions
  - 3.1 Conditional Branch: beg and bne
  - 3.2 Unconditional Jump: j
  - 3.3 IF statement
  - 3.4 Exercise #1: IF statement
- 4. Loops
  - 4.1 Exercise #2: FOR loop
  - 4.2 Inequalities
- 5. Array and Loop
- 6. Exercises

## 1. Memory Organisation (General)

- The main memory can be viewed as a large, single-dimension array of memory locations.
- Each location of the memory has an address, which is an index into the array.
  - Given a k-bit address, the address space is of size  $2^k$ .
- The memory map on the right contains one byte (8 bits) in every location/address.
  - This is called byte addressing

Addres	s Content
0	8 bits
1	8 bits
2	8 bits
3	8 bits
4	8 bits
5	8 bits
6	8 bits
7	8 bits
8	8 bits
9	8 bits
10	8 bits
11	8 bits

## 1.1 Memory: Transfer Unit

- Using distinct memory address, we can access:
  - a single byte (byte addressable) or
  - a single word (word addressable)

#### Word is:


- Usually 2<sup>n</sup> bytes
- The common unit of transfer between processor and memory
- Also commonly coincide with the register size, the integer size and instruction size in most architectures

#### 1.2 Memory: Word Alignment

#### Word alignment:

 Words are aligned in memory if they begin at a byte address that is a multiple of the number of bytes in a word.

Example: If a word consists of 4 bytes, then:




#### 2. MIPS Memory Instructions

- MIPS is a load-store register architecture
  - 32 registers, each 32-bit (4-byte) long
  - Each word contains 32 bits (4 bytes)
  - Memory addresses are 32-bit long

Name	Examples	Comments
32 registers	\$s0-\$s7, \$t0-\$t9, \$zero, \$a0- \$a3, \$v0-\$v1, \$gp, \$fp, \$sp, \$ra, \$at	Fast processor storage for data. In MIPS, data must be in registers to perform arithmetic.
2 <sup>30</sup> memory words	Mem[0], Mem[4],, Mem[4294967292]	Accessed only by data transfer instructions.  MIPS uses byte addresses, so consecutive words differ by 4.  Memory holds data structures, such as arrays, and spilled registers, such as those saved on procedure calls.

#### 2.1 Memory Instruction: Load Word


Example: lw \$t0, 4(\$s0)



- Steps:
  - 1. Memory Address = \$s0 + 4 = 8000 + 4 = 8004
  - 2. Memory word at Mem[8004] is loaded into \$t0

#### 2.2 Memory Instruction: Store Word

Example: sw \$t0, 12(\$s0)



- Steps:
  - 1. Memory Address = \$s0 + 12 = 8000 + 12 = 8012
  - 2. Content of \$t0 is stored into word at Mem [8012]

#### 2.3 Load and Store Instructions

- Only load and store instructions can access data in memory.
- Example: Each array element occupies a word.

C Code	MIPS Code
A[7] = h + A[10];	<pre>lw \$t0, 40(\$s3) add \$t0, \$s2, \$t0 sw \$t0, 28(\$s3)</pre>

- Each array element occupies a word (4 bytes).
- \$s3 contains the base address (address of first element, A[0]) of array A. Variable h is mapped to \$s2.
- Remember arithmetic operands (for add) are registers, not memory!

## 2.4 Memory Instructions: Others (1/2)

- Other than load word (1w) and store word (sw), there are other variants, example:
  - load byte (1b)
  - store byte (sb)
- Similar in format:


```
lb $t1, 12($s3)
sb $t2, 13($s3)
```

- Similar in working except that one byte, instead of one word, is loaded or stored
  - Note that the offset no longer needs to be a multiple of 4

## 2.4 Memory Instructions: Others (2/2)

- MIPS disallows loading/storing unaligned word using lw/sw:
  - Pseudo-Instructions unaligned load word (ulw) and unaligned store word (usw) are provided for this purpose
- Other memory instructions:
  - 1h and sh: load halfword and store halfword
  - lwl, lwr, swl, swr: load word left / right, store word left / right.
  - etc...

### 2.5 Example: Array (assume 4 bytes per element)



#### 2.6 Common Questions: Address vs Value

## **Key concept:**Registers do NOT have types

- A register can hold any 32-bit number:
  - The number has <u>no implicit data type</u> and is interpreted <u>according to the instruction that uses it</u>
- Examples:
  - add \$t2, \$t1, \$t0
    - → \$t0 and \$t1 should contain data values
  - lw \$t2, 0(\$t0)
    - → \$t0 should contain a memory address

#### 2.6 Common Questions: Byte vs Word

#### **Important:**

Consecutive word addresses in machines with byte-addressing do not differ by 1

- Common error:
  - Assume that the address of the next word can be found by incrementing the address in a register by 1 instead of by the word size in bytes
- For both lw and sw:
  - The sum of base address and offset must be a multiple of 4 (i.e. to adhere to word boundary)

### 2.7 Example: Swapping Elements

```
C Statement to translate

swap( int v[], int k )

int temp;
temp = v[k]
v[k] = v[k+1];
v[k+1] = temp;

}

Example: k \Rightarrow $5

Example: k \Rightarrow $15

Sumple: k \Rightarrow $15

Example: k \Rightarrow $15

E
```

swap:
 sll \$2, \$5, 2
 add \$2, \$4, \$2
 lw \$15, 0(\$2)
 lw \$16, 4(\$2)
 sw \$16, 0(\$2)
 sw \$15, 4(\$2)

Note: This is simplified and may not be a direct translation of the C code.

#### Reading

- Instructions: Language of the Computer
  - Read up COD Chapter 2, pages 52-57. (3<sup>rd</sup> edition)
  - Read up COD Section 2.3 (4<sup>th</sup> edition)



### 3. Making Decisions (1/2)

- We cover only sequential execution so far:
  - Instruction is executed in program order
- To perform general computing tasks, we need to:
  - Make decisions
  - Perform iterations (in later section)
- Decisions making in high-level language:
  - if and goto statements
  - MIPS decision making instructions are similar to if statement with a goto
    - goto is discouraged in high-level languages but necessary in assembly ©

## 3. Making Decisions (2/2)

- Decision-making instructions
  - Alter the control flow of the program
  - Change the next instruction to be executed
- Two types of decision-making statements in MIPS
  - Conditional (branch)

```
bne $t0, $t1, label
beq $t0, $t1, label
```

Unconditional (jump)

```
j label
```

- A label is an "anchor" in the assembly code to indicate point of interest, usually as branch target
  - Labels are <u>NOT</u> instructions!


#### 3.1 Conditional Branch: beq and bne

- Processor follows the branch only when the condition is satisfied (true)
- beq \$r1, \$r2, L1
  - Go to statement labeled L1 if the value in register \$r1 equals the value in register \$r2
  - beq is "branch if equal"
  - C code: if (a == b) goto L1
- bne \$r1, \$r2, L1
  - Go to statement labeled L1 if the value in register \$r1 does not equal the value in register \$r2
  - bne is "branch if not equal"
  - C code: if (a != b) goto L1

#### 3.2 Unconditional Jump: j

- Processor always follows the branch
- j L1
  - Jump to label L1 unconditionally
  - C code: goto L1
- Technically equivalent to such statement beq \$s0, \$s0, L1

## 3.3 IF statement (1/2)



- Two equivalent translations:
  - The one on the right is more efficient
- Common technique: Invert the condition for shorter code


## 3.3 IF statement (2/2)

C Statement to translate	Variables Mapping
<pre>if (i == j)     f = g + h; else     f = g - h;</pre>	<pre>f → \$s0 g → \$s1 h → \$s2 i → \$s3 j → \$s4</pre>

```
bne $s3, $s4, Else
add $s0, $s1, $s2
j Exit

Else: sub $s0, $s1, $s2
Exit:
```

Question: Rewrite with beq?



#### 3.4 Exercise #1: IF statement

MIPS code to translate into C	Variables Mapping
<pre>beq \$s1, \$s2, Exit    add \$s0, \$zero, \$zero Exit:</pre>	f → \$s0 i → \$s1 j → \$s2

What is the corresponding high-level statement?

### 4. Loops (1/2)

C while-loop:

Rewritten with goto

```
while (j == k)
i = i + 1;
```



#### **Key concept:**

Any form of loop can be written in assembly with the help of conditional branches and jumps.

## 4. Loops (2/2)

C Statement to translate	Variables Mapping
Loop: if (j != k)	i → \$s3
goto Exit;	j → \$s4
i = i+1;	k <b>→</b> \$s5
goto Loop;	
Exit:	

What is the corresponding MIPS code?

## 4.1 Exercise #2: FOR loop

Write the following loop statement in MIPS

C Statement to translate	Variables Mapping
for ( i=0; i<10; i++) a = a + 5;	i → \$s0 a → \$s2



### 4.2 Inequalities (1/2)

- We have beq and bne, what about branch-if-less-than?
  - There is no real blt instruction in MIPS
- Use slt (set on less than) or slti.

#### 4.2 Inequalities (1/2)

To build a "blt \$s1, \$s2, L" instruction:

```
slt $t0, $s1, $s2
bne $t0, $zero, L
== if ($s1 < $s2)
goto L;
```

- This is another example of pseudo-instruction:
  - Assembler translates (blt) instruction in an assembly program into the equivalent MIPS (two) instructions


#### Reading

- Instructions: Language of the Computer
  - Section 2.6 Instructions for Making Decisions. (3<sup>rd</sup> edition)
  - Section 2.7 Instructions for Making Decisions. (4<sup>th</sup> edition)



#### 5. Array and Loop

Typical example of accessing array elements in a loop:



### 5. Array and Loop: Question

#### Count the number of zeros in an Array A

- A is word array with 40 elements
- Address of A[] → \$t0, Result → \$t8

# Simple C Code result = 0; i = 0;

i = 0;
while ( i < 40 ) {
 if ( A[i] == 0 )
 result++;
 i++;
}</pre>

- Think about:
  - How to perform the right comparison
  - How to translate A[i] correctly

#### 5. Array and Loop: Version 1.0

```
Address of A[] → $t0
Result > $t8
                                      Comments
i → $t1
      addi $t8, $zero, 0
      addi $t1, $zero, 0
      addi $t2, $zero, 40
                              # end point
loop: bge $t1, $t2, end
      sll $t3, $t1, 2
                              # i * 4
      add $t4, $t0, $t3
                              # &A[i]
                              # $t3 ← A[i]
      lw $t5, 0($t4)
      bne $t5, $zero, skip
      addi $t8, $t8, 1
                              # result++
skip: addi $t1, $t1, 1
                              # i++
      j loop
end:
```

#### 5. Array and Loop: Version 2.0

```
Address of A[] → $t0
Result → $t8
                                     Comments
&A[i] → $t1
      addi $t8, $zero, 0
      addi $t1, $t0, 0
                              # addr of current item
      addi $t2, $t0, 160
                              # &A[40]
loop: bge $t1, $t2, end
                              # comparing address!
      lw $t3, 0($t1)
                              # $t3 ← A[i]
      bne $t3, $zero, skip
      addi $t8, $t8, 1
                              # result++
skip: addi $t1, $t1, 4
                              # move to next item
      j loop
end:
```

Use of "pointers" can produce more efficient code!

#### 6.1 Exercise #3: Simple Loop

Given the following MIPS code:

```
addi $t1, $zero, 10
       add $t1, $t1, $t1
       addi $t2, $zero, 10
Loop: addi $t2, $t2, 10
       addi $t1, $t1, -1
      beq $t1, $zero, Loop
```

- How many instructions are executed?

- (a) 6 (b) 30 (c) 33 (d) 36 (e) None of the above
- ii. What is the final value in \$t2?

- (a) 10 (b) 20 (c) 300 (d) 310 (e) None of the above

#### 6.2 Exercise #4: Simple Loop II

Given the following MIPS code:

```
add $t0, $zero, $zero
       add $t1, $t0, $t0
       addi $t2, $t1, 4
Again: add $t1, $t1, $t0
       addi $t0, $t0, 1
       bne $t2, $t0, Again
```

- How many instructions are executed?

- (a) 6 (b) 12 (c) 15 (d) 18 (e) None of the above
- ii. What is the final value in \$t1?

- (a) 0 (b) 4 (c) 6 (d) 10 (e) None of the above

## 6.3 Exercise #5: Simple Loop III (1/2)

Given the following MIPS code accessing a word array of elements in memory with the starting address in \$t0.

```
addi $t1, $t0, 10
       add $t2, $zero, $zero
Loop: ulw $t3, 0($t1) # ulw: unaligned lw
      add $t2, $t2, $t3
       addi $t1, $t1, -1
      bne $t1, $t0, Loop
```

- How many times is the **bne** instruction executed?

- (a) 1 (b) 3 (c) 9 (d) 10 (e) 11
- ii. How many times does the **bne** instruction actually branch to the label Loop?

- (a) 1 (b) 8 (c) 9 (d) 10 (e) 11

## 6.3 Exercise #5: Simple Loop III (2/2)

Given the following MIPS code accessing a word array of elements in memory with the starting address in \$t0.

```
addi $t1, $t0, 10
       add $t2, $zero, $zero
Loop: ulw $t3, 0($t1) # ulw: unaligned lw
      add $t2, $t2, $t3
       addi $t1, $t1, -1
      bne $t1, $t0, Loop
```

- iii. How many instructions are executed?

- (a) 6 (b) 12 (c) 41 (d) 42 (e) 46
- iv. How many unique bytes of data are read from the memory?

  - (a) 4 (b) 10 (c) 11 (d) 13 (e) 40

### Summary: Focus of CS2100

- Basic MIPS programming
  - Arithmetic: among registers only
  - Handling of large constants
  - Memory accesses: load/store
  - Control flow: branch and jump
  - Accessing array elements
  - System calls (covered in labs)
- Things we are not going to cover
  - Support for procedures
  - Linkers, loaders, memory layout
  - Stacks, frames, recursion
  - Interrupts and exceptions

## **End of File**