

ARTICLES PODCAST CONTACT DONATE

CALCULATION OF FLOW THROUGH NOZZLES AND ORIFICES

SUMMARY

This article provides calculation methods for correlating design, flow rate and pressure loss as a fluid passes through a nozzle or orifice. Nozzles and orifices are often used to deliberately reduce pressure, restrict flow or to measure flow rate.

1. DEFINITIONS

DD : Diameter

AA : Area

 C_dC_d : Discharge coefficient

gg: Gravitational acceleration

hh : Fluid head

 $\Delta h \Delta h$: Change in fluid head

kk: Ratio of specific heats $(C_P/C_VC_P/C_V)$

PP : Pressure

 $\Delta P \Delta P$: Differential pressure $(P_2 - P_1 P_2 - P_1)$

YY: Expansion coefficient (Y=1Y=1 for incompressible flow)

zz : Elevation

etaeta : Ratio of pipe diameter to orifice diameter ($D_o/D_1D_o/D_1$)

 $\rho\rho$: Mass density

Subscripts

11 : Upstream of orifice or nozzle

22 : Downstream of orifice or nozzle

cc: Compressible fluid

ii : Incompressible fluid

oo : Orifice or nozzle

ss : Static pressure

$$\frac{x}{x-1} = \frac{1}{x-1}$$

What is x?



2. INTRODUCTION

In the case of a simple concentric restriction orifice the fluid is accelerated as it passes through the orifice, reaching the maximum velocity a short distance downstream of the orifice itself (the Vena Contracta). The increase in velocity comes at the expense of fluid pressure resulting in low pressures in the Vena Contracta. In extreme cases this may lead to <u>cavitation</u> when the local pressure is less than the vapour pressure of a liquid.

Downstream of the Vena Contracta in the recovery zone, the fluid decelerates

converting excess kinetic energy into pressure as it slows. When the fluid has decelerated and returned to the normal bulk flow pattern the final downstream pressure has been reached.

The discharge coefficient C_dC_d characterises the relationship between flow rate and pressure loss based on the geometry of a nozzle or orifice. You can find typical values in our article on discharge coefficients for nozzles and orifices.



3 Foods to Throw Out
Cut a bit of belly bloat each day, by avoiding these 3 foods nucific.com

3. CALCULATIONS

The relationships for flow rate, pressure loss and head loss through orifices and nozzles are presented in the subsequent section. These relationships all utilise the parameter $\beta\beta$, the ratio of orifice to pipe diameter which is defined as:

$$\beta = \frac{D_o}{D_1} \beta = \frac{D_o}{D_1}$$

Where the point downstream of the orifice is sufficiently far away that the fluid has returned to normal full pipe velocity profile.

3.1 Horizontal Orifices and Nozzles

For orifices and nozzles installed in horizontal pipework where it can be assumed that there is no elevation change, head loss and flow rate may be calculated as

Property	Equation
Flow rate (in terms of PP)	$Q = C_d A_o Y \sqrt{rac{2\Delta P}{ ho \left(1-eta^4 ight)}}Q = C_d A_o Y \sqrt{rac{2\Delta P}{ ho \left(1-eta^4 ight)}}$
Flow rate (in terms of hh)	$Q=C_dA_oY\sqrt{rac{2g\Delta h}{(1-eta^4)}}Q=C_dA_oY\sqrt{rac{2g\Delta h}{(1-eta^4)}}$
Pressure loss	$\Delta P = rac{1}{2} ho\left(1-eta^4 ight)\left(rac{Q}{C_dA_oY} ight)^2\Delta P = rac{1}{2} ho\left(1-eta^4 ight)\left(rac{Q}{C_dA_oY} ight)^2$
Head Loss	$\Delta h = rac{1}{2g} \left(1 - eta^4 ight) \left(rac{Q}{C_d A_o Y} ight)^2 \Delta h = rac{1}{2g} \left(1 - eta^4 ight) \left(rac{Q}{C_d A_o Y} ight)^2$

3 Foods to Throw Out



Cut a bit of belly bloat each day, by avoiding these 3 foods nucific.com

3.2 Vertical Orifices and Nozzles

For orifices and nozzles installed in horizontal piping, with elevation change $\Delta z=z_1-z_2\Delta z=z_1-z_2$, the following head loss and flow rate equations may be used:

Property	Equation
Flow rate (in terms of PP)	$Q = C_d A_o Y \sqrt{rac{2\left(\Delta P + ho g \Delta z ight)}{ ho\left(1 - eta^4 ight)}}Q = C_d A_o Y \sqrt{rac{2\left(\Delta P + ho g \Delta z ight)}{ ho\left(1 - eta^4 ight)}}$
Flow rate (in terms of hh)	$Q = C_d A_o Y \sqrt{rac{2g\left(\Delta h + \Delta z ight)}{\left(1 - eta^4 ight)}}Q = C_d A_o Y \sqrt{rac{2g\left(\Delta h + \Delta z ight)}{\left(1 - eta^4 ight)}}$
Pressure loss	$\Delta P = rac{1}{2} ho\left(1-eta^4 ight)\left(rac{Q}{C_dA_oY} ight)^2 - ho g\Delta z\Delta P = rac{1}{2} ho\left(1-eta^4 ight)\left(rac{Q}{Q} ight)^2$
Head Loss	$\Delta h = rac{1}{2g} \left(1 - eta^4 ight) \left(rac{Q}{C_d A_o Y} ight)^2 - \Delta z \Delta h = rac{1}{2g} \left(1 - eta^4 ight) \left(rac{Q}{C_d A} ight)$

3.3 Expansion Coefficient

The expansion coefficient takes account of the difference between the discharge coefficient for compressible and incompressible flows. It is defined as:

$$Y=rac{C_{d,c}}{C_{d,i}}Y=rac{C_{d,c}}{C_{d,i}}$$

The expansion factor YY is typically determined empirically and can be calculated using one of the formulas below.

For incompressible fluids:

$$Y = 1Y = 1$$

American Gas Association method as described in AGA 3.1:

$$Y = 1 - \left(0.41 + 0.35 eta^4
ight) rac{\Delta P}{k P_{s,1}} Y = 1 - \left(0.41 + 0.35 eta^4
ight) rac{\Delta P}{k P_{s,1}}$$

International Standards Organistion method as described in ISO 5167-2:

$$Y=1-\left(0.351+0.256eta^4+0.93eta^8
ight)\left(1-\left(rac{P_{s,2}}{P_{s,1}}
ight)^{1/k}
ight)Y=1-\left(0.351-1.86
ight)$$

4. FURTHER READING

- 1. Flow Measurement Engineering Handbook, R. W. Miller
- 2. Albright's Chemical Engineering Handbook, L. Albright
- 3. Instrument Engineers' Handbook, Vol. 1: Process Measurement and Analysis







ARTICLE TAGS

Discharge Coefficient Expansion Coefficient Flow Orifice Nozzle Orifice

Restriction Orifice Venturi Meter

© 2017 Native Dynamics | Contact | Copyright and Disclaimer