Procedures for card's replacement

IOS

IMPORTANT: whenever an IOS card needs to be replaced, first step is to check the position of all jumpers (compare the new card with the old one). Verify that J17 and J18 are positioned to 2-3 [(it means the LAN termination is external) while position 1-2 it means is terminated internally (for test purposes only)]. Switch off the power supply of the card.

After replacing the card, power it up.

While powering up the card keep pressed together ENTER and CLEAR keys, for few seconds, until you see the display drop number goes flashing.

Press the up arrow key until you reach the related drop number and then press ENTER, to accept it.

If you experience problems to set the drop number, while drop number 0 is flashing, press up or down arrows keys to go to IOS UTIL then press ENTER. Scroll through to get SETUP MODE and press ENTER. Then with arrows keys move to drop number then press ENTER again. Afterwards with up arrow move to the desired drop number and press ENTER to accept it.

- · On the IOS display the message: LAN download required will appear,
- Move to MM2000 operator interface and select Console # 2, therefore you must press Ctrl, Alt and F3 at the same time on the PC keyboard.
- Then on the display it prompts for a user name and you type in: tim
- Press ENTER
- It asks you for the password, type: savorani
- Press ENTER
- When the screen appears move the highlighted cursor to Tool Interface Manager and press ENTER
- When the Tool Interface Manager screen appears with the arrow keys move the cursor to IOS and from the pulldown menu choose Download an IOS and press ENTER
- On the next screen you are requested to reply to some questions, like:

i.	Direction	press F2 and select Download to an IOS then press ENTER
ii.	System	press F2 and NKB606 (for RTGs) will appear then press ENTER
		Or NKB607 (for QCs) will appear then press ENTER
iii.	Network	press F2 and DLANP will appear so press ENTER
iv.	IOS device	press F2 and select the one you are going to download then press ENTER
V,	Drop number	it comes automatically according to the IOS selected then press ENTER
vi.	File	it comes automatically according to the IOS selected then press ENTER
vii.	Previous file	no need to write anything just press ENTER
viii.	Options	no need to write anything just press ENTER

The program start downloading the selected IOS and when it completes this operation it will prompt you to strike any key when ready,

- NOTE: If the program starts downloading operation then it stops giving error because of current IOS locked, press any key to clear the screen then on the next menu move the highlighted bar to Configure and press ENTER. On the System Login screen it asks you for the User name; therefore type admin for RTGs and matguest for OCs then press ENTER. The highlight will move to Password so type mfcorp1 for RTGs and maxspeed for OCs then press ENTER again. Afterwards press F2 to get the IOS's list and with arrow keys point to the one you need to unlock and press ENTER to get it on the screen, then press ENTER again. With arrow keys move to Utilities and press ENTER, and on Utility selections screen move the highlight to Remove all domain locks in this IOS then press ENTER. After a while press F10 to get to previous screen, then press F10 again to quit this utility and answer yes on OK to Quit and press ENTER. Afterwards repeat again the above step to download the IOS.
- If there's no need to download any other IOS you must close the TIM program therefore with arrows keys move the highlighted cursor back to File, then point to Exit and press ENTER
- On Cranes Tool Interface Manager point to Exit and press ENTER.

To sturpown PC, one must login with, File (Exit) (Exit)
Username: system
and possibord: savorani
and enter the command

/> recoot -ah after about 20 secs the lynxOS software would have shotdown and you may switch OFF power to the pc.