g	GE Energy			Functional To	esting Spe	ecification	
Parts & Repair Services Louisville, KY				LOU-TOFFEE-IS210MVRC			
Test Procedure for an IS210MVRCH1A card tested on the Toffee System							
DOCUI	MENT REVISION STATUS	Determined by the last e	entry in the "REV" an	d "DATE" column			
REV.		DESCRIPTION			SNATURE	REV. DATE	
Α	Initial release			P	. Kelley	4/16/2012	
В							
С							
	YRIGHT GENERAL ELECT! pies are uncontrolled and are						
PROPRIETARY INFORMATION – THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION OF GENERAL ELECTRIC COMPANY AND MAY NOT BE USED OR DISCLOSED TO OTHERS, EXCEPT WITH THE WRITTEN PERMISSION OF GENERAL ELECTRIC COMPANY. PREPARED BY REVIEWED BY REVIEWED BY QUALITY APPROVAL							
P. Ke		VEAICACD DI	KEVIEWEL	, 51	Charlie Was		
DATE 4/16/2	2012	DATE	DATE		DATE 4/16/2012		

GE Energy
Part & Repair Services
Louis ville, KY

LOU-TOFFEE-IS210MVRC REV. A

Functional test procedure for an IS210MVRCH1A card tested on the Toffee Test system

1. SCOPE

1.1 This is a functional testing procedure for the IS210MVRCH1A Signal Conditioning I/O Expansion Card. The IS210MVRC assembly is made up of an IS200MVRC and IS200HSLA cards.

2. STANDARDS OF QUALITY

2.1 Refer to the current revision of the IPC-A-610 standard for workmanship standards.

3. APPLICABLE DOCUMENTS

- 3.1 The following document(s) shall form part of this specification to the extent specified herein. Unless otherwise indicated, the latest issue shall apply.
 - **3.1.1** Check the board's electronic folder for more information.

4. ENGINEERING REQUIREMENTS

- 4.1 Equipment Cleaning
 - **4.1.1** Equipment should be clean and free of debris prior to applying power unless performing an initial check. Refer to site specific SRA's for cleaning guidelines.
- 4.2 Equipment Inspection
 - **4.2.1** Equipment should be visually inspected for any defects prior to applying power. This inspection should include the following as a minimum:
 - 4.2.1.1 Wires broken or cracked
 - 4.2.1.2 Terminal strips / connectors broken or cracked
 - **4.2.1.3** Loose wires
 - 4.2.1.4 Components visually damaged
 - 4.2.1.5 Capacitors leaking
 - 4.2.1.6 Solder joints damaged or cold
 - 4.2.1.7 Circuit board burned or de-laminated
 - 4.2.1.8 Printed wire runs burned or damaged

5. EQUIPMENT REQUIRED

5.1 The following equipment is required to perform the process requirements. Equipment may be substituted provided that all accuracy's and test ratios are equivalent or better.

Qty	Reference #	Description
1	H188818	Toffee Test System #14
1	H190004	Toffee test fixture for IS200MVRC
		IS200HSLA Card

g

LOU-TOFFEE-IS210MVRC REV. A

GE Energy Part & Repair Services Louisville, KY

Page 3 of 4

6. TESTING PROCESS

6.1 Setup

- **6.1.1** Install IS210MVRC fixture H190004 onto TOFFEE test System. The IS210MVRC assembly is made up of an IS200MVRC and IS200HSLA cards.
- 6.1.1 Install Unit Under Test into test fixture. Plug the black and white wire into back of unit. Plug the red Ethernet cable into the receptacle on the left and the blue Ethernet cable into the right.

6.2 Testing Procedure

- **6.2.1** Double click on the OPERATOR INTERFACE icon on screen.
- **6.2.2** On the user name dialogue box, choose either administrator or technician. If administrator password is NGFT2008*, technician password is KISS, case sensitive. The next window should say configuration management and you should always click on no.
- 6.2.3 The next dialogue box should say select DUT (device under test). Detected fixture should have the model number being tested and family name should say MVe. Click the drop down box DUT and your model number should be the only option. Select it and it should appear in the DUT model number. Put your revision level of unit being tested in DUT REV and click ok.
- 6.2.4 A delay dialogue box appears, counts down and then asks for a serial number, enter the serial number of the UUT and check the boxes marked RUN UPLOADS and DELETED LOGS. Click ok. If you logged on as an administrator, you will not get this dialogue box. The test will automatically run these.
- **6.2.5** A delay dialog box appears and counts down, do not stop it and then system runs test. You will get either a pass or fail message.
- 6.3 ***TEST COMPLETE ***

g

LOU-TOFFEE-IS210MVRC REV. A

GE Energy Part & Repair Services Louisville, KY

Page 4 of 4

7. NOTES

7.1 Changes to the electronic Toffee test are recorded in the <u>Software Control Database</u>

8. ATTACHEMENTS

8.1 Picture of the Toffee Test System

