VOICE & TAP CONTROL · AWAY ALERTS · NO SUBSCRIPTION

Put the *Control Freak* on your basement.

Two pumps, one watchful hub. Basement Guard Pro keeps an eye on the pit, the pipes and the floor — so you can stop listening for the pump every time it rains.


Basement Guard Pro
CONCEPT MARK

CONCEPT PHOTO

01
Two pumps take turns
Plug in the two pumps you already own. The lead pump swaps weekly so both wear evenly, and the two never start at the exact same moment.

02
Second pump steps in
If torrential rain causes the water to keep rising, the second pump is brought in automatically after a brief stagger — and you get a reassuring note.

03
See the water level
Know exact pit depth in inches and how fast it's rising on a live ring gauge, moving far beyond simplistic "alarm / no alarm" binary switches.



04
Pumps work if controller doesn't
Pump outlets stay continuously powered even if the controller is off, and each pump keeps its own float switch. Your basement is never worse off than with plain pumps.

05
Pump check-up
Spots a slow pump-down or a pump that didn't empty the pit before you face a crisis. With automated weekly self-tests, you replace a tired pump on your own schedule.


06
Leak and freeze watch
Monitors the perimeter with water heater and washer leak sensors, high-water float backups, and temperature probes that automatically trigger plug-in heat tape.

BASEMENT GUARD PRO ·
BROUGHT TO YOU BY CONTROL FREAK

CONCEPT · DEMO UI · EXAMPLE READINGS

Two pumps that actually work as a team.

Most homes with dual pumps have a primary unit doing all the heavy lifting while a backup pump sits idle for years — often failing the single time it is called upon. Basement Guard Pro manages your existing equipment with equalized wear. It alternates duty weekly and staggers starts so both pumps never kick on at the same instant. If the lead pump falls behind heavy storm inflow, the second pump smoothly engages to double capacity. Each pump keeps its own factory float.



CONCEPT · DEMO UI · LIGHT + DARK

WHY IT MATTERS · 02 · LOCAL-FIRST · CLOUD-FREE FOUNDATION

Reliability when internet or power fails.

Basement Guard Pro
CONCEPT MARK

Real storm weather knocks out connectivity and utility power. A basement system that relies on a remote cloud server to make switching decisions is a liability. All logic, pump rotation, high-water thresholds and the indoor siren run locally on the box in your basement. If the hub is unplugged, your pumps run directly on their own floats. When you're away, status reaches your phone over secure networking — with no monthly fees.



Lit when it's working

Safety-blue tiles for outlets that are on, slate for standby, muted for off.

Amber means "keep an eye on"

Never a siren for something you can plan for.


Runs in the basement

Pump rules and the siren keep working when the internet doesn't.

UNIFIED ECOSYSTEM · HOME ASSISTANT ON YOUR HOME NETWORK

How many apps do you open to run your home?

Basement Guard Pro ships with Home Assistant and the Control Freak integration already set up, so your sump, leak sensors and the rest of your smart home meet in one place. Connect the devices you already own and simplify to a single app.



When you're away and the forecast turns...

Storm mode · 1 storm → 4 things handled

Pumps take turns
The lead pump works the storm; the second waits its turn and only steps in if it's needed.

You get a note
Push, text or email wherever you are — the siren at home sounds even if the internet is down.

Ask, don't open
"Alexa, how's the sump?" through Home Assistant — no extra vendor app.

Morning summary
"Pit at 6 in · Pump A ran 14 times · both pumps healthy."

HA ON YOUR HOME NETWORK · NEVER CLOUD HA · VOICE VIA HA BRIDGES

CONCEPT · EXAMPLE HA DASHBOARD · DEVICE MOCK


HOW IT ALL CONNECTS · PIT, PIPES AND FLOOR

Two pumps, one watchful hub.

Basement Guard Pro
CONCEPT MARK

Plug the two pumps you already own into the Power Hub, drop in the level sensor, scan the QR code. No rewiring — and your pumps keep their own float switches.

CONCEPT ILLUSTRATION · NOT TO SCALE



1. **Pit level sensor**
   Pit depth in inches and how fast it's rising — not just "alarm / no alarm."
2. **High-water float**
   A second check if the water keeps rising.
3. **Your two pumps**
   They take turns every week; the second steps in if the water keeps rising. Pump outlets stay on if the controller is ever off.
4. **Leak sensors**
   By the water heater and the washer.
5. **Temperature probes**
   Basement, crawlspace, water heater area and outdoor. Heat tape switches on when it gets cold.
6. **Siren**
   Sounds in the house whether or not the internet is up.
7. **Home Assistant, pre-installed**
   Alerts by push, text, email and alarm — including when you're away.

2 PUMPS TAKE TURNS, WEEKLY	4 TEMPERATURE PROBES	0 SUBSCRIPTIONS

BASEMENT GUARD PRO · WHAT IT DOES

Stop listening for the pump.

Plug the two pumps you already own into the Power Hub, drop in the level sensor, scan the QR code. **No rewiring.** From then on the pumps take turns, the pit level is a number you can see, and leaks and cold pipes get noticed early — whether you're upstairs or a state away.

Built for homeowners with a basement sump, second-home and rental owners who can't pop downstairs, and Home Assistant users who'd rather not build it by hand. Water and freezing claims average **$15,400** (Insurance Information Institute) — a little attention goes a long way.

IN THE RECOMMENDED PACKAGE

- Controller with Home Assistant + Control Freak integration
- Power Hub — labelled outlets for two sump pumps, heat tape, a dehumidifier and a spare
- Pit level sensor (depth + rate of rise)
- High-water float (second check)
- Leak sensors — water heater + washer
- Temperature probes — basement, crawlspace, water heater area, outdoor
- Siren for inside the house
- Backup inverter hook-up (for one you already own)
- Keyed, colour-coded cables

Your sump pumps aren't in the box — keep the ones you have. Every sensor is its own cart line; the full package costs less than buying lines separately. Optional: UPS, partner 12 V battery backup pump.

TRY IT IN THE SITE DEMO



Still rising? Pump B joins in — never at the same moment — and the level falls back.



Each pump runs briefly in turn and reports back. Swap the lead with one tap.



The plug-in heat tape comes on by itself and you see why.

Pump check-up
Spots a slow pump-down or a pump that didn't empty the pit, so you replace on your schedule.

Alerts that reach you
Push, text, email and alarm — including away (cloud via Tailscale) — plus a siren in the house.

Keeps working offline
Pump rules and the siren run on the box in the basement. No subscription.

DEMO · TAP "WHAT IF"

EXAMPLE ALERT
Water by the water heater · siren on · push, text and email sent

Red appears only when you tap a "what if" in the demo. Everyday state is calm blue and slate.

Join Wave 1 Pro early

We're looking for homeowners to test Basement Guard Pro in their own basements before launch — test early kits with your existing pumps. No credit card required.

Join the interest list →