
HOW IT ALL CONNECTS · PIT, PIPES AND FLOOR

Two pumps, one watchful hub.

Plug the two pumps you already own into the Power Hub, drop in the level sensor, scan the QR code. No rewiring — and your pumps keep their own float switches.

Basement Guard Pro
CONCEPT MARK

CONCEPT ILLUSTRATION · NOT TO SCALE



1. **Pit level sensor**
   Pit depth in inches and how fast it's rising — not just "alarm / no alarm."
2. **High-water float**
   A second check if the water keeps rising.
3. **Your two pumps**
   They take turns every week; the second steps in if the water keeps rising. Pump outlets stay on if the controller is ever off.
4. **Leak sensors**
   By the water heater and the washer.
5. **Temperature probes**
   Basement, crawlspace, water heater area and outdoor. Heat tape switches on when it gets cold.
6. **Siren**
   Sounds in the house whether or not the internet is up.
7. **Home Assistant, pre-installed**
   Alerts by push, text, email and alarm — including when you're away.

2	PUMPS TAKE TURNS, WEEKLY
4	TEMPERATURE PROBES
0	SUBSCRIPTIONS