

Version 1.x

Cap rail enclosure set for ESP32 and ESP8266



Features enlosure and pcb:

- milled cab rail enclosure (4 modules)
- for EN50022 DIN rails
- Optional Integrated 5V/1,7A voltage regulator (Vin 9...35V DC)
- Integrated prototyping area
- 3x 2-pin terminal blocks for prototyping
- Marked and connected GPIO & power pins beside the proto area
- 1x 2-pin terminal block for power supply
- For Wemos D1 Mini (ESP8266) and ESP32 NodeMCU-32S only
- removable protections for terminals
- Opening for micro USB socket on top side
- Available with transparent lid or grey lid



Version 1.x

Cap rail enclosure set for ESP32 and ESP8266

Enclosure:

Outside dimensions: 70mm x 65mm x 90mm (W x H x L)

Breadboard area: 74mm x 45mm (W x H)

Material: PS

Finish top shell: light greyFinish bottom shell: light grey

Features optional voltage regulator:

Input voltage: 9 – 35V DC

Output voltage: 5V / 1.7A DC

Applications:

- Home automation
- Industrial control
- Door access and door control
- Temperature controls
- Education
- Internet of Things (IoT)
- Industry 4.0
- Data aquisition
- Gateways





Version 1.x

Cap rail enclosure set for ESP32 and ESP8266

Compatibility:

D1 Mini Pinout Diagram








Version 1.x

Cap rail enclosure set for ESP32 and ESP8266

Features main board:



- ① Terminals power supply
- ② Header for ESP32
- 3 Header for Wemos D1 Mini
- 4 voltage regulator
- S Breadboard / proto board area
- ⑥ Terminals for proto board
- ② GPIO pins for proto board
- ® Power pins (5V, 3,3V, GND) for proto board



Version 1.x

Cap rail enclosure set for ESP32 and ESP8266

Part number table:

Part-No.	Version	Features
ABXEPB	Basic	transparent lidwithout parts for voltage regulator
ABXEPS	Standard	 transparent lid including voltage regulator parts
ABXEPBG	Basic	- grey lid - without parts for voltage regulator
ABXEPSG	Standard	grey lidincluding voltage regulator parts





transparent lid



Version 1.x


Cap rail enclosure set for ESP32 and ESP8266

Different ways for power supply of ArduiBox ESP:

1.) Via the Micro-USB socket of the ESP module




2.) Via the terminal K4 (5V DC) for basic version only:



Note: J1 will connect K1 directely with the internal 5V of the ESP module

3.) Via the terminal K4 (9...35V DC) for **standard version** only:



Note: With assembled voltage regulator only. Leave J1 open in this case!