

HiMP-D06 EOCR — Setting Card

NO.4 E/R VENT. FAN (REV) · CT-OC 100/5A · Keep this at the panel

BUTTONS

MODE

Enter / leave
setting menu

SET

Show value /
SAVE setting

SELECT ▲▼

Change parameter
or value

RESET/TEST

Clear o.C trip /
test when stopped

HOW TO SET

1. Stop the motor if possible (safer).
 2. Press MODE → enter setting menu (may show rc).
 3. Press SELECT ▲▼ → choose the parameter.
 4. Press SET → current value appears.
 5. Press SELECT ▲▼ → change the value.
 6. Press SET again → SAVE.
 7. Press MODE → return to amp display.
- Tip: To only VIEW settings, browse with SELECT then MODE — do not press SET.

DRAWING SETTINGS (HI-2536) — USE THESE

Parameter	Set value	Notes
Operating current SET'G	3.27 A	Secondary = motor 65.4 A with CT 100/5
Characteristic CHA	INV	Inverse — delayed trip
O-TIME	10 s	OC operating time (ref. ~600%)
D-TIME	6 s	Start delay — ignore OC during start
PF (phase fail)	OFF	As drawing
CT ratio factor	1 *	If display shows ~3.x A (secondary)
Motor FLA / CT	65.4 A / 100/5	Primary ÷ 20 = EOCR secondary

* If CT factor = 20, display shows primary (~65 A) and SET must be ~65.4 — do NOT mix with SET 3.27.

AFTER o.C TRIP

1. Photo/note: o.C + phase LED (R/S/T)
2. Motor stopped → press RESET
3. Clear SMC ABNORMAL if latched
4. Check why current ≥ SET
5. Then restart

DO NOT

- Raise SET only to stop trips
 - Mix CT factor 20 + SET 3.27
 - Ignore R-phase high reading
 - Open CT secondary live
- Your case: door ~65 A, EOCR ~3.63 A
→ trips near 112.5% of SET 3.27