#### sensors



Robótica Móvel e Inteligente / Mobile and Inteligent Robotics Mestrado Integrado em Engenharia de Computadores e Telemática


Academic year 2022/23

Departamento de Electrónica, Telecomunicações e Informática Universidade de Aveiro

CC-BY-SA The IRIS team, 2023

# existencial problems in a robot's life





#### sensorial information



- Self perception ("How am I doing?")
  - Posture
  - Batteries, ...
- Location ("Where am I?")
  - Position
  - Orientation
- Environment perception ("Where can I go to?")
  - obstacles
  - maps: constructing and location
  - targets (application level)

# **Challenges in mobile robotics**



Navigate :: follow fixed path

# Line sensors: magnetic







https://www.roboteq.com/all-products/magnetic-guide-sensors

# **Line sensors :: optic**



- Reflection on a object
- Detection depends on the object colour







Navigate :: react to surroundings

#### contact sensors



#### mechanically actuated switch

- whisker
- bumper








# ultra-sound



 Detection based on the reflection by an object



$$x = \frac{1}{2} \cdot c \cdot t_{\text{echo}}$$




# infra-red



- Sharp sensor
  - Distance information





# **Robotic challenges**





Navigate :: follow a path in a map

# Laser range finder



- Laser scans the space ahead or around the robot
- Measuring obstacle distance
  - Limited to the bean working plan
  - Sometimes used with beam oscillation (<sup>⊥</sup> to the plan of beam)













Image of Sick's LRF software application






# LS3 – Legged Squad Support System



- The LS3 (Legged Squad Support System) is an example of a robot using LRF.
  - For example, in the YouTube video, at 1:17 you can clearly see the LFR oscillating to create a 3D perception of space ahead.

http://youtu.be/R7ezXBEBE6U?t=1m17s




# position



#### **GPS**

- Absolute positioning (error in the order of m)
- Relative positioning (error in the order of cm for short time intervals)
- Requires line of sight to a minimum number of satellites → outdoor use
- Start time



# error sources in GPS



Ionospheric effects	± 5 meters
Shifts in the satellite orbits	± 2.5 meter
Clock errors of the satellites' clocks	± 2 meter
Multipath effect	± 1 meter
Tropospheric effects	± 0.5 meter
Calculation and rounding errors	± 1 meter

http://www.kowoma.de/en/gps/errors.htm

## mobile phone location



- Based on mobile phone location services
  - e.g.: multilateration with cell tower signals




Photo by Intel Free Press - Indoor location services on mobile phone, CC BY-SA 2.0, https://commons.wikimedia.org/w/index.php?curid=71130241




Navigate :: sense myself

#### **Position**




#### Odometry

- def.: use of data from motion sensors to estimate change in position over time
- relative position
- Sources of error:
  - limited resolution (encoder)
  - · model inaccuracies:
    - systematic → accumulates (error in slope)
      - error in wheel diameter
  - slippage
    - random, can reach significant values
- Errors accumulate → unbounded !!



$$s = \alpha \times R$$






Robot location in the plane

Pose

$$p = \begin{bmatrix} x \\ y \\ \Theta \end{bmatrix}$$






$$\Delta s_{l} = R \alpha$$

$$\Delta s_{r} = (R+2L)\alpha$$

$$\Delta s = (R+L)\alpha$$

$$\Delta s = \frac{\Delta s_{l} + \Delta s_{r}}{2}$$






$$\Delta s_{l} = R \alpha$$

$$\Delta s_{r} = (R+2L)\alpha$$

$$\frac{\Delta s_{l}}{R} = \frac{\Delta s_{r}}{R+2L}$$

$$R = \frac{2L\Delta s_l}{\Delta s_r - \Delta s_l}$$






$$\Delta S_{l} = R \alpha$$

$$R = \frac{2L\Delta S_{l}}{\Delta S_{r} - \Delta S_{l}}$$

$$\alpha = \Delta S_{l}/R$$


$$= \frac{\Delta S_{r} - \Delta S_{l}}{2L}$$

$$\Delta \Theta \simeq \frac{\Delta S_{r} - \Delta S_{l}}{2L}$$





#### Robot may have an initial orientation Θ≠0



Projection of d on the x and y axis


$$\Delta x = \Delta d \cos(\Theta + \Delta \Theta/2)$$

$$\Delta y = \Delta d \sin(\Theta + \Delta \Theta/2)$$



$$\Delta x = \Delta s \cos(\Theta + \Delta \Theta/2)$$

$$\Delta y = \Delta s \sin(\Theta + \Delta \Theta/2)$$





Initial pose:

$$p = \begin{bmatrix} x \\ y \\ \Theta \end{bmatrix}$$

$$\Delta x = \Delta s \cos(\Theta + \Delta \Theta/2)$$


$$\Delta y = \Delta s \sin(\Theta + \Delta \Theta/2)$$

$$\Delta \Theta \simeq \frac{\Delta s_r - \Delta s_l}{2L}$$

$$\Delta s = \frac{\Delta s_l + \Delta s_r}{2}$$


Final pose (after displacement)

$$p' = \begin{bmatrix} x \\ y \\ \Theta \end{bmatrix} + \begin{bmatrix} \frac{\Delta s_l + \Delta s_r}{2} \cos(\Theta + \Delta \Theta/2) \\ \frac{\Delta s_l + \Delta s_r}{2} \sin(\Theta + \Delta \Theta/2) \\ \frac{\Delta s_r - \Delta s_l}{2L} \end{bmatrix}$$



# optical encoder








- Pulses generated by the interference of two patterns of stripes
- encoder characterized by p.p.r. (pulses per revolution)
- # of pulses proportional to displacement


$$\alpha = \frac{\text{count}}{\text{p.p.r.}} \cdot 2\pi$$

# optical encoder



- Interference generates a varying signal with displacement
- This signal is converted to digital







- Quadrature allows:
  - to detect the direction of movement
  - multiply encoder resolution by 4
    - 1 impulse = 4 counts

#### absolute encoder



- optical disk with Gray code
- output is shaft position (angle) in binary code






# magnetic encoder



- principle similar to optical incremental encoder
- small permanent magnets in the shaft drum
- sensing circuit detects passing magnets and measures rotation
- Pro: unaffected by dust, moisture, and extreme temperatures, and shock.



 bicycle computers work in a similar fashion




https://www.bicycle-guider.com/cycling-advice/best-bike-computers-buyers-guide/

#### hall effect encoder



#### Based on Hall effect


- production of a voltage difference (the Hall voltage) across an electrical conductor, transverse to an electric current in the conductor and to an applied magnetic field perpendicular to the current
- A permanent magnet is attached to the shaft
- Orientation of magnetic field is detected by an array sensor



https://www.dynapar.com/Technology/Encoder\_Basics/Magnetic\_Encoder/


#### accelerometers






$$k(x-y)+f(\dot{x}-\dot{y})-m_a\ddot{y}=0$$

- inertial mass principle
- Ex.: ADXL... from Analog Devices
- MEMS: Micro-electromechanical Systems







# accelerometers



- Detection by changes on:
  - capacity
  - resistance







## compass




- Ex.: HM55B (Hitachi)
  - Magnetic field detection in 2 axes, x e y
  - Trigonometry is used to compute angle with magnetic N





# working principle





#### Hall effect

voltage as a function of magnetic field

# **Gyroscopes**



- Based on inertia principle
  - rotating disk
- Electronic devices based on mechanical oscillation
  - Foucault pendulum






Navigate :: use external references

### **RFID** location




- set of RFID tags installed in the floor
  - identifying the tag allows knowledge of position.



[1] Sunhong Park e Shuji Hashimoto, «Autonomous Mobile Robot Navigation Using Passive RFID in Indoor Environment», IEEE Transactions on Industrial Electronics, vol. 56, n. 7, Jul 2009.

## **Charging and location**





Coils in the floor can work for both:


- Charging (Dynamic Wireless Charging)
- Location

Li, Y., Zhong, L., & Lin, F. (2021). Predicting-Scheduling-Tracking: Charging Nodes With Non-Deterministic Mobility. Ieee Access, 9, 2213–2228. https://doi.org/10.1109/ACCESS.2020.3046857

#### trilateration



- computing position by measuring distance to 3 reference points
- TOF: ultra-sounds
- RSSI: radio signal
  - D. Hahnel, W. Burgard,
     D. Fox, K. Fishkin, e M.
     Philipose, «Mapping and localization with RFID technology», 2004, pp.
     1015-1020 Vol.1.





$$d_{1}^{2} = (x - x_{1})^{2} + (y - y_{1})^{2}$$

$$= x^{2} - 2x x_{1} + x_{1}^{2} + y^{2} - 2y y_{1} + y_{1}^{2}$$

$$d_{2}^{2} = x^{2} - 2x x_{2} + x_{2}^{2} + y^{2} - 2y y_{2} + y_{2}^{2}$$

$$...$$

$$d_{n}^{2} = x^{2} - 2x x_{n} + x_{n}^{2} + y^{2} - 2y y_{n} + y_{n}^{2}$$

Subtracting the first equation from equations 2 to n:

$$d_{2}^{2}-d_{1}^{2}=2x(x_{1}-x_{2})+x_{2}^{2}-x_{1}^{2}+2y(y_{1}-y_{2})+y_{2}^{2}-y_{1}^{2}$$

$$d_{3}^{2}-d_{1}^{2}=2x(x_{1}-x_{3})+x_{3}^{2}-x_{1}^{2}+2y(y_{1}-y_{3})+y_{3}^{2}-y_{1}^{2}$$
...
$$d_{n}^{2}-d_{1}^{2}=2x(x_{1}-x_{n})+x_{n}^{2}-x_{1}^{2}+2y(y_{1}-y_{n})+y_{n}^{2}-y_{1}^{2}$$



$$2(x_1-x_2)x+2(y_1-y_2)y=d_2^2-d_1^2+x_1^2-x_2^2+y_1^2-y_2^2$$

$$2(x_1-x_3)x+2(y_1-y_3)y=d_3^2-d_1^2+x_1^2-x_3^2+y_1^2-y_3^2$$

$$2(x_1-x_n)x+2(y_1-y_n)y=d_n^2-d_1^2+x_1^2-x_n^2+y_1^2-y_n^2$$

$$\begin{bmatrix} 2(x_1 - x_2) & 2(y_1 - y_2) \\ 2(x_1 - x_3) & 2(y_1 - y_3) \\ \dots & \dots \\ 2(x_1 - x_n) & 2(y_1 - y_n) \end{bmatrix} \begin{bmatrix} x \\ y \end{bmatrix} = \begin{bmatrix} d_2^2 - d_1^2 + x_1^2 - x_2^2 + y_1^2 - y_2^2 \\ d_3^2 - d_1^2 + x_1^2 - x_3^2 + y_1^2 - y_3^2 \\ \dots & \dots \\ d_n^2 - d_1^2 + x_1^2 - x_n^2 + y_1^2 - y_n^2 \end{bmatrix}$$



$$AX = B$$

$$A = \begin{bmatrix} 2(x_1 - x_2) & 2(y_1 - y_2) \\ 2(x_1 - x_3) & 2(y_1 - y_3) \\ \dots & \dots \\ 2(x_1 - x_n) & 2(y_1 - y_n) \end{bmatrix} \quad X = \begin{bmatrix} x \\ y \end{bmatrix} \quad \text{A least-square approximation can be found by using the Moore-Penrose pseudo-inverse:}$$

$$X = \begin{bmatrix} x \\ y \end{bmatrix} \quad X = \begin{bmatrix} x$$

$$X = \begin{bmatrix} x \\ y \end{bmatrix}$$


$$X = (A^T \cdot A)^{-1} A^T B$$

$$B = \begin{bmatrix} d_2^2 - d_1^2 + x_1^2 - x_2^2 + y_1^2 - y_2^2 \\ d_3^2 - d_1^2 + x_1^2 - x_3^2 + y_1^2 - y_3^2 \\ \dots \\ d_n^2 - d_1^2 + x_1^2 - x_n^2 + y_1^2 - y_n^2 \end{bmatrix}$$


# visible light positioning (VLP)



- Conditions
  - widespread use of LED for illumination
  - LEDs allow light modulation → VLC (visible light communication)
- VLC + AOA (Angle of Arrival) = VLP
  - AOA is not the only method



J. Armstrong, Y. Sekercioglu, e A. Neild, «Visible light positioning: a roadmap for international standardization», *Communications Magazine, IEEE*, vol. 51, n. 12, pp. 68–73, Dez. 2013.




S.-Y. Jung, S. Hann, S. Park, e C.-S. Park, «Optical wireless indoor positioning system using light emitting diode ceiling lights», *Microwave and Optical Technology Letters*, vol. 54, n. 7, pp. 1622–1626, 2012.

## **Visible Light Positioning**




Perspective-N-Point



$$egin{bmatrix} u \ v \ 1 \end{bmatrix} = \mathbf{A} \, \mathbf{\Pi}^{\, \mathbf{c}} \mathbf{T_w} egin{bmatrix} X_w \ Y_w \ Z_w \ 1 \end{bmatrix}$$

$$egin{bmatrix} u \ v \ 1 \end{bmatrix} = egin{bmatrix} f_x & 0 & c_x \ 0 & f_y & c_y \ 0 & 0 & 1 \end{bmatrix} egin{bmatrix} 1 & 0 & 0 & 0 \ 0 & 1 & 0 & 0 \ 0 & 0 & 1 & 0 \end{bmatrix} egin{bmatrix} r_{11} & r_{12} & r_{13} & t_x \ r_{21} & r_{22} & r_{23} & t_y \ r_{31} & r_{32} & r_{33} & t_z \ 0 & 0 & 0 & 1 \end{bmatrix} egin{bmatrix} X_w \ Z_w \ 1 \end{bmatrix}$$



This matrix contains the camera (~robot) position coordinates in the world

# visible light positioning (VLP)



### sensor classification



- Proprioceptive / exteroceptive
  - Proprioceptive information internal to the robot.
    - Ex: motor speed, battery voltage, ...
  - Exteroceptive: external information to the robot
    - Ex .: distance to objects, light intensity
- Passive / Active
  - Passive: have no explicit source of energy; energy required comes from the measurement process itself
    - Ex temperature probes .:
  - Active: have internal power source, necessary for the measurement process; uses that energy to interact with the environment
    - Ex .: laser range finder

Classification	Sensor	PC/EC	A/P
Tactile Sensors	Switches	EC	Р
	Optical barrier	EC	А
	Contactless proximity sensors	EC	Α
Wheels and motors	Potentiometers	PC	Р
	Synchros and resolvers	PC	Α
	Optical encoders	PC	Α
Orientation	Compass	EC	Р
	Gyroscope	PC	Р
	Inclinometer	EC	A/P
Localization	GPS	EC	Α
	RF beacons	EC	Α
	Reflected beams	EC	Α
Ranging	Sensores ultrassons	EC	Α
	Laser Range Finder	EC	Α
	Optical triangulation	EC	Α
Vision	CCD/CMOS cameras	EC	Р

R. Siegwart e I. R. Nourbakhsh, *Introduction to autonomous mobile robots*. Cambridge Mass.: MIT Press, 2004.

## **Challenge**



- Think of a mobile robot mission
- Devise the sensor structure required for that mission
  - What sensors will the robot need?