State Diagrams

Embedded Temp System


Content

01 High-Level State Diagram Start-up/Init

02 High-Level State Diagram Normal/Run-Mode


03 High-Level State Diagram LED_Function

High-Level State Diagram
Start-up/Init



Mapping of SW used label
init_status == 255 -> == ERROR
init_status != 255 -> != ERROR

High-Level State Diagram
Normal/Run-Mode



!Attention! = not all jumps to ERROR Mode/State are visible in this diagram, only from readAdc as example

High-Level State Diagram
LED_Function

