
## ece 310 lab 2

```
%forward 10k
filename = 'Lab2.xlsx';
sheet = 1;
figure
subplot(2,1,1)
vr1 = xlsread(filename, sheet, 'B2:L2');
vd1 = xlsread(filename, sheet, 'B3:L3');
ir1 = vr1./9383;
plot(vd1,ir1);
hold on;
%reverse 10k
vrr1 = xlsread(filename, sheet, 'B7:Q7');
vdr1 = xlsread(filename, sheet, 'B8:Q8');
vdr1 = vdr1.*(-1);
irr1 = vrr1./9383;
irr1 = irr1.*(-1);
subplot(2,1,1)
plot(vdr1,irr1), grid on
xlabel('V_d')
ylabel('I_d')
title('I-V plot with diode')
%forward 500
subplot(2,1,2)
vr2 = xlsread(filename, sheet, 'B12:L12');
vd2 = xlsread(filename, sheet, 'B13:L13');
ir2 = vr2./474.95;
plot(vd2,ir2);
hold on;
%reverse 500
vrr2 = xlsread(filename, sheet, 'B17:Q17');
vdr2 = xlsread(filename, sheet, 'B18:Q18');
vdr2 = vdr2.*(-1);
irr2 = vrr2./474.95;
irr2 = irr2.*(-1);
plot(vdr2,irr2), grid on
xlabel('V_d');
ylabel('I_d');
title('I-V plot with zener diode')
```



Published with MATLAB® R2015b