PlasmidPure Mini Kit

Handbook for the purification of plasmid DNA

For research use only.

Contents

Kit contents..... 3
Storage..... 3
Protocol: plasmid miniprep..... 4
Troubleshooting..... 5

Kit contents

Component	50 preps	250 preps
Buffer R1 (resuspension)	15 ml	70 ml
Buffer L2 (lysis)	15 ml	70 ml
Spin columns	50	250

Storage

Store the buffers at room temperature (15–25 °C). After adding RNase A, store Buffer R1 at 2–8 °C.

Protocol: plasmid miniprep

Important: add the supplied RNase A to Buffer R1 before first use.

1. Pellet 1–5 ml of overnight culture by centrifugation at >8000 × g for 3 min.
2. Resuspend the pellet in 250 µl Buffer R1. No cell clumps should be visible after resuspension of the pellet.
3. Add 250 µl Buffer L2 and mix thoroughly by inverting the tube 4–6 times until the solution becomes clear. Do not allow the lysis reaction to proceed for more than 5 min.
4. Centrifuge for 1 min and discard the flow-through.

Optional: wash the column with 500 µl Buffer PB if the host strain has high nuclease activity.

5. Elute the DNA in 50 µl of water.

Troubleshooting

Problem	Comments and suggestions
Low yield	The culture was too old or the lysis was incomplete. Use fresh cultures and mix thoroughly after adding Buffer L2.
RNA in the eluate	RNase A was not added to Buffer R1, or the buffer was stored too long after adding it.