John Gangemi U 6871-4612 CDA 4203 Sec 001 Spring 2015 2/2/15

Homework 2: PicoBlaze Microcontroller

1. (5 pts.) PicoBlaze Architecture

Answer the following questions about the PicoBlaze Architecture:

- a. List all storage units and what kind of data they can store (data, instructions, addresses)?
 - i. 1K x 18 Instruction PROM [instructions]
 - ii. 16 Byte-wide registers [data]
 - iii. 64-byte scratchpad RAM [data]
 - iv. Call/Return stack [instruction addresses]
- b. What is the address range (in hex) for the instruction PROM?
 - i. PROM can hold 210 instructions where the range is from 0 to 2n-1 in binary (11111111112) and in hexadecimal the range is from 000 to 3FF.
- c. How many cycles does an instruction consume?
 - i. All instructions under all conditions will execute over 2 clock cycles
- d. What is the purpose of NOP instruction?
 - i. To stall program execution by a single instruction for more predictable timing.
- e. List all instructions that *directly* manipulate the call/return stack.
 - i. CALL, RETURN, RETURNI, enabled INTERRUPT event, RESET event
- f. How many clock cycles does instruction decode take?
 - i. Instruction decode takes one clock cycle.
- g. What is the purpose of the interrupt input? How can we disable interrupts?
 - **i.** To handle multiple asynchronous external events. To disable interrupts call the DINT instruction.
- h. What flags does the test instruction affect? Does it affect the register contents?
 - **i.** The test instruction only affects the CARRY and ZERO flags, and does not affect register contents.
- i. When we execute a call instruction, does the PicoBlaze save the register file contents?
 - i. No, the register file address space is not directly modified by the CALL instruction per Table
 - 3-2 from PicoBlaze Documentation.
- j. What is the difference between ADD and ADDCY instructions? Explain why we need two variants of ADD instructions?
 - **i.** ADD and ADDCY instructions compute the sum of two 8-bit operands, however the ADDCY instruction accounts for the CARRY flag having been set. Having both variants increases program flexibility.

2. (5 pts.) PicoBlaze -- Word Parity:

```
IN_PORT DSIN $00
OUT_PORT DSOUT $01

LOOP:
IN s0, IN_PORT
DINT
TEST s0, $FF
EINT
LOAD s1, $00
ADDC s1, $00
OUT s1, OUT_PORT
JUMP LOOP
```

3. (15 pts.) Simple Loopback System

a. (2 pts.) Explain under what condition(s) should the following signals be asserted?

```
    i. read_from_uart

            data_present (port_id 4) = 1 and read_strobe = 1 and buffer_full (port_id 5) = 0

    ii. write_to_uart

            write_strobe = 1
```

b. **(4 pts.)** cold_start: Write code to output a message "Welcome to Loopback!" to the serial port. You need encode the message in ASCII format.

```
; adapted from PicoBlaze KCPSM6 Instruction Set Reference Documentation
; topic: "Text Strings"
; author: Xilinx
; page: 99
buffer full DSIN $05
tx_data DSOUT $03
LOOP:
 LOAD s0, $61; W
 CALL TRANSMIT
 LOAD s0, $65 ;e
 CALL TRANSMIT
 LOAD s0, $6B ;1
 CALL TRANSMIT
 LOAD s0, $63 ;c
 CALL TRANSMIT
 LOAD s0, $6F ;o
```

```
CALL TRANSMIT
 LOAD s0, $6D; m
 CALL TRANSMIT
 LOAD s0, $65 ;e
 CALL TRANSMIT
 LOAD s0, $20 ;space
 CALL TRANSMIT
 LOAD s0, $74 ;t
 CALL TRANSMIT
 LOAD s0, $6F ;o
 CALL TRANSMIT
 LOAD s0, $20 ;space
 CALL TRANSMIT
 LOAD s0, $4C ;L
 CALL TRANSMIT
 LOAD s0, $6F ;0
 CALL TRANSMIT
 LOAD s0, $6F ;0
 CALL TRANSMIT
 LOAD s0, $70 ;p
 CALL TRANSMIT
 LOAD s0, $62 ;b
 CALL TRANSMIT
 LOAD s0, $61 ;a
 CALL TRANSMIT
 LOAD s0, $63 ;c
 CALL TRANSMIT
 LOAD s0, $6B ;k
 CALL TRANSMIT
 LOAD s0, $21 ;!
 CALL TRANSMIT
 LOAD s0, $0 ; null
 CALL TRANSMIT
 JUMP LOOP
TRANSMIT:
 IN s1, buffer_full
 COMP s1, $00 ; set zero flag if buffer_full == 0
 JUMP NZ, TRANSMIT; loop recursive if zero flag not set
```

OUT s0, tx_data ; transmit data

RET

c. (4 pts.) led_echo: Write code to read switches and write it, inverted, to the LEDs.

```
switches DSIN $00
leds DSOUT $01
LOOP:
IN s0, switches
XOR s0, $FF
OUT s0, leds
```

JUMP LOOP

d. **(5 pts.)** rs232_echo: Write code to check if a byte has been received by UART_RX. If so, send it back to PC via UART_TX.

```
data_present DSIN $04
buffer_full DSIN $05
rx_data DSIN $02
tx_data DSOUT $03
LOOP:
 IN s2, rx_data
 CALL CHECK_DATA
 CALL CHECK_BUFF
 OUT s2, tx_data
 JUMP LOOP
CHECK_DATA:
 IN s0, data_present
 COMP s0, $01 ; set zero flag if data_present == 1
 RET Z ; return if zero is set
 JUMP CHECK_DATA
CHECK_BUFF:
 IN s1, buffer_full
 COMP s1, $00 ; set zero flag if buffer_full == 0
 RET Z ; return if zero is set
```

JUMP CHECK_BUFF