Warning!

Install the Arduino board on the **bottom side** (opposite the other components).

Install only AFTER installing D40, D51, R54, C7 or you won't be able to solder them!

Cut along edges. To be placed inside a separate plastic pouch with the Arduino board, separate from the rest of the components.