



Dishwasher tablets · Lemon, x51

Fairy Platinum Dishwasher Tablets

All-in-one tablets for household & small dishwashers

1 tablet**All-in-one****No unwrapping**
per cycle detergent, rinse aid & saltfilm dissolves in the wash

Fairy Platinum Dishwasher Tablets are all-in-one tablets combining detergent, rinse aid and salt action in one dose — no need to separately top up rinse aid or dishwasher salt for most water hardness levels. The outer film dissolves during the wash, so there's no unwrapping.

Before you start

- Keep tablets in their original packaging until use, out of reach of children.
- Do not cut or break tablets.

How to use it

No measuring — just one tablet per cycle.

●Running a cycle

- 1 Place one tablet in the dishwasher's detergent compartment.
- 2 Close the compartment and start the cycle as normal — the film dissolves during the wash.
- 3 In very hard water areas, you may still want to top up dishwasher salt separately for best results.

Product details

Format	Individually wrapped tablets (x51)
Fragrance	Lemon

Suitable for: household and small commercial dishwashers.