

Office of Residence Life Laundry Maintenance Guide

LAUNDRY MACHINE OPERATION AND MAINTENANCE

In order to ensure the proper operation of your apartment's dryer, please be sure to clean the lint trap after each use.


LOCATING YOUR UNIT'S LINT TRAP

In some models, a basket is mounted inside the dryer barrel. Simply pull this basket out to remove the lint. Other models feature a door mounted lint trap. To access this lint trap, slide the rectangular grate out to expose the lint trap. Remove the lint from the door mounted trap and return the grate before reusing the dryer.

INTERNAL LINT TRAP



DOOR MOUNTED LINT TRAP



ENSURE EFFICIENT OPERATION

When lint builds up in your lint trap, air flow is diminished, and your dryer will not function efficiently. In some apartments your laundry unit may have a closet door. We recommend that you leave this door open when your washer or dryer are in use. Please remove lint after each use of the dryer.

If you suspect their is a maintenance issue with your laundry unit, please file a work order and follow up with the Residence Life team. To file a work order, please follow the instructions posted in your apartment or make use of the St. John's app. You can share your ticket number with the Residence Life team for additional attention or follow up.