




## Replacement Parts

Keep this manual for ordering replacement parts.





- NO NAME
- 1. Handle
- 2. Handle body
- 3. Allen screw(M4)
- 4. Cartridge holder
- 5. Cartridge
- 6. Faucet body
- 7. Oring
- 8. Aerator
- 9. Aerator holder
- 10. Oring
- 11. Rubber gasket
- 12. Stainless steel gasket
- 13. Lock screw
- 14. Lock nut
- 15. Supply pipe
- 16. Spanner for body














## Notice:

Please removing all of the sand, silt and other things from the water hose before assembling, to avoid blocking the faucet and effecting water rate. Please use the special tools to disassemble it and wash with pneumatic equipment, if the faucet blocked