




Product Description and Measurements

Installation Instruction

Single Lever Pul Out Sink Mixer



Dear Valued Customer,

Kraus would like to take this opportunity to thank you for purchasing Kraus products. It is our sincere hope that you are completely satisfied with your new purchase. We welcome any questions or comments you may have and look forward to assisting you in the future.

Sincerely,

Kraus customer service department.

Prior To Installation Steps

- 1. Unpack your new product and ensure that all the parts are contained in the packaging. Keep the product in its original box until you are ready to install it.
- 2. Shut off the water supply if replacing a previously-installed faucet.
- 3. Observe all plumbing and building codes in your area.
- 4. It is recommended that installation of the product be done by a professional plumber.

Installation Steps

- **1.** Shut off all water supply prior to installation
- 2. Remove the metal spring (#14) by disassembling it from the hose.
- 3. Screw on the aerator head (#2) onto the spout (#3). Make sure that a black rubber washer is attached to the end of the hose prior to attaching the aerator head.
- 4. Place the black rubber o-ring (#4) into the metal ring (#5).
- 5. Place the metal ring (#5) onto the faucet body (#1).
- 6. Unscrew the brass nut (#7) from the brass screw (#6).
- 7. Place the faucet on the countertop.
- 8. If the countertop is thin or the faucet is being mounted on the sink itself, place the countertop extender (#15) from underneath the countertop and tighten it onto the brass screw. **Optional**
- 9. Place the rubber washer (#8) and then the metal washer (#9) onto the brass screw from underneath the countertop.
- 10. Tighten the brass nut (#7) onto the brass screw (#6).
- 11. Place the plastic enclosure (#10) onto the hose and situate the smaller opening onto the brass screw (#6).
- 12. Place the spring (#14) onto the hose.
- 13. Place the red hard washer (#11) into the hose inlet (#13) and screw the hose (#12) (with the spring already attached) onto the brass screw (#6).
- 14. Screw in the hot and cold waterlines (#16) and attach them to the water supply.



MODEL-KPF-1620

Installation

Code	Parts List	Quantity	(3)
1	Faucet	1	
2	Aerator Head	1	
3	Spout	1	2
4	Rubber O-Ring	1	
5	Metal Ring	1	
6	Brass Screw	1	Aerator
7	Brass Nut	1	(1) — Aeraior
8	Rubber Washer	1	
9	Metal Washer	1	(5)
10	Plastic Enclosure	1	4 (15)
11	Red Hard Washer	1	6
12	Hose	1	8
13	Hose Inlet	1	9 (16)
14	Spring	1	7
15	Counter Top Extender (optional)	1	10
16	Hot & Cold Water Lines	2	13 (11)
lush ne pipe	Do Not Disassemble		13 11 14


Do not disassemble the main body, as it has been installed & commissioned correctly & precisely before leaving the factory.

To avoid the faucet from jamming, DO flush the water pipe before installation. After installation make sure every joint is safely sealed (NO LEAKAGE). Make sure to connect the hot/cold inlet pipe correctly form front view hot water pipe connecting to the left and cold water pipe connecting to the right.



MODEL-KPF-1620

Installation



Usage, Cleaning & Maintenance

Cleaning & Maintenance

To keep product clean and shiny follow the instruction below.

- Flush with clean water and dry with soft cloth only.
 Do not use any detergent, polisher, sane-cloth, or a scraper.
 - 3. Do not use acid detergent.

Usage

How to operate the handle

- 1. Raise the handle lever up for opening water, push it down for close.
- 2. Turn the handle lever to left to increase hot water flow for higher water temperature by operating reversely.
- 3. The swivelling can be circled 360.