PSS®E PTI License Manual Version 3
September 2017

Copyright © 1990-2017 Siemens Industry, Inc., Siemens Power Technologies International

Information in this manual and any software described herein is confidential and subject to change without notice and does not represent a commitment on the part of Siemens Industry, Inc., Siemens Power Technologies International. The software described in this manual is furnished under a license agreement or nondisclosure agreement and may be used or copied only in accordance with the terms of the agreement. No part of this manual may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, for any purpose other than the purchaser's personal use, without the express written permission of Siemens Industry, Inc., Siemens Power Technologies International.

PSS®E high-performance transmission planning software is a registered trademark of Siemens Industry, Inc., Siemens Power Technologies International in the United States and other countries.

The Windows 7® and Windows 10® operating systems, the Visual C++® development system, Microsoft Office Excel® and Microsoft Visual Studio® are registered trademarks of Microsoft Corporation in the United States and other countries.

Intel® Visual Fortran Compiler for Windows is a trademark of Intel Corporation in the United States and other countries.

The Python™ programming language is a trademark of the Python Software Foundation.

Other names may be trademarks of their respective owners.

Table of Contents

Introduction to Siemens PTI License 1
Installing CodeMeter Runtime 2
Getting Ticket ID 3
Individual License Collection 4
Errors Collecting With Web Browser 6
Manual Collecting 8
Network License Collection 9
Client License Setup 11
Checking Your Installed Licenses 12
Returning a License 13
CodeMeter Performance Tuning 14
Troubleshooting 15

All material contained in this documentation is proprietary to Siemens Industry Inc., Siemens Power Technologies International

Chapter 1
Introduction to Siemens PTI License

Wibu CodeMeter®

Siemens PTI uses CodeMeter® from Wibu-Systems to provide protection and license management of Siemens PTI software. CodeMeter® offers hardware (CmDongle) and software based (CmActLicense) protection and licensing technology for digital contents for desktop PCs and servers. CmDongle, the hardware-based variant of the protection and licensing technology from CodeMeter®, is available in many form factors for a variety of interfaces and allows for multiple Independent Software Vendors to share a single CmDongle. Siemens PTI uses USB hardware devices. CmActLicense is a completely software-based variant of the protection and licensing technology from CodeMeter® that protects software by binding to the characteristics of an individual PC with the exception of virtual machines (see Virtual Machines below). CmActLicense licenses are bound to hardware properties of the PC on which they are accessed. Please make sure you activate a CmActLicense license only on the PC for which you want to use the license.

Siemens PTI products protected with CodeMeter

PSS®E starting with versions 33.8 and 34.1

PSS®MUST starting with versions 11.2.5 and 12.0

Model Management starting with version 1.0

CIM Importer starting with version 1.0.1

Requirements to run Siemens PTI product protected with CodeMeter

The CodeMeter Runtime Kit installed.

CmActLicense from Siemens PTI. A CmActLicense is created on your computer by using a Ticket ID, supplied by Siemens PTI, during the license collection process.

Virtual Machines:

- CodeMeter license collection is not allowed on Virtual Machines. Virtual machines can obtain a license from USB CmDongle or a network license collected on a physical machine.

All material contained in this documentation is proprietary to Siemens Industry Inc., Siemens Power Technologies International

Chapter 2
Installing CodeMeter Runtime

Installing CodeMeter Runtime

The CodeMeter® Runtime Kit Setup Wizard is installed to support WIBU license management. Installation on 32/64-bit Windows operating systems begins by running "CodeMeterRuntime.exe" that shipped with the software.

More CodeMeter® options are available for downloaded from http://www.wibu.com/en/downloads-user-software.html.

Full Installation Package

This package holding all necessary components of the CodeMeter® Runtime is available for 32/64-bit operating systems.

It is available as executable file (CodeMeterRuntime32/64.exe) and as separate package for Managed Software Installation using the Windows Installer service msiexec.exe (CodeMeterRuntime32/64.msi).

Reduced Installation Package

This package also available for 32/64-bit operating systems presents a reduced functional scope of CodeMeter® Runtime. Not included are the relevant files of CodeMeter Control Center, the separate User Help, and the entries is the Windows start menu (shortcuts).

It is available as executable file (CodeMeterRuntime32/64Reduced.exe) and as separate package for Managed Software Installation using the Windows Installer service msiexec.exe (CodeMeterRuntime32/64Reduced.msi).

The executable file of the reduced installation package is not downloadable in the user section of the WibuSystems website but in the developer section.

If you use the reduced installation package, please note that the CmDust entry of the start menu is no longer available. Creating the log file then alternative must be triggered using the command line tool cmu.

All material contained in this documentation is proprietary to Siemens Industry Inc., Siemens Power Technologies International

Chapter 3
Getting Ticket ID

A Ticket ID is needed to license your Siemens PTI product

A Ticket ID is a 25 character string consisting of alpha numeric characters in a five quintet character string separated by hyphens.

Example ABCD1-EF23G-4HI5J-K6LMN-7OPQR

Where to get Ticket ID

Ticket ID are issues by Siemens PTI to the primary contact for each software product. You can contact Siemens PTI if you do not know whom the primary contact is at your organization. Contact Siemens PTI via any of the following methods. Visit the Siemens PTI Products Customer Support Form at https://siemens-energy.secure.force.com/pti. Send an e-mail to technical support at pti.support.energy@siemens.com.

How to use Ticket ID

Collect a license using a web browser with Java enabled. Refer to Chapter 4, *Individual License Collection* for more information.

Collect a license through the exchange of files with Siemens PTI customer support. Refer to Chapter 6, *Manual Collecting* for more information.

All material contained in this documentation is proprietary to Siemens Industry Inc., Siemens Power Technologies International

Chapter 4
Individual License Collection

Instructions to collect a license with a Ticket Id

CodeMeter licenses cannot be collected on virtual machines. They must be collected on a physical computer or a CmDongle (a CodeMeter USB dongle). When collecting a CodeMeter network license, make sure to collect the license on the computer that will be the license server.

Note: CodeMeter licenses must be returned before decommissioning a computer. A License not returned will be lost.

1. Navigate to Siemens PTI WebDepot URL: http://na.ptd.siemens.com/pti/wibu/webdepot/

2. Enter the Ticket: XXXXX-XXXXX-XXXXX-XXXXX-XXXXX and click Next

3. Click Activate Licenses. You may see 3 options:

   - "I want my licenses in a dongle (CmDongle) to be able to use them on different computers. Firm Code: 102346". This is for hardware based licensing using a WIBU CodeMeter CmDongle.

   - "I want my licenses on one computer (CmActLicense). Firm Code: 5000333 | CmContainer: PTI_CmAct_1 (0001)". This is for software based licensing where the license is bound to an individual PC. Tickets issued before June 2017 should use the “PTI_CmAct_1 (0001)" option.

   - If you see the 3rd option, "I want my licenses on one computer (CmActLicense). Firm Code: 5000333 | CmContainer: PTI_CmAct_All (0002)". You should choose this option. This option should only be available for tickets issued after June 2017.

4. Click the option that is correct for your situation. If you don't have a CmDongle you have to use the CmActLicense option. If you ordered a CmDongle, you must wait until you receive the CmDongle to collect the licenses. Once a CodeMeter license is collected into a CmAct software container, it cannot be returned and re-collected into a CmDongle.

5. License Type:

   - For CmAct licenses, Select "Get CmContainer automatically" from the drop down menu and click "Activate Selected Licenses now".

   - For CmDongle licenses, Select your CmDongles serial number from the drop down menu and click "Activate Selected Licenses now".

If you are having problems collecting/updating a license, update your CodeMeter runtime to the latest version.

1. Download and install the latest version of the CodeMeter Runtime from http://www.CodeMeter.com/

2. From the menu bar, select Downloads.

All material contained in this documentation is proprietary to Siemens Industry Inc., Siemens Power Technologies International

3. Download and install the latest CodeMeter Runtime, currently "CodeMeter Runtime-Kit 6.50c for Windows 32 and 64 Bit Update": 2017-09-27.

PSS® MUST only:


- Delete the default "Using Sentinel License"
- On any system running PSS®MUST with a CodeMeter license, you need to delete the default installed MUST_12.x.x_Use_Sentinel_License entry
- You can either use the .bat file shipped with MUST: "C:\Program Files (x86)\PTI\MUST 12.x.x\Dongle\Delete_MUST_12.x.x_Container_EXP_Apr.1.2019.bat."
- Download and run the .bat file: https://ptisupport.ptd.siemens.com/files/PTI_Customer/3WIBU_LIF/Delete_MUST_12_Container.bat
- Or with the command: "C:\Program files (x86)\CodeMeter\Runtime\bin\CMU32" --delete-cmact-license --serial 128-4578038
- To run this command, open a DOS window with administrative rights and give execute the command above
- Be very careful when using this command as it can delete any license and they are not recoverable
- Do not use this to delete any other license

All material contained in this documentation is proprietary to Siemens Industry Inc., Siemens Power Technologies International

Chapter 5
Errors Collecting With Web Browser

If the collection of a license is unavailable due to Java/ActiveX problems, use the offline activation.

1. Click OK on the Application Clocked by Java Security window.



2. You may see 3 options:


   - "I want my licenses in a dongle (CmDongle) to be able to use them on different computers. Firm Code: 102346". This is for hardware based licensing using a WIBU CodeMeter CmDongle.

   - "I want my licenses on one computer (CmActLicense). Firm Code: 5000333 | CmContainer: PTI_CmAct_1 (0001)". This is for software based licensing where the license is bound to an individual PC. Tickets issued before June 2017 should use the “PTI_CmAct_1 (0001)" option.

   - If you see the 3rd option, "I want my licenses on one computer (CmActLicense). Firm Code: 5000333 | CmContainer: PTI_CmAct_All (0002)". You should choose this option. This option should only be available for tickets issued after June 2017.

3. Click on the Offline Activation link at the bottom of the page.

All material contained in this documentation is proprietary to Siemens Industry Inc., Siemens Power Technologies International



4. Open the CodeMeter Control Center window. It is available in Windows start menu at: All Programs -> CodeMeter -> CodeMeter Control Center.

5. Import the file (PTI_CmAct_1.wbb) into CodeMeter Control Center. The file PTI_CmAct_1.wbb is located in your Siemens PTI software installation folder.

6. Click Activate License.

7. Click Next.

8. Make sure Create license request is selected.

9. . Choose a location to save the License Request File (*.WibuCmRAC) for your computer.

10. Click Commit and then Finish.

11. Go back to the Siemens PTI WebDepot and click Browse to locate the License Request File (*.WibuCmRAC) created in step 9.

12. Click Get License Update.

13. Once you receive the license update file, import it into the CodeMeter Control Center and Activate the license.

All material contained in this documentation is proprietary to Siemens Industry Inc., Siemens Power Technologies International

Chapter 6
Manual Collecting

Activating CmActLicense licenses

Contact Siemens PTI via any of the following methods to begin the license process. Visit the Siemens PTI Products Customer Support Form at https://siemens-energy.secure.force.com/pti. Send an e-mail to technical support at pti.support.energy@siemens.com.

You will be given a license information file to begin the process. If available, you will be directed to our Web Depot to collect your license with a ticket ID.

Proceed as follows to activate a CmActLicense licenses on your PC with a license information file you received from Siemens PTI

1. Drag & drop the *.wbb file, e.g. MyCmActLicense.wbb, you received from Siemens PTI onto CodeMeter Control Center.

   The "Status" field will show that this is only an empty license container and not a license. At the same time the CodeMeter® symbol changes to red.

2. Click the "Activate License" button to create a license request fill, e.g. *.WibuCmRaC, and send it to Siemens PTI.

3. Siemens PTI will send you a license update file, e.g. *.WibuCmRaU.

4. Drag & drop the *.WibuCmRaU file you received from Siemens PTI onto CodeMeter Control Center.

   The "Status" field shows that the license has been activated. At the same time, the license has a serial number, and the CodeMeter® symbol has switched to activated status.

All material contained in this documentation is proprietary to Siemens Industry Inc., Siemens Power Technologies International

Chapter 7
Network License Collection

Instructions to collect a CodeMeter network license, into a CmAct container or CmDongle, with a Ticket Id

When collecting a CodeMeter network license, make sure to collect the license on the computer that will be the license server. The CodeMeter runtime is required to be installed on the computer that will be the license server. See below to download the CodeMeter runtime.CodeMeter licenses cannot be collected on virtual machines. They must be collected on a physical computer or a CmDongle (a CodeMeter USB dongle).

Note: CodeMeter licenses must be returned before decommissioning a computer. A License not returned will be lost.

1. On the computer that will be the license server, navigate to Siemens PTI WebDepot URL: http://na.ptd.siemens.com/pti/wibu/webdepot/
2. Enter the Ticket: XXXXX-XXXXX-XXXXX-XXXXX-XXXXX and click Next
3. Click Activate Licenses. You may see 3 options:
   - "I want my licenses in a dongle (CmDongle) to be able to use them on different computers. Firm Code: 102346". This is for hardware based licensing using a WIBU CodeMeter CmDongle.
   - "I want my licenses on one computer (CmActLicense). Firm Code: 5000333 | CmContainer: PTI_CmAct_1 (0001)". This is for software based licensing where the license is bound to an individual PC. Tickets issued before June 2017 should use the “PTI_CmAct_1 (0001)" option.
   - If you see the 3rd option, "I want my licenses on one computer (CmActLicense). Firm Code: 5000333 | CmContainer: PTI_CmAct_All (0002)". You should choose this option. This option should only be available for tickets issued after June 2017.
4. Click the option that is correct for your situation. If you don't have a CmDongle you have to use the CmActLicense option. If you ordered a CmDongle, you must wait until you receive the CmDongle to collect the licenses. Once a CodeMeter license is collected into a CmAct software container, it cannot be returned and re-collected into a CmDongle.
5. License Type:
   - For CmAct licenses, Select "Get CmContainer automatically" from the drop down menu and click "Activate Selected Licenses now".
   - For CmDongle licenses, Select your CmDongles serial number from the drop down menu and click "Activate Selected Licenses now".
6. If you receive a Java/ActiveX warning when trying to collect a license, use the following file to complete the steps in Chapter 4, Collecting With Web Browser or Chapter 6, Manual Collecting.
7. Once the license has been collected, open the CodeMeter Control Center window. It is available in Windows start menu at: All Programs>CodeMeter>CodeMeter Control Center.

All material contained in this documentation is proprietary to Siemens Industry Inc., Siemens Power Technologies International

8. Click the WebAdmin button in the lower right of the dialog window. This will open your default browser to the CodeMeter WebAdmin.

9. In WebAdmin, select Configuration>Server>Server Access

10. On the Server Access tab, enable Network Server and if desired CmWAN Server. Click apply. Note: Changes only take effect after restarting CodeMeter.

11. Return to the CodeMeter Control Center and click Process>Restart CodeMeter Service to apply your changes

12. Your license server is now set up to distribute network licenses

13. For detailed information on administering CodeMeter license, download the "CodeMeter Administrator Manual" from: https://www.wibu.com/manuals-guides.html Note: CodeMeter license servers use port 22350 by default.

If you are having problems collecting/updating a license, update your CodeMeter runtime to the latest version.

1. Download and install the latest version of the CodeMeter Runtime from http://www.CodeMeter.com/

2. From the menu bar, select Downloads.

3. Download and install the latest CodeMeter Runtime, currently "CodeMeter Runtime-Kit 6.50c for Windows 32 and 64 Bit Update": 2017-09-27.

All material contained in this documentation is proprietary to Siemens Industry Inc., Siemens Power Technologies International

Chapter 8
Client License Setup

The client license setup should be performed after a Network License has been collected.

1. Install the Siemens PTI software. This will also install the CodeMeter Runtime.
2. Open the CodeMeter Control Center window. It is available in Windows start menu at: All Programs>CodeMeter>CodeMeter Control Center.
   - If the CodeMeter Control Center is not installed, you may have had an issue with the CodeMeter Runtime installation. Install the latest version of the CodeMeter User Runtime for Windows which can be downloaded from https://www.wibu.com/downloads-user-software.html.
3. Click the WebAdmin button in the lower right of the dialog window. This will open your default browser to the CodeMeter WebAdmin.
4. In WebAdmin, select Configuration>Basic>Server Search List.
5. Click "add new Server" and Enter the Server's name or IP-Address.
6. Click Add and then Apply.
7. Your Client computer is now set up to search for a network licenses.

CodeMeter license servers use port 22350 by default.

All material contained in this documentation is proprietary to Siemens Industry Inc., Siemens Power Technologies International

Chapter 9
Checking Your Installed Licenses

Viewing License

You can view all of your CodeMeter licenses using the WebAdmin. Open the CodeMeter Control Center either by navigating to the Start menu program option Start Menu\Programs\CodeMeter\ CodeMeter Control Center or by clicking on the CodeMeter icon on you task bar.

Once the CodeMeter Control Center is open, click on the WebAdmin button. That will open the WebAdmin in your browser (http://localhost:22350).

Click on Content>Licenses to see what licenses you have installed. Siemens PTI licenses will be under the sections 102346 and 5000333. You may see license information for other non-Siemens PTI products as well. This is normal as other products may also use CodeMeter technology.

More information about CodeMeter licensing is available in the CodeMeter Administrators Manual, downloaded from http://www.wibu.com/en/manuals-guides.html.

All material contained in this documentation is proprietary to Siemens Industry Inc., Siemens Power Technologies International

Chapter 10
Returning a License

Instructions on how to return a CodeMeter License

When the computer has Internet access:

1. Navigate to Siemens PTI WebDepot URL: http://na.ptd.siemens.com/pti/wibu/webdepot/
2. Enter the Ticket: XXXXX-XXXXX-XXXXX-XXXXX-XXXXX and click Next
3. If you see the button "Continue License Transfer", click it. After the license transfer is done, click the Home link on the upper left of the page and enter the ticket ID again. Click next
4. Click Return license. After a few seconds this process should finish. The license should have been returned and be available for collection. CodeMeter licenses collected into a CmActLicense container, cannot be returned and re-collected into a CmDongle.

When the computer does not have Internet access:

This process requires the sending of multiple emails to confirm license deletion.

1. Run the program Start Menu\Programs\CodeMeter\Tools\CmDust, to create a log file, listing the licenses on your system.
2. A DOS Box will appear for some moments. Windows Explorer will open in the location of C:\Users\User-Name, Were UserName is the login name of the user. There you will find a file named “CmDust-Result.log”.
3. Send us the file named “CmDust-Result.log”. If more that 1 log file is created in that directory, please send us the most recent.
4. PTI examines the log file to confirm which license to delete.
5. Send the user a command to delete the license.
6. After running the command on each system, have the user create new log files, using CmDust.
7. Send the log file to PTI.
8. PTI examines the log file to confirm that the license has been deleted.
9. PTI will issue a new license that can be collected on the users system.

All material contained in this documentation is proprietary to Siemens Industry Inc., Siemens Power Technologies International

Chapter 11
CodeMeter Performance Tuning

Speed Up Options / Delayed Start-up Issues:

A delayed start time can happen when your system UDP waiting time set to 1000 Milliseconds. The PSS®E installer should have changed this to 100 Milliseconds. Make sure to reboot your system after installing a PSS® product. A reboot is needed to the change the UDP waiting time.

To change/check the UDP Waiting Time setting:

1. Open the CodeMeter Control Center window. It is available in your Windows start menu at: All Programs>CodeMeter>CodeMeter Control Center.

2. Click the WebAdmin button in the lower right of the dialog window. This will open your default browser to the CodeMeter WebAdmin.

3. Select Configuration>Advanced

4. On the Extra tab you can change the UDP Waiting Time to 100 Milliseconds if needed

Note:

Changes only take effect after restarting CodeMeter service.

Another reason your start time could be delayed is if your system is looking for a CodeMeter network license, when it shouldn't. If you are using a Sentinel network license and not a CodeMeter network license, you should not have an entry in your Server Search List.

1. Open the CodeMeter Control Center window. It is available in your Windows start menu at: All Programs>CodeMeter>CodeMeter Control Center.

2. Click the WebAdmin button in the lower right of the dialog window. This will open your default browser to the CodeMeter WebAdmin.

3. In WebAdmin, select Configuration>Basic>Server Search List

4. If you have a Server listed, that is not for another product, deleting this entry should reduce the PSS® product start up time.

5. Another option is to add you local system to this Server Search List. Click add new Server. Enter the IP Address 127.0.0.1 and click add.

All material contained in this documentation is proprietary to Siemens Industry Inc., Siemens Power Technologies International

Chapter 12
Troubleshooting

Troubleshooting

Generate a CmDust Diagnostic Report on the system having problems. Here is how to generate one.

To generate a CmDust Diagnostic Report:

1. Go to Start->CodeMeter->Tools->CmDust.
2. A DOS Box will appear for some moments.
3. An Explorer window will open in C:\Users\username. There will be a file named “CmDust-Result.log”. Send us the file “CmDust-Result.log”.

All material contained in this documentation is proprietary to Siemens Industry Inc., Siemens Power Technologies International