
Table of Contents				
01	Title Page			
02	Block Diagram			
03	MCU MCXC444			
04	Headers			
05	USB & PWR			
06	MCU_LINK_USB			
07	MCU_LINK_DEBUG			
08	APPENDIX JUMPER/DNF			


		1					
	Revisions						
Rev	Description	Date	Approved				
X1	Initial release	Mar 5, 2024	William Jiang				
X2	BOM optimzatiom	Mar 6, 2024	William Jiang				
Α	SCH optimzation	Mar 12, 2024	William Jiang				

# FRDM-MCXC444












#### **ARDUINO HEADERS**










#### MOUNTING HOLE














#### POWER













## MCU-Link Debug Interface



#### MCU-Link UART



### USB Bridge





REF DES	JUMPER	PAGE NAME
JP6,JP7	1-2	03-MCU MCXC444
JP1	1-2	05 USB & PWR
JP2,JP3,JP4	OPEN	06 MCU_LINK_USB
JP5	1-2	07 MCU LINK DEBUG

REF DES	ASSY_OPT	PAGE NAME
C17,C18,C19,C22,J7,J11,R30, R31	DNP	04-Headers
C4,C6,C12,D2,JP6,R3	DNP	03-MCU MCXC444
D7,R43,U4	DNP	05 USB & PWR
C44,C45,R57,R62,R63,R64,R67, U6	DNP	06 MCU_LINK_USB
R72,R73,R74,R75,R76,R77,R78, R79	DNP	07 MCU_LINK_DEBUG

