Smartcard activation for voting and consolidation

Thanks to this process you can activate the smartcards that will be used to start a voting session in a voting machine. At the same time you can scan the barcode of each vote cast by the voters and also perform the count of votes.

To start this process you need to have:

- Installed at least one voting machine
- A smartcard reader correctly connected to the president machine
- Smartcards ready to be activated for a voting session
- An e-Urn correctly connected to the president machine
- The ballots of the voters

To activate a smartcard you need to:

- 1. Click on the nationality of the voter
- 2. Insert a smartcard into the reader
- 3. Wait for the confirmation message of the activation of the smartcard
- 4. Give the card to the voter
- 5. Repeat these steps for each smartcard that you need to activate

To scan the ballots you need to:

- 1. The voter should place his vote in the e-Urn and scan the barcode
- 2. Verify that the vote has been processed and check if the counter is increased
- 3. If the voter has a problem scanning the ballot try the recovery procedure
- 4. The voter should insert the ballot inside the ballot box

When you have finished, click on the red cross (X) in the upper right side of the screen

Click on 'Print' to obtain more detailed information about this process

To close this window, click on the red cross (X) in the upper right side of the screen