

The Industry print list

The Industry v1. Online at cannonsandcoastlines.com/print-list/industry-set.

HOW TO DO IT

1. **Get the files.** The STLs are in this zip. The plates folder has a 3MF for each color, with the settings, for OrcaSlicer or CubbySlicer.
2. **Get the free base set too**, from cannonsandcoastlines.com/print-guide. It has the masts, cargo, cannons and wheels, and the coins, islands and terrain a game needs.
3. **Print each color** with the settings below.
4. **Put it together** with the steps at the end.

3 warships with 3 fittings each (turret, smokestack, cargo)

	PART	QTY	COLOR	SUPPORTS
	Hull <i>ship-industry.stl</i>	3	Rust brown or steel blue PLA	No
	Turret <i>industry-turret.stl</i> The second cannon slot is on top.	3	Rust brown or steel blue PLA	No
	Smokestack <i>industry-smokestack.stl</i>	3	Rust brown or steel blue PLA	No
	Cargo <i>cargo.stl from the base set</i>	3	Brown	No
	Movement wheel <i>movement-wheel.stl from the base set</i>	3	Any	No
	Cannon <i>cannon.stl from the base set</i>	4	Black	No
	Cannonball <i>cannonball.stl from the base set</i>	10	Something bright, like neon green or orange	No

MATERIAL	LAYER	Z	ORIENTATION	INFILL
PLA	HEIGHT	CONTOURING	Use your slicer's	10% or more
	0.12–0.20 mm	On	auto-orient.	
	(0.16 mm recommended)			

Printing and putting it together

1. Print the fit test (*ship-tolerance-test.stl* in the base set) first. If a peg is loose, scale it up 0.5 to 1% in your slicer. If it's tight, sand it a bit. If it won't go in at all, your nozzle is probably too close to the bed.
2. Print a spare cannon or two. The arm loses tension after a few hundred shots.
3. Stretch a 10 mm rubber band or silicone cable tie around each wheel's rim and push the wheel into the slot under the stern. It should be snug but still spin, and it stays in.
4. Plug the fittings into the deck.

The shop page is cannonsandcoastlines.com/shop/industry, and the print guide is at cannonsandcoastlines.com/print-guide.