APPENDIX

A

ARM AND THUMB ASSEMBLER INSTRUCTIONS

This appendix lists the ARM and Thumb instructions available up to, and including, ARM architecture ARMv6, which was just released at the time of writing. We list the operations in alphabetical order for easy reference. Sections A.4 and A.5 give quick reference guides to the ARM and GNU assemblers *armasm* and *gas*.

We have designed this appendix for practical programming use, both for writing assembly code and for interpreting disassembly output. It is not intended as a definitive architectural ARM reference. In particular, we do not list the exhaustive details of each instruction bitmap encoding and behavior. For this level of detail, see the *ARM Architecture Reference Manual*, edited by David Seal, published by Addison Wesley. We do give a summary of ARM and Thumb instruction set encodings in Appendix B.

A.1 Using This Appendix

Each appendix entry begins by enumerating the available instructions formats for the given instruction class. For example, the first entry for the instruction class ADD reads

1. ADD<cond>{S} Rd, Rn, #<rotated immed>

ARMv1

The fields <cond> and <rotated_immed> are two of a number of standard fields described in Section A.2. Rd and Rn denote ARM registers. The instruction is only executed if the

Table A.1 Instruction types.

Type	Meaning
ARMvX THUMBvX MACRO	32-bit ARM instruction first appearing in ARM architecture version X 16-bit Thumb instruction first appearing in Thumb architecture version X Assembler pseudoinstruction

condition <cond> is passed. Each entry also describes the action of the instruction if it is executed.

The {S} denotes that you may apply an optional S suffix to the instruction. Finally, the right-hand column specifies that the instruction is available from the listed ARM architecture version onwards. Table A.1 shows the entries possible for this column.

Note that there is no direct correlation between the Thumb architecture number and the ARM architecture number. The THUMBv1 architecture is used in ARMv4T processors; the THUMBv2 architecture, in ARMv5T processors; and the THUMBv3 architecture, in ARMv6 processors.

Each instruction definition is followed by a notes section describing restrictions on the use of the instruction. When we make a statement such as "*Rd* must not be *pc*," we mean that the description of the function only applies when this condition holds. If you break the condition, then the instruction may be unpredictable or have predictable effects that we haven't had space to describe here. Well-written programs should not need to break these conditions.

A.2 SYNTAX

We use the following syntax and abbreviations throughout this appendix.

A.2.1 OPTIONAL EXPRESSIONS

- {<expr>} is an optional expression. For example, LDR{B} is shorthand for LDR or LDRB.
- {<exp1>|<exp2>|...|<expN>}, including at least one "|" divider, is a list of expressions. One of the listed expressions must appear. For example LDR{B|H} is shorthand for LDRB or LDRH. It does not include LDR. We would represent these three possibilities by LDR{|B|H}.

A.2.2 REGISTER NAMES

- *Rd*, *Rn*, *Rm*, *Rs*, *RdHi*, *RdLo* represent ARM registers in the range *r0* to *r15*.
- Ld, Ln, Lm, Ls represent low-numbered ARM registers in the range r0 to r7.

- Hd, Hn, Hm, Hs represent high-numbered ARM registers in the range r8 to r15.
- Cd, Cn, Cm represent coprocessor registers in the range c0 to c15.
- sp, lr, pc are names for r13, r14, r15, respectively.
- Rn[a] denotes bit a of register Rn. Therefore $Rn[a] = (Rn \gg a) \& 1$.
- Rn[a:b] denotes the a+1-b bit value stored in bits a to b of Rn inclusive.
- RdHi:RdLo represents the 64-bit value with high 32 RDHi bits and low 32 bits RdLo.

A.2.3VALUES STORED AS IMMEDIATES

- <immedN> is any unsigned N-bit immediate. For example, <immed8> represents any integer in the range 0 to 255. <i mmed5>*4 represents any integer in the list 0, 4, 8, ..., 124.
- <address N> is an address or label stored as a relative offset. The address must be in the range $pc - 2^N \le address < pc + 2^N$. Here, pc is the address of the instruction plus eight for ARM state, or the address of the instruction plus four for Thumb state. The address must be four-byte aligned if the destination is an ARM instruction or two-byte aligned if the destination is a Thumb instruction.
- <A-B> represents any integer in the range A to B inclusive.
- <rotated immed> is any 32-bit immediate that can be represented as an eightbit unsigned value rotated right (or left) by an even number of bit positions. In other words, <rotated immed> = <immed8> ROR (2*<immed4>). For example 0xff, 0x104, 0xe0000005, and 0x0bc00000 are possible values for <rotated immed>. However, 0x101 and 0x102 are not. When you use a rotated immediate, <shifter C> is set according to Table A.3 (discussed in Section A.2.5). A nonzero rotate may cause a change in the carry flag. For this reason, you can also specify the rotation explicitly, using the assembly syntax <immed8>, 2*<immed4>.

A.2.4 CONDITION CODES AND FLAGS

- <cond> represents any of the standard ARM condition codes. Table A.2 shows the possible values for <cond>.
- SignedOverflow> is a flag indicating that the result of an arithmetic operation suffered from a signed overflow. For example, 0x7ffffffff + 1 = 0x80000000 produces a signed overflow because the sum of two positive 32-bit signed integers is a negative 32- bit signed integer. The *V* flag in the *cpsr* typically records signed overflows.
- <UnsignedOverflow> is a flag indicating that the result of an arithmetic operation suffered from an unsigned overflow. For example, 0xfffffffff + 1 = 0 produces an overflow in unsigned 32-bit arithmetic. The C flag in the cpsr typically records unsigned overflows.

T 11 1 1	4 D 3 C 11	
Table A.2	ARM condi	tion mnemonics.

<cond></cond>	Instruction is executed when	cpsr condition
{ AL}	ALways	TRUE
EQ	EQual (last result zero)	Z==1
NE	Not Equal (last result nonzero)	Z==0
{CS HS}	Carry Set, unsigned Higher or Same (following a compare)	C==1
{CC LO}	Carry Clear, unsigned LOwer (following a comparison)	C==0
MI	MInus (last result negative)	N==1
PL	PLus (last result greater than or equal to zero)	N==0
VS	V flag Set (signed overflow on last result)	V==1
VC	V flag Clear (no signed overflow on last result)	V==0
HI	unsigned HIgher (following a comparison)	C==1 && Z==0
LS	unsigned Lower or Same (following a comparison)	C==0 Z==1
GE	signed Greater than or Equal	N = = V
LT	signed Less Than	N!=V
GT	signed Greater Than	N==V && Z==0
LE	signed Less than or Equal	N!=V Z==1
NV	NeVer—ARMv1 and ARMv2 only—DO NOT USE	FALSE

- <NoUnsignedOverflow> is the same as 1 <UnsignedOverflow>.
- <Zero> is a flag indicating that the result of an arithmetic or logical operation is zero.
 The Z flag in the cpsr typically records the zero condition.
- <Negative> is a flag indicating that the result of an arithmetic or logical operation is negative. In other words, <Negative> is bit 31 of the result. The N flag in the cpsr typically records this condition.

A.2.5 SHIFT OPERATIONS

- <imm_shift> represents a shift by an immediate specified amount. The possible shifts are LSL #<0-31>, LSR #<1-32>, ASR #<1-32>, ROR #<1-31>, and RRX. See Table A.3 for the actions of each shift.
- <reg_shift> represents a shift by a register-specified amount. The possible shifts are LSL Rs, LSR Rs, ASR Rs, and ROR Rs. Rs must not be pc. The bottom eight bits of Rs are used as the shift value k in Table A.3. Bits Rs[31:8] are ignored.
- <shift> is shorthand for <imm shift> or <reg shift>.
- <shifted_Rm> is shorthand for the value of Rm after the specified shift has been applied. See Table A.3.

Shift	k range	<shifted_rm></shifted_rm>	<shifter_c></shifter_c>
LSL k	k = 0	Rm	C (from <i>cpsr</i>)
LSL k	$1 \le k \le 31$	Rm << k	Rm[32-k]
LSL k	k = 32	0	Rm[0]
LSL k	$k \ge 33$	0	0
LSR k	k = 0	Rm	С
LSR k	$1 \le k \le 31$	(unsigned)Rm>>k	Rm[k-1]
LSR k	k = 32	0	Rm[31]
LSR k	$k \ge 33$	0	0
ASR k	k = 0	Rm	С
ASR k	$1 \le k \le 31$	(signed)Rm>>k	Rm[k-1]
ASR k	$k \ge 32$	—Rm[31]	Rm[31]
ROR k	k = 0	Rm	С
ROR k	$1 \le k \le 31$	((unsigned)Rm >> k) (Rm << (32-k))	Rm[k-1]
ROR k	$k \ge 32$	Rm ROR (k & 31)	Rm[(k-1)&31]
RRX		(C << 31) ((unsigned)Rm >> 1)	Rm[0]

Table A.3 Barrel shifter circuit outputs for different shift types.

<shifter C> is shorthand for the carry value output by the shifting circuit. See Table A.3.

ALPHABETICAL LIST OF ARM AND THUMB INSTRUCTIONS

Instructions are listed in alphabetical order. However, where signed and unsigned variants of the same operation exist, the main entry is under the signed variant.

ADC	Add two 32-bit values and carry	
	 ADC<cond>{S} Rd, Rn, #<rotated< li=""> </rotated<></cond>	_immed> ARMv1
	2. ADC <cond>{S} Rd, Rn, Rm {, <sh< td=""><td>rift>} ARMv1</td></sh<></cond>	rift>} ARMv1
	3. ADC Ld, Lm	THUMBv1
	Action	Effect on the <i>cpsr</i>
	<pre>1. Rd = Rn + <rotated_immed> + C</rotated_immed></pre>	Updated if S suffix specified

```
2. Rd = Rn + < shifted Rm > + C
                                      Updated if S suffix specified
3. Ld = Ld + Lm + C
                                      Updated (see Notes below)
```

Notes

- If the operation updates the *cpsr* and *Rd* is not *pc*, then $N = \langle Negative \rangle$, $Z = \langle Zero \rangle$, $C = \langle UnsignedOverflow \rangle$, $V = \langle SignedOverflow \rangle$.
- If Rd is pc, then the instruction effects a jump to the calculated address. If the operation updates the cpsr, then the processor mode must have an spsr; in this case, the cpsr is set to the value of the spsr.
- If Rn or Rm is pc, then the value used is the address of the instruction plus eight bytes.

Examples

```
ADDS
       r0, r0, r2
                    ; first half of a 64-bit add
ADC
       r1, r1, r3 ; second half of a 64-bit add
       r0, r0, r0; shift r0 left, inserting carry (RLX)
ADCS
```

Add two 32-bit values ADD

1.	ADD <cond>S</cond>	Rd,	Rn,	<pre>#<rotated_immed></rotated_immed></pre>	ARMv1
2.	ADD <cond>S</cond>	Rd,	Rn,	Rm {, <shift>}</shift>	ARMv1
3.	ADD	Ld,	Ln,	# <immed3></immed3>	THUMBv1
4.	ADD	Ld,	# <im< td=""><td>nmed8></td><td>THUMBv1</td></im<>	nmed8>	THUMBv1
5.	ADD	Ld,	Ln,	Lm	THUMBv1
6.	ADD	Hd,	Lm		THUMBv1
7.	ADD	Ld,	Hm		THUMBv1
8.	ADD	Hd,	Hm		THUMBv1
9.	ADD	Ld,	pc,	# <immed8>*4</immed8>	THUMBv1
10.	ADD	Ld,	sp,	# <immed8>*4</immed8>	THUMBv1
11.	ADD	sp,	# <in< td=""><td>nmed7>*4</td><td>THUMBv1</td></in<>	nmed7>*4	THUMBv1

Action

Effect on the *cpsr*

```
2. Rd = Rn + <shifted Rm>
                                       Updated if S suffix specified
 3. Ld = Ln + < immed3 >
                                       Updated (see Notes below)
 4. Ld = Ld + < immed8 >
                                       Updated (see Notes below)
 5. Ld = Ln + Lm
                                       Updated (see Notes below)
 6. Hd = Hd + Lm
                                       Preserved
 7. Ld = Ld + Hm
                                       Preserved
 8. Hd = Hd + Hm
                                       Preserved
 9. Ld = pc + 4 \times immed8 >
                                       Preserved
10. Ld = sp + 4*<immed8>
                                       Preserved
11. sp = sp + 4*<immed7>
                                       Preserved
```

Notes

- If the operation updates the *cpsr* and *Rd* is not *pc*, then $N = \langle Negative \rangle$, $Z = \langle Zero \rangle$, $C = \langle UnsignedOverflow \rangle$, $V = \langle SignedOverflow \rangle$.
- If *Rd* or *Hd* is *pc*, then the instruction effects a jump to the calculated address. If the operation updates the *cpsr*, then the processor mode must have an *spsr*; in this case, the *cpsr* is set to the value of the *spsr*.
- If Rn or Rm is pc, then the value used is the address of the instruction plus eight bytes.
- If *Hd* or *Hm* is *pc*, then the value used is the address of the instruction plus four bytes.

Examples

```
ADD r0, r1, #4 ; r0 = r1 + 4

ADDS r0, r2, r2 ; r0 = r2 + r2 and flags updated

ADD r0, r0, r0, LSL #1 ; r0 = 3*r0

ADD pc, pc, r0, LSL #2 ; skip r0+1 instructions

ADD r0, r1, r2, ROR r3 ; r0 = r1 + ((r2 >> r3)|(r2 << (32-r3))

ADDS pc, lr, #4 ; jump to lr+4, restoring the cpsr
```

ADR Address relative

```
1. ADR{L}<cond> Rd, <address> MACRO
```

This is not an ARM instruction, but an assembler macro that attempts to set *Rd* to the value <address> using a *pc*-relative calculation. The ADR instruction macro always uses a single ARM (or Thumb) instruction. The long-version ADRL always uses two ARM instructions

and so can access a wider range of addresses. If the assembler cannot generate an instruction sequence reaching the address, then it will generate an error.

The following example shows how to call the function pointed to by r9. We use ADR to set lr to the return address; in this case, it will assemble to ADD 1r, pc, #4. Recall that pc reads as the address of the current instruction plus eight in this case.

```
ADR lr, return_address ; set return address MOV r0, \#O ; set a function argument BX r9 ; call the function return address ; resume
```

AND Logical bitwise AND of two 32-bit values

```
    AND<cond>{S} Rd, Rn, #<rotated_immed> ARMv1
    AND
    AND
```

Action Effect on the *cpsr*

```
    Rd = Rn & <rotated_immed> Updated if S suffix specified
    Rd = Rn & <shifted_Rm> Updated if S suffix specified
    Ld = Ld & Lm Updated (see Notes below)
```

Notes

- If the operation updates the *cpsr* and *Rd* is not *pc*, then $N = \langle Negative \rangle$, $Z = \langle Zero \rangle$, $C = \langle shifter \ C \rangle$ (see Table A.3), V is preserved.
- If *Rd* is *pc*, then the instruction effects a jump to the calculated address. If the operation updates the *cpsr*, then the processor mode must have an *spsr*; in this case, the *cpsr* is set to the value of the *spsr*.
- If *Rn* or *Rm* is *pc*, then the value used is the address of the instruction plus eight bytes.

Examples

ASR

```
AND r0, r0, \#0xFF ; extract the lower 8 bits of a byte ANDS r0, r0, \#1<<31 ; extract sign bit
```

Arithmetic shift right for Thumb (see MOV for the ARM equivalent)

```
1. ASR Ld, Lm, #<immed5> THUMBv1
2. ASR Ld, Ls THUMBv1
```

Action

Effect on the cpsr

2. Ld = Ld ASR Ls[7:0]

Note

• The *cpsr* is updated: $N = \langle Negative \rangle$, $Z = \langle Zero \rangle$, $C = \langle shifter_C \rangle$ (see Table A.3).

Updated

Branch relative

1. B<cond> <address25>

ARMv1

2. B<cond> <address8>

THUMBv1

3. B <address11>

THUMBv1

Branches to the given address or label. The address is stored as a relative offset. Examples

B label

; branch unconditionally to a label

BGT loop

; conditionally continue a loop

BIC Logical bit clear (AND NOT) of two 32-bit values

1. BIC<cond>{S} Rd, Rn, #<rotated immed>

ARMv1

2. BIC<cond>{S} Rd, Rn, Rm {, <shift>}

ARMv1

3. BIC

Ld, Lm

THUMBv1

Action

Effect on the *cpsr*

1. Rd = Rn & \sim <rotated immed>

Updated if S suffix specified

2. Rd = Rn & \sim <shifted Rm>

Updated if S suffix specified

3. Ld = Ld & \sim Lm

Updated (see Notes below)

Notes

If the operation updates the *cpsr* and *Rd* is not *pc*, then $N = \langle Negative \rangle$, $Z = \langle Zero \rangle$, $C = \langle shifter_C \rangle$ (see Table A.3), V is preserved.

- If *Rd* is *pc*, then the instruction effects a jump to the calculated address. If the operation updates the *cpsr*, then the processor mode must have an *spsr*; in this case, the *cpsr* is set to the value of the *spsr*.
- If Rn or Rm is pc, then the value used is the address of the instruction plus eight bytes.

Examples

```
BIC r0, r0, \#1 << 22; clear bit 22 of r0
```

BKPT Breakpoint instruction

1. BKPT <immed16> ARMv5

2. BKPT <immed8> THUMBv2

The breakpoint instruction causes a prefetch data abort, unless overridden by debug hardware. The ARM ignores the immediate value. This immediate can be used to hold debug information such as the breakpoint number.

BL Relative branch with link (subroutine call)

1. BL<cond> <address25> ARMv1

2. BL <address22> THUMBv1

Action Effect on the *cpsr*

1. lr = ret+0; pc = <address25> None

2. lr = ret+1; pc = <address22> None

Note

■ These instructions set *lr* to the address of the following instruction ret plus the current *cpsr T*-bit setting. Therefore you can return from the subroutine using BX lr to resume execution address and ARM or Thumb state.

Examples

```
BL subroutine ; call subroutine (return with MOV pc,lr)
BLVS overflow ; call subroutine on an overflow
```

Effect on the *cpsr*

T=Rm & 1

BLX	Branch with link and exchange (subroutine	call with possible state switch)				
	1. BLX <address25></address25>	ARMv5				
	2. BLX <cond> Rm</cond>	ARMv5				
	3. BLX <address22></address22>	THUMBv2				
	4. BLX Rm	THUMBv2				
	Action	Effect on the <i>cpsr</i>				
	1. lr = ret+0; pc = <address25></address25>	T=1 (switch to Thumb state)				
	2. 1r = ret+0; pc = Rm & 0xfffffffe	T=Rm & 1				
	<pre>3. 1r = ret+1; pc = <address22></address22></pre>	T=0 (switch to ARM state)				
	4. lr = ret+1; pc = Rm & Oxfffffffe	T=Rm & 1				
	Notes					
	■ These instructions set <i>lr</i> to the address of th <i>cpsr T</i> -bit setting. Therefore you can return execution address and ARM or Thumb star	from the subroutine using BX 1r to resum				
	■ <i>Rm</i> must not be <i>pc</i> .	Rm must not be pc.				
	■ <i>Rm</i> & 3 must not be 2. This would cause a	branch to an unaligned ARM instruction.				
	Example					
	BLX rO ; call the sub	o subroutine from ARM state proutine pointed to by r0 r0 even, Thumb if r0 odd				
BX BXJ	Branch with exchange (branch with possibl	e state switch)				
DAU	1. BX <cond> Rm</cond>	ARMv4T				
	2. BX Rm	THUMBv1				
	3. BXJ <cond> Rm</cond>	ARMv5J				

Action

1. pc = Rm & Oxfffffffe

- 2. pc = Rm & Oxfffffffe T=Rm & 1
- 3. Depends on JE configuration bit J,T affected

Notes

- If *Rm* is *pc* and the instruction is word aligned, then *Rm* takes the value of the current instruction plus eight in ARM state or plus four in Thumb state.
- *Rm* & 3 must not be 2. This would cause a branch to an unaligned ARM instruction.
- If the JE (Java Enable) configuration bit is clear, then BXJ behaves as a BX. Otherwise, the behavior is defined by the architecture of the Java Extension hardware. Typically it sets J = 1 in the *cpsr* and starts executing Java instructions from a general purpose register designated as the Java program counter *jpc*.

Examples

```
BX lr ; return from ARM or Thumb subroutine
BX r0 ; branch to ARM or Thumb function pointer r0
```

CDP Coprocessor data processing operation

```
    CDP<cond> <copro>, <op1>, Cd, Cn, Cm, <op2> ARMv2
    CDP2 <copro>, <op1>, Cd, Cn, Cm, <op2> ARMv5
```

These instructions initiate a coprocessor-dependent operation. $\langle copro \rangle$ is the number of the coprocessor in the range p0 to p15. The core takes an undefined instruction trap if the coprocessor is not present. The coprocessor operation specifiers $\langle op1 \rangle$ and $\langle op2 \rangle$, and the coprocessor register numbers Cd, Cn, Cm, are interpreted by the coprocessor and ignored by the ARM. CDP2 provides an additional set of coprocessor instructions.

CLZ Count leading zeros

```
1. CLZ<cond> Rd, Rm ARMv5
```

Rn is set to the maximum left shift that can be applied to Rm without unsigned overflow. Equivalently, this is the number of zeros above the highest one in the binary representation of Rm. If Rm = 0, then Rn is set to 32. The following example normalizes the value in r0 so that bit 31 is set.

```
CLZ r1, r0 ; find normalization shift MOV r0, r0, LSL r1 ; normalize so bit 31 is set (if r0!=0)
```

CMN Compare negative

CMN<cond> Rn, #<rotated immed>

ARMv1

2. CMN<cond> Rn, Rm {, <shift>} ARMv1 3. CMN Ln, Lm THUMBv1

Action

- 1. cpsr flags set on the result of (Rn + <rotated immed>)
- 2. cpsr flags set on the result of (Rn + <shifted Rm>)
- 3. cpsr flags set on the result of (Ln + Lm)

Notes

- In the cpsr: $N = \langle Negative \rangle$, $Z = \langle Zero \rangle$, $C = \langle Unsigned Overflow \rangle$, $V = \langle SignedOverflow \rangle$. These are the same flags as generated by CMP with the second operand negated.
- If *Rn* or *Rm* is *pc*, then the value used is the address of the instruction plus eight bytes.

Example

```
CMN
        r0, #3
                      ; compare r0 with -3
        label
                       ; if (r0 < -3) goto label
BLT
```

Compare two 32-bit integers **CMP**

1	. CMP <cond></cond>	Rn,	<pre>#<rotated_immed></rotated_immed></pre>	ARMv1
2	. CMP <cond></cond>	Rn,	Rm {, <shift>}</shift>	ARMv1
3	. CMP	Ln,	# <immed8></immed8>	THUMBv1
4	. CMP	Rn,	Rm	THUMBv1

Action

- 1. cpsr flags set on the result of (Rn <rotated immed>)
- 2. cpsr flags set on the result of (Rn <shifted Rm>)
- 3. cpsr flags set on the result of (Ln <immed8>)
- 4. cpsr flags set on the result of (Rn Rm)

Notes

■ In the cpsr: $N = \langle Negative \rangle$, $Z = \langle Zero \rangle$, $C = \langle NoUnsigned - Overflow \rangle$, $V = \langle SignedOverflow \rangle$. The carry flag is set this way because the subtract x - y is implemented as the add $x + \sim y + 1$. The carry flag is one if $x + \sim y + 1$ overflows. This happens when $x \ge y$ (equivalently when x - y doesn't overflow).

■ If *Rn* or *Rm* is *pc*, then the value used is the address of the instruction plus eight bytes for ARM instructions, or plus four bytes for Thumb instructions.

Example

```
CMP r0, r1, LSR#2; compare r0 with (r1/4)
BHS label; if (r0 >= (r1/4)) goto label;
```

CPS Change processor state; modifies selected bits in the *cpsr*

1.	CPS	# <mode></mode>	ARMv6
2.	CPSID	<flags> {, #<mode>}</mode></flags>	ARMv6
3.	CPSIE	<flags> {, #<mode>}</mode></flags>	ARMv6
4.	CPSID	<flags></flags>	THUMBv3
5.	CPSIE	<flags></flags>	THUMBv3

Action

```
    cpsr[4:0] = <mode>
    cpsr = cpsr | mask; { cpsr[4:0] = <mode> }
    cpsr = cpsr & ~mask; { cpsr[4:0] = <mode> }
    cpsr = cpsr | mask
    cpsr = cpsr & ~mask
```

Bits are set in mask according to letters in the <flags> value as in Table A.4. The ID (interrupt disable) variants mask interrupts by setting cpsr bits. The IE (interrupt enable) variants unmask interrupts by clearing *cpsr* bits.

Table A.4 CPS flags characters.

Character	<i>cpsr</i> bit affected	Bit set in mask
a	imprecise data Abort mask bit	0x100 = 1 << 8
i	IRQ mask bit	0x080 = 1 << 7
f	FIO mask bit	0x040 = 1 << 6

CPY Copy one ARM register to another without affecting the *cpsr*.

1. CPY<cond> Rd, Rm

ARMv6

2. CPY Rd, Rm

THUMBv3

This assembles to MOV<cond> Rd, Rm except in the case of Thumb where Rd and Rm are low registers in the range r0 to r7. Then it is a new operation that sets Rd=Rm without affecting the cpsr.

EOR Logical exclusive OR of two 32-bit values

ARMv1

ARMv1

THUMBv1

ARMv2

Action

Effect on the cpsr

Updated if S suffix specified

Updated if S suffix specified

Updated (see Notes below)

Notes

- If the operation updates the *cpsr* and *Rd* is not *pc*, then $N = \langle Negative \rangle$, $Z = \langle Zero \rangle$, $C = \langle shifter_C \rangle$ (see Table A.3), V is preserved.
- If *Rd* is *pc*, then the instruction effects a jump to the calculated address. If the operation updates the *cpsr*, then the processor mode must have an *spsr*; in this case, the *cpsr* is set to the value of the *spsr*.
- If Rn or Rm is pc, then the value used is the address of the instruction plus eight bytes.

Example

EOR r0, r0,
$$\#1 << 16$$

; toggle bit 16

Load to coprocessor single or multiple 32-bit values

LDM

Table A.5 LDC addressing modes.

Addressing format	Address accessed	Value written back to Rn
<pre>[Rn {,# {-}<immed>}] [Rn {,# {-}<immed>}]! [Rn], # {-}<immed> [Rn], <option></option></immed></immed></immed></pre>	<pre>Rn + {{-}<immed>} Rn + {{-}<immed>} Rn Rn</immed></immed></pre>	Rn preserved Rn + {{-} <immed>} Rn + {-}<immed> Rn preserved</immed></immed>

4.	LDC2{L}	<copro>, Cd,</copro>	[Rn $\{, \#\{-\} < i mmed8 > *4\}]\{!\}$	ARMv5
5.	LDC2{L}	<copro>, Cd,</copro>	[Rn], $\#\{-\}*4$	ARMv5
6.	LDC2{L}	<copro>, Cd,</copro>	[Rn], <option></option>	ARMv5

These instructions initiate a memory read, transferring data to the given coprocessor. < copro> is the number of the coprocessor in the range p0 to p15. The core takes an undefined instruction trap if the coprocessor is not present. The memory read consists of a sequence of words from sequentially increasing addresses. The initial address is specified by the addressing mode in Table A.5. The coprocessor controls the number of words transferred, up to a maximum limit of 16 words. The fields $\{L\}$ and Cd are interpreted by the coprocessor and ignored by the ARM. Typically Cd specifies the destination coprocessor register for the transfer. The <option> field is an eight-bit integer enclosed in $\{\}$. Its interpretation is coprocessor dependent.

If the address is not a multiple of four, then the access is *unaligned*. The restrictions on unaligned accesses are the same as for LDM.

Load multiple 32-bit words from memory to ARM registers

These instructions load multiple words from sequential memory addresses. The <register_list> specifies a list of registers to load, enclosed in curly brackets {}. Although the assembler allows you to specify the registers in the list in any order, the order is not stored in the instruction, so it is good practice to write the list in increasing order of register number because this is the usual order of the memory transfer.

The following pseudocode shows the normal action of LDM. We use <register_list>[i] to denote the register appearing at position i in the list, starting at 0 for the first register. This assumes that the list is in order of increasing register number.

Addressing mode	Lowest address accessed	Highest address accessed	Value written back to <i>Rn</i> if! specified
{IA FD}	Rn	Rn + N*4 - 4	Rn + N*4
{IB ED}	Rn + 4	Rn + N*4	Rn + N*4
{DA FA}	Rn - N*4 + 4	Rn	Rn - N*4
{DB EA}	Rn - N*4	Rn - 4	Rn - N*4

Table A.6 LDM addressing modes.

```
N = the number of registers in <register_list>
start = the lowest address accessed given in Table A.6
for (i=0; i<N; i++)
   <register_list>[i] = memory(start+i*4, 4);
if (! specified) then update Rn according to Table A.6
```

Note that memory (a, 4) returns the four bytes at address a packed according to the current processor data endianness. If a is not a multiple of four, then the load is unaligned. Because the behavior of an unaligned load depends on the architecture revision, memory system, and system coprocessor (CP15) configuration, it's best to avoid unaligned loads if possible. Assuming that the external memory system does not abort unaligned loads, then the following rules usually apply:

- If the core has a system coprocessor and bit 1 (A-bit) or bit 22 (U-bit) of CP15:c1:c0:0 is set, then unaligned load multiples cause an alignment fault data abort exception.
- Otherwise the access ignores the bottom two address bits.

Table A.6 lists the possible addressing modes specified by <amode>. If you specify the !, then the base address register is updated according to Table A.6; otherwise it is preserved. Note that the lowest register number is always read from the lowest address.

The first half of the addressing mode mnemonics stands for Increment After, Increment Before, Decrement After, and Decrement Before, respectively. Increment modes load the registers sequentially forward, starting from address Rn (increment after) or Rn + 4 (increment before). Decrement modes have the same effect as if you loaded the register list backwards from sequentially descending memory addresses, starting from address Rn (decrement after) or Rn - 4 (decrement before).

The second half of the addressing mode mnemonics stands for the stack type you can implement with that address mode: Full Descending, Empty Descending, Full Ascending, and Empty Ascending, With a full stack, *Rn* points to the last stacked value; with an empty stack, *Rn* points to the first unused stack location. ARM stacks are usually full descending.

You should use full descending or empty ascending stacks by preference, since LDC also supports these addressing modes.

Notes

- For Thumb (format 2), Rn and the register list registers must be in the range r0 to r7.
- The number of registers *N* in the list must be nonzero.
- \blacksquare *Rn* must not be *pc*.
- Rn must not appear in the register list if! (writeback) is specified.
- If *pc* appears in the register list, then on ARMv5 and above the processor performs a BX to the loaded address. For ARMv4 and below, the processor branches to the loaded address.
- If ^ is specified, then the operation is modified. The processor must not be in *user* or *system* mode. If *pc* is not in the register list, then the registers appearing in the register list refer to the *user* mode versions of the registers and writeback must not be specified. If *pc* is in the register list, then the *spsr* is copied to the *cpsr* in addition to the standard operation.
- The time order of the memory accesses may depend on the implementation. Be careful when using a load multiple to access I/O locations where the access order matters. If the order matters, then check that the memory locations are marked as I/O in the page tables, do not cross page boundaries, and do not use *pc* in the register list.

Examples

LDR Load a single value from a virtual address in memory

```
LDR<cond>{|B}
                       Rd, [Rn {, #{-}<immed12>}]{!}
1.
                                                            ARMv1
2. LDR<cond>{|B}
                       Rd, [Rn, {-}Rm {,<imm shift>}]{!}
                                                            ARMv1
3. LDR<cond>{|B}{T}
                       Rd, [Rn], \#\{-\}<immed12>
                                                            ARMv1
4. LDR<cond>{|B}{T}
                       Rd, [Rn], {-}Rm {,<imm shift>}
                                                            ARMv1
5. LDR<cond>{H|SB|SH} Rd, [Rn, {, #{-}<immed8>}]{!}
                                                            ARMv4
6. LDR<cond>{H|SB|SH} Rd, [Rn, {-}Rm]{!}
                                                            ARMv4

    LDR<cond>{H|SB|SH} Rd, [Rn], #{-}<immed8>

                                                            ARMv4
```

8.	LDR <cond>{H SB SH}</cond>	Rd,	[Rn], {-}Rm	ARMv4
9.	LDR <cond>D</cond>	Rd,	[Rn, {, #{-} <immed8>}]{!}</immed8>	ARMv5E
10.	LDR <cond>D</cond>	Rd,	[Rn, {-}Rm]{!}	ARMv5E
11.	LDR <cond>D</cond>	Rd,	[Rn], #{-} <immed8></immed8>	ARMv5E
12.	LDR <cond>D</cond>	Rd,	[Rn], {-}Rm	ARMv5E
13.	LDREX <cond></cond>	Rd,	[Rn]	ARMv6
14.	LDR{ B H}	Ld,	[Ln, # <immed5>*<size>]</size></immed5>	THUMBv1
15.	LDR{ B H SB SH}	Ld,	[Ln, Lm]	THUMBv1
16.	LDR	Ld,	[pc, # <immed8>*4]</immed8>	THUMBv1
17.	LDR	Ld,	[sp, # <immed8>*4]</immed8>	THUMBv1
18.	LDR <cond><type></type></cond>	Rd,	<label></label>	MACRO
19.	LDR <cond></cond>	Rd,	=<32-bit-value>	MACRO

Formats 1 to 17 load a single data item of the type specified by the opcode suffix, using a preindexed or postindexed addressing mode. Tables A.7 and A.8 show the different addressing modes and data types.

In Table A.8 memory (a, n) reads n sequential bytes from address a. The bytes are packed according to the configured processor data endianness. The function memory T(a, n) performs the same access but with *user* mode privileges, regardless of the current processor mode. The function memory Ex(a, n) used by LDREX performs the access and marks the access as exclusive. If address a has the *shared* TLB attribute, then this marks address a exclusive to the current processor and clears any other exclusive addresses for this processor.

Table A.7 LDR Addressing Modes.

Addressing format	Address a accessed	Value written back to <i>Rn</i>
<pre>[Rn {,#{-}<immed>}] [Rn {,#{-}<immed>}]! [Rn, {-}Rm {,<shift>}] [Rn, {-}Rm {,<shift>}]! [Rn], #{-}<immed> [Rn], #{-}<immed></immed></immed></shift></shift></immed></immed></pre> [Rn], {-}Rm {, <shift>}</shift>	<pre>Rn + {{-}<immed>} Rn + {{-}<immed>} Rn + {{-}<immed>} Rn + {-}<shifted_rm> Rn + {-}<shifted_rm> Rn Rn</shifted_rm></shifted_rm></immed></immed></immed></pre>	Rn preserved Rn + {{-} <immed>} Rn preserved Rn + {-}<shifted_rm> Rn + {-}<immed> Rn + {-}<shifted_rm></shifted_rm></immed></shifted_rm></immed>

Load	Datatype	<size> (bytes)</size>	Action
LDR	word	4	Rd = memory(a, 4)
LDRB	unsigned Byte	1	Rd = (zero-extend)memory(a, 1)
LDRBT	Byte Translated	1	<pre>Rd = (zero-extend)memoryT(a, 1)</pre>
LDRD	Double word	8	Rd = memory(a, 4)
			R(d+1) = memory(a+4, 4)
LDREX	word EXclusive	4	Rd = memoryEx(a, 4)
LDRH	unsigned Halfword	2	Rd = (zero-extend)memory(a, 2)
LDRSB	Signed Byte	1	Rd = (sign-extend)memory(a, 1)
LDRSH	Signed Halfword	2	Rd = (sign-extend)memory(a, 2)
LDRT	word Translated	4	Rd = memoryT(a, 4)

Table A.8 LDR datatypes.

Otherwise the processor remembers that there is an outstanding exclusive access. Exclusivity only affects the action of the STREX instruction.

If address a is not a multiple of <size>, then the load is *unaligned*. Because the behavior of an unaligned load depends on the architecture revision, memory system, and system coprocessor (CP15) configuration, it's best to avoid unaligned loads if possible. Assuming that the external memory system does not abort unaligned loads, then the following rules usually apply. In the rules, A is bit 1 of system coprocessor register CP15:c1:c0:0, and U is bit 22 of CP15:c1:c0:0, introduced in ARMv6. If there is no system coprocessor, then A = U = 0.

- If A = 1, then unaligned loads cause an alignment fault data abort exception except that word-aligned double-word loads are supported if U = 1.
- If A = 0 and U = 1, then unaligned loads are supported for LDR{|T|H|SH}. Wordaligned loads are supported for LDRD. A non-word-aligned LDRD generates an alignment fault data abort.
- If A = 0 and U = 0, then LDR and LDRT return the value memory (a & \sim 3, 4) ROR ((a&3)*8). All other unaligned operations are unpredictable but do not generate an alignment fault.

Format 18 generates a *pc*-relative load accessing the address specified by <label>. In other words, it assembles to LDR<cond><type> Rd, [pc, #<offset>] whenever this instruction is supported and <offset>=<label>-pc is in range.

Format 19 generates an instruction to move the given 32-bit value to the register *Rd*. Usually the instruction is LDR<cond> Rd, [pc, #<offset>], where the 32-bit value is stored in a literal pool at address pc+<offset>.

Notes

- For double-word loads (formats 9 to 12), Rd must be even and in the range r0 to r12.
- If the addressing mode updates *Rn*, then *Rd* and *Rn* must be distinct.
- If *Rd* is *pc*, then *<size>* must be 4. Up to ARMv4, the core branches to the loaded address. For ARMv5 and above, the core performs a BX to the loaded address.
- If Rn is pc, then the addressing mode must not update Rn. The value used for Rn is the address of the instruction plus eight bytes for ARM or four bytes for Thumb.
- \blacksquare Rm must not be pc.
- For ARMv6 use LDREX and STREX to implement semaphores rather than SWP.

Examples

```
LDR
        r0, [r0]
                              r0 = *(int*)r0;
        r0, [r1], #4
                              ; r0 = *(short*)r1; r1 += 4;
LDRSH
        r0, [r1, #-8]!
                              ; r1 = 8; r0 = *(char*)r1;
LDRB
        r2, [r1]
                              ; r2 = * (int*)r1; r3 = * (int*)(r1+4);
LDRD
        r0, [r2, #55]
                             ; r0 = *(signed char*)(r2+55);
LDRSB
LDRCC
        pc, [pc, r0, LSL #2]; if (C==0) goto *(pc+4*r0);
LDRB
        r0, [r1], -r2, LSL #8; r0 = *(char*)r1; r1 -= 256*r2;
LDR
        r0. = 0x12345678
                              : r0 = 0x12345678:
```

Logical shift left for Thumb (see MOV for the ARM equivalent)

```
    LSL Ld, Lm, #<immed5>
    LSL Ld, Ls
    THUMBv1
```

Action

LSL

LSR

Effect on the *cpsr*

```
    Ld = Lm LSL #<immed5> Updated (see Note below)
```

Note

■ The *cpsr* is updated: $N = \langle Negative \rangle$, $Z = \langle Zero \rangle$, $C = \langle shifter_C \rangle$ (see Table A.3).

Logical shift right for Thumb (see MOV for the ARM equivalent)

```
    LSR Ld, Lm, #<immed5>
    LSR Ld, Ls
    THUMBv1
```

Action

Effect on the cpsr

1. Ld = Lm LSR #<immed5> Updated (see Note below)

2. Ld = Ld LSR Ls[7:0] Updated

Note

■ The *cpsr* is updated: $N = \langle Negative \rangle$, $Z = \langle Zero \rangle$, $C = \langle shifter_C \rangle$ (see Table A.3).

MCR MCRR

Move to coprocessor from an ARM register

1.	MCR <cond></cond>	<copro>, <op1>, Rd, Cn, Cm {, <op2>}</op2></op1></copro>	ARMv2
2.	MCR2	<copro>, <op1>, Rd, Cn, Cm {, <op2>}</op2></op1></copro>	ARMv5
3.	MCRR <cond></cond>	<copro>, <op1>, Rd, Rn, Cm</op1></copro>	ARMv5E
4.	MCRR2	<copro>, <op1>, Rd, Rn, Cm</op1></copro>	ARMv6

These instructions transfer the value of ARM register Rd to the indicated coprocessor. Formats 3 and 4 also transfer a second register Rn. <copro> is the number of the coprocessor in the range p0 to p15. The core takes an undefined instruction trap if the coprocessor is not present. The coprocessor operation specifiers <op1> and <op2>, and the coprocessor register numbers Cn, Cm, are interpreted by the coprocessor, and ignored by the ARM. Rd and Rn must not be pc. Coprocessor p15 controls memory management options. See Chapters 13 and 14 for descriptions of the MPU and MMU memory management units. For example, the following code sequence enables alignment fault checking:

```
MRC p15, 0, r0, c1, c0, 0 ; read the MMU register, c1 ORR r0, r0, \#2 ; set the A bit MCR p15, 0, r0, c1, c0, 0 ; write the MMU register, c1
```

MLA Multiply with accumulate

1. MLA<cond>{S} Rd, Rm, Rs, Rn

ARMv2

Action

Effect on the cpsr

Notes

- *Rd* is set to the lower 32 bits of the result.
- \blacksquare *Rd*, *Rm*, *Rs*, *Rn* must not be *pc*.

- *Rd* and *Rm* must be different registers.
- Implementations may terminate early on the value of the *Rs* operand. For this reason use small or constant values for *Rs* where possible. See Appendix D.
- If the *cpsr* is updated, then $N = \langle Negative \rangle$, $Z = \langle Zero \rangle$, C is unpredictable, and V is preserved. Avoid using the instruction MLAS because implementations often impose penalty cycles for this operation. Instead use MLA followed by a compare, and schedule the compare to avoid multiply result use interlocks.

Move a 32-bit value into a register

1.	MOV <cond>{S}</cond>	<pre>Rd, #<rotated_immed></rotated_immed></pre>	ARMv1
2.	MOV <cond>{S}</cond>	Rd, Rm {, <shift>}</shift>	ARMv1
3.	MOV	Ld, # <immed8></immed8>	THUMBv1
4.	MOV	Ld, Ln	THUMBv1
5.	MOV	Hd, Lm	THUMBv1
6.	MOV	Ld, Hm	THUMBv1
7.	MOV	Hd, Hm	THUMBv1

Action

1.	<pre>Rd = <rotated_immed></rotated_immed></pre>	Updated if S suffix specified
2.	Rd = <shifted_rm></shifted_rm>	$\label{thm:pdated} \mbox{Updated if S suffix specified} \\$
3.	Ld = <immed8></immed8>	Updated (see Notes below)
4.	Ld = Ln	Updated (see Notes below)
5.	Hd = Lm	Preserved
6.	Ld = Hm	Preserved
7.	Hd = Hm	Preserved

Effect on the cpsr

Notes

- If the operation updates the *cpsr* and *Rd* is not *pc*, then $N = \langle Negative \rangle$, $Z = \langle Zero \rangle$, $C = \langle shifter_C \rangle$ (see Table A.3), and V is preserved.
- If *Rd* or *Hd* is *pc*, then the instruction effects a jump to the calculated address. If the operation updates the *cpsr*, then the processor mode must have an *spsr*; in this case, the *cpsr* is set to the value of the *spsr*.

- If *Rm* is *pc*, then the value used is the address of the instruction plus eight bytes.
- If *Hm* is pc, then the value used is the address of the instruction plus four bytes.

Examples

```
MOV r0, #0x00ff0000; r0 = 0x00ff0000

MOV r0, r1, LSL#2; r0 = 4*r1

MOV pc, lr; return from subroutine (pc=lr)

MOVS pc, lr; return from exception (pc=lr, cpsr=spsr)
```

MRC MRRC

MRS

Move to ARM register from a coprocessor

```
      1. MRC<cond>
      <copro>, <op1>, Rd, Cn, Cm , <op2>
      ARMv2

      2. MRC2
      <copro>, <op1>, Rd, Cn, Cm , <op2>
      ARMv5

      3. MRRC<cond><copro>, <op1>, Rd, Rn, Cm
      ARMv5E

      4. MRRC2
      <copro>, <op1>, Rd, Rn, Cm
      ARMv6
```

These instructions transfer a 32-bit value from the indicated coprocessor to the ARM register Rd. Formats 3 and 4 also transfer a second 32-bit value to Rn. <copro> is the number of the coprocessor in the range p0 to p15. The core takes an undefined instruction trap if the coprocessor is not present. The coprocessor operation specifiers <0p1> and <0p2>, and the coprocessor register numbers Cn, Cm, are interpreted by the coprocessor and ignored by the ARM. For formats 1 and 2, if Rd is pc, then the top four bits of the cpsr (the NZCV condition code flags) are set from the top four bits of the 32-bit value transferred; pc is not affected. For other formats, Rd and Rn must be distinct and not pc.

Coprocessor *p15* controls memory management options (see Chapters 12 and 13). For example, the following instruction reads the main ID register from *p15*:

```
MRC p15, 0, r0, c0, c0; read the MMU ID register, c0
```

Move to ARM register from status register (cpsr or spsr)

1. MRS<cond> Rd, cpsr ARMv3

2. MRS<cond> Rd, spsr ARMv3

These instructions set Rd = cpsr and Rd = spsr, respectively. Rd must not be pc.

MSR Move to status register (*cpsr* or *spsr*) from an ARM register

1. MSR<cond> cpsr <fields>, #<rotated immed> ARMv3

Table A.9	Format of the <fields> specifier.</fields>
-----------	--

<fields> letter</fields>	Meaning	Bits set in <mask></mask>
С	Control byte	0x00000ff
Χ	eXtension byte	0x0000ff00
S	Status byte	0x00ff0000
f	Flags byte	0xff000000

```
    MSR<cond> cpsr_<fields>, Rm
    MSR<cond> spsr_<fields>, #<rotated_immed>
    ARMv3
    MSR<cond> spsr_<fields>, Rm
    ARMv3
```

Action

```
    cpsr = (cpsr & ~<mask>) | (<rotated_immed> & <mask>)
    cpsr = (cpsr & ~<mask>) | (Rm & <mask>)
    spsr = (spsr & ~<mask>) | (<rotated_immed> & <mask>)
    spsr = (spsr & ~<mask>) | (Rm & <mask>)
```

These instructions alter selected bytes of the *cpsr* or *spsr* according to the value of <mask>. The <fields> specifier is a sequence of one or more letters, determining which bytes of <mask> are set. See Table A.9.

Some old ARM toolkits allowed *cpsr* or *cpsr_all* in place of *cpsr_fsxc*. They also used *cpsr_flg* and *cpsr_ctl* in place of *cpsr_f* and *cpsr_c*, respectively. These formats, and the *spsr* equivalents, are obsolete, so you should not use them. The following example changes to *system* mode and enables IRQ, which is useful in a reentrant interrupt handler:

```
MRS r0, cpsr ; read cpsr state
BIC r0, r0, #0x9f ; clear IRQ disable and mode bits
ORR r0, r0, #0x1f ; set system mode
MSR cpsr_c, r0 ; update control byte of the cpsr
```

MUL Multiply

1.	MUL <cond>{S}</cond>	Rd,	Rm,	Rs	ARMv2
2.	MUL	Ld,	Lm		THUMBv1

Action	Effect on the <i>cpsr</i>
--------	---------------------------

2. Ld = Lm*Ld Updated

Notes

- Rd or Ld is set to the lower 32 bits of the result.
- \blacksquare Rd, Rm, Rs must not be pc.
- *Rd* and *Rm* must be different registers. Similarly *Ld* and *Lm* must be different.
- Implementations may terminate early on the value of the *Rs* or *Ld* operand. For this reason use small or constant values for *Rs* or *Ld* where possible.
- If the *cpsr* is updated, then $N = \langle Negative \rangle$, $Z = \langle Zero \rangle$, C is unpredictable, and V is preserved. Avoid using the instruction MULS because implementations often impose penalty cycles for this operation. Instead use MUL followed by a compare, and schedule the compare, to avoid multiply result use interlocks.

MVN Move the logical not of a 32-bit value into a register

1.	MVN <cond>{S}</cond>	Rd,	<pre>#<rotated_immed></rotated_immed></pre>	ARMv1
2.	MVN <cond>{S}</cond>	Rd,	Rm {, <shift>}</shift>	ARMv1
3.	MVN	Ld,	Lm	THUMBv1

Action Effect on the *cpsr*

1.	Rd = \sim <rotated_immed></rotated_immed>	Updated if S suffix specified
2.	Rd = ~ <shifted_rm></shifted_rm>	Updated if S suffix specified
3.	Ld = ∼Lm	Updated (see Notes below)

Notes

- If the operation updates the *cpsr* and *Rd* is not *pc*, then $N = \langle Negative \rangle$, $Z = \langle Zero \rangle$, $C = \langle shifter_C \rangle$ (see Table A.3), and V is preserved.
- If *Rd* is *pc*, then the instruction effects a jump to the calculated address. If the operation updates the *cpsr*, then the processor mode must have an *spsr*; in this case, the *cpsr* is set to the value of the *spsr*.
- If *Rm* is *pc*, then the value used is the address of the instruction plus eight bytes.

Examples

MVN r0, #0xff ; r0 = 0xffffff00 MVN r0, #0 ; r0 = -1

NEG Negate value in Thumb (use RSB to negate in ARM state)

1. NEG Ld, Lm THUMBv1

Action Effect on the *cpsr*

1. Ld = -Lm Updated (see Notes below)

Notes

- The *cpsr* is updated: $N = \langle Negative \rangle$, $Z = \langle Zero \rangle$, $C = \langle NoUnsignedOverflow \rangle$, $V = \langle SignedOverflow \rangle$. Note that Z = C and V = (Ld = 0x80000000).
- This is the same as the operation RSBS Ld, Lm, #0 in ARM state.

NOP No operation

1. NOP MACRO

This is not an ARM instruction. It is an assembly macro that produces an instruction having no effect other than advancing the *pc* as normal. In ARM state it assembles to MOV r0, r0. In Thumb state it assembles to MOV r8, r8. The operation is not guaranteed to take one processor cycle. In particular, if you use NOP after a load of *r0*, then the operation may cause pipeline interlocks.

ORR Logical bitwise OR of two 32-bit values

2.

Action Effect on the *cpsr*

Notes

- If the operation updates the *cpsr* and *Rd* is not *pc*, then $N = \langle Negative \rangle$, $Z = \langle Zero \rangle$, $C = \langle shifter_C \rangle$ (see Table A.3), and V is preserved.
- If *Rd* is *pc*, then the instruction effects a jump to the calculated address. If the operation updates the *cpsr*, then the processor mode must have an *spsr*, in this case, the *cpsr* is set to the value of the *spsr*.
- If Rn or Rm is pc, then the value used is the address of the instruction plus eight bytes.

Example

```
ORR r0, r0, \#1 << 13; set bit 13 of r0
```

PKH Pack 16-bit halfwords into a 32-bit word

- 1. PKHBT<cond> Rd, Rn, Rm {, LSL #<0-31>} ARMv6
- 2. PKHTB<cond> Rd, Rn, Rm {, ASR #<1-32>} ARMv6

Action

- 1. Rd[15:00] = Rn[15:00]; Rd[31:16] = < shifted Rm>[31:16]
- 2. Rd[31:16] = Rn[31:16]; Rd[15:00] = < shifted Rm>[15:00]

Note

■ *Rd*, *Rn*, *Rm* must not be *pc*. *cpsr* is not affected.

Examples

```
PKHBT r0, r1, r2, LSL#16 ; r0 = (r2[15:00] << 16) | r1[15:00] PKHTB r0, r2, r1, ASR#16 ; r0 = (r2[31:15] << 16) | r1[31:15]
```

PLD Preload hint instruction

1. PLD [Rn {, #{-}<immed12>}]

ARMv5E

2. PLD [Rn, {-}Rm {,<imm shift>}]

ARMv5E

Action

- Preloads from address (Rn + {{-}<immed12>})
- 2. Preloads from address (Rn + {-}<shifted Rm>)

This instruction does not affect the processor registers (other than advancing pc). It merely hints that the programmer is likely to read from the given address in future. A cached processor may take this as a hint to load the cache line containing the address into the cache. The instruction should not generate a data abort or any other memory system error. If Rn is pc, then the value used for Rn is the address of the instruction plus eight. Rm must not be pc.

Examples

```
PLD [r0, #7] ; Preload from r0+7
PLD [r0, r1, LSL#2] ; Preload from r0+4*r1
```

POP Pops multiple registers from the stack in Thumb state (for ARM state use LDM)

1. POP <regster_list>

THUMBv1

Action

equivalent to the ARM instruction LDMFD sp!, <register_list>

The <register_list> can contain registers in the range *r0* to *r7* and *pc*. The following example restores the low-numbered ARM registers and returns from a subroutine:

PUSH Pushes multiple registers to the stack in Thumb state (for ARM state use STM)

PUSH <regster list>

THUMBv1

Action

. . . .

equivalent to the ARM instruction STMFD sp!, <register list>

The <register_list> can contain registers in the range *r0* to *r7* and *lr*. The following example saves the low-numbered ARM registers and link register.

QADD QDADD	Saturated signed and	Saturated signed and unsigned arithmetic				
QDSUB OSUB	1. QADD <cond></cond>	Rd, Rm, Rn	ARMv5E			
ЧЭОВ	2. QDADD <cond></cond>	Rd, Rm, Rn	ARMv5E			

3.	QSUB <cond></cond>	Rd,	Rm,	Rn	ARMv5E
4.	QDSUB <cond></cond>	Rd,	Rm,	Rn	ARMv5E
5.	{U}QADD16 <cond></cond>	Rd,	Rn,	Rm	ARMv6
6.	{U}QADDSUBX <cond></cond>	Rd,	Rn,	Rm	ARMv6
7.	{U}QSUBADDX <cond></cond>	Rd,	Rn,	Rm	ARMv6
8.	{U}QSUB16 <cond></cond>	Rd,	Rn,	Rm	ARMv6
9.	{U}QADD8 <cond></cond>	Rd,	Rn,	Rm	ARMv6
10.	{U}QSUB8 <cond></cond>	Rd,	Rn,	Rm	ARMv6

Action

1. Rd = sat32(Rm+Rn)2. Rd = sat32(Rm+sat32(2*Rn))3. Rd = sat32(Rm-Rn)4. Rd = sat32(Rm-sat32(2*Rn))5. Rd[31:16] = sat16(Rn[31:16] + Rm[31:16]);Rd[15:00] = sat16(Rn[15:00] + Rm[15:00])6. Rd[31:16] = sat16(Rn[31:16] + Rm[15:00]);Rd[15:00] = sat16(Rn[15:00] - Rm[31:16])7. Rd[31:16] = sat16(Rn[31:16] - Rm[15:00]);Rd[15:00] = sat16(Rn[15:00] + Rm[31:16])8. Rd[31:16] = sat16(Rn[31:16] - Rm[31:16]);Rd[15:00] = sat16(Rn[15:00] - Rm[15:00])9. Rd[31:24] = sat8(Rn[31:24] + Rm[31:24]);

Rd[23:16] = sat8(Rn[23:16] + Rm[23:16]);Rd[15:08] = sat8(Rn[15:08] + Rm[15:08]);Rd[07:00] = sat8(Rn[07:00] + Rm[07:00])

Rd[23:16] = sat8(Rn[23:16] - Rm[23:16]);

10. Rd[31:24] = sat8(Rn[31:24] - Rm[31:24]);

```
Rd[15:08] = sat8(Rn[15:08] - Rm[15:08]);

Rd[07:00] = sat8(Rn[07:00] - Rm[07:00])
```

Notes

- The operations are signed unless the U prefix is present. For signed operations, satN(x) saturates x to the range $-2^{N-1} \le x < 2^{N-1}$. For unsigned operations, satN(x) saturates x to the range $0 \le x < 2^N$.
- The *cpsr Q*-flag is set if saturation occurred; otherwise it is preserved.
- \blacksquare *Rd*, *Rn*, *Rm* must not be *pc*.
- The X operations are useful for packed complex numbers. The following examples assume bits [15:00] hold the real part and [31:16] the imaginary part.

Examples

```
QDADD r0, r0, r2; add Q30 value r2 to Q31 accumulator r0 QADD16 r0, r1, r2; SIMD saturating add QADDSUBX r0, r1, r2; r0=r1+i*r2 in packed complex arithmetic QSUBADDX r0, r1, r2; r0=r1-i*r2 in packed complex arithmetic
```

REV Reverse bytes within a word or halfword.

1. REV<cond> Rd. Rm

ARMv6/THUMBv3

2. REV16<cond> Rd, Rm

ARMv6/THUMBv3

3. REVSH<cond> Rd, Rm

ARMv6/THUMBv3

Action

```
    Rd[31:24] = Rm[07:00]; Rd[23:16] = Rm[15:08];
        Rd[15:08] = Rm[23:16]; Rd[07:00] = Rm[31:24]
    Rd[31:24] = Rm[23:16]; Rd[23:16] = Rm[31:24];
        Rd[15:08] = Rm[07:00]; Rd[07:00] = Rm[15:08]
    Rd[31:08] = sign-extend(Rm[07:00]); Rd[07:00] = Rm[15:08]
```

Notes

- \blacksquare *Rd* and *Rm* must not be *pc*.
- For Thumb, *Rd*, *Rm* must be in the range *r0* to *r7* and <cond> cannot be specified.

 These instructions are useful to convert big-endian data to little-endian and vice versa.

Examples

```
REV r0, r0 ; switch endianness of a word
```

REV16 r0, r0 ; switch endianness of two packed halfwords REVSH r0, r0 ; switch endianness of a signed halfword

RFE Return from exception

1. RFF<amode> Rn!

ARMv6

This performs the operation that LDM<amode> Rn{!}, {pc, cpsr} would perform if LDM allowed a register list of {pc, cpsr}. See the entry for LDM.

ROR Rotate right for Thumb (see MOV for the ARM equivalent)

1. ROR Ld, Ls

THUMBv1

Action

Effect on the cpsr

1. Ld = Ld ROR Ls[7:0]

Updated

Notes

The *cpsr* is updated: $N = \langle Negative \rangle$, $Z = \langle Zero \rangle$, $C = \langle shifter_C \rangle$ (see Table A.3).

RSB Reverse subtract of two 32-bit integers

1. RSB<cond>{S} Rd, Rn, #<rotated_immed>

ARMv1

2. RSB<cond>{S} Rd, Rn, Rm {, <shift>}

ARMv1

Action

Effect on the cpsr

Rd = <rotated immed> - Rn Updated if S suffix present

2. Rd = <shifted Rm> - Rn Updated if S suffix present

Notes

■ If the operation updates the *cpsr* and *Rd* is not *pc*, then $N = \langle Negative \rangle$, $Z = \langle Zero \rangle$, $C = \langle NoUnsignedOverflow \rangle$, and $V = \langle SignedOverflow \rangle$. The carry flag is set this way

because the subtract x - y is implemented as the add $x + \sim y + 1$. The carry flag is one if $x + \sim y + 1$ overflows. This happens when $x \ge y$, when x - y doesn't overflow.

- If *Rd* is *pc*, then the instruction effects a jump to the calculated address. If the operation updates the *cpsr*, then the processor mode must have an *spsr* in this case, the *cpsr* is set to the value of the *spsr*.
- If Rn or Rm is pc, then the value used is the address of the instruction plus eight bytes.

Examples

```
RSB r0, r0, #0 ; r0 = -r0
RSB r0, r1, r1, LSL#3 ; r0 = 7*r1
```

RSC Reverse subtract with carry of two 32-bit integers

```
    RSC<cond>{S} Rd, Rn, #<rotated immed> ARMv1
```

Action

Effect on the cpsr

```
1. Rd = <rotated_immed> - Rn - (\simC) Updated if S suffix present
```

2. Rd =
$$<$$
shifted_Rm> - Rn - (\sim C) Updated if S suffix present

Notes

- If the operation updates the *cpsr* and *Rd* is not *pc*, then $N = \langle Negative \rangle$, $Z = \langle Zero \rangle$, $C = \langle NoUnsignedOverflow \rangle$, $V = \langle SignedOverflow \rangle$. The carry flag is set this way because the subtract $x y \sim C$ is implemented as the add $x + \sim y + C$. The carry flag is one if $x + \sim y + C$ overflows. This happens when $x y \sim C$ doesn't overflow.
- If *Rd* is *pc*, then the instruction effects a jump to the calculated address. If the operation updates the *cpsr*, then the processor mode must have an *spsr*; in this case the *cpsr* is set to the value of the *spsr*.
- If *Rn* or *Rm* is *pc*, then the value used is the address of the instruction plus eight bytes.

The following example negates a 64-bit integer where r0 is the low 32 bits and r1 the high 32 bits.

```
RSBS r0, r0, #0 ; r0 = -r0 C=NOT(borrow)
RSC r1, r1, #0 ; r1 = -r1-borrow
```

SADD Parallel modulo add and subtract operations

2. {S|U}ADDSUBX<cond> Rd, Rn, Rm

<pre>3. {S U}SUBADDX<cond></cond></pre>	Rd, Rn, Rm	ARMv6
4. {S U}SUB16 <cond></cond>	Rd, Rn, Rm	ARMv6
5. {S U}ADD8 <cond></cond>	Rd, Rn, Rm	ARMv6
6. {S U}SUB8 <cond></cond>	Rd, Rn, Rm	ARMv6
Action		Effect on the <i>cpsr</i>
1. Rd[31:16]=Rn[31:16]+R	m[31:16];	GE3=GE2=cmn(Rn[31:16],Rm[31:16])
Rd[15:00]=Rn[15:00]+R	m[15:00]	GE1=GE0=cmn(Rn[15:00],Rm[15:00])
2. Rd[31:16]=Rn[31:16]+R	m[15:00];	GE3=GE2=cmn(Rn[31:16],Rm[15:00])
Rd[15:00]=Rn[15:00]-R	m[31:16]	GE1=GE0=(Rn[15:00] >= Rm[31:16])
3. Rd[31:16]=Rn[31:16]-R	m[15:00];	GE3=GE2=(Rn[31:16] >= Rm[15:00])
Rd[15:00]=Rn[15:00]+R	m[31:16]	GE1=GE0=cmn(Rn[15:00],Rm[31:16])
4. Rd[31:16]=Rn[31:16]-R	m[31:16];	GE3=GE2=(Rn[31:16] >= Rm[31:16])
Rd[15:00]=Rn[15:00]-R	m[15:00]	GE1=GE0=(Rn[15:00] >= Rm[15:00])

ARMv6

1.	Rd[31:16]=Rn[31:16]+Rm[31:16];	GE3=GE2=cmn(Rn[31:16],Rm[31:16])
	Rd[15:00]=Rn[15:00]+Rm[15:00]	GE1=GE0=cmn(Rn[15:00],Rm[15:00])
2.	Rd[31:16]=Rn[31:16]+Rm[15:00];	GE3=GE2=cmn(Rn[31:16],Rm[15:00])
	Rd[15:00]=Rn[15:00]-Rm[31:16]	GE1=GE0=(Rn[15:00] >= Rm[31:16])
3.	Rd[31:16]=Rn[31:16]-Rm[15:00];	GE3=GE2=(Rn[31:16] >= Rm[15:00])
	Rd[15:00]=Rn[15:00]+Rm[31:16]	GE1=GE0=cmn(Rn[15:00],Rm[31:16])
4.	Rd[31:16]=Rn[31:16]-Rm[31:16];	GE3=GE2=(Rn[31:16] >= Rm[31:16])
	Rd[15:00]=Rn[15:00]-Rm[15:00]	GE1=GE0=(Rn[15:00] >= Rm[15:00])
5.	Rd[31:24]=Rn[31:24]+Rm[31:24];	GE3 = cmn(Rn[31:24],Rm[31:24])
	Rd[23:16]=Rn[23:16]+Rm[23:16];	GE2 = cmn(Rn[23:16],Rm[23:16])
	Rd[15:08] = Rn[15:08] + Rm[15:08];	GE1 = cmn(Rn[15:08],Rm[15:08])
	Rd[07:00]=Rn[07:00]+Rm[07:00]	GEO = cmn(Rn[07:00],Rm[07:00])
6.	Rd[31:24]=Rn[31:24]-Rm[31:24];	GE3 = (Rn[31:24] >= Rm[31:24])
	Rd[23:16]=Rn[23:16]-Rm[23:16];	GE2 = (Rn[23:16] >= Rm[23:16])
	Rd[15:08] = Rn[15:08] - Rm[15:08];	GE1 = (Rn[15:08] >= Rm[15:08])
	Rd[07:00]=Rn[07:00]-Rm[07:00]	GEO = (Rn[07:00] >= Rm[07:00])

Notes

- If you specify the S prefix, then all comparisons are signed. The cmn(x,y) function returns $x \ge -y$ or equivalently $x + y \ge 0$.
- If you specify the U prefix, then all comparisons are unsigned. The cmn(x,y) function returns $x \ge (unsigned)(-y)$ or equivalently if the x + y operation produces a carry.
- *Rd*, *Rn*, and *Rm* must not be *pc*.

■ The X operations are useful for packed complex numbers. The following examples assume bits [15:00] hold the real part and [31:16] the imaginary part.

Examples

```
SADD16 r0, r1, r2; Signed 16-bit SIMD add
SADDSUBX r0, r1, r2; r0=r1+i*r2 in packed complex arithmetic
SSUBADDX r0, r1, r2; r0=r1-i*r2 in packed complex arithmetic
```

SBC Subtract with carry

```
1. SBC<cond>{S} Rd, Rn, #<rotated immed> ARMv1
```

Action

Effect on the cpsr

1. Rd = Rn - - (
$$\sim$$
C) Updated if S suffix specified

2. Rd = Rn -
$$<$$
shifted_Rm> - (\sim C) Updated if S suffix specified

3. Ld = Ld - Lm - (
$$\sim$$
C) Updated (see Notes below)

Notes

- If the operation updates the *cpsr* and *Rd* is not *pc*, then $N = \langle Negative \rangle$, $Z = \langle Zero \rangle$, $C = \langle NoUnsignedOverflow \rangle$, $V = \langle SignedOverflow \rangle$. The carry flag is set this way because the subtract $x y \sim C$ is implemented as the add $x + \sim y + C$. The carry flag is one if $x + \sim y + C$ overflows. This happens when $x y \sim C$ doesn't overflow.
- If *Rd* is *pc*, then the instruction effects a jump to the calculated address. If the operation updates the *cpsr*, then the processor mode must have an *spsr*. In this case the *cpsr* is set to the value of the *spsr*.
- If Rn or Rm is pc, then the value used is the address of the instruction plus eight bytes.

The following example implements a 64-bit subtract:

```
SUBS r0, r0, r2; subtract low words, C=NOT(borrow)
SBC r1, r1, r3; subtract high words and borrow
```

SEL Select between two source operands based on the GE flags

```
1. SEL<cond> Rd, Rn, Rm
```

Action

```
1. Rd[31:24] = GE3 ? Rn[31:24] : Rm[31:24];
  Rd[23:16] = GE2 ? Rn[23:16] : Rm[23:16];
  Rd[15:08] = GE1 ? Rn[15:08] : Rm[15:08];
  Rd[07:00] = GE0 ? Rn[07:00] : Rm[07:00]
```

Notes

- *Rd*, *Rn*, *Rm* must not be *pc*.
- See SADD for instructions that set the *GE* flags in the *cpsr*.

SETEND Set the endianness for data accesses

1. SETEND BE ARMv6/THUMBv3

2. SETEND LE ARMv6/THUMBv3

Action

- 1. In the cpsr E=1 so data accesses will be big-endian
- 2. In the cpsr E=0 so data accesses will be little-endian

Note

ARMv6 uses a byte-invariant endianness model. This means that byte loads and stores are not affected by the configured endianess. For little-endian data access the byte at the lowest address appears in the least significant byte of the loaded word. For big-endian data accesses the byte at the lowest address appears in the most significant byte of the loaded word.

SHADD Parallel halving add and subtract operations

1.	{S U}HADD16 <cond></cond>	Rd,	Rn,	Rm	ARMv6
2.	{S U}HADDSUBX <cond></cond>	Rd,	Rn,	Rm	ARMv6
3.	{S U}HSUBADDX <cond></cond>	Rd,	Rn,	Rm	ARMv6
4.	{S U}HSUB16 <cond></cond>	Rd,	Rn,	Rm	ARMv6
5.	{S U}HADD8 <cond></cond>	Rd,	Rn,	Rm	ARMv6
6.	{S U}HSUB8 <cond></cond>	Rd,	Rn,	Rm	ARMv6

Action

```
1. Rd[31:16] = (Rn[31:16] + Rm[31:16]) >> 1;
    Rd[15:00] = (Rn[15:00] + Rm[15:00]) >> 1
2. Rd[31:16] = (Rn[31:16] + Rm[15:00]) >> 1;
    Rd[15:00] = (Rn[15:00] - Rm[31:16]) >> 1
3. Rd[31:16] = (Rn[31:16] - Rm[15:00]) >> 1;
    Rd[15:00] = (Rn[15:00] + Rm[31:16]) >> 1
4. Rd[31:16] = (Rn[31:16] - Rm[31:16]) >> 1;
    Rd[15:00] = (Rn[15:00] - Rm[15:00]) >> 1
5. Rd[31:24] = (Rn[31:24] + Rm[31:24]) >> 1;
    Rd[23:16] = (Rn[23:16] + Rm[23:16]) >> 1;
    Rd[15:08] = (Rn[15:08] + Rm[15:08]) >> 1;
    Rd[07:00] = (Rn[07:00] + Rm[07:00]) >> 1
6. Rd[31:24] = (Rn[31:24] - Rm[31:24]) >> 1;
    Rd[23:16] = (Rn[23:16] - Rm[23:16]) >> 1;
    Rd[15:08] = (Rn[15:08] - Rm[15:08]) >> 1;
    Rd[07:00] = (Rn[07:00] - Rm[07:00]) >> 1
```

Notes

- If you use the S prefix, then all operations are signed and values are sign-extended before the addition.
- If you use the U prefix, then all operations are unsigned and values are zero-extended before the addition.
- *Rd*, *Rn*, and *Rm* must not be *pc*.
- These operations provide parallel arithmetic that cannot overflow, which is useful for DSP processing of normalized signals.

SMLA SMLS

Signed multiply accumulate instructions

1.	SMLA <x><y><cond></cond></y></x>	Rd,	Rm,	Rs,	Rn	ARMv5E
2.	SMLAW <y><cond></cond></y>	Rd,	Rm,	Rs,	Rn	ARMv5E
3.	SMLAD{X} <cond></cond>	Rd,	Rm,	Rs,	Rn	ARMv6

4.	SMLSD{X} <cond></cond>	Rd, Rm, Rs, Rn	ARMv6
5.	$\{U \mid S\}MLAL < cond > \{S\}$	RdLo, RdHi, Rm, Rs	ARMv3M
6.	SMLAL <x><y><cond></cond></y></x>	RdLo, RdHi, Rm, Rs	ARMv5E
7.	SMLALD{X} <cond></cond>	RdLo, RdHi, Rm, Rs	ARMv6
8.	SMLSLD{X} <cond></cond>	RdLo, RdHi, Rm, Rs	ARMv6

Action

1. Rd =
$$Rn + (Rm. < x > * Rs. < y >)$$

2. Rd =
$$Rn + (((signed)Rm * Rs. < y>) >> 16)$$

Notes

- <x> and <y> can be B or T.
- Rm.B is shorthand for (*sign-extend*)Rm[15:00], the bottom 16 bits of Rm.
- \blacksquare Rm. T is shorthand for (sign-extend)Rm[31:16], the top 16 bits of Rm.
- <rotated_Rs> is Rs if you do not specify the X suffix or Rs ROR 16 if you do specify the X suffix.
- *RdHi* and *RdLo* must be different registers. For format 5, *Rm* must be a different register from *RdHi* and *RdLo*.
- Formats 1 to 4 update the *cpsr Q*-flag: $Q = Q | \langle SignedOverflow \rangle$.
- Format 5 implements an unsigned multiply with the U prefix or a signed multiply with the S prefix.
- Format 5 updates the *cpsr* if the S suffix is present: N = RdHi[31], Z = (RdHi=0 && RdLo=0); the C and V flags are unpredictable. Avoid using $\{U \mid S\}MLALS$ because implementations often impose penalty cycles for this operation.

- Implementations may terminate early on the value of *Rs*. For this reason use small or constant values for *Rs* where possible.
- The X suffix and multiply subtract versions are useful for packed complex numbers. The following examples assume bits [15:00] hold the real part and [31:16] the imaginary part.

Examples

```
SMLABB r0, r1, r2, r0 ; r0 += (short)r1 * (short)r2

SMLABT r0, r1, r2, r0 ; r0 += (short)r1 * ((signed)r2>>16)

SMLAWB r0, r1, r2, r0 ; r0 += (r1*(short)r2)>>16

SMLAL r0, r1, r2, r3 ; acc += r2*r3, acc is 64 bits [r1:r0]

SMLALTB r0, r1, r2, r3 ; acc += ((signed)r2>>16)*((short)r3)

SMLSD r0, r1, r2, r0 ; r0 += real(r1*r2) in complex maths

SMLADX r0, r1, r2, r0 ; r0 += imag(r1*r2) in complex maths
```

SMMUL SMMLA SMMLS

Signed most significant word multiply instructions

```
    SMMUL{R}<cond> Rd, Rm, Rs
    ARMv6
```

2. SMMLA{R}<cond> Rd, Rm, Rs, Rn ARMv6

SMMLS{R}<cond> Rd, Rm, Rs, Rn ARMv6

Action

```
    Rd = ((signed)Rm*(signed)Rs + round) >> 32
    Rd = ((Rn << 32) + (signed)Rm*(signed)Rs + round) >> 32
```

3.
$$Rd = ((Rn << 32) - (signed)Rm*(signed)Rs + round) >> 32$$

Notes

- If you specify the R suffix then $round = 2^{31}$; otherwise, round = 0.
- *Rd*, *Rm*, *Rs*, and *Rn* must not be *pc*.
- Implementations may terminate early on the value of *Rs*.
- For 32-bit DSP algorithms these operations have several advantages over using the high result register from SMLAL: They often take fewer cycles than SMLAL. They also implement rounding, multiply subtract, and don't require a temporary scratch register for the low 32 bits of result.

Example

```
SMMULR r0, r1, r2; r0=r1*r2/2 using Q31 arithmetic
```

SMUL
SMUA
SMUS

Signed multiply instructions

1.	SMUL <x><y><cond></cond></y></x>	Rd, Rm, Rs	ARMv5E
2.	SMULW <y><cond></cond></y>	Rd, Rm, Rs	ARMv5E
3.	SMUAD{X} <cond></cond>	Rd, Rm, Rs	ARMv6
4.	SMUSD{X} <cond></cond>	Rd, Rm, Rs	ARMv6

ARMv3M

5. {U|S}MULL<cond>{S} RdLo, RdHi, Rm, Rs

Action

```
1. Rd = Rm.<x> * Rs.<y>
2. Rd = (Rm * Rs.<y>) >> 16
3. Rd = Rm.B*<rotated_Rs>.B + Rm.T*<rotated_Rs>.T
4. Rd = Rm.B*<rotated_Rs>.B - Rm.T*<rotated_Rs>.T
5. RdHi:RdLo = Rm*Rs
```

Notes

- \blacksquare <x> and <y> can be B or T.
- \blacksquare Rm.B is shorthand for (sign-extend)Rm[15:00], the bottom 16 bits of Rm.
- \blacksquare *Rm.T* is shorthand for (*sign-extend*)Rm[31:16], the top 16 bits of Rm.
- <rotated_Rs> is Rs if you do not specify the X suffix or Rs ROR 16 if you do specify the X suffix.
- *RdHi* and *RdLo* must be different registers. For format 5, *Rm* must be a different register from *RdHi* and *RdLo*.
- Format 4 updates the *cpsr Q*-flag: $Q = Q \mid \langle SignedOverflow \rangle$.
- Format 5 implements an unsigned multiply with the U prefix or a signed multiply with the S prefix.
- Format 5 updates the *cpsr* if the *S* suffix is present: N = RdHi[31], Z = (RdHi=0 && RdLo=0); the *C* and *V* flags are unpredictable. Avoid using $\{S \mid U\}MULLS$ because implementations often impose penalty cycles for this operation.
- Implementations may terminate early on the value of *Rs*. For this reason use small or constant values for *Rs* where possible.
- The X suffix and multiply subtract versions are useful for packed complex numbers. The following examples assume bits [15:00] hold the real part and [31:16] the imaginary part.

Examples

```
SMULBB r0, r1, r2 ; r0 = (short)r1 * (short)r2
SMULBT r0, r1, r2 ; r0 = (short)r1 * ((signed)r2>>16)
SMULWB r0, r1, r2 ; r0 = (r1*(short)r2)>>16
SMULL r0, r1, r2, r3 ; acc = r2*r3, acc is 64 bits [r1:r0]
SMUADX r0, r1, r2 ; r0 = imag(r1*r2) in complex maths
```

SRS Save return state

1. SRS<amode> #<mode>{!}

ARMv6

This performs the operation that *STM*<*amode*> *sp_*<*mode*>{!}, {*lr*, *spsr*} would perform if STM allowed a register list of {*lr*, *spsr*} and allowed you to reference the stack pointer of a different mode. See the entry for STM.

SSAT Saturate to *n* bits

```
1. {S|U}SAT<cond> Rd, #<n>, Rm {, LSL#<0-31>}
```

- 2. {S|U}SAT<cond> Rd, #<n>, Rm {, ASR#<1-32>}
- 3. $\{S|U\}SAT16 < cond > Rd, \# < n > Rm$

Action

Effect on the *cpsr*

```
    Rd = sat(<shifted_Rm>, n);
    Rd = sat(<shifted_Rm>, n);
    Rd = sat(<shifted_Rm>, n);
    Rd[31:16] = sat(Rm[31:16], n);
    Rd[15:00] = sat(Rm[15:00], n)
```

Notes

- If you specify the S prefix, then sat(x, n) saturates the signed value x to a signed n-bit value in the range $-2^{n-1} \le x < 2^{n-1}$. n is encoded as 1 + <immed5> for SAT and 1 + <immed4> for SAT16.
- If you specify the U prefix, then sat(x, n) saturates the signed value x to an unsigned n-bit value in the range $0 \le x < 2^n$. n is encoded as < immed 5> for SAT and < immed 4> for SAT16.
- \blacksquare *Rd* and *Rm* must not be *pc*.

Store to coprocessor single or multiple 32-bit values

```
STC<cond>{L} <copro>, Cd, [Rn {, #{-}<immed8>*4}]{!}
                                                               ARMv2
2.
    STC < cond > \{L\} < copro >, Cd, [Rn], \#\{-\} < immed 8 > *4
                                                               ARMv2
    STC<cond>{L} <copro>, Cd, [Rn], <option>
                                                               ARMv2
    STC2{L}
                   <copro>, Cd, [Rn {, #{-}<immed8>*4}]{!}
                                                               ARMv5
    STC2{L}
                   <copro>, Cd, [Rn], #{-}<immed8>*4
                                                               ARMv5
    STC2{L}
                   <copro>, Cd, [Rn], <option>
                                                               ARMv5
```

These instructions initiate a memory write, transferring data to memory from the given coprocessor. < copro> is the number of the coprocessor in the range p0 to p15. The core takes an undefined instruction trap if the coprocessor is not present. The memory write consists of a sequence of words to sequentially increasing addresses. The initial address is specified by the addressing mode in Table A.10. The coprocessor controls the number of words transferred, up to a maximum limit of 16 words. The fields $\{L\}$ and Cd are interpreted by the coprocessor and ignored by the ARM. Typically Cd specifies the source coprocessor register for the transfer. The < option> field is an eight-bit integer enclosed in $\{J\}$. Its interpretation is coprocessor dependent.

If the address is not a multiple of four, then the access is unaligned. The restrictions on an unaligned access are the same as for STM.

Table A.10 STC addressing modes.

Addressing format	Address accessed	Value written back to Rn
<pre>[Rn {,#{-}<immed>}] [Rn {,#{-}<immed>}]! [Rn], #{-}<immed> [Rn], <option></option></immed></immed></immed></pre>	Rn + {{-} <immed>} Rn + {{-}<immed>} Rn Rn</immed></immed>	Rn preserved Rn + {{-} <immed>} Rn + {-}<immed> Rn preserved</immed></immed>

STM Store multiple 32-bit registers to memory

These instructions store multiple words to sequential memory addresses. The <*register_list>* specifies a list of registers to store, enclosed in curly brackets {}. Although the

Addressing mode	Lowest address accessed	Highest address accessed	Value written back to <i>Rn</i> if ! specified
{IA EA}	Rn	Rn + N*4 - 4	Rn + N*4
{IB FA}	Rn + 4	Rn + N*4	Rn + N*4
{DA ED}	Rn - N*4 + 4	Rn	Rn - N*4
{DB FD}	Rn - N*4	Rn - 4	Rn - N*4

Table A.11 STM addressing modes.

assembler allows you to specify the registers in the list in any order, the order is not stored in the instruction, so it is good practice to write the list in increasing order of register number since this is the usual order of the memory transfer.

The following pseudocode shows the normal action of STM. We use < register_list>[i] to denote the register appearing at position i in the list starting at 0 for the first register. This assumes that the list is in order of increasing register number.

```
N = the number of registers in <register_list>
start = the lowest address accessed given in Table A.11
for (i=0; i<N; i++)
  memory(start+i*4, 4) = <register_list>[i];
if (! specified) then update Rn according to Table A.11
```

Note that memory (a, 4) refers to the four bytes at address a packed according to the current processor data endianness. If a is not a multiple of four, then the store is unaligned. Because the behavior of an unaligned store depends on the architecture revision, memory system, and system coprocessor (CP15) configuration, it is best to avoid unaligned stores if possible. Assuming that the external memory system does not abort unaligned stores, then the following rules usually apply:

- If the core has a system coprocessor and bit 1 (*A*-bit) or bit 22 (*U*-bit) of CP15:c1:c0:0 is set, then unaligned store-multiples cause an alignment fault data abort exception.
- Otherwise, the access ignores the bottom two address bits.

Table A.11 lists the possible addressing modes specified by <amode>. If you specify the !, then the base address register is updated according to Table A.11; otherwise, it is preserved. Note that the lowest register number is always written to the lowest address.

The first half of the addressing mode mnemonics stands for Increment After, Increment Before, Decrement After, and Decrement Before, respectively. Increment modes store the registers sequentially forward starting from address Rn (increment after) or Rn + 4 (increment before). Decrement modes have the same effect as if you stored the register

STR

list backwards to sequentially descending memory addresses starting from address Rn (decrement after) or Rn - 4 (decrement before).

The second half of the addressing mode mnemonics stands for the stack type you can implement with that address mode: Full Descending, Empty Descending, Full Ascending, and Empty Ascending. With a full stack, *Rn* points to the last stacked value. With an empty stack, *Rn* points to the first unused stack location. ARM stacks are usually full descending. You should use full descending or empty ascending stacks by preference, since STC also supports these addressing modes.

Notes

- For Thumb (format 2), Rn and the register list registers must be in the range r0 to r7.
- The number of registers *N* in the list must be nonzero.
- \blacksquare Rn must not be pc.
- If *Rn* appears in the register list and ! (writeback) is specified, the behavior is as follows: If *Rn* is the lowest register number in the list, then the original value is stored; otherwise, the stored value is unpredictable.
- If pc appears in the register list, then the value stored is implementation defined.
- If ^ is specified, then the operation is modified. The processor must not be in *user* or *system* mode. The registers appearing in the register list refer to the *user* mode versions of the registers and writeback must not be specified.
- The time order of the memory accesses may depend on the implementation. Be careful when using a store multiple to access I/O locations where the access order matters. If the order matters, then check that the memory locations are marked as I/O in the page tables. Do not cross page boundaries, and do not use *pc* in the register list.

Examples

Store a single value to a virtual address in memory

```
    STR<cond>{|B}
    Rd, [Rn {, #{-}<immed12>}]{!}
    STR<cond>{|B}
    Rd, [Rn, {-}Rm {,<imm_shift>}]{!}
    ARMv1
    STR<cond>{|B}{T}
    Rd, [Rn], #{-}<immed12>
    ARMv1
    STR<cond>{|B}{T}
    Rd, [Rn], {-}Rm {,<imm_shift>}
    ARMv1
    STR<cond>{|B}{T}
    Rd, [Rn], {-}Rm {,<imm_shift>}
    ARMv1
    STR<cond>{|B}
    Rd, [Rn, {, #{-}<immed8>}]{!}
    ARMv4
```

6.	STR <cond>{H}</cond>	Rd,	[Rn, {-}Rm]{!}	ARMv4
7.	STR <cond>{H}</cond>	Rd,	[Rn], #{-} <immed8></immed8>	ARMv4
8.	STR <cond>{H}</cond>	Rd,	[Rn], {-}Rm	ARMv4
9.	STR <cond>D</cond>	Rd,	[Rn, {, #{-} <immed8>}]{!}</immed8>	ARMv5E
10.	STR <cond>D</cond>	Rd,	[Rn, {-}Rm]{!}	ARMv5E
11.	STR <cond>D</cond>	Rd,	[Rn], #{-} <immed8></immed8>	ARMv5E
12.	STR <cond>D</cond>	Rd,	[Rn], {-}Rm	ARMv5E
13.	STREX <cond></cond>	Rd,	Rm, [Rn]	ARMv6
14.	STR{ B H}	Ld,	[Ln, # <immed5>*<size>]</size></immed5>	THUMBv1
15.	STR{ B H}	Ld,	[Ln, Lm]	THUMBv1
16.	STR	Ld,	[sp, # <immed8>*4]</immed8>	THUMBv1
17.	STR <cond><type></type></cond>	Rd,	<label></label>	MACRO

Formats 1 to 16 store a single data item of the type specified by the opcode suffix, using a preindexed or postindexed addressing mode. Tables A.12 and A.13 show the different addressing modes and data types.

In Table A.13, memory (a, n) refers to n sequential bytes at address a. The bytes are packed according to the configured processor data endianness. memory T(a, n) performs the access with *user* mode privileges, regardless of the current processor mode. The act of function IsExclusive(a) used by STREX depends on address a. If a has the shared TLB attribute, then IsExclusive(a) is true if address a is marked as exclusive for this processor. It then clears any exclusive accesses on this processor and any exclusive accesses to address a on other processors in the system. If a does not have the shared TLB attribute, then IsExclusive(a) is true if there is an outstanding exclusive access on this processor. It then clears any such outstanding access.

Table A.12 STR addressing modes.

Addressing format	Address a accessed	Value written back to Rn
<pre>[Rn {,#{-}<immed>}] [Rn {,#{-}<immed>}]! [Rn, {-}Rm {,<shift>}] [Rn, {-}Rm {,<shift>}]! [Rn], #{-}<immed> [Rn], #{-}<mmed> [Rn], {-}Rm {,<shift>}</shift></mmed></immed></shift></shift></immed></immed></pre>	<pre>Rn + {{-}<immed>} Rn + {{-}<immed>} Rn + {{-}<immed>} Rn + {-}<shifted_rm> Rn + {-}<shifted_rm> Rn Rn</shifted_rm></shifted_rm></immed></immed></immed></pre>	Rn preserved Rn + {{-} <immed>} Rn preserved Rn + {-}<shifted_rm> Rn + {-}<immed> Rn + {-}<shifted_rm></shifted_rm></immed></shifted_rm></immed>

Table A.13	STR data types.
------------	-----------------

Store	Datatype	<size> (bytes)</size>	Action
STR	word	4	memory(a, 4) = Rd
STRB	unsigned Byte	1	memory(a, 1) = (char)Rd
STRBT	Byte Translated	1	memoryT(a, 1) = (char)Rd
STRD	Double word	8	memory(a , 4) = Rd memory(a +4, 4) = R(d +1)
STREX	word EXclusive	4	<pre>if (IsExclsuive(a)) { memory(a, 4) = Rm; Rd = 0; } else { Rd = 1; }</pre>
STRH	unsigned Halfword	2	memory(a, 2) = (short) Rd
STRT	word Translated	4	memoryT(a, 4) = Rd

If the address a is not a multiple of $\langle size \rangle$, then the store is unaligned. Because the behavior of an unaligned store depends on the architecture revision, memory system, and system coprocessor (CP15) configuration, it is best to avoid unaligned stores if possible. Assuming that the external memory system does not abort unaligned stores, then the following rules usually apply. In the rules, A is bit 1 of system coprocessor register CP15:c1:c0:0, and U is bit 22 of CP15:c1:c0:0, introduced in ARMv6. If there is no system coprocessor, then A = U = 0.

- If A = 1, then unaligned stores cause an alignment fault data abort exception except that word-aligned double-word stores are supported if U = 1.
- If A = 0 and U = 1, then unaligned stores are supported for STR{|T|H|SH}. Wordaligned stores are supported for STRD. A non-word-aligned STRD generates an alignment fault data abort.
- If A = 0 and U = 0, then STR and STRT write to $memory(a \& \sim 3, 4)$. All other unaligned operations are unpredictable but do not cause an alignment fault.

Format 17 generates a pc-relative store accessing the address specified by $\langle label \rangle$. In other words it assembles to $STR \langle cond \rangle \langle type \rangle Rd$, $[pc, \#\langle offset \rangle]$ whenever this instruction is supported and $\langle offset \rangle = \langle label \rangle - pc$ is in range.

Notes

- For double-word stores (formats 9 to 12), Rd must be even and in the range r0 to r12.
- If the addressing mode updates *Rn*, then *Rd* and *Rn* must be distinct.

- If *Rd* is *pc*, then *<size>* must be 4. The value stored is implementation defined.
- If Rn is pc, then the addressing mode must not update Rn. The value used for Rn is the address of the instruction plus eight bytes.
- \blacksquare Rm must not be pc.

Examples

```
STR r0, [r0] ; *(int*)r0 = r0;

STRH r0, [r1], #4 ; *(short*)r1 = r0; r1+=4;

STRD r2, [r1, #-8]! ; r1-=8; *(int*)r1=r2; *(int*)(r1+4)=r3

STRB r0, [r2, #55] ; *(char*)(r2+55) = r0;

STRB r0, [r1], -r2, LSL #8; *(char*)r1 = r0; r1-=256*r2;
```

SUB Subtract two 32-bit values

1.	SUB <cond>{S}</cond>	Rd,	<pre>Rn, #<rotated_immed></rotated_immed></pre>	ARMv1
2.	SUB <cond>{S}</cond>	Rd,	<pre>Rn, Rm {, <shift>}</shift></pre>	ARMv1
3.	SUB	Ld,	Ln, # <immed3></immed3>	THUMBv1
4.	SUB	Ld,	# <immed8></immed8>	THUMBv1
5.	SUB	Ld,	Ln, Lm	THUMBv1
6.	SUB	sp,	# <immed7>*4</immed7>	THUMBv1

Action

Effect on the cpsr

1.	Rd = Rn - <rotated_immed></rotated_immed>	Updated if S suffix specified
2.	Rd = Rn - <shifted_rm></shifted_rm>	Updated if S suffix specified
3.	Ld = Ln - <immed3></immed3>	Updated (see Notes below)
4.	Ld = Ld - <immed8></immed8>	Updated (see Notes below)
5.	Ld = Ln - Lm	Updated (see Notes below)
6.	sp = sp - <immed7>*4</immed7>	Preserved

Notes

■ If the operation updates the *cpsr* and *Rd* is not *pc*, then $N = \langle Negative \rangle$, $Z = \langle Zero \rangle$, $C = \langle NoUnsignedOverflow \rangle$, and $V = \langle SignedOverflow \rangle$. The carry flag is set this way because the subtract x - y is implemented as the add $x + \sim y + 1$. The carry flag is one if $x + \sim y + 1$ overflows. This happens when $x \geq y$, when x - y doesn't overflow.

SWP

- If *Rd* is *pc*, then the instruction effects a jump to the calculated address. If the operation updates the *cpsr*, then the processor mode must have an *spsr*; in this case, the *cpsr* is set to the value of the *spsr*.
- If Rn or Rm is pc, then the value used is the address of the instruction plus eight bytes.

Examples

```
SUBS r0, r0, #1; r0-=1, setting flags

SUB r0, r1, r1, LSL #2; r0 = -3*r1

SUBS pc, lr, #4; jump to lr-4, set cpsr=spsr
```

SWI Software interrupt

SWI < cond > <immed24>
 SWI < <immed8>
 THUMBv1

The SWI instruction causes the ARM to enter *supervisor* mode and start executing from the SWI vector. The return address and *cpsr* are saved in *lr_svc* and *spsr_svc*, respectively. The processor switches to ARM state and IRQ interrupts are disabled. The SWI vector is at address 0x00000008, unless high vectors are configured; then it is at address 0xFFFF0008.

The immediate operand is ignored by the ARM. It is normally used by the SWI exception handler as an argument determining which function to perform.

Example

```
SWI Ox123456; Used by the ARM tools to implement Semi-Hosting
```

Swap a word in memory with a register, without interruption

```
    SWP<cond> Rd, Rm, [Rn] ARMv2a
    SWP<cond>B Rd, Rm, [Rn] ARMv2a
```

Action

- temp=memory(Rn,4); memory(Rn,4)=Rm; Rd=temp;
- 2. temp=(zero extend)memory(Rn,1); memory(Rn,1)=(char)Rm; Rd=temp;

Notes

- The operations are atomic. They cannot be interrupted partway through.
- \blacksquare *Rd*, *Rm*, *Rn* must not be *pc*.

- *Rn* and *Rm* must be different registers. *Rn* and *Rd* must be different registers.
- Rn should be aligned to the size of the memory transfer.
- If a data abort occurs on the load, then the store does not occur. If a data abort occurs on the store, then *Rd* is not written.

You can use the SWP instruction to implement 8-bit or 32-bit semaphores on ARMv5 and below. For ARMv6 use LDREX and STREX in preference. As an example, suppose a byte semaphore register pointed to by r1 can have the value 0xFF (claimed) or 0x00 (free). The following example claims the lock. If the lock is already claimed, then the code loops, waiting for an interrupt or task switch that will free the lock.

```
MOV r0, #0xFF; value to claim the lock
loop SWPB r0, r0, [r1]; try and claim the lock
CMP r0, #0xFF; check to see if it was already claimed
BEQ loop; if so wait for it to become free
```

SXT SXTA

Byte or halfword extract or extract with accumulate

1.	{S U}XTB16 <cond></cond>	Rd, Rm {, ROR#8* <rot> }</rot>	ARMv6
2.	{S U}XTB <cond></cond>	Rd, Rm {, ROR#8* <rot> }</rot>	ARMv6
3.	{S U}XTH <cond></cond>	Rd, Rm {, ROR#8* <rot> }</rot>	ARMv6
4.	{S U}XTAB16 <cond></cond>	Rd, Rn, Rm {, ROR#8* <rot> }</rot>	ARMv6
5.	{S U}XTAB <cond></cond>	Rd, Rn, Rm {, ROR#8* <rot> }</rot>	ARMv6
6.	{S U}XTAH <cond></cond>	Rd, Rn, Rm {, ROR#8* <rot> }</rot>	ARMv6
7.	{S U}XTB	Ld, Lm	THUMBv3
8.	{S U}XTH	Ld, Lm	THUMBv3

Action

```
    Rd[31:16] = extend(<shifted_Rm>[23:16]);
    Rd[15:00] = extend(<shifted_Rm>[07:00])
    Rd = extend(<shifted_Rm>[07:00])
    Rd = extend(<shifted_Rm>[15:00])
    Rd[31:16] = Rn[31:16] + extend(<shifted_Rm>[23:16]);
    Rd[15:00] = Rn[15:00] + extend(<shifted_Rm>[07:00])
    Rd = Rn + extend(<shifted_Rm>[07:00])
```

```
6. Rd = Rn + extend(<shifted_Rm>[15:00])
```

- 7. Ld = extend(Lm[07:00])
- 8. Ld = extend(Lm[15:00])

Notes

- If you specify the S prefix, then extend(x) sign extends x.
- If you specify the U prefix, then extend(x) zero extends x.
- \blacksquare *Rd* and *Rm* must not be *pc*.
- <rot> is an immediate in the range 0 to 3.

TEQ Test for equality of two 32-bit values

1. TEQ<cond> Rn, #<rotated immed>

ARMv1

2. TEQ<cond> Rn, Rm {, <shift>}

ARMv1

Action

- 1. Set the cpsr on the result of (Rn $^{\wedge}$ <rotated immed>)
- 2. Set the cpsr on the result of (Rn $^{\wedge}$ <shifted Rm>)

Notes

- The *cpsr* is updated: $N = \langle Negative \rangle$, $Z = \langle Zero \rangle$, $C = \langle shifter_C \rangle$ (see Table A.3).
- If Rn or Rm is pc, then the value used is the address of the instruction plus eight bytes.
- Use this instruction instead of CMP when you want to check for equality and preserve the carry flag.

Example

TEQ r0, #1

; test to see if r0==1

TST Test bits of a 32-bit value

TST<cond> Rn, #<rotated immed>

ARMv1

2. TST<cond> Rn, Rm {, <shift>}

ARMv1

3. TST

Ln, Lm

THUMBv1

Action

- 1. Set the cpsr on the result of (Rn & <rotated immed>)
- 2. Set the cpsr on the result of (Rn & <shifted Rm>)
- 3. Set the cpsr on the result of (Ln & Lm)

Notes

- The cpsr is updated: $N = \langle Negative \rangle$, $Z = \langle Zero \rangle$, $C = \langle shifter C \rangle$ (see Table A.3).
- If Rn or Rm is pc, then the value used is the address of the instruction plus eight bytes.
- Use this instruction to test whether a selected set of bits are all zero.

Example

TST r0, #0xFF ; test if the bottom 8 bits of r0 are 0

UADD	Unsigned parallel modulo add (see the entry for SADD)
UHADD UHSUB	Unsigned halving add and subtract (see the entry for SHADD)
UMAAL	Unsigned multiply accumulate accumulate long

1. UMAAL<cond> RdLo, RdHi, Rm, Rs

ARMv6

Action

1. RdHi:RdLo = (unsigned)Rm*Rs + (unsigned)RdLo + (unsigned)RdHi

Notes

- *RdHi* and *RdLo* must be different registers.
- *RdHi*, *RdLo*, *Rm*, *Rs* must not be *pc*.
- This operation cannot overflow because $(2^{32} 1)(2^{32} 1) + (2^{32} 1) + (2^{32} 1) = 1$ $(2^{64} - 1)$. You can use it to synthesize the multiword multiplications used by public key cryptosystems.

UMLAL UMULL	Unsigned long multiply and multiply accumulate (see the SMLAL and SMULL entrie	s)		
UQADD UQSUB	Unsigned saturated add and subtract (see the QADD entry)			
USAD	Unsigned sum of absolute differences			
	1. USAD8 <cond> Rd, Rm, Rs ARMv6</cond>			
	2. USADA8 <cond> Rd, Rm, Rs, Rn ARMv6</cond>			
	Action			
	1. Rd = $abs(Rm[31:24]-Rs[31:24]) + abs(Rm[23:16]-Rs[23:16])$			
	+ abs(Rm[15:08]-Rs[15:08]) + abs(Rm[07:00]-Rs[07:00])			
	2. $Rd = Rn + abs(Rm[31:24]-Rs[31:24]) + abs(Rm[23:16]-Rs[23:16])$			
	+ abs(Rm[15:08]-Rs[15:08]) + abs(Rm[07:00]-Rs[07:00])			
	Notes			
	• $abs(x)$ returns the absolute value of x . Rm and Rs are treated as unsigned.			
	■ <i>Rd</i> , <i>Rm</i> , and <i>Rs</i> must not be <i>pc</i> .			
	■ The sum of absolute differences operation is common in video codecs where it prova metric to measure how similar two images are.	vides		
USAT	Unsigned saturation instruction (see the SSAT entry)			
USUB	Unsigned parallel modulo subtracts (see the SADD entry)			
UXT UXTA	Unsigned extract, extract with accumulate (see the entry for SXT)			

A.4 ARM ASSEMBLER QUICK REFERENCE

This section summarizes the more useful commands and expressions available with the ARM assembler, armasm. Each assembly line has one of the following formats:

```
{<label>}
          {<instruction>}
                                                      ; comment
{<symbol>} <directive>
                                                      ; comment
           <macro> {<arg_1>} {,<arg_2>} .. {,<arg_n>} ; comment
```

where

- <instruction> is any ARM or Thumb instruction supported by the processor you are assembling for. See Section A.3.
- <label> is the name of a symbol to store the address of the instruction.
- <directive> is an ARM assembler directive. See Section A.4.4.
- <symbol> is the name of a symbol used by the <directive>.
- <macro> is the name of a new directive defined using the MACRO directive.
- \blacksquare < arg_k > is the kth macro argument.

You must use an AREA directive to define an area before any ARM or Thumb instructions appear. All assembly files must finish with the END directive. The following example shows a simple assembly file defining a function add that returns the sum of the two input arguments:

```
AREA maths_routines, CODE, READONLY
EXPORT add ; give the symbol add external linkage

add ADD r0, r0, r1 ; add input arguments
MOV pc, lr ; return from sub-routine

END
```

A.4.1 ARM ASSEMBLER VARIABLES

The ARM assembler supports three types of assemble time variables (see Table A.14). Variable names are case sensitive and must be declared before use with the directives GBLx or LCLx.

You can use variables in expressions (see Section A.4.2), or substitute their value at assembly time using the \$ operator. Specifically, \$name. expands to the value of the variable

Table	A.14	ARM	assemble	r variable	types.
-------	------	-----	----------	------------	--------

Variable type	Declare globally	Declare locally to a macro	Set value	Example values
Unsigned 32-bit integer	GBLA	LCLA	SETA	15, Oxab
ASCII string	GBLS	LCLS	SETS	"", "ADD"
Logical	GBLL	LCLL	SETL	{TRUE}, {FALSE}

name before the line is assembled. You can omit the final period if name is not followed by an alphanumeric or underscore. Use \$\$ to produce a single \$. Arithmetic variables expand to an eight-digit hexadecimal string on substitution. Logical variables expand to *T* or *F*.

The following example code shows how to declare and substitute variables of each type:

```
; arithmetic variables
        GRI A
                count
                             ; declare an integer variable count
                             ; set count = 1
        SETA
                1
count
        WHILE
                count<15
          RI
                test$count
                             ; call test00000001, test00000002 ...
          SETA count+1
                             : .... test00000000E
count
        WFND
        ; string variables
        GBL S
                 СС
                             ; declare a string variable called cc
        SFTS
                 "NF"
                             : set cc="NE"
CC
        ADD$cc
                 r0, r0, r0; assembles as ADDNE r0, r0, r0
        STR$cc.B r0, [r1]
                             ; assembles as STRNEB r0,[r1]
        ; logical variable
        GBLL
                             ; declare a logical variable called debug
                 debug
        SETL
                 {TRUE}
                             ; set debug={TRUE}
debug
        IF debua
                             ; if debug is TRUE then
          BL
                 print debug; print out some debug information
        ENDIF
```

A.4.2 ARM ASSEMBLER LABELS

A label definition must begin on the first character of a line. The assembler treats indented text as an instruction, directive, or macro. It treats labels of the form < N >< name> as a local label, where < N > is an integer in the range 0 to 99 and < name> is an optional textual name. Local labels are limited in scope by the ROUT directive. To reference a local label, you refer to it as $\{ |F|B \} \{ |A|T \} < N > \{ < name> \}$. The extra prefix letters tell the assembler how to search for the label:

- If you specify F, the assembler searches forward; if B, then the assembler searches backwards. Otherwise the assembler searches backwards and then forwards.
- If you specify T, the assembler searches the current macro only; if A, then the assembler searches all macro levels. Otherwise the assembler searches the current and higher macro nesting levels.

A.4.3 ARM ASSEMBLER EXPRESSIONS

The ARM assembler can evaluate a number of numeric, string, and logical expressions at assembly time. Table A.15 shows some of the unary and binary operators you can use within expressions. Brackets can be used to change the order of evaluation in the usual way.

Table A.15 ARM assembler unary and binary operators.

Expression	Result	Example
A+B, A-B	A plus or minus B	1-2 = 0xffffffff
A*B, A/B	A multiplied by or divided by B	2*3 = 6, 7/3 = 2
A:MOD:B	A modulo B	7:MOD:3 = 1
:CHR:A	string with ASCII code A	:CHR:32 = " "
'X'	the ASCII value of X	'a' = 0x61
:STR:A,	A or L converted to a string	:STR:32 = "00000020"
:STR:L	-	:STR:{TRUE} = "T"
A << B,	A shifted left by B bits	1 << 3 = 8
A:SHL:B	·	
A >> B,	A shifted right by B bits (logical	0x80000000 >> 4 =
A:SHR:B	shift)	0x08000000
A:ROR:B,	A rotated right/left by B bits	1:ROR:1 = 0x80000000
A:ROL:B		0x80000000:R0L:1 = 1
A=B, $A>B$,	comparison of arithmetic or string	$(1=2) = \{FALSE\},$
A >= B, $A < B$,	variables (/= and <> both mean	$(1<2) = \{TRUE\},$
$A \le B$, $A / = B$,	not equal)	("a"="c") = {FALSE},
A<>B		("a"<"c") = {TRUE}
A:AND:B,	Bitwise AND, OR, exclusive OR of	1:AND:3 = 1
A:OR:B,	A and B; bitwise NOT of A.	1:0R:3 = 3
A:EOR:B,		:NOT:0 = 0xFFFFFFF
:NOT:A		
:LEN:S	length of the string S	:LEN:"ABC" = 3
S:LEFT:B,	leftmost or rightmost B characters	"ABC":LEFT:2 = "AB",
S:RIGHT:B	of S	"ABC":RIGHT:2 = "BC"
S:CC:T	the concatenation of S, T	"AB":CC:"C" = "ABC"
L:LAND:M,	logical AND, OR, exclusive OR of	{TRUE}:LAND:{FALSE} =
L:LOR:M,	L and M	{FALSE}
L:LEOR:M		
:DEF:X	returns TRUE if a variable called X is defined	
:BASE:A :INDEX:A	see the MAP directive	

Table A.16 Predefined expressions.

Variable	Value
{ARCHITECURE}	The ARM architecture of the CPU ("4T" for ARMv4T)
{ARMASM VERSION}	The assembler version number
$\{CONFIG}$ or	The bit width of the instructions being assembled (32 for
{CODESIZE}	ARM state, 16 for Thumb state)
{CPU}	The name of the CPU being assembled for
{ENDIAN}	The configured endianness, "big" or "little"
{INTER}	{TRUE} if ARM/Thumb interworking is on
{PC} (alias.)	The address of the current instruction being assembled
{ROPI}, {RWPI}	{TRUE} if read-only/read-write position independent
{VAR} (alias 0)	The MAP counter (see the MAP directive)

In Table A.15, A and B represent arbitrary integers; S and T, strings; and L and M, logical values. You can use labels and other symbols in place of integers in many expressions.

A.4.3.1 Predefined Variables

Table A.16 shows a number of special variables that can appear in expressions. These are predefined by the assembler, and you cannot override them.

A.4.4 ARM ASSEMBLER DIRECTIVES

Here is an alphabetical list of the more common *armasm* directives.

ALIGN

Aligns the address of the next instruction to the form q*<expression>+<offset>. The alignment is relative to the start of the ELF section so this must be aligned appropriately (see the AREA directive). <expression> must be a power of two; the default is 4. <offset> is zero if not specified.

AREA

Starts a new code or data section of name <section>. Table A.17 lists the possible attributes.

Table A.17 AREA attributes.

Attribute	Meaning
ALIGN= <expression> ASSOC=<sectionname> CODE</sectionname></expression>	Align the ELF section to a 2 ^{expression} byte boundary. If this section is linked, also link <sectionname>. The section contains instructions and is read only.</sectionname>
DATA NOINIT	The section contains data and is read write. The data section does not require initialization.
READONLY READWRITE	The section is read only. The section is read write.

ASSERT

ASSERT <logical-expression>

Assemble time assert. If the logical expression is false, then assembly terminates with an error.

CN

<name> CN <numeric-expression>

Set <name> to be an alias for coprocessor register <numeric-expression>.

CODE16, CODE32

CODE16 tells the assembler to assemble the following instructions as 16-bit Thumb instructions. CODE32 indicates 32-bit ARM instructions (the default for *armasm*).

CP

<name> CP <numeric-expression>

Set <name> to be an alias for coprocessor number <numeric-expression>.

DATA

<label> DATA

The DATA directive indicates that the label points to data rather than code. In Thumb mode this prevents the linker from setting the bottom bit of the label. Bit 0 of a function pointer or code label is 0 for ARM code and 1 for Thumb code (see the BX instruction).

Table A.18	Memor	y initialization	directives.
------------	-------	------------------	-------------

Directive	Alias	Data size (bytes)	Initialization value
DCB	=	1	byte or string
DCW		2	16-bit integer (aligned to 2 bytes)
DCD	&	4	32-bit integer (aligned to 4 bytes)
DCQ		8	64-bit integer (aligned to 4 bytes)
DCI		2 or 4	integer defining an ARM or Thumb instruction

DCB, DCD{U}, DCI, DCQ{U}, DCW{U}

These directives allocate one or more bytes of initialized memory according to Table A.18. Follow each directive with a comma-separated list of initialization values. If you specify the optional U suffix, then the assembler does not insert any alignment padding.

Examples

```
hello DCB "hello", 0
powers DCD 1, 2, 4, 8, 10, 0x20, 0x40, 0x80
DCI 0xEA000000
```

ELSE (alias |)

See IF.

END

This directive must appear at the end of a source file. Assembler source after an END directive is ignored.

ENDFUNC (alias ENDP), ENDIF (alias])

See FUNCTION and IF, respectively.

ENTRY

This directive specifies the program entry point for the linker. The entry point is usually contained in the ARM C library.

EQU (alias *)

<name> EQU <numeric-expression>

This directive is similar to #define in C. It defines a symbol <name> with value defined by the expression. This value cannot be redefined. See Section A.4.1 for the use of redefinable variables.

EXPORT (alias GLOBAL)

```
EXPORT <symbol>{[WEAK]}
```

Assembler symbols are local to the object file unless exported using this command. You can link exported symbols with other object and library files. The optional [WEAK] suffix indicates that the linker should try and resolve references with other instances of this symbol before using this instance.

EXTERN, IMPORT

```
EXTERN <symbol>{[WEAK]}
IMPORT <symbol>{[WEAK]}
```

Both of these directives declare the name of an external symbol, defined in another object file or library. If you use this symbol, then the linker will resolve it at link time. For IMPORT, the symbol will be resolved even if you don't use it. For EXTERN, only used symbols are resolved. If you declare the symbol as [WEAK], then no error is generated if the linker cannot resolve the symbol; instead the symbol takes the value 0.

FIELD (alias #)

See MAP.

FUNCTION (alias PROC) and ENDFUNC (alias ENDP)

The FUNCTION and ENDFUNC directives mark the start and end of an ATPCS-compliant function. Their main use is to improve the debug view and allow backtracking of function calls during debugging. They also allow the profiler to more accurately profile assembly functions. You must precede the function directive with the ATPCS function name. For example:

```
sub FUNCTION
SUB r0, r0, r1
MOV pc, lr
FNDFUNC
```

GBLA, GBLL, GBLS

Directives defining global arithmetic, logic, and string variables, respectively. See Section A.4.1.

GET

See INCLUDE.

GLOBAL

See EXPORT.

IF (alias [), ELSE (alias |), ENDIF (alias])

These directives provide for conditional assembly. They are similar to #if, #else, #endif, available in C. The IF directive is followed by a logical expression. The ELSE directive may be omitted. For example:

```
IF ARCHITECTURE="5TE"

SMULBB r0, r1, r1

ELSE

MUL r0, r1, r1

ENDIF
```

IMPORT

See EXTERN.

INCBIN

```
INCBIN <filename>
```

This directive includes the raw data contained in the binary file <filename> at the current point in the assembly. For example, INCBIN table.dat.

INCLUDE (alias GET)

```
INCLUDE <filename>
```

Use this directive to include another assembly file. It is similar to the #include command in C. For example, INCLUDE header.h.

INFO (alias!)

If <*numeric_expresssion*> is nonzero, then assembly terminates with error <*string_expresssion*>. Otherwise the assembler prints <*string_expression*> as an information message.

KEEP

```
KEEP {<symbol>}
```

By default the assembler does not include local symbols in the object file, only exported symbols (see EXPORT). Use KEEP to include all local symbols or a specified local symbol. This aids the debug view.

LCLA, LCLL, LCLS

These directives declare macro-local arithmetic, logical, and string variables, respectively. See Section A.4.1.

LTORG

Use LTORG to insert a literal pool. The assembler uses literal pools to store the constants appearing in the *LDR Rd*,=<*value*> instruction. See LDR format 19. Usually the assembler inserts literal pools automatically, at the end of each area. However, if an area is too large, then the LDR instruction cannot reach this literal pool using *pc*-relative addressing. Then you need to insert a literal pool manually, near the LDR instruction.

MACRO, MEXIT, MEND

Use these directives to declare a new assembler macro or pseudoinstruction. The syntax is

```
MACRO

{$<arg_0>} <macro_name> {$<arg_1>} {,$<arg_2>} ... {,$<arg_k>}

<macro_code>

MEND
```

The macro parameters are stored in the dummy variables \$<arg_i>. This argument is set to the empty string if you don't supply a parameter when calling the macro. The MEXIT directive terminates the macro early and is usually used inside IF statements. For example, the following macro defines a new pseudoinstruction SMUL, which evaluates to a SMULBB on an ARMv5TE processor, and an MUL otherwise.

```
MACRO
$label SMUL $a, $b, $c
IF {ARCHITECTURE}="5TE"
$label SMULBB $a, $b, $c
MEXIT
ENDIF
$label MUL $a, $b, $c
MEND
```

MAP (alias $^{\wedge}$), FIELD (alias #)

These directives define objects similar to C structures. MAP sets the base address or offset of a structure, and FIELD defines structure elements. The syntax is

The MAP directive sets the value of the special assembler variable {VAR} to the base address of the structure. This is either the value <base> or the register relative value <base_register>+<base>. Each FIELD directive sets <name> to the value VAR and increments VAR by the specified number of bytes. For register relative values, the expressions :INDEX:<name> and :BASE:<name> return the element offset from base register, and base register number, respectively.

In practice the base register form is not that useful. Instead you can use the plain form and mention the base register explicitly in the instruction. This allows you to point to a structure of the same type with different base registers. The following example sets up a structure on the stack of two int variables:

```
MAP
                                 ; structure elements offset from 0
       FIELD
                4
                                 ; define an int called count
count
       FIELD
                                 ; define an int called type
tvpe
size
       FIELD
                0
                                 ; record the struct size
                sp, sp, #size
       SUB
                                 ; make room on the stack
       MOV
                r0. #0
       STR
                r0, [sp, #count]; clear the count element
       STR
                r0, [sp, #type]; clear the type element
```

NOFP

This directive bans the use of floating-point instructions in the assembly file. We don't cover floating-point instructions and directives in this appendix.

OPT

The OPT directive controls the formatting of the *armasm -list* option. This is seldom used now that source-level debugging is available. See the *armasm* documentation.

PROC

See FUNCTION.

RLIST, RN

```
<name> RN <numeric expression>
<name> RLIST <list of ARM register enclosed in {}>
```

These directives name a list of ARM registers or a single ARM register. For example, the following code names *r0* as arg and the ATPCS preserved registers as saved.

```
arg RN 0 saved RLIST {r4-r11}
```

ROUT

The ROUT directive defines a new local label area. See Section A.4.2.

SETA, SETL, SETS

These directives set the values of arithmetic, logical, and string variables, respectively. See Section A.4.1.

SPACE (alias %)

```
{<label>} SPACE <numeric expression>
```

This directive reserves < numeric expression > bytes of space. The bytes are zero initialized.

WHILE, WEND

These directives supply an assemble-time looping structure. WHILE is followed by a logical expression. While this expression is true, the assembler repeats the code between WHILE and WEND. The following example shows how to create an array of powers of two from 1 to 65,536.

```
GBLA count
count SETA 1
WHILE count<=65536
DCD count
count SETA 2*count
WEND
```

A.5 GNU ASSEMBLER QUICK REFERENCE

This section summarizes the more useful commands and expressions available with the GNU assembler, *gas*, when you target this assembler for ARM. Each assembly line has the format

```
{<label>:} {<instruction or directive>}  @ comment
```

Unlike the ARM assembler, you needn't indent instructions and directives. Labels are recognized by the following colon rather than their position at the start of the line. The following example shows a simple assembly file defining a function *add* that returns the sum of the two input arguments:

```
.section .text, "x"

.global add @ give the symbol add external linkage

add:

ADD r0, r0, r1 @ add input arguments

MOV pc, lr @ return from subroutine
```

A.5.1 GNU ASSEMBLER DIRECTIVES

Here is an alphabetical list of the more common gas directives.

```
.ascii "<string>"
```

Inserts the string as data into the assembly, as for DCB in armasm.

```
.asciz "<string>"
```

As for .ascii but follows the string with a zero byte.

```
.balign <power_of_2> {,<fill_value> {,<max_padding>} }
```

Aligns the address to *<power_of_2>* bytes. The assembler aligns by adding bytes of value *<fill_value>* or a suitable default. The alignment will not occur if more than *<max_padding>* fill bytes are required. Similar to ALIGN in *armasm*.

```
.byte <byte1> {,<byte2>} ...
```

Inserts a list of byte values as data into the assembly, as for DCB in armasm.

```
.code <number of bits>
```

Sets the instruction width in bits. Use 16 for Thumb and 32 for ARM assembly. Similar to CODE16 and CODE32 in *armasm*.

.else

Use with .if and .endif. Similar to ELSE in armasm.

.end

Marks the end of the assembly file. This is usually omitted.

.endif

Ends a conditional compilation code block. See .if, .ifdef, .ifndef. Similar to ENDIF in *armasm*.

.endm

Ends a macro definition. See .macro. Similar to MEND in armasm.

.endr

Ends a repeat loop. See .rept and .irp. Similar to WEND in armasm.

```
.equ <symbol name>, <value>
```

This directive sets the value of a symbol. It is similar to EQU in armasm.

.err

Causes assembly to halt with an error.

.exitm

Exit a macro partway through. See .macro. Similar to MEXIT in armasm.

.global <symbol>

This directive gives the symbol external linkage. It is similar to EXPORT in armasm.

```
.hword <short1> {,<short2>} ...
```

Inserts a list of 16-bit values as data into the assembly, as for DCW in armasm.

.if <logical expression>

Makes a block of code conditional. End the block using .endif. Similar to IF in *armasm*. See also .else.

.ifdef <symbol>

Include a block of code if <symbol > is defined. End the block with .endif.

.ifndef <symbol>

Include a block of code if <symbol > is not defined. End the block with .endif.

```
.include "<filename>"
```

Includes the indicated source file. Similar to INCLUDE in armasm or #include in C.

```
.irp <param> {,<val_1>} {,<val_2>} ...
```

Repeats a block of code, once for each value in the value list. Mark the end of the block using a .endr directive. In the repeated code block, use \param> to substitute the associated value in the value list.

```
.macro <name> {<arg 1>} {,<arg 1>} ... {,<arg k>}
```

Defines an assembler macro called < name> with k parameters. The macro definition must end with .endm. To escape from the macro at an earlier point, use .exitm. These directives are similar to MACRO, MEND, and MEXIT in armasm. You must precede the dummy macro parameters by \setminus . For example:

```
.rept <number_of_times>
```

Repeats a block of code the given number of times. End the block with .endr.

```
<register_name> .req <register_name>
```

This directive names a register. It is similar to the RN directive in *armasm* except that you must supply a name rather than a number on the right. For example, *acc.req r0*.

```
.section <section_name> {,"<flags>"}
```

Starts a new code or data section. Usually you should call a code section .text, an initialized data section .data, and an uninitialized data section .bss . These have default flags, and the linker understands these default names. The directive is similar to the *armasm*

Table A.19 .section flags for ELF format files.

Flag	Meaning
a	allocatable section
W X	writable section executable section

directive AREA. Table A.19 lists possible characters to appear in the <flags> string for ELF format files.

.set <variable_name>, <variable_value>

This directive sets the value of a variable. It is similar to SETA in *armasm*.

.space <number of bytes> {,<fill byte>}

Reserves the given number of bytes. The bytes are filled with zero or <fill byte> if specified. It is similar to SPACE in armasm.

.word <word1> {,<word2>} ...

Inserts a list of 32-bit word values as data into the assembly, as for DCD in armasm.