

OLED INITIALIZATION SEQUENCE

- Make VDD = 0 (Active LOW signal)
- Wait for 2 ms
- Send display OFF command (0xAE)
- Apply reset (oled_rstn = 0, Active LOW signal)
- Wait for 2 ms
- Remove reset (oled_rstn = 1)
- Configure charge pump (0x8D, 0x14)
- Configure pre-charge (0xD9, 0xF1)
- Make VBAT = 0 (Active LOW signal)
- Wait for 2 ms
- Set Contrast (0x81, 0xFF)
- Set segment remap (0xA0)
- Set scan direction (0xC0)
- Set COM pin (0xDA, 0x00)
- Send Display ON command (0xAF)