A simple device driver

1 Introduction

This lab is concerned with device driver development for the LPC_2378_STK development board.

Developing a device driver can be a complicated business. Even for a device as simple as a LED.

Consider the steps required to develop a driver for the USB_LINK_LED on this board.

- 1. Identify the hardware features of the microcontroller that are used to control the device
 - A LED is an *output* device. It is a simple device that is either *on* or *off*. We can guess that it is associated with one of the GPIO (General Purpose I/O) pins of the LPC_2378. But which one? We could read the schematic. Download and open the schematic in a pdf viewer (e.g. acrobat reader or evince) and zoom in until you can read the details (about 300% for me). Find the USB_LINK pin on the schematic of the microcontroller. Notice that it is associated with P0.13. That means pin 13 in GPIO port 0. Actually, the pin is associated with several functions. We'll assume that the GPIO function is selected for this pin when we develop our device driver.
- 2. Understand how to control the relevant hardware features from software So now we need to know how to program the GPIO pins. We need to read the user manual for the LPC_2378. Notice by looking at page 16 that the LPC_2378 communicates with its peripheral devices (I/O devices) by mapping them into its own memory space. The devices are said to be memory-mapped. This is convenient for the programmer, who can control devices simply by assigning values to the device addresses as though they were ordinary variables. Note that some other processors, e.g. the Intel range, require the programmer to control I/O devices by working with a dedicated set of I/O ports using special read and write instructions. These devices are said to be I/O mapped. We won't consider this approach in this module. There's more relevant information about programming the GPIO ports in Chapter 10 of the LP23xx user manual, see p.173 in particular.
- 3. The user manual tells us that the direction register for fast GPIO port 0 (FIOODIR) is at memory address 0x3FFFC000. This register is used to

determine, for each pin, whether it's an *input* pin (value 0) or an *output* pin (value 1). To control an LED we need an output pin. The manual also mentions a register (FIOOPIN) that controls the value of the pins. Its address is 0x3FFFC014.

4. So, in order to configure pin 13 as an output pin, we need to set bit 13 of the direction register to the value 1. Once the pin is configured as an output pin, we can control the state of the pin by setting (assigning the value 1 to) or clearing (assigning the value 0 to) bit 13 in the FIOOPIN register. We should modify both of these registers without disturbing the value of the other bits in them. We need to understand how to manipulate individual bits in order to do this. Read the section on 'Common Bit Manipulation Techniques' in this Wikipedia article for more information. Once, we've gathered enough information from the documentation, we might try the following program to control the LED:

```
#include <stdbool.h>
   #include <stdint.h>
   typedef uint32_t volatile *pDeviceRegister_t;
   #define FIO0DIR ((*(pDeviceRegister_t)0x3FFFC000))
   #define FIO0PIN ((*(pDeviceRegister_t)0x3FFFC014))
   #define LINK_LED_MASK ((1UL << 13))
10
   void main(void)
     pid main(void) {
FIO0DIR |= LINK_LED_MASK;
11
                                     /* make P0.13 an output pin */
12
      while (true) {
13
        FIOOPIN |= LINK_LED_MASK;
                                    /* set pin high (1)
14
        FIO0PIN &= LINKLED_MASK; /* set pin low
15
16
17
```

5. In fact, there are so many device registers associated with the LPC2378 that the provider of the compiler has written a header file containing definitions for all of them, so that we don't have to write our own. The file iolpc2378.h defines FIOODIR and FIOOPIN, along with all the other device registers. We can use these names in our programs by including iolpc2378.h.

2 In the lab

- 1. Download the file workspace.zip into a suitable directory either on a pen drive or in your University workspace. I suggest you call the directory EN572/labs/lab02. Unzip workspace.zip.
- 2. Start up EWARM and load the workspace workspace/workspace.eww.
- 3. Connect a LPC-2378-STK board to a USB port on your computer.
- 4. Download and debug the project lab02. Run it and observe its behaviour.

- 5. Carefully read the file leds.c and make sure that you understand how it works. It's a bit different from the program discussed in the introduction. Ask your lab tutor to explain anything that isn't clear to you.
- 6. Modify the main program so that it has exactly the same behaviour but uses the ledToggle() function instead of ledSetState(). Keep the size of your code as compact as you can.
- 7. Write your own function to toggle the link LED (call it ledToggleXor()). It should have the same behaviour as ledToggle() but it should be implemented using FIOOPIN and the exclusive or operator, ^.
- 8. Modify the leds.c file to provide a similar driver for the USB_CONNECT_LED. Add suitable function prototypes to leds.h. Use your new driver in main.c to flash the USB_CONNECT_LED at the same rate as the USB_LINK_LED. Notice that you'll also need to add some code to ledsInit().
- Modify main.c so that your program flashes the USB_CONNECT_LED at half the rate of the USB_LINK_LED.
- 10. Define an enumeration type in leds.h called ledIdentifier_t. The type should contain two constants: USB_LINK_LED and USB_CONNECT_LED. You can base your code on the definition of ledState_t that is already present in leds.h. Add a function prototype to your interface to allow the user to select which LED to set by passing a led identifier as a parameter. For example,

ledSetState(USB_LINK_LED, LED_ON)

should turn on the link LED and

ledSetState(USB_CONNECT_LED, LED_ON)

should turn on the connect LED.

- 11. Implement your new function in leds.c and test it. Add a similar function ledGetState to leds.c to allow the user to get the current state of a specified led.
- 12. Modify the file delay.c so that the word volatile is removed from the declarations of dly and dly100. Download and debug the modified program. How has the behaviour of the program changed? If at all. Try changing the compiler settings in

Project->Options->C/C++ Compiler->Optimizations

so that optimization is set to the high level. Download and debug the program again. How does the program behave now? Can you explain what's going on?. After you've thought about this, read Use volatile judiciously to help your understanding. Why is the approach to creating a delay that is taken by the function dly100us() so poor?

3 Other activities

- 1. Read Symbolic constants for a discussion of the use of #define, enum and const for defining constant values is C programs.
- 2. Develop your understanding of the IAR EWARM IDE by working through tutorials 1 and 2. Start up EWARM. Click on the tutorials icon on the introductory page, follow the links to tutorials 1 and 2.
- 3. See if you can find out roughly what proportion of the number of lines of code in a traditional OS (e.g. Windows, Unix, Mac OS) is contributed by the device driver code.
- Based on your experience in this lab, explain why you are glad that your computer comes with an operating system that provides drivers for all of its devices.
- 5. Check that you understand the following:
 - memory-mapped I/O
 - use of #define and #include
 - \bullet how to give a name to a specific memory address
 - the use of typedef and volatile
 - the use of bit operators: | & ^ ~ and <<
 - the use of pointers and enumeration types
 - \bullet the use of EWARM to edit, compile, link, download and execute programs