
M-1861 T-22

B CONECTOR / NOZZLES BOQUILLAS / CONNECTOR

TERMP BOQUILA 1 - $\begin{pmatrix} 1 & \bigcirc & \bigcirc & 9 \\ 2 & \bigcirc & \bigcirc & 10 \\ + \text{ TERMP BOQUILA 2} \end{pmatrix}$ TERMP BOQUILA 3 - $\begin{pmatrix} 3 & \bigcirc & \bigcirc & 11 \\ 4 & \bigcirc & \bigcirc & 12 \\ + \text{ TERMP BOQUILA 3} \end{pmatrix}$ TERMP BOQUILA 4 - $\begin{pmatrix} 4 & \bigcirc & \bigcirc & 12 \\ 0 & \bigcirc & 12 \\ + \text{ TERMP BOQUILA 4} \end{pmatrix}$ REST BOQUILA 1 $\begin{pmatrix} 1 & \bigcirc & \bigcirc & 12 \\ 0 & \bigcirc & 12 \\ + \text{ TERMP BOQUILA 3} \end{pmatrix}$ REST BOQUILA 2 $\begin{pmatrix} 1 & \bigcirc & \bigcirc & 12 \\ 0 & \bigcirc & 12 \\ + \text{ TERMP BOQUILA 4} \end{pmatrix}$ REST BOQUILA 1 $\begin{pmatrix} 1 & \bigcirc & \bigcirc & 12 \\ 0 & \bigcirc & 12 \\ + \text{ TERMP BOQUILA 3} \end{pmatrix}$ REST BOQUILA 2 $\begin{pmatrix} 1 & \bigcirc & \bigcirc & 12 \\ 0 & \bigcirc & 0 \\ - & \bigcirc & 0 \\ 0 & \bigcirc & 12 \\ - & \bigcirc & 0 \\ - & \bigcirc &$

MOLDE ABIERTO VISTO POR PARTE FIJA

A CONECTOR / HRS BLOQUE / CONNECTOR



07/06/2020

C

CONECTOR / HRS
BLOQUE / CONNECTOR

CONECTOR / NOZZLES
BOQUILLAS / CONNECTOR

