TALLER DE MICROCONTROLADORES CON DSPIC33FJ32MC202 CLASE2

Instructor: Juan David Rosadio Vega

Miembro IEEE RAS UNAC

Contacto: +51933718584

jrlte98@gmail.com



A Student Chapter of the IEEE Robotics & Automation Society


Ejercicio - Manejo de Puertos


Hacer que los pines RB5, RB6 Y RB7 parpadeen cada un seg. sin cambiar el estado del pin RB15

```
#include "reloi.h"
#include "config.h"
#include <xc.h>
#include "libpic30.h'
#include "p33fj32mc202.h"
int main(void) {
 AD1PCFGL = 0xFFFF;
 TRISB=0;
 LATB=0x8000; //Pin RB15 seteado incialmente
   //Hacer que los pines RB5, RB6 Y RB7 parpadeeen cada un seg.
   //sin cambiar el estado del pin RB15
   //En Binario:
   //LATB = 0b000000011100000;
   //En Hexadecimal
   //LATB = 0x00E0;
   //Mediante operaciones a nivel de bit
   LATB |= (1<<5) | (1<<6) | (1<<7);
   //LATB = LATB | (1<<5) | (1<<6) | (1<<7)
   //LATB = 100000000000000 +
        000000000100000
         000000001000000
         0000000010000000
```

//LATB = 1000000011100000

```
//Usando Macros
 LATBbits.LATB5 = 1;
 LATBbits.LATB6 = 1:
 LATBbits.LATB7 = 1;
 delay ms(1000);
 //En Hexadecimal
 //LATB = 0x0000;
 //Mediante operaciones a nivel de bit
 //~: alt+126
 LATB \&=^{(1<<5)(1<<6)(1<<7))};
 //LATB = LATB & ~ (1<<5) | (1<<6) | (1<<7)
 //LATB = 10000000000000000 * ~(000000000100000 +
                 000000001000000
                 0000000010000000)
 //LATB = 100000000000000000000 * ~(0000000011100000)
 //LATB = 1000000000000000 * 11111111100011111
 //LATB = 1000000000000000
  delay ms(1000);
return 0;
```









A Student Chapter of the IEEE Robotics & Automation Society

BIBLIOGRAFIA

- Operadores a Nivel de Bits https://es.wikipedia.org/wiki/Operador a nivel de bits#:~:text=Una%20operaci%C3%B3n%20bit%20a %20bit,soportada%20directamente%20por%20los%20procesadores.
- VIDEO Tips para microcontroladores mascara de bits https://www.youtube.com/watch?v=ZbdOecJ2JIc&t=798s&ab channel=iSebasmicroProgramando



