GROUP 70


COMPONENT LOCATIONS

CONTENTS

GROUNDING	70-2	INSPECTION TERMINAL	70-7
GROUNDING CABLE	70-4	SENSOR	70-8
FUSIBLE LINK, FUSE AND IOD OR STO		CONTROL UNIT	70-12
		OTHER DEVICES	70-15
RELAY	/U-6	SOLENOID AND SOLENOID VALVE	70-16


GROUNDING


M1701000300328





AC208856AB


NOTE: Numbers 1 to 17 correspond to the body ground point numbers in CIRCUIT DIAGRAMS.













































GROUNDING CABLE


M1701001000278





AC208930AB


FUSIBLE LINK, FUSE AND IOD OR STORAGE CONNECTOR


NAME	SYMBOL	NAME	SYMBOL
Fuses No.6 to 25 (Engine compartment)	В	Fusible link No.26 (Battery positive terminal)	A
Fuses No.1 to 23 (Passenger compartment)	С	IOD or storage connector	В
Fusible links No.1 to 5 (Engine compartment)	В		




















RELAY


M1701000400314

NAME	SYMBOL	NAME	SYMBOL
A/C compressor relay	В	Fuel pump relay (2)	С
Blower relay	С	Fuel pump relay (3)	А
Condenser fan relay (HI)	В	Horn relay	В
Condenser fan relay (LO)	В	Charge air cooler water spray relay	С
Defogger relay	С	MFI relay	В
Fan control relay	В	Power window relay	С
Fog light relay	В	Starter relay	В
Fuel pump relay (1)	С		











TSB Revision





INSPECTION TERMINAL


M1701000200310

NAME	SYMBOL	NAME	SYMBOL
Data link connector	В	Engine speed detection connector	Α












SENSOR

M1701000600341

NAME	SYMBOL	NAME	SYMBOL
Air thermo sensor	L	Heated oxygen sensor (front)	F
Camshaft position sensor	G	Heated oxygen sensor (rear)	N
Crankshaft position sensor	Α	Knock sensor	С
Engine coolant temperature sensor	G	Manifold differential pressure sensor	В
Front impact sensor	I	Steering angular velocity sensor	J
Fuel level sensor (sub)	0	Throttle position sensor	Е
Fuel pump and level sensor (main)	0	Vehicle speed sensor	D
Fuel tank differential pressure sensor	0	Volume airflow sensor	Н
Fuel tank temperature sensor	0	ABS sensor (front)	М
G-sensor (lateral)	K	ABS sensor (rear)	Р
G-sensor (longitudinal)	K		










AC208853AB


NOTE: The * symbols indicate also equipped at the right side.


TSB Revision



















TSB Revision





























CONTROL UNIT

M1701000700315

NAME	SYMBOL	NAME	SYMBOL
ABS-ECU	Α	Front-ECU	В
A/C-ECU	G	HEADLIGHT ASSEMBLY (with built-in ECU)	D
Column-ECU	E	Immobilizer-ECU	F
Engine control module	J	SUNROOF MOTOR ASSEMBLY (with built-in ECU)	K
ETACS-ECU	Н	SRS-ECU	I
Fan control module	С		











AC208870 AB


NOTE: The * symbols indicate also equipped at the right side.































OTHER DEVICES


M1701005600272


NAME	SYMBOL	NAME	SYMBOL
A/C compressor (built-in A/C refrigerant temperature switch)	D	Idle air control motor	В
Dual pressure switch	Α	Power steering pressure switch	С




AC208821AB











SOLENOID AND SOLENOID VALVE


M1701000800301


NAME	SYMBOL	NAME	SYMBOL
EGR vacuum regulator solenoid valve	С	Fuel pressure solenoid	В
Evaporative emission purge solenoid	В	Hydraulic unit (with built-in ABS solenoid valve)	А
Evaporative emission ventilation solenoid	E	Turbocharger wastegate solenoid	D








AC208830 AB











NOTES