

Flat Prevention

pressure written on the sidewall -Check your tire pressure often -Stay within the pressure range your tires specify, usually: recoccomended inflation -Tires usually have a

-Road: 80-100 psi -Mountain: 35-45



-Hybrid: 70-80



sing a Tire Lever Insert tire lever

13

© 2018 Jacob Tillman


Check the

tube









lease or unscrew Open quick rebolts

Push derailleur Remove the foreward wheel

Ride

Safe!

Tool Kit

Assembling This Zine

- -Bike specific multitool
 - -Spare tube or patch kit

Print

- CO2 with inflator -Mini pump or
 - -15mm wrench -Tire levers

Cut



Fold



Staple

Bring these with you on every

14

Push derailleur

foreward

12

Sand the area to be patched



Snakebite-low pressure

Pinhole-thorn or wire

Pump the tube up slightly-this creates a white dot where your puncture is

Blowout (jagged hole)-

high pressure

the touch, then press on the Wait until the fluid is dry to patch

inside-spoke nipple, Circle/thin spot on

0

bad rim strip

5

 ∞

Pull tube out



Install wheel

Push out valve



release or tighten Close quick bolts

10