

CTAT NMOS Biasing Characterization Flow

1. Testbench Configuration

Testbench: PrimeSim.default

Design: Tese/nfinZTC/schematic

Analysis: DC Operating Point (dc_op)

Sweeps:

- **Temperature (temp):** Sweep from -40°C to 125°C (step 16.5).
- **Bias Current (Ibias):** Parametric sweep from $0\ \mu\text{A}$ to $7\ \mu\text{A}$ (30 points).

2. Output Expressions

OUTPUT	EXPRESSION
I_{dev} (Device_current)	i(/N0/D)
V_{dev} (Device_voltage)	v(/Ibias)