WEATHER BALLOON RESEARCH

Adding Tektelic Gateway to The Things Network

- 1. Create The Things Network account from https://account.thethingsnetwork.org/register
- 2. Login from https://eu1.cloud.thethings.network/oauth/login
- 3. Click "Go to the Console"



Welcome, Junhyung Park! 🤞




You have successfully logged into the Account App. The Account App is the official user account management application of The Things Stack. In the near future, you will additionally be able to use this application to

- 1. Manage your active sessions
- 2. Manage your OAuth authorizations

If you wish to manage your applications, end devices and/or gateways, you can use the button below to head over to the Console.



4. North America server will be used. Click "North America 1."




5. A gateway will be added to The Things Network in this tutorial. Click "Go to gateways" from this console.



6. Click "Add gateway"



7. Add necessary information



***Gateway EUI can be found here:



LoRaWAN options

Frequency plan ? *

United States 902-928 MHz, FSB 2 (used by TTN)

8. Create the gateway

Create gateway