

## STATUS INDICATOR MODULE



Unused Pins ========== CLK/TRIG: Connect to GND if not used INT: Leave unconnected if not used



Notes V0\_0:

The Jan 2020 prototype included status information update over bluetooth to a smartphone BLE serial terminal.

ouecount of a smartphone ELE serial terminal.

For the Sep 2020 units instead of sending the data over bluetooth it has been requested to use a very basic diagnostic indicator.

The reason proposed is that the smartphone app would be too much of a training burden for the seasonal contracted operators.

What has been requested is a minimal status led display to indicate the following key information: CAT-M1 connected?

System measuring?

To avoid excess power usage it is intended that this status display only comes on for say 15 min after the operator presses a 'show status' button. The display should have a very low power shutdown mode to save battery energy.

TITLE Status Indicator V0_0	CDT CONFIDENTIAL FOR INTERNAL USE ONLY
FILE:	REVISION: 4 MAY 2020
PAGE 1 OF 1	DRAWN BY: NM