




POLITECNICO
MILANO 1863

ASSIGNMENT 1

STRUCTURAL DYNAMICS AND AEROELASTICITY

POLITECNICO DI MILANO
Laurea Magistrale – Aeronautical Engineering

Author : Camile Sam Adam BRIARD
Person Code : 11154383
Professors : G. Quaranta
Date : April 10, 2026



Problem Setup

According to the datas, the wing is free to bend and twist, with a strut attached at $y = y_B$. The aerodynamic center (AC) is located at e from the elastic axis. The aileron is located at the wing tip, with span b_a and deflection β .

Thus, the wing has two degrees of freedom (DOFs) :

- $w(y, t)$: Bending deformation along $\mathbf{z}$
- $\theta(y, t)$: Rotation around $\mathbf{y}$

The goal is to develop a numerical model for wing bending and torsion based on the Ritz–Galerkin approach to perform a static aeroelastic analysis.

Divergence Dynamic Pressure q_D - Derivation

Shape Functions

The wing is clamped at the root. Essential boundary conditions :

For w : $w(0) = 0$ (No displacement), $w'(0) = 0$ (No bending)

For θ : $\theta(0) = 0$ (No rotation)

We approximate the problem with the Ritz–Galerkin approach :

$$w(y, t) = N_w(y) \phi_w(t), \quad \theta(y, t) = N_\theta(y) \phi_\theta(t) \quad (1)$$

To comply with the essential boundary conditions, the shape functions must satisfy :

— N_w : at least 2nd order (2 BCs to satisfy)

— N_θ : at least 1st order (1 BC to satisfy)

For N_w , we take a parabolic shape function :

$$N_w(y) = A_w \left(\frac{y}{b}\right)^2 + B_w \left(\frac{y}{b}\right) + C_w$$

Applying BCs : $N_w(0) = 0 \Rightarrow C_w = 0$, $N'_w(0) = 0 \Rightarrow B_w = 0$; Normalizing : $N_w(b) = 1 \Rightarrow A_w = 1$.

$$\boxed{N_w(y) = \left(\frac{y}{b}\right)^2 \Rightarrow w(y, t) = \left(\frac{y}{b}\right)^2 \phi_w(t)} \quad (2)$$

For N_θ , we take an affine shape function :

$$N_\theta(y) = A_\theta \frac{y}{b} + B_\theta$$

Applying BC : $N_\theta(0) = 0 \Rightarrow B_\theta = 0$; Normalizing $N_\theta(b) = 1 \Rightarrow A_\theta = 1$.

$$\boxed{N_\theta(y) = \frac{y}{b} \Rightarrow \theta(y, t) = \frac{y}{b} \phi_\theta(t)} \quad (3)$$

Principle of Virtual Work

To find the equations of motion, we apply the PVW : $\delta W_i = \delta W_e$.

Internal Virtual Work

$$\delta W_i = \int_0^b \delta w_{,yy} EJ w_{,yy} dy + \int_0^b \delta \theta_{,y} GJ \theta_{,y} dy \quad (4)$$

$$= \int_0^b \delta \phi_w \frac{2}{b^2} EJ \frac{2}{b^2} \phi_w dy + \int_0^b \delta \phi_\theta \frac{1}{b} GJ \frac{1}{b} \phi_\theta dy \quad (5)$$

$$= \delta \phi_w \underbrace{\frac{4EJ}{b^3}}_{K_w} \phi_w + \delta \phi_\theta \underbrace{\frac{GJ}{b}}_{K_\theta} \phi_\theta \quad (6)$$

$$\delta W_i = \delta \begin{Bmatrix} \phi_w \\ \phi_\theta \end{Bmatrix}^T \begin{bmatrix} K_w & 0 \\ 0 & K_\theta \end{bmatrix} \begin{Bmatrix} \phi_w \\ \phi_\theta \end{Bmatrix} \quad (7)$$

External Virtual Work

$$\delta W_e = \delta W_A^w + \delta W_A^A + \delta W_{\text{STR}}$$

(1) Wing aerodynamic virtual work δW_A^w

The virtual displacement of the AC in z -direction :

$$h_{AC}(y) = w(y) + e \theta(y)$$

Lift per unit span (perturbation only, $\alpha = \theta$) :

$$L'_w(y) = q c C_{L/\alpha} \theta(y)$$

$$\delta W_A^w = \int_0^b \delta h_{AC} L'_w(y) dy \quad (8)$$

$$= \int_0^b \delta(w + e\theta) q c C_{L/\alpha} \theta dy \quad (9)$$

$$= \int_0^b \delta \phi_w \left(\frac{y}{b}\right)^2 q c C_{L/\alpha} \frac{y}{b} \phi_\theta dy + \int_0^b \delta \phi_\theta \frac{y}{b} e q c C_{L/\alpha} \frac{y}{b} \phi_\theta dy \quad (10)$$

Evaluating the integrals :

$$\delta W_A^w = \delta \begin{Bmatrix} \phi_w \\ \phi_\theta \end{Bmatrix}^T q \begin{bmatrix} 0 & \frac{cb}{4} C_{L/\alpha} \\ 0 & \frac{ecb}{3} C_{L/\alpha} \end{bmatrix} \begin{Bmatrix} \phi_w \\ \phi_\theta \end{Bmatrix} \quad (11)$$

(2) Aileron aerodynamic virtual work δW_A^A

The aileron spans from $y = b - b_a$ to $y = b$, with deflection β . The pitching moment coefficient is :

$$C_{m_{AC}} = C_{m_0} + C_{m/\beta} \beta$$

$$\delta W_A^A = \int_{b-b_a}^b \delta h_{AC} L'_{\text{Ail}}(y) dy + \int_{b-b_a}^b \delta \theta M'_{AC\text{Ail}}(y) dy \quad (12)$$

$$= \int_{b-b_a}^b \delta(w + e\theta) q c C_{L/\beta} \beta dy + \int_{b-b_a}^b \delta \theta q c^2 C_{m/\beta} \beta dy \quad (13)$$

Evaluating :

$$\delta W_A^A = \delta \phi_w q e C_{L/\beta} \frac{1}{b^2} \left[\frac{b^3 - (b - b_a)^3}{3} \right] \beta \quad (14)$$

$$+ \delta \phi_\theta q e c C_{L/\beta} \frac{1}{b} \left[\frac{b^2 - (b - b_a)^2}{2} \right] \beta \quad (15)$$

$$+ \delta \phi_\theta q c^2 C_{m/\beta} \frac{1}{b} \left[\frac{b^2 - (b - b_a)^2}{2} \right] \beta \quad (16)$$

In matrix form :

$$\delta W_A^A = \delta \begin{Bmatrix} \phi_w \\ \phi_\theta \end{Bmatrix}^T q \frac{c}{b} \beta \left\{ \begin{array}{c} C_{L/\beta} \cdot \frac{1}{b} \left[\frac{b^3 - (b - b_a)^3}{3} \right] \\ (e C_{L/\beta} + c C_{m/\beta}) \left[\frac{b^2 - (b - b_a)^2}{2} \right] \end{array} \right\} \quad (17)$$

(3) Strut virtual work δW_{STR}

From PCVW applied in the axial direction of the strut :

$$F_S = -\frac{EA}{\ell} u, \quad \ell = \frac{z_A}{\sin \gamma}, \quad u = h_B \sin \gamma$$

$$F_S = -\frac{EA}{z_A} \sin^2(\gamma) h_B, \quad F_{Sz} = F_S \sin(\gamma)$$

$$\boxed{F_{Sz} = -\underbrace{\frac{EA}{z_A} \sin^3(\gamma)}_{K_{STR}} h_B} \quad (18)$$

Defining the normalized strut spanwise position :

$$\eta_B = \frac{z_A}{b \tan(\gamma)}$$

The displacement at the strut attachment point B :

$$h_B(x_B) = \left(\frac{y_B}{b} \right)^2 \phi_w - x_B \frac{y_B}{b} \phi_\theta, \quad y_B = \frac{z_A}{\tan \gamma}$$

$$h_B(x_B) = \frac{z_A}{b \tan \gamma} \left[\frac{z_A}{b \tan \gamma} \phi_w - x_B \phi_\theta \right] = \eta_B [\eta_B \phi_w - x_B \phi_\theta]$$

$$\delta W_{STR} = \delta \phi_w K_{STR} \eta_B^4 \phi_w - \delta \phi_w K_{STR} \eta_B^3 x_B \phi_\theta \quad (19)$$

$$- \delta \phi_\theta K_{STR} \eta_B^3 x_B \phi_w + \delta \phi_\theta K_{STR} \eta_B^2 x_B^2 \phi_\theta \quad (20)$$

$$\boxed{\delta W_{STR} = \delta \begin{Bmatrix} \phi_w \\ \phi_\theta \end{Bmatrix}^T (-K_{STR} \eta_B^2) \begin{bmatrix} \eta_B^2 & -\eta_B x_B \\ -\eta_B x_B & x_B^2 \end{bmatrix} \begin{Bmatrix} \phi_w \\ \phi_\theta \end{Bmatrix}} \quad (21)$$

where $K_{STR} = \frac{EA}{z_A} \sin^3(\gamma)$, $\eta_B = \frac{z_A}{b \tan(\gamma)}$.

Application of PVW : $\delta W_i = \delta W_e$

$$\delta \phi^T \begin{bmatrix} K_w & 0 \\ 0 & K_\theta \end{bmatrix} \phi = \delta \phi^T \left(q \begin{bmatrix} 0 & \frac{cb}{4} C_{L/\alpha} \\ 0 & \frac{ecb}{3} C_{L/\alpha} \end{bmatrix} + q \frac{c}{b} \beta \mathbf{F}_{\text{Ail}} - K_{\text{STR}} \eta_B^2 \begin{bmatrix} \eta_B^2 & -\eta_B x_B \\ -\eta_B x_B & x_B^2 \end{bmatrix} \right) \phi \quad (22)$$

Full Stiffness Matrix and Equilibrium

The full system (non-forced, static for q_D computation) :

$$\begin{bmatrix} K_w + K_{\text{STR}} \eta_B^4 & -K_{\text{STR}} \eta_B^3 x_B \\ -K_{\text{STR}} \eta_B^3 x_B & K_\theta + K_{\text{STR}} \eta_B^2 x_B^2 \end{bmatrix} - q \begin{bmatrix} 0 & \frac{cb}{4} C_{L/\alpha} \\ 0 & \frac{ecb}{3} C_{L/\alpha} \end{bmatrix} = \mathbf{0}$$

Defining :

$$\mathbf{K}_S = \begin{bmatrix} K_{S_1} & K_{S_{12}} \\ K_{S_{12}} & K_{S_2} \end{bmatrix}$$

with :

$$K_{S_1} = K_w + K_{\text{STR}} \eta_B^4 = \frac{4EJ}{b^3} + \frac{EA}{z_A} \sin^3(\gamma) \eta_B^4$$

$$K_{S_{12}} = -K_{\text{STR}} \eta_B^3 x_B = -\frac{EA}{z_A} \sin^3(\gamma) \eta_B^3 x_B$$

$$K_{S_2} = K_\theta + K_{\text{STR}} \eta_B^2 x_B^2 = \frac{GJ}{b} + \frac{EA}{z_A} \sin^3(\gamma) \eta_B^2 x_B^2$$

Divergence Dynamic Pressure q_D

For divergence, the system is unforced ($\beta = 0$). The condition is :

$$\det(\mathbf{K}_S - q_D \mathbf{K}_A) = 0$$

where $\mathbf{K}_A = q \begin{bmatrix} 0 & \frac{cb}{4} C_{L/\alpha} \\ 0 & \frac{ecb}{3} C_{L/\alpha} \end{bmatrix}$.

Expanding the determinant :

$$K_{S_1} K_{S_2} - q_D K_{S_1} K_{A_2} - (K_{S_{12}})^2 + q_D K_{S_{12}} K_{A_{12}} = 0$$

$$q_D (K_{S_1} K_{A_2} - K_{S_{12}} K_{A_{12}}) = K_{S_1} K_{S_2} - (K_{S_{12}})^2$$

$$q_D = \frac{K_{S_1} K_{S_2} - (K_{S_{12}})^2}{K_{S_1} K_{A_2} - K_{S_{12}} K_{A_{12}}} = \frac{K_{S_1} K_{S_2} - (K_{S_{12}})^2}{K_{S_1} K_{S_2} - (K_{S_{12}})^2} \cdot \frac{K_{S_1} K_{S_2} - (K_{S_{12}})^2}{K_{S_1} K_{S_2} - K_{S_{12}} K_{A_{12}}} \quad (23)$$

More explicitly :

$$q_D = \frac{K_{S_1} K_{S_2} - (K_{S_{12}})^2}{K_{S_1} K_{A_2} - K_{S_{12}} K_{A_{12}}}$$