⚠ Safety

- Charge only from a 5 V USB charger.
- Do not open, crush or puncture the case — it contains a Li-Po battery.
- Keep away from water, moisture, fire and high temperatures.
- Damaged or swollen device: do not charge it — contact us.

Do not dispose of with household waste. Take it to a collection point for electronic equipment — the device contains a battery.

CE EU declaration of conformity: **kalkmate.pl/docs/ce-declaration.pdf**

Help & warranty

Website: **kalkmate.pl/en**
Help and FAQ: **kalkmate.pl/pomoc**
24-month warranty. Complaints: **kalkmate.pl/reklamacja**
kontakt@kalkmate.pl

Manufacturer

KAJPA Kacper Popko
ul. Zastawie I 37, 16-070 Choroszcz, Poland
VAT ID (NIP) 9662222951

Model KalkMate-ESP32S3-v1 · Li-Po battery 3.7 V 1500 mAh · USB-C 5 V charging · Wi-Fi 2.4 GHz

Made in Poland · Guide v4 · firmware 2.0.5 · 10/2026



▲ 8	or +	up
▼ 2	or −	down
◀ 4	or ±	back
▶ 6	or ▶	right / edit
OK 5	or =	select, OK
C/CE		cancel
MU		panic

MU Panic key



MU jumps from any AI screen straight back to the plain calculator. Type the code to return to AI. Change the key in **Settings → Security → Panic key**.

Ask in text
Solve problem → Enter text. On-screen keyboard, finish with OK.

History
Solve problem → History. 6 = edit the question and send it again.

No internet
The problem waits in the offline queue and is sent once WiFi is back and you open **Solve problem**.

Change the AI code
Settings → Security → AI code: 8 2 digit, 4 6 position, OK = save.

Updates
Settings → System → Software update → OK. Do not switch off the calculator while installing.

Battery
Settings → Battery: level in % and charging. “LOW BATTERY” = plug in USB-C.

Language
Settings → Language: Polski, English, Deutsch, Čeština, Slovenčina, Lietuvių, Беларуская, Español, Português, Français, Italiano.

Factory reset
In calculator mode (“0”) hold C/CE for 5 s → OK. Erases WiFi, AI code (back to 1111), history, notes and pairing. Your tokens stay on your account.

EN

KalkMate

User guide


Quick start

Calculator with an AI assistant
Maths · Physics · Chemistry · Biology




↔ **Unfold — 8 steps to your first solution**

1 Charge



Connect the USB-C cable to a 5 V USB charger. A full charge takes about 2 h.


2 Switch on



Slide the switch on the side to ON. A plain calculator showing “0” appears.

After 4 min of inactivity the screen goes dark — any key wakes it up.


3 Enter the AI code



Type just the digits of the code: **1111** or the code chosen with your order. “AI” flashes and the menu opens.


No + − × ÷ = between the digits.

4 Connect to WiFi




Settings → WiFi & account → WiFi network → OK (scan) → pick a 2.4 GHz network → type the password on the on-screen keyboard.

5 Account & pairing




Create an account at **kalkmate.pl/en** — 200k tokens to start. **Settings → WiFi & account → Device ID + QR** → scan the code with your phone and enter the AI code.

6 Code from the box




kalkmate.pl/panel → AI → enter the license code from the box: **+2M tokens**. No subscription — buy more tokens in the panel.

7 Snap the problem



Solve problem → Camera photo. The camera is on the back — fit the problem in the frame and press OK.

8 Read the solution



Scroll with 8 / 2, exit with 4. Every solution is saved in History.