by Stefano IK5WWG 30 May 2024

Function Keys for Firmware by Armel F4HWN v2.x Quansheng UV K5

https://www.instagram.com/sevenbrains11/ https://www.qrz.com/db/IK5WWG



Scan frequency range function Scan frequency range runction

1. switch to frequency mode,
2. set Upper and Lower frequencies
to scan in VFO A and VFO B;
3. Long-press 5 NOAA, ScnRng
label should show up;
4. start scan with long-press * Scan,
it will scan between given
boundaries,
5. long-press 5 NOAA or EXIT or
switch VFO to exit ScnRng mode


Scan Range function F3 145.000 OO FN LON1 6.25K NIDE SAL1 ScnRng 145:00000


	Service Menu (26) Personal Set	PTT+Side key 2 = 1750 Tone	Service Menu (22-23) Personal Set	Service Menu (24-25) Personal Set
F+	Menu	-	Change step +	Change step -
long	Change Mode Display (MO/DWR/DW/XB) In Channel SCAN, put in Blacklist	PTT	Light ON/OFF	Switch mode (FM/AM/USB)
short	Menu or OK (Enter)	PTT/Stop Scan	Monitor	none
keys	M	PTT	Side key 1	Side key 2
Short in Spectrum Mode	In Reception Optimization mode, select the four receiver settings in sequence (arrows to change)	Change Spectrum/Rec.Optimization	Blacklists the frequency	Light ON/OFF

F+ Squelch + Up short Menu, Frequency, Settings, etc. F+ Squelch -Down Menu, Frequency, Settings, etc. short Deletes all input, Exit DTMF input box, long Exit monitor mode, Exit ScnRng
Exit current menu/function
Stop and return (Scan)
Canc last entry

EXIT

short





F+	In frequency mode: switches Bands 1-7+ In channel mode: channel settings are copied to Frequency mode	Switch VFO A/B	Switch VFO/MR	Turns on CTCSS scanner for current frequency
long	In frequency mode: switches Bands 1-7+ In channel mode: channel settings are copied to Frequency mode	Switch VFO A/B	Switch VFO/MR	Start Scan (ListMem/VFO) Menu18 for list
short	1	2	3	enters DTMF input mode
keys	1 (Band)	2 (A/B)	3 (VFO/MR)	* Scan
Short in Spectrum	Change channel separation +			

Short in Spectrum Mode	Change number of channels analyzed (16x/32x/64x/128x)	Insertion of lower scanning frequency (for the Mhz point use *) M for confirmation	Change Bandwidth (6,25k/12,5k/25k)	Switch mode (FM/AM/USB)
keys	4 (FC)	5 (NOAA)	6 (H/M/L)	0 (FM)
short	4	5	6	0
long	Turns on frequency and CTCSS copy mode, turn the scan on and start transmitting with the other radio, the frequency and CTCSS code will be detected, you can save those setting with M button	In channel mode: toggles scan lists that the selected channel is assigned to. You will see 1 and 2 symbols changing on the right side of the channel label In frequency mode: activates scan range function	Sel Power H/M/L	FM Radio Broadcasting ON/OFF
F+	Turns on frequency and CTCSS copy mode, turn the scan on and start transmitting with the other radio, the frequency and CTCSS code will be detected, you can save those setting with M button	Spectrum ON/OFF	Sel Power H/M/L	FM Radio Broadcasting ON/OFF

F+	Vox ON/OFF	Display light always ON/OFF (quickly switch backlight between BLMin and BLMax)	Return to BackLt strategy, disables the manual backlight management	-
long	Vox ON/OFF	Switch Reverse (Mem/Duplex)	Recall fast Channel (Personal set)	Lock key ON/OFF
short	7	8	9	Function + other key
keys	7(vox)	8 ®	9 (Call)	F (#)