

2.15 Manipulate both the Release Lever and Ring Cage by hand to ensure that there is no binding or obstruction.

2.16 Tighten both pivot bolt nuts. Torque to 30 - 40 lb-ins (3.5 - 4.5 N-m) and repeat Para 2.15 above.

2.17 Lock the two Cross Tubes by edge centre punching.

2.18 Lock the two Shear nuts by centre punching.

3. TESTING.

3.1 Carry out the tests given in Para. 4 (ix) et seq and, if considered necessary, Para. 5 of the unit Log Book.

4. INSTALLATION.

4.1 Using new lock nuts re-fit the unit to the glider and carry out the standard insitu functional check.

Check tighten the mounting bolts/nuts within 25 - 50 launches.

5. RECORDS.

5.1 Record the spring change on the last page of the Q.R. Unit Log Book.

6. APPROVAL.

6.1 The Log Book entry in Para. 5 above should be signed for/countersigned by a suitably qualified Aircraft Engineer/Inspector with a Glider endorsement.