

- 2.5 Fit the new spring and bush to the Lever/Lever Carriage and insert the carriage, complete with the original shim washers into the casing.
- 2.6 Re-fit the 1/4" UNF pivot bolt, washer and new nut. Do not tighten at this stage.
- 2.7 Using the notched screwdriver push each leg in turn into the top of the Casing locating them in position with the 3/8" Bullet Guide.
- 2.8 Fit the 3/8" Cross Tube on to the shoulder of the Bullet Guide and using the 3/8" Drift, drive the tube into position. If necessary lock by edge centre punching.
- 2.9 Where applicable refit the 2BA C/S Stop bolt and lock by centre punching. (CW417 Lever only).
- 2.10 Manipulate the Release Lever by hand to ensure that there is no binding or obstruction.
- 2.11 Tighten both pivot bolt nuts. Torque to 30 - 40 lb-ins (3.5 - 4.5 N-m), and repeat the check in Para 2.10 above.

3. TESTING.

- 3.1 Carry out the tests given in Para. 4, and if necessary, Para.5 in the unit Log Book.

4. INSTALLATION.

- 4.1 Re-install the unit in the glider using new locknuts.

5. RECORDS.

- 5.1 Record the spring change on the last page of the Q.R. Unit Log Book.

6. APPROVAL.

- 6.1 The Log Book entry in Para. 5 above should be signed for/countersigned by a suitably qualified Aircraft Engineer/Inspector with a Glider endorsement.

DB