

GENERAL - AIRCRAFT INSTALLATION.

Both the CW300 and CW400 units are designed to enable their installation and removal using only simple hand tools and it is envisaged that once 'type' installation is finalised the Lever/Link Plates being used and their attachments, will remain with the aircraft. Removal requiring the extraction of only one A25-3 2BA bolt to disconnect the unit, leaving the aircraft system undisturbed.

The aircraft installation for the CW300 unit when installed in the Centre of Gravity position for Winch or Auto launching, must ensure that the Longitudinal Datum of the unit is placed at the design angle of incidence with the aircraft Longitudinal Datum.

Both units can be utilised for Aerotow use, however it is assumed that 'type' installation approval is the responsibility of the aircraft manufacturer.

For both the CW300 and CW400 the aircraft installation must not place any uneven stress on the unit Casings. The operating cable/rod system should, as far as is possible, be friction free. Any residual friction must not restrict the return of an unloaded unit by more than 1 daN. (2.2lbsf)

The effort to operate the Cockpit Control with the unit unloaded must not exceed 7.5 daN. (17.0lbsf)

Where the aircraft installation requires the simultaneous operation of both a CW300 and a CW400 unit the twin cable connecting link must ensure the FULL opening of BOTH units from the Cockpit Control. As a guide the effort to operate the Cockpit Control in the twin configuration with one unit loaded to 150 daN (330.0lbsf) should not exceed 17 daN. (37.5lbsf)

Operating cable length(s) must provide free play or excess length of 10mm to ensure the FULL closing of the unit(s). With the lever in the mid travel position the operating cable should act at approximately 90° to a line drawn through the lever attachment hole and the lever pivot centre.

Amdt. P14

February 2006.